

SERIES PM172 POWERMETERS

COMMUNICATIONS

ASCII Communications Protocol

REFERENCE GUIDE

Every effort has been made to ensure that the material herein is complete and accurate. However, the manufacturer is not responsible for any mistakes in printing or faulty instructions contained in this book. Notification of any errors or misprints will be received with appreciation.

For further information regarding a particular installation, operation or maintenance of equipment, contact the manufacturer or your local representative or distributor.

This book is copyrighted. No part of this book may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise without the prior written permission of the manufacturer.

Table of Contents

| | |
|--|-----------|
| 1 GENERAL | 4 |
| 2 ASCII FRAMING | 5 |
| 2.1 ASCII Message Frame..... | 5 |
| 2.2 Exception Responses | 6 |
| 3 PROTOCOL IMPLEMENTATION | 7 |
| 3.1 ASCII Specific and Direct Requests..... | 7 |
| 3.2 Data Formats | 7 |
| 3.3 Configuring and Accessing Log Files | 7 |
| 3.4 Password Protection | 8 |
| 4 SPECIFIC ASCII REQUESTS | 9 |
| 4.1 Basic Data | 9 |
| 4.2 Basic Setup..... | 11 |
| 4.3 Instrument Status | 12 |
| 4.4 Reset/Clear Functions | 12 |
| 4.5 Reset the Instrument (warm restart)..... | 13 |
| 4.6 Firmware Version Number | 13 |
| 4.7 Extended Instrument Status | 13 |
| 4.8 Log Memory Status | 15 |
| 4.9 Analog Output Allocation..... | 15 |
| 4.10 Analog Expander Channel Allocation | 16 |
| 4.11 Digital Inputs Allocation..... | 18 |
| 4.12 Timer Setup | 19 |
| 4.13 Pulsing Setpoints..... | 19 |
| 4.14 Pulse Counters Setup | 20 |
| 4.15 Log Memory Partition Setup..... | 21 |
| 4.16 Data Log Setup | 22 |
| 4.17 Event Log (Sequential Access)..... | 23 |
| 4.18 Data Log (Sequential Access)..... | 25 |
| 4.19 Min/Max Log | 26 |
| 4.20 TOU Registers Allocation | 27 |
| 4.21 TOU Daily Profiles | 28 |
| 4.22 TOU Calendars | 29 |
| 4.23 TOU Calendar Years | 29 |
| 4.24 Real Time Clock..... | 30 |
| 5 DIRECT READ/WRITE REQUESTS | 31 |
| 5.1 General..... | 31 |
| 5.1.1 Long-Size Direct Read/Write | 31 |
| 5.1.2 Variable-Size Direct Read/Write | 32 |
| 5.1.3 User Assignable Registers..... | 32 |
| 5.2 Extended Data Registers | 33 |
| 5.3 Basic Setup Registers..... | 39 |
| 5.4 User Selectable Options Setup..... | 39 |
| 5.5 Communications Setup..... | 40 |
| 5.6 Alarm/Event Setpoints | 41 |
| 5.7 Relay Operation Control Registers..... | 45 |
| 5.8 Instrument Options Registers | 45 |
| 5.9 Extended Status Registers | 46 |
| 5.10 Alarm Status Registers | 46 |
| 5.11 Reset/Clear Registers | 47 |
| 5.12 Memory Allocation Status Registers | 47 |
| 5.13 Memory Partition Status/Control Registers | 48 |
| 5.14 Event Log Registers (Circular Access)..... | 50 |
| 5.15 Data Log Registers (Circular Access)..... | 52 |
| 5.16 Min/Max Log Registers | 54 |
| 5.17 Digital Inputs Allocation Registers | 56 |
| 5.18 Time Zone Information Registers | 56 |
| 5.19 Communications Password Register | 57 |

1 GENERAL

This document specifies the ASCII serial communications protocol used to transfer data between a master computer station and the PM172. The document provides the complete information necessary to develop a third-party communications software capable of communication with the Series PM172 instruments.

All messages within the ASCII communications protocol are designed to consist only of printable characters.

Additional information concerning communications operation, configuring the communications parameters and communications connections is found in "Series PM172 Powermeters Installation and Operation Manual".

IMPORTANT

1. The voltage parameters throughout the protocol can represent line-to-neutral or line-to-line voltages depending on the wiring mode selected in the instrument. When the 4LN3 or 3LN3 wiring mode is selected, the voltages will be line-to-neutral; for any other wiring mode, they will be line-to-line voltages. In 4LN3, 4LL3, 3LN3 and 3LL3 wiring modes, harmonic voltages will represent line-to-neutral voltages. In a 3-wire direct connection, harmonic voltages will represent line-to-neutral voltages as they appear on the instrument's input transformers. In a 3-wire open delta connection, harmonic voltages will comprise L12 and L23 line-to-line voltages.
2. In 3-wire connection schemes, the unbalanced current and phase readings for power factor, active power, and reactive power will be zeros, because they have no meaning. Only the total three-phase power values can be used.

2 ASCII FRAMING

2.1 ASCII Message Frame

The following specifies the ASCII message frame:

| Field No. | 1 | 2 | 3 | 4 | 5 | 6 | 7 |
|--------------|----------|----------------|---------------|--------------|--------------|-----------|----------------|
| Contents | SYNC (!) | Message length | Slave address | Message type | Message body | Check sum | Trailer (CRLF) |
| Length, char | 1 | 3 | 2 | 1 | 0 to 246 | 1 | 2 |

SYNC

Synchronization character: one character '!' (ASCII 33), used for starting synchronization.

Message length

The length of the message including only number of bytes in fields #2, #3, #4 and #5. Contains three characters between '006' and '252'.

Slave address

Two characters from '00' to '99'. The instrument with address '00' responds to requests with any incoming address. For RS-422/RS-485 communications (multi-drop mode), this field must NEVER be zero.

Message type

One character representing the type of a host request. A list of the message types is shown in Tables 2-1 and 2-2. Note that they are case-sensitive.

Message body

Contains the message parameters in ASCII representation. All parameter fields have a fixed format. The data fields vary in length depending on the data type. Unless otherwise indicated, the parameters should be right justified and left-padded with zeros. Most parameters are represented in ASCII hexadecimal notation, and in some cases (to provide compatibility with old instruments) a decimal representation is preserved. For data formats, see Section 3.2.

Check sum

Arithmetic sum, calculated in a 2-byte word over fields #2, #3, #4 and #5 to produce a one-byte check sum in the range of 22h to 7Eh (hexadecimal) as follows: $[\sum(\text{each byte} - 22\text{H})] \bmod 5\text{CH} + 22\text{H}$

Trailer

Two ASCII characters CR (ASCII 13) and LF (ASCII 10).

NOTE

Fields #3 and #4 of the instrument response are always the same as those in the host request.

Table 2-1 Specific ASCII Requests

| Message type | | Description |
|--------------|-----------|---------------------------|
| Char | ASCII Hex | |
| 0 | 30h | Read basic data registers |
| 1 | 31h | Read basic setup |
| 2 | 32h | Write basic setup |
| 3 | 33h | Read instrument status |
| 4 | 34h | Reset/clear functions |
| 8 | 38h | Reset the instrument |

| Message type | | Description |
|--------------|-----------|--|
| Char | ASCII Hex | |
| 9 | 39h | Read version number |
| ? | 3F | Read extended status |
| @ | 40h | Read log memory status (E) |
| B | 42h | Read analog output allocation |
| b | 62h | Write analog output allocation |
| C | 43h | Read analog expander channel allocation |
| c | 63h | Write analog expander channel allocation |
| D | 44h | Read digital input allocation |
| d | 64h | Write digital input allocation |
| E | 45h | Read timer setup (E) |
| e | 65h | Write timer setup (E) |
| G | 47h | Read pulsing setpoint (E) |
| g | 67h | Write pulsing setpoint (E) |
| J | 4Ah | Read pulse counter setup |
| j | 6Ah | Write pulse counter setup |
| K | 4Bh | Read memory partition setup (E) |
| k | 6Bh | Write memory partition setup (E) |
| L | 4Ch | Read data log setup (E) |
| l | 6Ch | Write data log setup (E) |
| M | 4Dh | Read event log (E) |
| N | 4Eh | Read data log (E) |
| O | 4Fh | Read Min/Max log |
| P | 50h | Read TOU register allocation (E) |
| p | 70h | Write TOU register allocation (E) |
| Q | 51h | Read TOU daily profile (E) |
| q | 71h | Write TOU daily profile (E) |
| R | 52h | Read TOU calendar (E) |
| r | 72h | Write TOU calendar (E) |
| S | 53h | Read Real Time Clock |
| T | 54h | Write Real Time Clock |
| U | 55h | Read TOU calendar year (E) |
| u | 75h | Write TOU calendar year (E) |

(E) - available in the PM172E

Table 2-2 Direct Read/Write ASCII Requests

| Message type | | Description |
|--------------|-----------|----------------------------|
| Char | ASCII Hex | |
| A | 41h | Long-size direct read |
| a | 61h | Long-size direct write |
| X | 58h | Variable-size direct read |
| x | 78h | Variable-size direct write |

2.2 Exception Responses

The instrument will send the following error codes in the message body in response to incorrect host requests:

- XK** - the powermeter is in programming mode
- XM** - invalid request type or illegal operation
- XP** - invalid data address or data value, or data is not available

NOTE

When a check or framing error is detected, the powermeter will not act on or respond to the master's request.

3 PROTOCOL IMPLEMENTATION

3.1 ASCII Specific and Direct Requests

The ASCII protocol implements two different types of messages to transfer data between a master application and the instrument: specific requests and direct read/write requests.

Specific ASCII requests use different formats for accessing different data locations. The message body differs depending on the request type. Each data field has a fixed position in the ASCII string. Chapter 4 describes specific ASCII requests and their message body formats.

Direct read/write requests use a universal message body format, specified in Section 5.1. These requests allow a master application to access different data locations (registers) in the instrument by specifying a direct register index. A number of consequent registers can be read or written by a single request by specifying an arbitrary start register and the number of registers to be accessed. Chapter 5 describes registers accessed via direct read/write requests and their contents.

All measurement data in your instrument can be accessed using direct read requests, and some data can be read via specific ASCII requests. In all cases, a direct register read offers you more precise data with extended resolution. Setup data can be partially accessed using both specific and direct requests, and partially via either specific or direct requests.

3.2 Data Formats

Specific ASCII requests use both decimal and hexadecimal notation. Direct requests transfer ASCII data only in a hexadecimal notation.

Using a decimal notation, data is transmitted in a decimal representation as is, i.e., no conversion is needed. Negative numbers are transmitted with a sign at the left. Fractional numbers are represented with a decimal point. When the value exceeds the field range, it is truncated to the right.

In a hexadecimal notation, each data byte is transferred by two hexadecimal characters in ASCII representation (i.e., ASCII printable characters 0-9, A-F are used to represent hexadecimal digits 0h-9h, 0ah-0fh). All data is transferred as 2-character (8-bit unsigned byte), 4-character (16-bit unsigned or signed integer) or 8-character (32-bit unsigned or signed long integer) whole numbers. Negative numbers are transmitted in 2-complement code. Each data byte is transmitted high order digit first. Each integer or long integer register is transmitted high order bytes first.

Fractional numbers are transmitted being scaled by 10 in power N, where N is the number of digits in the fractional part. For example, the frequency reading of 50.01 Hz is transmitted as 5001 being pre-multiplied by 100. Whenever a data register contains a fractional number, the register measurement unit is given with a multiplier $\times 0.1$, $\times 0.01$ or $\times 0.001$, showing an actual register resolution (the weight of the least significant decimal digit). To get an actual fractional number with specified precision, scale the register value with the given multiplier. To write a fractional number into the register, divide the number by the given multiplier.

3.3 Configuring and Accessing Log Files

Configuring Memory for Logging

To use the onboard data logging, allocate a separate log partition for each specific data you want to be recorded in your instrument. The PM172E provides concurrent recording data in 9 different memory partitions, one of which is intended to record event log data and the others to store 8 different data logs using different sets of data parameters. Additionally, the two last data logs #7 and #8 can be configured to automatically record TOU monthly and daily profile data respectively using season TOU tariffs. Refer to Section 4.15 for information on how to allocate a memory partition for your specific data. Refer to Section 4.16 on how to configure a set of parameters to be recorded to each data log.

Each memory partition you allocated for logging is organized as a sequential file of records where all data is recorded in chronological order with a time and date stamp. When a partition is filled up, recording can be stopped or can continue to record over the oldest records if you specified a partition with a wrap-around (circular) attribute. TOU profile log partitions are automatically configured to be of a wrap-around type.

Each record within a log file has a unique sequence number that guards against missing or duplicated records when reading the log file. This number is incremented (modulo 65536) with each log and will not be replicated within the following 65535 logs. If a record is missing because of a communication problem, the read sequence for the log can be restored from the record with the desired sequence number.

Accessing Log Files

Each log file has a separate file read pointer which always points to the current file record that will be read next, and a separate register window which gives access to the record pointed to by this pointer. Initially, the read pointer is associated with the oldest record in the file. Reading a record via the file window returns the current record data, and then the pointer automatically advances to the following record in the file. Consequent requests addressed to the file window will return a new record each time in the direction from the oldest record to the more recent records. Because the file window advances automatically after the instrument responses to the master request (disregarding of the number of registers in the window being accessed), the entire window must be read at once using a single request.

The instrument offers you two different techniques for accessing your log files, using specific or direct read requests. Specific ASCII requests provide sequential reading of a file records until the end of a file is reached. When a record is requested after the end of a file, the response message will contain a zero record with an exception code indicating the end of a log file. As opposite, direct read requests provide circular file reading, i.e., after the last record has been read, the file read pointer is automatically shifted to the beginning of the file. Using direct read requests always allows you to read the entire log file disregarding of the current file status. You can simply poll the file window registers just as you poll ordinal data in your SCADA applications, without the need to manipulate with the file pointer. Refer to Sections 4.17 and 4.18 for information on specific ASCII requests you can use to access your log files, and to Sections 5.14 and 5.15 for information on direct read requests.

A log file can be read both in an arbitrary order and in sequence as explained above. To access the log records in a random order, the file read pointer can be re-written with the desired sequence number to point to the desired record. Refer to Sections 4.8, 5.12 and 5.13 for information on how to check the log file status and how to re-write the file read pointer. Writing to the memory partition command register (see Section 5.13) allows you to force the file pointer to point to the oldest record in the file or to the first new record in the file that you have not yet read. You can also use the instrument reset registers (see Sections 4.4 and 5.11) to restore the file read pointer to the oldest record in your log file if you want to re-read the file from the beginning.

IMPORTANT: Take into consideration the fact that in a wrap-around (circular) log partition, the oldest records may be overwritten by the most recent records since you have read either log status register. An attempt to point to the particular record directly by using its sequence number may fail if the addressed record has just been overwritten.

3.4 Password Protection

The PM172 has a password protection option allowing you to protect your setups, cumulative registers and logs from being changed or cleared through communications. You can disable or enable password protection for communications via the front panel. For details, refer to your instrument Installation and Operation Manual. When password protection is enabled, the user password you set in your instrument should be written into the communications password register (see Section 5.19) before another write request will be issued. If the correct password is not supplied while password protection is enabled, the instrument will respond to all write requests with the exception code XM (illegal operation). It is recommended to clear the password register after you have completed your changes in order to activate password protection.

4 SPECIFIC ASCII REQUESTS

4.1 Basic Data

Table 4-1 Read Request

| Message type (ASCII) | | | | | |
|------------------------|--------|--------|---|-----------|------------------|
| 0 | | | | | |
| Message body (decimal) | | | | | |
| Request - no body | | | | | |
| Response | | | | | |
| Field | Offset | Length | Parameter | Unit ② | Range ① |
| 1 | 0 | 4 | Voltage L1/L12 ⑥ | V/kV | 0 to Vmax |
| 2 | 4 | 4 | Voltage L2/L21 ⑥ | V/kV | 0 to Vmax |
| 3 | 8 | 4 | Voltage L3/L31 ⑥ | V/kV | 0 to Vmax |
| 4 | 12 | 5 | Current L1 | A | 0 to Imax |
| 5 | 17 | 5 | Current L2 | A | 0 to Imax |
| 6 | 22 | 5 | Current L3 | A | 0 to Imax |
| 7 | 27 | 6 | kW L1 | kW/MW | -Pmax to Pmax |
| 8 | 33 | 6 | kW L2 | kW/MW | -Pmax to Pmax |
| 9 | 39 | 6 | kW L3 | kW/MW | -Pmax to Pmax |
| 10 | 45 | 4 | Power factor L1 | | -.99 to 1.00 ④ |
| 11 | 49 | 4 | Power factor L2 | | -.99 to 1.00 ④ |
| 12 | 53 | 4 | Power factor L3 | | -.99 to 1.00 ④ |
| 13 | 57 | 6 | kW total | kW/MW | -Pmax to Pmax |
| 14 | 63 | 4 | Power factor total | | -.99 to 1.00 ④ |
| 15 | 67 | 6 | kWh import (E) | MWh ③ | 0 to 99999. |
| 16 | 73 | 5 | Neutral (unbalanced) current | A | 0 to Imax |
| 17 | 78 | 4 | Frequency | Hz | 45.0 to 65.0 |
| 18 | 82 | 6 | kvar L1 | kvar/Mvar | -Pmax to Pmax |
| 19 | 88 | 6 | kvar L2 | kvar/Mvar | -Pmax to Pmax |
| 20 | 94 | 6 | kvar L3 | kvar/Mvar | -Pmax to Pmax |
| 21 | 100 | 6 | kVA L1 | kVAMVA | 0 to Pmax |
| 22 | 106 | 6 | kVA L2 | kVAMVA | 0 to Pmax |
| 23 | 112 | 6 | kVA L3 | kVAMVA | 0 to Pmax |
| 24 | 118 | 6 | kvarh net (E) | Mvarh ③ | -9999. to 99999. |
| 25 | 124 | 6 | kvar total (E) | kvar/Mvar | -Pmax to Pmax |
| 26 | 130 | 6 | kVA total (E) | kVAMVA | 0 to Pmax |
| 27 | 136 | 6 | Maximum sliding window kW import demand ⑤ (E) | kW/MW | 0 to Pmax |
| 28 | 142 | 6 | Accumulated kW import demand (E) | kW/MW | 0 to Pmax |
| 29 | 148 | 5 | Max. ampere demand L1 | A | 0 to Imax |
| 30 | 153 | 5 | Max. ampere demand L2 | A | 0 to Imax |
| 31 | 158 | 5 | Max. ampere demand L3 | A | 0 to Imax |
| 32 | 163 | 2 | Status inputs (hex) | | See Table 4-13 |
| 33 | 165 | 6 | kWh export (E) | MWh ③ | 0 to 99999. |
| 34 | 171 | 6 | Maximum sliding window kVA demand ⑤ (E) | kVAMVA | 0 to Pmax |
| 35 | 177 | 4 | Voltage THD L1/L12 | % | 0.0 to 999. |
| 36 | 181 | 4 | Voltage THD L2/L23 | % | 0.0 to 999. |
| 37 | 185 | 4 | Voltage THD L3 | % | 0.0 to 999. |
| 38 | 189 | 4 | Current THD L1 | % | 0.0 to 999. |
| 39 | 193 | 4 | Current THD L2 | % | 0.0 to 999. |
| 40 | 197 | 4 | Current THD L3 | % | 0.0 to 999. |
| 41 | 201 | 8 | kVAh (E) | MVAh ③ | 0 to 99999.99 |
| 42 | 209 | 6 | Present sliding window kW import demand ⑤ (E) | kW/MW | 0 to Pmax |

| Message type (ASCII) | | | | | |
|------------------------|--------|--------|---|--------|-------------|
| 0 | | | | | |
| Message body (decimal) | | | | | |
| Request - no body | | | | | |
| Response | | | | | |
| Field | Offset | Length | Parameter | Unit ② | Range ① |
| 43 | 215 | 6 | Present sliding window kVA demand ⑤ (E) | kVAMVA | 0 to Pmax |
| 44 | 221 | 4 | PF (import) at maximum KVA demand (E) | | 0 to 1.00 |
| 45 | 225 | 4 | Current TDD L1 | % | 0.0 to 99.9 |
| 46 | 229 | 4 | Current TDD L2 | % | 0.0 to 99.9 |
| 47 | 233 | 4 | Current TDD L3 | % | 0.0 to 99.9 |

Fields indicated by an N/A mark are padded with ASCII zeros.

① The parameter limits are as follows:

$$I_{max} \text{ (100\% over-range)} = 2 \times \text{CT primary current [A]}$$

Direct wiring (PT Ratio = 1):

$$V_{max} \text{ (690 V input option)} = 828.0 \text{ V}$$

$$V_{max} \text{ (120 V input option)} = 144.0 \text{ V}$$

$$P_{max} = (I_{max} \times V_{max} \times 3) [\text{kW} \times 0.001] \text{ if wiring mode is 4LN3 or 3LN3}$$

$$P_{max} = (I_{max} \times V_{max} \times 2) [\text{kW} \times 0.001] \text{ if wiring mode is 4LL3, 3OP2, 3DIR2, 3OP3 or 3LL3}$$

Wiring via PTs (PT Ratio > 1):

$$V_{max} \text{ (690 V input option)} = 144 \times \text{PT Ratio [V]}$$

$$V_{max} \text{ (120 V input option)} = 144 \times \text{PT Ratio [V]}$$

$$P_{max} = (I_{max} \times V_{max} \times 3)/1000 [\text{MW} \times 0.001] \text{ if wiring mode is 4LN3 or 3LN3}$$

$$P_{max} = (I_{max} \times V_{max} \times 2)/1000 [\text{MW} \times 0.001] \text{ if wiring mode is 4LL3, 3OP2, 3DIR2, 3OP3 or 3LL3}$$

② When ASCII compatibility mode is disabled (see Section 5.5), voltages, currents and powers are always transmitted with a decimal point at highest resolution available for the field. For direct wiring (PT Ratio = 1), voltages are transmitted in volts, currents in amperes, and powers in kilowatts. For wiring via PT (PT Ratio > 1), voltages are transmitted in kilovolts, currents in amperes, and powers in megawatts. When the value is greater than the field width, the right most digits of the fractional part are truncated. For the best available resolution, see Note ② to Table 5-7.

When ASCII compatibility mode is enabled, the PM172 provides a fully downward-compatible response using a lower resolution for voltages, currents and powers - the value is transmitted as a whole number until the field is filled up, and then it is converted to higher units and transmitted with a decimal point (when the value is greater than the field width, the right most digits of the fractional part will be truncated). Voltages are transmitted in volts as whole numbers or in kilovolts with a decimal point, currents in amperes as whole numbers, and powers in kilowatts as whole numbers or in megawatts with a decimal point.

③ Energy readings are transmitted in MWh, Mvarh and MVAh units with a decimal point. If the energy value exceeds the field resolution, the right-most digits are truncated. The energy roll value is user selectable (see Section 5.4).

④ For negative power factor, the minus sign is transmitted before a decimal point as shown in the table.

⑤ To get block interval demand readings, set the number of demand periods equal to 1 (see Table 4-4).

⑥ When the 4LN3 or 3LN3 wiring mode is selected, the voltages will be line-to-neutral; for any other wiring mode, they will be line-to-line voltages.

(E) available in the PM172E

4.2 Basic Setup

Table 4-2 Read Request

| Message type (ASCII) | | | | |
|------------------------|--------|--------|----------------------|-------------------------|
| 1 | | | | |
| Message body (decimal) | | | | |
| Request | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 3 | Parameter identifier | see Table 4-4 |
| Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 3 | Parameter identifier | see Table 4-4 |
| 2 | 3 | 4 | Not used | permanently set to 00.0 |
| 3 | 7 | 6 | Parameter value | see Table 4-4 |

Table 4-3 Write Request

| Message type (ASCII) | | | | |
|------------------------|--------|--------|----------------------|---------------|
| 2 | | | | |
| Message body (decimal) | | | | |
| Request/Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 3 | Parameter identifier | see Table 4-4 |
| 2 | 3 | 4 | Not used | set to 00.0 |
| 3 | 7 | 6 | Parameter value | see Table 4-4 |

Table 4-4 Basic Setup Parameters

| Parameter | Identifier | Range |
|----------------------------------|------------|---|
| Wiring mode ① | W40 | 0 = 3OP2, 1 = 4LN3, 2 = 3DIR2, 3 = 4LL3, 4 = 3OP3, 5 = 3LN3, 6 = 3LL3 |
| PT ratio | U14 | 1.0 to 6500.0 |
| CT primary current | I17 | 1 to 5000 A |
| Power demand period (E) | D11 | 1,2,5,10,15,20,30,60 min 255 = external synchronization |
| The number of demand periods (E) | F47 | 1 - 15 |
| Volt/ampere demand period | C12 | 0 to 1800 sec |
| Averaging buffer size | S41 | 8, 16, 32 |
| Reset enable/disable | R42 | 0 = disable, 1 = enable |
| Nominal frequency | Q51 | 50, 60 |
| Maximum demand load current | Q52 | 0 to 10000 A (0 = CT primary current) |

① The wiring mode options are as follows:

3OP2 - 3-wire open delta using 2 CTs (2 element)

4LN3 - 4-wire WYE using 3 PTs (3 element), line to neutral voltage readings

3DIR2 - 3-wire direct connection using 2 CTs (2 element)

4LL3 - 4-wire WYE using 3 PTs (3 element), line to line voltage readings

3OP3 - 3-wire open delta using 3 CTs (2 1/2 element)

3LN3 - 4-wire WYE using 2 PTs (2 1/2 element), line to neutral voltage readings

3LL3 - 4-wire WYE using 2 PTs (2 1/2 element), line to line voltage readings

(E) available in the PM172E

4.3 Instrument Status

Table 4-5 Read Request

| Message type (ASCII) | | | | |
|----------------------------|--------|--------|--------------|---------------------|
| 3 | | | | |
| Message body (hexadecimal) | | | | |
| Request - no body | | | | |
| Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 8 | Not used | 00000000 |
| 2 | 8 | 1 | Not used | 0 |
| 3 | 9 | 1 | Relay status | 0-F (see Table 4-6) |

Table 4-6 Relay Status

| Bit | Description |
|-----|----------------------------|
| 0-1 | N/A (permanently set to 1) |
| 2 | Relay #2 status |
| 3 | Relay #1 status |

Bit meaning: 0 = relay is energized, 1 = relay is not energized

4.4 Reset/Clear Functions

These operations can be also performed by using the direct write requests instead of the specific request '4' (see Section 5.11).

Table 4-7 Write Request

| Message type (ASCII) | | | | |
|----------------------------|--------|--------|----------------|--|
| 4 | | | | |
| Message body (hexadecimal) | | | | |
| Request/Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 1 | Reset function | see Table 4-8 |
| 2 | 1 | 2 | Target | see Table 4-8 (the field can be omitted if it is equal to 0) |

Table 4-8 Reset/Clear Functions

| Function | Description | Target |
|----------|---|---|
| 1 | Clear total energy registers (E) | 0 |
| 2 | Clear total maximum demand registers | 0 = all maximum demands 1 = power demands (E) 2 = volt/ampere demands |
| 3 | Clear TOU energy registers (E) | 0 |
| 4 | Clear TOU demand registers (E) | 0 |
| 5 | Clear pulse counters | 0 = all counters 1-4 = counter #1 - #4 |
| 6 | Clear Min/Max log | 0 |
| 7 | Clear event log (E) | 0 |
| 8 | Clear data log (E) | 0-7 = data logs #1 - #8 16 = all data logs |
| 9-B | Reserved | 0 |
| C | Restore event log read queue to the beginning (E) | 0 |

| Function | Description | Target |
|----------|--|---|
| D | Restore data log read queue to the beginning (E) | 0-7 = data logs #1 - #8 16-23 = monthly profile logs for TOU energy registers #1 - #8 32-34 = monthly profile logs for TOU maximum demand registers #1 - #3 48-55 = daily profile logs for TOU energy registers #1 - #8 64-66 = daily profile logs for TOU maximum demand registers #1 - #3 |
| E-F | Reserved | N/A |

(E) available in the PM172E

4.5 Reset the Instrument (warm restart)

This request causes the instrument to perform full reset and restart, the same as when the instrument is turned on. No response is expected.

Table 4-9 Write Request

| Message type (ASCII) | |
|------------------------|--|
| 8 | |
| Message body | |
| Request - no body | |
| Response - no response | |

4.6 Firmware Version Number

Table 4-10 Read Request

| Message type (ASCII) | | | | |
|------------------------|--------|--------|------------------|---------|
| 9 | | | | |
| Message body (decimal) | | | | |
| Request - no body | | | | |
| Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 3 | Firmware version | 400-499 |

4.7 Extended Instrument Status

Table 4-11 Read Request

| Message type (ASCII) | | | | |
|----------------------------|--------|--------|------------------|----------------|
| ? | | | | |
| Message body (hexadecimal) | | | | |
| Request - no body | | | | |
| Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 4 | Relay status | see Table 4-12 |
| 2 | 4 | 4 | Not used | 0 |
| 3 | 8 | 4 | Status inputs | see Table 4-13 |
| 4 | 12 | 4 | Setpoints status | see Table 4-14 |
| 5 | 16 | 4 | Log status | see Table 4-15 |
| 6 | 20 | 4 | Data log status | see Table 4-16 |
| 7 | 24 | 32 | Not used | 0 |

Table 4-12 Relay Status

| Bit | Description |
|------|---------------------------------|
| 0 | Relay #1 status |
| 1 | Relay #2 status |
| 2-15 | Not used (permanently set to 0) |

Bit meaning: 0 = relay is not energized, 1 = relay is energized

Table 4-13 Status Inputs

| Bit | Description |
|------|---------------------------------|
| 0 | Status input #1 |
| 1 | Status input #2 |
| 2-15 | Not used (permanently set to 0) |

Bit meaning: 0 = contact open, 1 = contact closed

Table 4-14 Setpoints Status

| Bit | Description |
|-----|----------------------|
| 0 | Setpoint # 1 status |
| 1 | Setpoint # 2 status |
| 2 | Setpoint # 3 status |
| 3 | Setpoint # 4 status |
| 4 | Setpoint # 5 status |
| 5 | Setpoint # 6 status |
| 6 | Setpoint # 7 status |
| 7 | Setpoint # 8 status |
| 8 | Setpoint # 9 status |
| 9 | Setpoint # 10 status |
| 10 | Setpoint # 11 status |
| 11 | Setpoint # 12 status |
| 12 | Setpoint # 13 status |
| 13 | Setpoint # 14 status |
| 14 | Setpoint # 15 status |
| 15 | Setpoint # 16 status |

Bit meaning: 0 = setpoint is released, 1 = setpoint is operated

Table 4-15 Log Status

| Bit | Description |
|------|---------------------------------|
| 0 | Reserved |
| 1 | New Min/Max log |
| 2 | New event log |
| 3 | New data log (any) |
| 4-15 | Not used (permanently set to 0) |

Bit meaning: 0 = no new logs, 1 = new log recorded (the new log flag is reset when the user reads the first log record after the flag has been set)

Table 4-16 Data Log Status

| Bit | Description |
|------|---------------------------------|
| 0 | New data log #1 |
| 1 | New data log #2 |
| 2 | New data log #3 |
| 3 | New data log #4 |
| 4 | New data log #5 |
| 5 | New data log #6 |
| 6 | New data log #7 |
| 7 | New data log #8 |
| 8-15 | Not used (permanently set to 0) |

Bit meaning: 0 = no new logs, 1 = new log recorded (the new log flag is reset when the user reads the first log record after the flag has been set)

4.8 Log Memory Status

Table 4-17 Read Request

| Message type (ASCII) | | | |
|----------------------------|--------|--------|---|
| @ | | | |
| Message body (hexadecimal) | | | |
| Request - no body | | | |
| Response | | | |
| Field | Offset | Length | Parameter |
| 1 | 0 | 8 | Total memory size, byte |
| 2 | 8 | 8 | Free memory size, byte |
| 3 | 16 | 4 | The number of logged records in event log |
| 4 | 20 | 4 | The number of logged records in data log #1 |
| 5 | 24 | 4 | The number of logged records in data log #2 |
| 6 | 28 | 4 | The number of logged records in data log #3 |
| 7 | 32 | 4 | The number of logged records in data log #4 |
| 8 | 36 | 4 | The number of logged records in data log #5 |
| 9 | 40 | 4 | The number of logged records in data log #6 |
| 10 | 44 | 4 | The number of logged records in data log #7 |
| 11 | 48 | 4 | The number of logged records in data log #8 |
| 12 | 52 | 40 | Not used |
| 13 | 92 | 4 | The number of new event log records |
| 14 | 96 | 4 | The number of new data log #1 records |
| 15 | 100 | 4 | The number of new data log #2 records |
| 16 | 104 | 4 | The number of new data log #3 records |
| 17 | 108 | 4 | The number of new data log #4 records |
| 18 | 112 | 4 | The number of new data log #5 records |
| 19 | 116 | 4 | The number of new data log #6 records |
| 20 | 120 | 4 | The number of new data log #7 records |
| 21 | 124 | 4 | The number of new data log #8 records |
| 22 | 128 | 40 | Not used |

The number of logged records includes all records currently logged in the memory partition. The number of the new records includes the number of records that are logged after the last read request has been issued for the memory partition.

4.9 Analog Output Allocation

Table 4-18 Read Request

| Message type (ASCII) | | | | |
|----------------------------|--------|--------|------------------------|---------------------|
| B | | | | |
| Message body (hexadecimal) | | | | |
| Request | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Analog channel number | 0-1 = channel #1-#2 |
| Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Analog channel number | 0-1 = channel #1-#2 |
| 2 | 2 | 4 | Output parameter index | see Table 4-22 |
| 3 | 6 | 8 | Zero scale (0/4 mA) | see Table 4-22 |
| 4 | 14 | 8 | Full scale (20/1 mA) | see Table 4-22 |

Table 4-19 Write Request

| Message type (ASCII) | | | | |
|----------------------------|--------|--------|------------------------|---------------------|
| b | | | | |
| Message body (hexadecimal) | | | | |
| Request/Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Analog channel number | 0-1 = channel #1-#2 |
| 2 | 2 | 4 | Output parameter index | see Table 4-22 |
| 3 | 6 | 8 | Zero scale (0/4 mA) | see Table 4-22 |
| 4 | 14 | 8 | Full scale (20/1 mA) | see Table 4-22 |

1. Except for the signed power factor (see Note 3 to Table 4-22), the output scale is linear within the value range. The scale range will be inverted if the full scale specified is less than the zero scale.
2. For bi-directional analog output (± 1 mA), the zero scale corresponds to the center of the scale range (0 mA) and the direction of the current matches the sign of the output parameter. For signed (bi-directional) values, such as powers and signed power factor, the scale is always symmetrical with regard to 0 mA, and the full scale corresponds to +1 mA output for positive readings and to -1 mA output for negative readings. For these, the zero scale (0 mA output) is permanently set in the instrument to zero for all parameters except the signed power factor for which it is set to 1.000. In the write request, the zero scale is ignored. No error will occur when you attempt to change it. Unsigned parameters are output within the current range 0 to +1 mA and can be scaled using both zero and full scales as in the case of single-ended analog output.

4.10 Analog Expander Channel Allocation

Table 4-20 Read Request

| Message type (ASCII) | | | | |
|----------------------------|--------|--------|------------------------|-----------------------|
| C | | | | |
| Message body (hexadecimal) | | | | |
| Request | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Analog channel number | 0-15 = channel #1-#16 |
| Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Analog channel number | 0-15 = channel #1-#16 |
| 2 | 2 | 4 | Output parameter index | see Table 4-22 |
| 3 | 6 | 8 | Zero scale (0/4 mA) | see Table 4-22 |
| 4 | 14 | 8 | Full scale (20 mA) | see Table 4-22 |

Table 4-21 Write Request

| Message type (ASCII) | | | | |
|----------------------------|--------|--------|------------------------|-----------------------|
| c | | | | |
| Message body (hexadecimal) | | | | |
| Request/Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Analog channel number | 0-15 = channel #1-#16 |
| 2 | 2 | 4 | Output parameter index | see Table 4-22 |
| 3 | 6 | 8 | Zero scale (0/4 mA) | see Table 4-22 |
| 4 | 14 | 8 | Full scale (20 mA) | see Table 4-22 |

NOTE

Analog expander outputs settings will not be in effect until the analog expander output is globally enabled. To activate the analog expander output, set the analog expander option to the enabled state in the user selectable options setup (see Section 5.4).

Table 4-22 Analog Output Parameters

| Parameter | Data index | Length | Unit ② | Scale range ① |
|------------------------------------|------------|--------|-----------------|---------------|
| None | | | | |
| None | 0000h | 4 | | 0 |
| Real-time values per phase | | | | |
| Voltage L1/L12 ⑤ | 0C00h | 8 | 0.1V/1V | 0 to Vmax |
| Voltage L2/L23 ⑤ | 0C01h | 8 | 0.1V/1V | 0 to Vmax |
| Voltage L3/L31 ⑤ | 0C02h | 8 | 0.1V/1V | 0 to Vmax |
| Current L1 | 0C03h | 8 | 0.01A | 0 to Imax |
| Current L2 | 0C04h | 8 | 0.01A | 0 to Imax |
| Current L3 | 0C05h | 8 | 0.01A | 0 to Imax |
| Real-time total value | | | | |
| Total kW | 0F00h | 8 | 0.001kW/1kW | -Pmax to Pmax |
| Total kvar | 0F01h | 8 | 0.001kvar/1kvar | -Pmax to Pmax |
| Total kVA | 0F02h | 8 | 0.001kVA/1kVA | 0 to Pmax |
| Total PF ④ | 0F03h | 4 | 0.001 | -999 to 1000 |
| Total PF Lag | 0F04h | 4 | 0.001 | -999 to 1000 |
| Total PF Lead | 0F05h | 4 | 0.001 | -999 to 1000 |
| Real-time auxiliary values | | | | |
| Frequency ③ | 1002h | 4 | 0.01Hz | 0 to 10000 |
| Average values per phase | | | | |
| Voltage L1/L12 ⑤ | 1100h | 8 | 0.1V/1V | 0 to Vmax |
| Voltage L2/L23 ⑤ | 1101h | 8 | 0.1V/1V | 0 to Vmax |
| Voltage L3/L31 ⑤ | 1102h | 8 | 0.1V/1V | 0 to Vmax |
| Current L1 | 1103h | 8 | 0.01A | 0 to Imax |
| Current L2 | 1104h | 8 | 0.01A | 0 to Imax |
| Current L3 | 1105h | 8 | 0.01A | 0 to Imax |
| Average total values | | | | |
| Total kW | 1400h | 8 | 0.001kW/1kW | -Pmax to Pmax |
| Total kvar | 1401h | 8 | 0.001kvar/1kvar | -Pmax to Pmax |
| Total kVA | 1402h | 8 | 0.001kVA/1kVA | 0 to Pmax |
| Total PF ④ | 1403h | 4 | 0.001 | -999 to 1000 |
| Total PF Lag | 1404h | 4 | 0.001 | -999 to 1000 |
| Total PF Lead | 1405h | 4 | 0.001 | -999 to 1000 |
| Average auxiliary values | | | | |
| Neutral current | 1501h | 8 | 0.01A | 0 to Imax |
| Frequency ③ | 1502h | 4 | 0.01Hz | 0 to 10000 |
| Present demands | | | | |
| Accumulated kW import demand (E) | 160Fh | 8 | 0.001kW/1kW | 0 to Pmax |
| Accumulated kvar import demand (E) | 1610h | 8 | 0.001kvar/1kvar | 0 to Pmax |
| Accumulated kVA demand (E) | 1611h | 8 | 0.001kVA/1kVA | 0 to Pmax |
| Accumulated kW export demand (E) | 161Ah | 8 | 0.001kW/1kW | 0 to Pmax |
| Accumulated kvar export demand (E) | 161Bh | 8 | 0.001kvar/1kvar | 0 to Pmax |

① For parameter limits, see Note ① to Table 4-1.

② When using direct wiring (PT Ratio = 1), voltages are transmitted in 0.1 V units, currents in 0.01 A units, and powers in 0.001 kW/kvar/kVA units. For wiring via PTs (PT Ratio > 1), voltages are transmitted in 1V units, currents in 0.01 A units, and powers in 1 kW/kvar/kVA units.

③ The actual frequency range is 45.00 to 65.00 Hz

④ The output scale for signed (bi-directional) power factor is symmetrical with regard to ±1.000 and is linear from -0 to -1.000, and from 1.000 to +0 (note that -1.000 ≡ +1.000). Negative power factor is output as [-1.000 minus measured value], and non-negative power factor is output as [+1.000 minus measured value]. To define the entire range for power factor from -0 to +0, the scales would be specified as -0/0. Because of the fact that negative zero may not be transmitted, the value of -0.001 is used to specify the scale of -0, and both +0.001 and 0.000 are used to specify the scale of +0. To define the range of -0 to 0, you must send -1/1 or -1/0 (considering the modulus of ×0.001).

⑤ When the 4LN3 or 3LN3 wiring mode is selected, the voltages will be line-to-neutral; for any other wiring mode, they will be line-to-line voltages.

(E) available in the PM172E

4.11 Digital Inputs Allocation

Table 4-23 Read Request

| Message type (ASCII) | | | | |
|----------------------------|--------|--------|------------------------|----------------|
| D | | | | |
| Message body (hexadecimal) | | | | |
| Request | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Digital input group ID | see Table 4-25 |
| Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Digital input group ID | see Table 4-25 |
| 2 | 2 | 2 | Allocation mask | see Table 4-26 |

Table 4-24 Write Request

| Message type (ASCII) | | | | |
|----------------------------|--------|--------|------------------------|----------------|
| d | | | | |
| Message body (hexadecimal) | | | | |
| Request/Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Digital input group ID | see Table 4-25 |
| 2 | 2 | 2 | Allocation mask | see Table 4-26 |

Table 4-25 Digital Input Groups

| Group ID | Description |
|----------|---|
| 0 | Status inputs ① |
| 1 | Pulse inputs |
| 2 | Not used (read as 0) ① |
| 3 | External demand synchronization pulse input (E) |
| 4 | Time synchronization pulse input |

① Writing to these locations is ignored. No error will occur.

(E) available in the PM172E

NOTES

- All digital inputs that were not allocated as pulse inputs will be automatically configured as status inputs.
- A digital input allocated for the external demand synchronization pulse or time synchronization pulse will be automatically configured as a pulse input.

Table 4-26 Digital Inputs Allocation Mask

| Bit number | Description |
|------------|--------------------------------------|
| 0 | Discrete input # 1 allocation status |
| 1 | Discrete input # 2 allocation status |
| 2-7 | Not used |

Bit meaning: 0 = input not allocated, 1 = input allocated to the group

4.12 Timer Setup

Table 4-27 Read Request

| Message type (ASCII) | | | | |
|----------------------------|--------|--------|---------------------|----------------------------|
| E | | | | |
| Message body (hexadecimal) | | | | |
| Request | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Timer ID | 0-1 = timer #1-#2 |
| Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Timer ID | 0-1 = timer #1-#2 |
| 2 | 2 | 4 | Timer interval, sec | 1-9999, 0 = timer disabled |

Table 4-28 Write Request

| Message type (ASCII) | | | | |
|----------------------------|--------|--------|---------------------|---------------------------|
| e | | | | |
| Message body (hexadecimal) | | | | |
| Request/Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Timer ID | 0-1 = timer #1-#2 |
| 2 | 2 | 4 | Timer interval, sec | 1-9999, 0 = disable timer |

4.13 Pulsing Setpoints

Table 4-29 Read Request

| Message type (ASCII) | | | | |
|----------------------------|--------|--------|---|----------------------|
| G | | | | |
| Message body (hexadecimal) | | | | |
| Request | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Pulse output ID | 0-1 (see Table 4-31) |
| Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Pulse output ID | 0-1 (see Table 4-31) |
| 2 | 2 | 2 | Output parameter ID | see Table 4-32 |
| 3 | 4 | 4 | For energy pulsing = number of unit-hours per pulse, otherwise - permanently set to 0 | 0-9999 |

Table 4-30 Write Request

| Message type (ASCII) | | | | |
|----------------------------|--------|--------|---|----------------------|
| g | | | | |
| Message body (hexadecimal) | | | | |
| Request/Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Pulse output ID | 0-1 (see Table 4-31) |
| 2 | 2 | 2 | Output parameter ID | see Table 4-32 |
| 3 | 4 | 4 | For energy pulsing = number of unit-hours per pulse, otherwise - set to 0 | 0-9999 |

Table 4-31 Pulse Outputs

| Pulsing output ID | Output allocation |
|-------------------|-------------------|
| 0 | Relay #1 |
| 1 | Relay #2 |

Table 4-32 Pulsing Output Parameters

| Pulsing parameter ID | Identifier |
|------------------------|------------|
| None | 0 |
| kWh import | 1 |
| kWh export | 2 |
| kvarh import | 4 |
| kvarh export | 5 |
| kvarh total (absolute) | 6 |
| kVAh total | 7 |

4.14 Pulse Counters Setup

Table 4-33 Read Request

| Message type (ASCII) | | | | |
|----------------------------|--------|--------|--|----------------------|
| J | | | | |
| Message body (hexadecimal) | | | | |
| Request | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Pulse counter ID | 0-3 (see Table 4-35) |
| Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Pulse counter ID | 0-3 (see Table 4-35) |
| 2 | 2 | 2 | Digital input ID | 0-1 (see Table 4-36) |
| 3 | 4 | 4 | Scale factor - number of units per pulse | 1-9999 |

Table 4-34 Write Request

| Message type (ASCII) | | | | |
|----------------------------|--------|--------|--|----------------------|
| j | | | | |
| Message body (hexadecimal) | | | | |
| Request/Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Pulse counter ID | 0-3 (see Table 4-35) |
| 2 | 2 | 2 | Digital input ID | 0-8 (see Table 4-36) |
| 3 | 4 | 4 | Scale factor - number of units per pulse | 1-9999 |

Table 4-35 Pulse Counters

| Counter ID | Description |
|------------|-------------------|
| 0 | Pulse counter # 1 |
| 1 | Pulse counter # 2 |
| 2 | Pulse counter # 3 |
| 3 | Pulse counter # 4 |

Table 4-36 Digital Inputs

| Input ID | Description |
|----------|-------------------|
| 0 | Not allocated |
| 1 | Digital input # 1 |
| 2 | Digital input # 2 |

4.15 Log Memory Partition Setup

Table 4-37 Read Request

| Message type (ASCII) | | | | |
|----------------------------|--------|--------|---|---|
| K | | | | |
| Message body (hexadecimal) | | | | |
| Request | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Partition number | 0-8 (see Table 4-39) |
| Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Partition number | 0-8 (see Table 4-39) |
| 2 | 2 | 8 | Partition size, byte | 0-524288 |
| 3 | 10 | 4 | The number of records in the partition | 0-65535 |
| 4 | 14 | 4 | Record size, byte | |
| 5 | 18 | 2 | The number of log parameters in the record (for a data log partition) | 0-16 |
| 6 | 20 | 2 | Partition type | 0 = non-wrap 1 = wrap around 16 = TOU monthly profile log (partition #7 only) 32 = TOU daily profile log (partition #8 only) |

Table 4-38 Write Request

| Message type (ASCII) | | | | |
|----------------------------|--------|--------|---|---|
| k | | | | |
| Message body (hexadecimal) | | | | |
| Request | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Partition number | 0-8 (see Table 4-39) |
| 2 | 2 | 4 | The number of records in the partition | 1-65535, 0=delete partition |
| 3 | 6 | 2 | The number of log parameters in the record (for a data log partition) | 0-16 |
| 4 | 8 | 2 | Partition type | 0 = non wrap 1 = wrap around 16 = TOU monthly profile log (partition #7 only) 32 = TOU daily profile log (partition #8 only) |
| Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Partition number | 0-8 (see Table 4-39) |

This request allows you to allocate a memory partition for logging and to specify the partition size and type. Before allocating a partition, it is recommended to check the available memory by issuing request "@". To help you in planning memory, Table 4-40 shows the record size for each partition. Note that an existing partition may not be resized. To change the partition properties, you should first delete the partition, and then reallocate it with the desirable properties. After reallocation of memory, the instrument performs the memory optimization and will not respond to the host requests for approximately 1 second per 128 Kbyte of memory.

Partitions #7 and #8 can be configured as TOU monthly and daily profile log partitions respectively. Both will be set as wrap-around partitions. Before you configure the partition as a profile partition, you should set up your TOU registers, daily profiles and calendars. The memory for a profile log will be allocated automatically in accordance with the number of TOU registers you defined in the TOU setup. For each TOU energy and maximum demand register, a separate log sub-partition will be allocated within a parent log partition. Each of these can be accessed and read individually (see Section 5.15). The number of log parameters in the record should specify the maximum number of active season tariffs. The file record size will be set in accordance with this number. If you specified it as less than the actual number of tariffs that may be in effect within a tariff season, then only a part of the tariff registers will be recorded to the profile.

Table 4-39 Log Memory Partitions

| Partition number | Partition allocation |
|------------------|--|
| 0 | Event log |
| 1 | Data log #1 |
| 2 | Data log #2 |
| 3 | Data log #3 |
| 4 | Data log #4 |
| 5 | Data log #5 |
| 6 | Data log #6 |
| 7 | Data log #7 (can be configured as a TOU monthly profile log partition) |
| 8 | Data log #8 (can be configured as a TOU daily profile log partition) |

Table 4-40 Partitions' Record Size

| Partition | Record size, byte |
|-----------|--------------------------------|
| Event log | 14 |
| Data log | 8 + 4 * (NUMBER OF PARAMETERS) |

4.16 Data Log Setup

Table 4-41 Read Request

| Message type (ASCII) | | | | |
|----------------------------|--------|--------|---|----------------------------------|
| L | | | | |
| Message body (hexadecimal) | | | | |
| Request | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Data log number | 0-7 = log #1-#8 |
| Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Data log number | 0-7 = log #1-#8 |
| 2 | 2 | 2 | The number of parameters in the data log record | 1-16, 0=partition does not exist |
| 3 | 4 | 4 | Log parameter #1 ID | see Table 5-7 |
| 4 | 8 | 4 | Log parameter #2 ID | see Table 5-7 |
| 5 | 12 | 4 | Log parameter #3 ID | see Table 5-7 |
| 6 | 16 | 4 | Log parameter #4 ID | see Table 5-7 |
| 7 | 20 | 4 | Log parameter #5 ID | see Table 5-7 |
| 8 | 24 | 4 | Log parameter #6 ID | see Table 5-7 |
| 9 | 28 | 4 | Log parameter #7 ID | see Table 5-7 |
| 10 | 32 | 4 | Log parameter #8 ID | see Table 5-7 |
| 11 | 36 | 4 | Log parameter #9 ID | see Table 5-7 |
| 12 | 40 | 4 | Log parameter #10 ID | see Table 5-7 |
| 13 | 44 | 4 | Log parameter #11 ID | see Table 5-7 |
| 14 | 48 | 4 | Log parameter #12 ID | see Table 5-7 |
| 15 | 52 | 4 | Log parameter #13 ID | see Table 5-7 |
| 16 | 56 | 4 | Log parameter #14 ID | see Table 5-7 |
| 17 | 60 | 4 | Log parameter #15 ID | see Table 5-7 |
| 18 | 64 | 4 | Log parameter #16 ID | see Table 5-7 |

Table 4-42 Write Request

| Message type (ASCII) | | | | |
|----------------------------|--------|--------|---|-----------------|
| I | | | | |
| Message body (hexadecimal) | | | | |
| Request | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Data log number | 0-7 = log #1-#8 |
| 2 | 2 | 2 | The number of parameters in the data log record | 1-16 |
| 3 | 4 | 4 | Log parameter #1 ID | see Table 5-7 |
| 4 | 8 | 4 | Log parameter #2 ID | see Table 5-7 |
| 5 | 12 | 4 | Log parameter #3 ID | see Table 5-7 |
| 6 | 16 | 4 | Log parameter #4 ID | see Table 5-7 |
| 7 | 20 | 4 | Log parameter #5 ID | see Table 5-7 |
| 8 | 24 | 4 | Log parameter #6 ID | see Table 5-7 |
| 9 | 28 | 4 | Log parameter #7 ID | see Table 5-7 |
| 10 | 32 | 4 | Log parameter #8 ID | see Table 5-7 |
| 11 | 36 | 4 | Log parameter #9 ID | see Table 5-7 |
| 12 | 40 | 4 | Log parameter #10 ID | see Table 5-7 |
| 13 | 44 | 4 | Log parameter #11 ID | see Table 5-7 |
| 14 | 48 | 4 | Log parameter #12 ID | see Table 5-7 |
| 15 | 52 | 4 | Log parameter #13 ID | see Table 5-7 |
| 16 | 56 | 4 | Log parameter #14 ID | see Table 5-7 |
| 17 | 60 | 4 | Log parameter #15 ID | see Table 5-7 |
| 18 | 64 | 4 | Log parameter #16 ID | see Table 5-7 |
| Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Data log number | 0-7 = log #1-#8 |

1. The memory partition must be allocated for the log before setting up its parameters.
2. If a partition has been allocated as a TOU profile log partition, the data log setup for the partition cannot be written. Write requests will be ignored. A read request will return identifiers of the TOU season tariff energy registers 7000h to 700Fh.

4.17 Event Log (Sequential Access)

This request allows you to read a packet of consequent records from the event log partition. Up to eight event log records can be read at a time. The read queue pointer is shifted forward after each request until the last logged record is read. After that, the exception code 98 is returned instead of log data. To restore the pointer to the log file origin, request '4' followed by function code 'C' or direct write to register A00Bh should be used.

Table 4-43 Read Request

| Message type (ASCII) | | | | | |
|----------------------------|--------|--------|------------------------------------|--|----------------|
| M | | | | | |
| Message body (hexadecimal) | | | | | |
| Request - no body | | | | | |
| Response | | | | | |
| Field | Offset | Length | Parameter | Range | |
| 1 | 0 | 2 | The number of events in the packet | 1-8, 98 = no more events 99 = no events logged | |
| 2 | 2 | 2 | Event log #1 | 0-59, 97 = record corrupted | |
| 3 | 4 | 2 | | Second | 0-59 |
| 4 | 6 | 2 | | Minute | 0-23 |
| 5 | 8 | 2 | | Hour | 1-31 |
| 6 | 10 | 2 | | Day | 1-12 |
| 7 | 12 | 2 | | Month | 0-99 |
| 8 | 14 | 2 | | Year | see Table 4-44 |
| 10 | 18 | 8 | | Event cause | see Table 4-44 |
| 11 | 26 | 4 | | Log value | see Table 4-44 |
| 12 | 30 | 2 | | Effect | see Table 4-44 |
| | | | | Target | see Table 4-44 |

| Message type (ASCII) | | | | | |
|----------------------------|--------|--------|--------------|----------------|-----------------------------|
| M | | | | | |
| Message body (hexadecimal) | | | | | |
| Request - no body | | | | | |
| Response | | | | | |
| Field | Offset | Length | Parameter | | Range |
| 13 | 32 | 2 | Event log #2 | Second | 0-59, 97 = record corrupted |
| 14 | 34 | 2 | | Minute | 0-59 |
| 15 | 36 | 2 | | Hour | 0-23 |
| 16 | 38 | 2 | | Day | 1-31 |
| 17 | 40 | 2 | | Month | 1-12 |
| 18 | 42 | 2 | | Year | 0-99 |
| 19 | 44 | 2 | | Event cause | see Table 4-44 |
| 20 | 46 | 2 | | Event origin | see Table 4-44 |
| 21 | 48 | 8 | | Log value | see Table 4-44 |
| 22 | 56 | 4 | | Effect | see Table 4-44 |
| 23 | 60 | 2 | Target | see Table 4-44 | |
| ... | | | | | |
| 78 | 212 | 2 | Event log #8 | Second | 0-59, 97 = record corrupted |
| 79 | 214 | 2 | | Minute | 0-59 |
| 80 | 216 | 2 | | Hour | 0-23 |
| 81 | 218 | 2 | | Day | 1-31 |
| 82 | 220 | 2 | | Month | 1-12 |
| 83 | 222 | 2 | | Year | 0-99 |
| 84 | 224 | 4 | | Event cause | see Table 4-44 |
| 85 | 228 | 8 | | Log value | see Table 4-44 |
| 86 | 236 | 4 | | Effect | see Table 4-44 |
| 87 | 240 | 2 | | Target | see Table 4-44 |

Table 4-44 Event Log Parameters

| Event cause | Event cause code | | Log value | Event effect | |
|------------------------|---|--|--|--|------------------------|
| | High byte: cause code | Low byte: event origin (location) | | Effect code | Target code |
| Setpoint event | Trigger parameter ID high byte (see Table 5-12) | Trigger parameter ID low byte (see Table 5-12) | Trigger parameter value (see Table 5-12) | 225 (E1h) = setpoint operated 226 (E2h) = setpoint released | Setpoint number = 0-15 |
| Communication activity | 91 (5Bh) | Data location code (see Table 4-45) | N/A | See Table 4-46 | See Table 4-46 |
| Front panel activity | 92 (5Ch) | Data location code (see Table 4-45) | N/A | See Table 4-46 | See Table 4-46 |
| Self-check | 93 (5Dh) | Data location code (see Table 4-45) | N/A | See Table 4-46 | See Table 4-46 |
| Self-update | 94 (5Eh) | 8 = RTC | N/A | 245 = RTC set | N/A |
| External event | 99 (63h) | 0 = power down 8 = power up | N/A | N/A | N/A |

Table 4-45 Data Location Codes

| Location code | Description |
|---------------|----------------------|
| 3 | Data keeping memory |
| 8 | Real-time clock |
| 16 | Event/alarm setpoint |

Table 4-46 Event Effect Codes

| Effect code | | Description | Target |
|-------------|-----|-----------------------------|---|
| Dec | Hex | | |
| 96 | 60h | Clear energy registers | N/A |
| 97 | 61h | Clear demand registers | 0 = all demands 1 = power demands 2 = volt/ampere demands |
| 98 | 62h | Clear TOU energy registers | N/A |
| 99 | 63h | Clear TOU demand registers | N/A |
| 100 | 64h | Clear counters | 0 = all 1-4 = counter #1-#4 |
| 101 | 65h | Clear Min/Max log registers | N/A |
| 102 | 66h | Clear event log | N/A |
| 103 | 67h | Clear data log | 0-7 = log #1-#8 16 (10h) = all data logs |
| 225 | E1h | Setpoint operated | 0-15 (0Fh) = setpoint #1-#16 |
| 226 | E2h | Setpoint released | 0-15 (0Fh) = setpoint #1-#16 |
| 241 | F1h | Setpoint disabled | 0-15 (0Fh) = setpoint #1-#16 |
| 245 | F5h | RTC set | N/A |

4.18 Data Log (Sequential Access)

This request is used to read subsequent records from the requested data log partition. All records from the partition are read in sequence until the end of the log file. After that, the error code 98 is returned in the response's first field. A specific request '4' followed by function code 'D' or direct write to register A00Ch can be used to restore the read pointer to the file origin. A direct write to the partition status/control register can be used to point to an arbitrary record in the log file (see Section 5.13).

NOTE. The PM172 offers you another mechanism to access data logs, allowing you to read records in a circular manner without needing a file pointer. In this event, the file pointer is automatically restored to the file origin after the last file record has been read (see Section 5.15).

Table 4-47 Read Request

| Message type (ASCII) | | | | |
|----------------------------|--------|--------|--|--|
| N | | | | |
| Message body (hexadecimal) | | | | |
| Request | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Data log number | 0-7 = log #1-#8 |
| Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Trigger setpoint number | 1-16, 0 = profile log 97 = record corrupted 98 = no more logged records 99 = no data logged |
| 2 | 2 | 2 | Hundredths of second | 0-99 |
| 3 | 4 | 2 | Second | 0-59 |
| 4 | 6 | 2 | Minute | 0-59 |
| 5 | 8 | 2 | Hour | 0-23 |
| 6 | 10 | 2 | Day | 1-31 |
| 7 | 12 | 2 | Month | 1-12 |
| 8 | 14 | 2 | Year | 0-99 |
| 9 | 16 | 2 | The number of parameters in the packet | 1-16 |
| 10 | 18 | 8 | Parameter #1 value | see Table 5-7 |
| 11 | 26 | 8 | Parameter #2 value | see Table 5-7 |
| 12 | 34 | 8 | Parameter #3 value | see Table 5-7 |
| | | | ... | |
| 25 | 138 | 8 | Parameter #16 value | see Table 5-7 |

If data log partition #7 or #8 is configured as a TOU monthly or daily profile partition, reading data from this log file will return data from the first TOU profile sub-partition allocated for TOU energy register #1, or for the following first available TOU register if this register is not configured.

4.19 Min/Max Log

Table 4-48 Read Request

| Message type (ASCII) | | | | | |
|----------------------------|--------|--------|---|------------------|---------------|
| 0 | | | | | |
| Message body (hexadecimal) | | | | | |
| Request | | | | | |
| Field | Offset | Length | Parameter | | Range |
| 1 | 0 | 4 | Start Min/Max parameter ID | | see Table 5-7 |
| 2 | 4 | 2 | The number of subsequent parameters to read | | 1-12 |
| Response | | | | | |
| Field | Offset | Length | Parameter | | Range |
| 1 | 0 | 2 | The number of parameters in message | | 1-12 |
| 2 | 2 | 2 | Log parameter #1 | Second | 0-59 |
| 3 | 4 | 2 | | Minute | 0-59 |
| 4 | 6 | 2 | | Hour | 0-23 |
| 5 | 8 | 2 | | Day | 1-31 |
| 6 | 10 | 2 | | Month | 1-12 |
| 7 | 12 | 2 | | Year | 0-99 |
| 8 | 14 | 8 | | Parameter value | see Table 5-7 |
| 9 | 22 | 2 | | Log parameter #2 | Second |
| 10 | 24 | 2 | Minute | | 0-59 |
| 11 | 26 | 2 | Hour | | 0-23 |
| 12 | 28 | 2 | Day | | 1-31 |
| 13 | 30 | 2 | Month | | 1-12 |
| 14 | 32 | 2 | Year | | 0-99 |
| 15 | 34 | 8 | Parameter value | | see Table 5-7 |
| . . . | | | | | |
| 79 | 222 | 2 | Log parameter #12 | Second | 0-59 |
| 80 | 224 | 2 | | Minute | 0-59 |
| 81 | 226 | 2 | | Hour | 0-23 |
| 82 | 228 | 2 | | Day | 1-31 |
| 83 | 230 | 2 | | Month | 1-12 |
| 84 | 232 | 2 | | Year | 0-99 |
| 85 | 234 | 8 | | Parameter value | see Table 5-7 |

This request allows the user to obtain the Min/Max log parameters. Up to 12 parameters can be read in one packet from a single parameter group. The available Min/Max log parameters are listed in Table 5-7.

4.20 TOU Registers Allocation

Table 4-49 Read Request

| Message type (ASCII) | | | | |
|----------------------------|--------|--------|---|-----------------------|
| P | | | | |
| Message body (hexadecimal) | | | | |
| Request | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | TOU system register ID | 0-10 (see Table 4-51) |
| Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | TOU system register ID | 0-10 (see Table 4-51) |
| 2 | 2 | 2 | Register input ID | see Tables 4-52, 4-53 |
| 3 | 4 | 4 | For a pulse input = number of unit-hours per pulse, otherwise - permanently set to 0. | 0-9999 |

Table 4-50 Write Request

| Message type (ASCII) | | | | |
|----------------------------|--------|--------|---|-----------------------|
| p | | | | |
| Message body (hexadecimal) | | | | |
| Request/Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | TOU system register ID | 0-10 (see Table 4-51) |
| 2 | 2 | 2 | Register input ID | see Tables 4-52, 4-53 |
| 3 | 4 | 4 | For a pulse input = number of unit-hours per pulse, otherwise - set to 0. | 0-9999 |

Table 4-51 TOU System Registers Identifiers

| Register ID | Description |
|-------------|--------------------------------|
| 0 | TOU energy register #1 |
| 1 | TOU energy register #2 |
| 2 | TOU energy register #3 |
| 3 | TOU energy register #4 |
| 4 | TOU energy register #5 |
| 5 | TOU energy register #6 |
| 6 | TOU energy register #7 |
| 7 | TOU energy register #8 |
| 8 | TOU maximum demand register #1 |
| 9 | TOU maximum demand register #2 |
| 10 | TOU maximum demand register #3 |

Table 4-52 TOU Energy Registers Inputs

| Register input | Input ID |
|----------------|----------|
| None | 0 |
| kWh import | 1 |
| kWh export | 2 |
| N/A ① | 3 |
| N/A ① | 4 |
| kvarh import | 5 |
| kvarh export | 6 |
| N/A ① | 7 |
| N/A ① | 8 |
| kVAh total | 9 |
| Pulse input #1 | 10 |
| Pulse input #2 | 11 |

① Specifying this input will be accepted as NONE. No error will occur.

Table 4-53 TOU Maximum Demand Registers Inputs

| Register input | Input ID |
|---|----------|
| None | 0 |
| Maximum kW import sliding window demand | 1 |
| Maximum kW export sliding window demand | 2 |
| Maximum kvar import sliding window demand | 3 |
| Maximum kvar export sliding window demand | 4 |
| Maximum kVA sliding window demand | 5 |

4.21 TOU Daily Profiles

Table 4-54 Read Request

| Message type (ASCII) | | | | | |
|----------------------------|--------|--------|--------------------------|----------------------|-------|
| Q | | | | | |
| Message body (hexadecimal) | | | | | |
| Request | | | | | |
| Field | Offset | Length | Parameter | | Range |
| 1 | 0 | 2 | TOU daily profile number | | 0-15 |
| Response | | | | | |
| Field | Offset | Length | Parameter | | Range |
| 1 | 0 | 2 | TOU daily profile number | | 0-15 |
| 2 | 2 | 2 | 1st tariff change | Tariff start hour | 0 |
| 3 | 4 | 2 | | Tariff start minute | 0 |
| 4 | 6 | 2 | | Active tariff number | 0-15 |
| 5 | 8 | 2 | 2nd tariff change | Tariff start hour | 0-23 |
| 6 | 10 | 2 | | Tariff start minute | 0-45 |
| 7 | 12 | 2 | | Active tariff number | 0-15 |
| ... | | | | | |
| 23 | 44 | 2 | 8th tariff change | Tariff start hour | 0-23 |
| 24 | 46 | 2 | | Tariff start minute | 0-45 |
| 25 | 48 | 2 | | Active tariff number | 0-15 |

Table 4-55 Write Request

| Message type (ASCII) | | | | | |
|----------------------------|--------|--------|--------------------------|----------------------|-------|
| q | | | | | |
| Message body (hexadecimal) | | | | | |
| Request | | | | | |
| Field | Offset | Length | Parameter | | Range |
| 1 | 0 | 2 | TOU daily profile number | | 0-15 |
| 2 | 2 | 2 | 1st tariff change | Tariff start hour | 0 |
| 3 | 4 | 2 | | Tariff start minute | 0 |
| 4 | 6 | 2 | | Active tariff number | 0-15 |
| 5 | 8 | 2 | 2nd tariff change | Tariff start hour | 0-23 |
| 6 | 10 | 2 | | Tariff start minute | 0-45 |
| 7 | 12 | 2 | | Active tariff number | 0-15 |
| ... | | | | | |
| 23 | 44 | 2 | 8th tariff change | Tariff start hour | 0-23 |
| 24 | 46 | 2 | | Tariff start minute | 0-45 |
| 25 | 48 | 2 | | Active tariff number | 0-15 |
| Response | | | | | |
| Field | Offset | Length | Parameter | | Range |
| 1 | 0 | 2 | TOU daily profile number | | 0-15 |

The request allows you to change the daily profile for any of the 16 TOU system profiles. The daily start time for each tariff is specified with a resolution of 15 minutes. If another value is specified, it will be truncated to the lower value divisible by 15 minutes. No error will occur. The first daily tariff change time is always 00:00. It is preserved internally and cannot change.

4.22 TOU Calendars

Table 4-56 Read Request

| Message type (ASCII) | | | | |
|----------------------------|--------|--------|------------------------|-------|
| R | | | | |
| Message body (hexadecimal) | | | | |
| Request | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Annual calendar number | 0-1 |
| 1 | 2 | 2 | Calendar month | 1-12 |
| Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Annual calendar number | 0-1 |
| 1 | 2 | 2 | Calendar month | 1-12 |
| 4 | 4 | 2 | 1st month day profile | 0-15 |
| 5 | 6 | 2 | 2nd month day profile | 0-15 |
| 6 | 8 | 2 | 3rd month day profile | 0-15 |
| | | | ... | |
| 33 | 64 | 2 | 31st month day profile | 0-15 |

Table 4-57 Write Request

| Message type (ASCII) | | | | |
|----------------------------|--------|--------|------------------------|-------|
| r | | | | |
| Message body (hexadecimal) | | | | |
| Request | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Annual calendar number | 0-1 |
| 1 | 2 | 2 | Calendar month | 1-12 |
| 4 | 4 | 2 | 1st month day profile | 0-15 |
| 5 | 6 | 2 | 2nd month day profile | 0-15 |
| 6 | 8 | 2 | 3rd month day profile | 0-15 |
| | | | ... | |
| 33 | 64 | 2 | 31st month day profile | 0-15 |
| Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Annual calendar number | 0-1 |
| 1 | 2 | 2 | Calendar month | 1-12 |

These requests allow you to read/write the setup of the one-month calendar from one of the two TOU system annual calendars. The actual year should be assigned beforehand to the accessed calendar. The present calendar year can be obtained by using request U.

4.23 TOU Calendar Years

Table 4-58 Read Request

| Message type (ASCII) | | | | |
|----------------------------|--------|--------|------------------------|-------|
| U | | | | |
| Message body (hexadecimal) | | | | |
| Request | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Annual calendar number | 0-1 |
| Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Annual calendar number | 0-1 |
| 1 | 2 | 2 | Calendar year | 0-99 |

Table 4-59 Write Request

| Message type (ASCII) | | | | |
|----------------------------|--------|--------|------------------------|-------|
| u | | | | |
| Message body (hexadecimal) | | | | |
| Request/Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Annual calendar number | 0-1 |
| 1 | 2 | 2 | Calendar year | 0-99 |

This request allows you to associate a specific year with one of the two TOU system annual calendars.

4.24 Real Time Clock

Table 4-60 Read Request

| Message type (ASCII) | | | | |
|------------------------|--------|--------|-------------|----------------|
| S | | | | |
| Message body (decimal) | | | | |
| Request - no body | | | | |
| Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Second | 0-59 |
| 2 | 2 | 2 | Minute | 0-59 |
| 3 | 4 | 2 | Hour | 0-23 |
| 4 | 6 | 2 | Day | 1-31 |
| 5 | 8 | 2 | Month | 1-12 |
| 6 | 10 | 2 | Year | 0-99 |
| 7 | 12 | 2 | Day of week | 1-7 (1=Sunday) |

Table 4-61 Write Request

| Message type (ASCII) | | | | |
|------------------------|--------|--------|-------------|----------------|
| T | | | | |
| Message body (decimal) | | | | |
| Request/Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Second | 0-59 |
| 2 | 2 | 2 | Minute | 0-59 |
| 3 | 4 | 2 | Hour | 0-23 |
| 4 | 6 | 2 | Day | 1-31 |
| 5 | 8 | 2 | Month | 1-12 |
| 6 | 10 | 2 | Year | 0-99 |
| 7 | 12 | 2 | Day of week | 1-7 (1=Sunday) |

The day of week is not checked when written. It is set automatically when you change the date.

5 DIRECT READ/WRITE REQUESTS

5.1 General

This chapter describes the instrument data locations (registers) that are addressed directly using register indexes. These registers can be accessed by using universal direct read/write requests instead of specific ASCII requests, which use different formats for accessing different data locations.

Data (register) indexes are given in a 4-digit hexadecimal format. All data are transmitted in ASCII hexadecimal notation as 2-character (8-bit unsigned byte), 4-character (16-bit unsigned or signed integer) or 8-character (32-bit unsigned or signed long integer) numbers. Negative numbers are transmitted in 2-complement code. Register size in the tables below shows an actual data size in ASCII hexadecimal characters for data accessed using variable-size direct read/write requests. When long-size direct read/write request is used, an actual data size is ignored and all registers are transmitted in 8-character format as long signed or unsigned integers.

5.1.1 Long-Size Direct Read/Write

Table 5-1 Read Request

| Message type (ASCII) | | | | |
|----------------------------|--------|--------|---|------------------|
| A | | | | |
| Message body (hexadecimal) | | | | |
| Request | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 4 | Start data (register) index to read | 0000h - FFFFh |
| 2 | 4 | 2 | The number of contiguous data items to read | 1-30 (01h - 1Eh) |
| Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 2 | Number of data items in the message | 1-30 (01h - 1Eh) |
| 2 | 2 | 8 | Data #1 value | |
| 3 | 10 | 8 | Data #2 value | |
| ... | ... | ... | ... | |
| 31 | 234 | 8 | Data #30 value | |

Table 5-2 Write Request

| Message type (ASCII) | | | | |
|----------------------------|--------|--------|--------------------------------|---------------|
| a | | | | |
| Message body (hexadecimal) | | | | |
| Request/Response | | | | |
| Field | Offset | Length | Parameter | Range |
| 1 | 0 | 4 | Data (register) index to write | 0000h - FFFFh |
| 2 | 4 | 8 | Data value to write | |

In long-size direct read/write messages, all data items are read and written as long unsigned or signed integers, which are represented in messages by 8-digit hexadecimal numbers, regardless of the actual data size.

By using a long-size direct read request, up to 30 contiguous parameters can be read at once. A write request allows for writing only one data location at a time.

5.1.2 Variable-Size Direct Read/Write

Table 5-3 Read Request

| Message type (ASCII) | | | | |
|----------------------------|--------|-------|---|------------------|
| X | | | | |
| Message body (hexadecimal) | | | | |
| Request | | | | |
| Field | Offset | Size | Parameter | Range |
| 1 | 0 | 4 | Start data index (register) to read | 0000h - FFFFh |
| 2 | 4 | 2 | The number of contiguous data items to read | 1-61 (01h - 3Dh) |
| Response | | | | |
| Field | Offset | Size | Parameter | Range |
| 1 | 0 | 2 | Number of data items in the message | 1-61 (01h - 3Dh) |
| 2 | 2 | 2/4/8 | Data #1 value | |
| 3 | | 2/4/8 | Data #2 value | |
| ... | ... | ... | ... | |
| 60 | | 2/4/8 | Data #60 value | |

Table 5-4 Write Request

| Message type (ASCII) | | | | |
|----------------------------|--------|-------|--|------------------|
| X | | | | |
| Message body (hexadecimal) | | | | |
| Request | | | | |
| Field | Offset | Size | Parameter | Range |
| 1 | 0 | 4 | Start data index (register) to write | 0000h - FFFFh |
| 2 | 4 | 2 | The number of contiguous data items to write | 1-61 (01h - 3Dh) |
| 3 | 6 | 2/4/8 | Data #1 value | |
| 4 | | 2/4/8 | Data #2 value | |
| ... | ... | ... | ... | |
| 60 | | 2/4/8 | Data #60 value | |
| Request | | | | |
| Field | Offset | Size | Parameter | Range |
| 1 | 0 | 4 | Start data index (register) written | 0000h - FFFFh |
| 2 | 4 | 2 | The number of data items written | 1-61 (01h - 3Dh) |

With variable-size direct read/write messages, data items are read and written as 2, 4 or 8-character hexadecimal numbers. The actual data size is indicated for each data location. When written, the data format should be exactly the same as indicated.

The number of parameters that can be read or written by a single read/write request depends on the size of each data item. The total length of all parameters should not exceed 240 characters.

5.1.3 User Assignable Registers

The instrument contains 120 user assignable registers in the range of indexes 8000h to 8077h (see Table 5-5). You can map any of these registers to either register index, accessible in the instrument through direct read/write requests. Registers that reside in different locations may be accessed by a single request by re-mapping them to adjacent addresses in the user assignable registers area.

The actual indexes of the user assignable registers, which are accessed via indexes 8000h to 8077h, are specified in the user assignable register map. It occupies indexes 8100h to 8177h (see Table 5-6), where the map register 8100h should contain the actual index of the register accessed via assignable register 8000h, register 8101h should contain the actual index of the register accessed via assignable register 8001h, and so on. Note that the user assignable register indexes and the user register map indexes may not be re-mapped.

Table 5-5 User Assignable Registers

| Register | Register contents | Size | Direction | Range |
|----------|-------------------------|------|-----------|-------|
| 8000h | User definable data 0 | ① | ① | ① |
| 8001h | User definable data 1 | ① | ① | ① |
| 8002h | User definable data 2 | ① | ① | ① |
| ... | ... | ... | | |
| 8077h | User definable data 119 | ① | ① | ① |

① - depends on the mapped register

Table 5-6 User Assignable Register Map

| Register | Register contents | Size | Direction | Range |
|----------|---|------|-----------|-------------|
| 8100h | Data (register) index for user data 0 | 4 | R/W | 0000h-FFFFh |
| 8101h | Data (register) index for user data 1 | 4 | R/W | 0000h-FFFFh |
| 8102h | Data (register) index for user data 2 | 4 | R/W | 0000h-FFFFh |
| ... | ... | ... | | |
| 8177h | Data (register) index for user data 119 | 4 | R/W | 0000h-FFFFh |

To build your own register map, write to map registers (8100h to 8177h) the actual addresses you want to read from or write to via the assignable area (8000h to 8077h). For example, if you want to read registers 0C00h (real-time voltage of phase A) and 1700h (kWh import) via indexes 8000h-8001h, do the following:

- write 0C00h to register 8100h
- write 1700h to register 8101h

Reading from registers 8000h-8001h will return the voltage reading in register 8000h, and the kWh reading in register 8001h.

5.2 Extended Data Registers

Table 5-7 Extended Data Table

| Parameter | Data ID | Length | Direction | Unit | Range ① |
|-----------------------------------|---------|--------|-----------|-----------------|----------------|
| None | | | | | |
| None | 0000h | 4 | R | | 0 |
| Status inputs | | | | | |
| Status inputs | 0600h | 4 | R | | see Table 4-13 |
| Relays | | | | | |
| Relay status | 0800h | 4 | R | | see Table 4-12 |
| Pulse counters (E) | | | | | |
| Pulse counter #1 | 0A00h | 8 | R/W | | 0 to 999999 |
| Pulse counter #2 | 0A01h | 8 | R/W | | 0 to 999999 |
| Pulse counter #3 | 0A02h | 8 | R/W | | 0 to 999999 |
| Pulse counter #4 | 0A03h | 8 | R/W | | 0 to 999999 |
| Real-time values per phase | | | | | |
| Voltage L1/L12 ⑥ | 0C00h | 8 | R | 0.1V/1V | 0 to Vmax |
| Voltage L2/L23 ⑥ | 0C01h | 8 | R | 0.1V/1V | 0 to Vmax |
| Voltage L3/L31 ⑥ | 0C02h | 8 | R | 0.1V/1V | 0 to Vmax |
| Current L1 | 0C03h | 8 | R | 0.01A | 0 to Imax |
| Current L2 | 0C04h | 8 | R | 0.01A | 0 to Imax |
| Current L3 | 0C05h | 8 | R | 0.01A | 0 to Imax |
| kW L1 | 0C06h | 8 | R | 0.001kW/1kW | -Pmax to Pmax |
| kW L2 | 0C07h | 8 | R | 0.001kW/1kW | -Pmax to Pmax |
| kW L3 | 0C08h | 8 | R | 0.001kW/1kW | -Pmax to Pmax |
| kvar L1 | 0C09h | 8 | R | 0.001kvar/1kvar | -Pmax to Pmax |
| kvar L2 | 0C0Ah | 8 | R | 0.001kvar/1kvar | -Pmax to Pmax |
| kvar L3 | 0C0Bh | 8 | R | 0.001kvar/1kvar | -Pmax to Pmax |
| kVA L1 | 0C0Ch | 8 | R | 0.001kVA/1kVA | 0 to Pmax |
| kVA L2 | 0C0Dh | 8 | R | 0.001kVA/1kVA | 0 to Pmax |
| kVA L3 | 0C0Eh | 8 | R | 0.001kVA/1kVA | 0 to Pmax |
| Power factor L1 | 0C0Fh | 4 | R | 0.001 | -999 to 1000 |
| Power factor L2 | 0C10h | 4 | R | 0.001 | -999 to 1000 |
| Power factor L3 | 0C11h | 4 | R | 0.001 | -999 to 1000 |

| Parameter | Data ID | Length | Direction | Unit | Range ① |
|-----------------------------------|---------|--------|-----------|-----------------|---------------|
| Voltage THD L1/L12 | 0C12h | 4 | R | 0.1% | 0 to 9999 |
| Voltage THD L2/L23 | 0C13h | 4 | R | 0.1% | 0 to 9999 |
| Voltage THD L3 | 0C14h | 4 | R | 0.1% | 0 to 9999 |
| Current THD L1 | 0C15h | 4 | R | 0.1% | 0 to 9999 |
| Current THD L2 | 0C16h | 4 | R | 0.1% | 0 to 9999 |
| Current THD L3 | 0C17h | 4 | R | 0.1% | 0 to 9999 |
| K-Factor L1 | 0C18h | 4 | R | 0.1 | 10 to 9999 |
| K-Factor L2 | 0C19h | 4 | R | 0.1 | 10 to 9999 |
| K-Factor L3 | 0C1Ah | 4 | R | 0.1 | 10 to 9999 |
| Current TDD L1 | 0C1Bh | 4 | R | 0.1% | 0 to 1000 |
| Current TDD L2 | 0C1Ch | 4 | R | 0.1% | 0 to 1000 |
| Current TDD L3 | 0C1Dh | 4 | R | 0.1% | 0 to 1000 |
| Voltage L12 | 0C1Eh | 8 | R | 0.1V/1V | 0 to Vmax |
| Voltage L23 | 0C1Fh | 8 | R | 0.1V/1V | 0 to Vmax |
| Voltage L31 | 0C20h | 8 | R | 0.1V/1V | 0 to Vmax |
| Real-time total values | | | | | |
| Total kW | 0F00h | 8 | R | 0.001kW/1kW | -Pmax to Pmax |
| Total kvar | 0F01h | 8 | R | 0.001kvar/1kvar | -Pmax to Pmax |
| Total kVA | 0F02h | 8 | R | 0.001kVA/1kVA | 0 to Pmax |
| Total PF | 0F03h | 4 | R | 0.001 | -999 to 1000 |
| Reserved | 0F04h | 4 | R | | 0 |
| Reserved | 0F05h | 4 | R | | 0 |
| Real-time auxiliary values | | | | | |
| Reserved | 1000h | 8 | R | | 0 |
| Neutral current | 1001h | 8 | R | 0.01A | 0 to Imax |
| Frequency ④ | 1002h | 4 | R | 0.01Hz | 0 to 10000 |
| Voltage unbalance | 1003h | 4 | R | 1% | 0 to 300 |
| Current unbalance | 1004h | 4 | R | 1% | 0 to 300 |
| Average values per phase | | | | | |
| Voltage L1/L12 ⑥ | 1100h | 8 | R | 0.1V/1V | 0 to Vmax |
| Voltage L2/L23 ⑥ | 1101h | 8 | R | 0.1V/1V | 0 to Vmax |
| Voltage L3/L31 ⑥ | 1102h | 8 | R | 0.1V/1V | 0 to Vmax |
| Current L1 | 1103h | 8 | R | 0.01A | 0 to Imax |
| Current L2 | 1104h | 8 | R | 0.01A | 0 to Imax |
| Current L3 | 1105h | 8 | R | 0.01A | 0 to Imax |
| kW L1 | 1106h | 8 | R | 0.001kW/1kW | -Pmax to Pmax |
| kW L2 | 1107h | 8 | R | 0.001kW/1kW | -Pmax to Pmax |
| kW L3 | 1108h | 8 | R | 0.001kW/1kW | -Pmax to Pmax |
| kvar L1 | 1109h | 8 | R | 0.001kvar/1kvar | -Pmax to Pmax |
| kvar L2 | 110Ah | 8 | R | 0.001kvar/1kvar | -Pmax to Pmax |
| kvar L3 | 110Bh | 8 | R | 0.001kvar/1kvar | -Pmax to Pmax |
| kVA L1 | 110Ch | 8 | R | 0.001kVA/1kVA | 0 to Pmax |
| kVA L2 | 110Dh | 8 | R | 0.001kVA/1kVA | 0 to Pmax |
| kVA L3 | 110Eh | 8 | R | 0.001kVA/1kVA | 0 to Pmax |
| Power factor L1 | 110Fh | 4 | R | 0.001 | -999 to 1000 |
| Power factor L2 | 1110h | 4 | R | 0.001 | -999 to 1000 |
| Power factor L3 | 1111h | 4 | R | 0.001 | -999 to 1000 |
| Voltage THD L1/L12 | 1112h | 4 | R | 0.1% | 0 to 9999 |
| Voltage THD L2/L23 | 1113h | 4 | R | 0.1% | 0 to 9999 |
| Voltage THD L3 | 1114h | 4 | R | 0.1% | 0 to 9999 |
| Current THD L1 | 1115h | 4 | R | 0.1% | 0 to 9999 |
| Current THD L2 | 1116h | 4 | R | 0.1% | 0 to 9999 |
| Current THD L3 | 1117h | 4 | R | 0.1% | 0 to 9999 |
| K-Factor L1 | 1118h | 4 | R | 0.1 | 10 to 9999 |
| K-Factor L2 | 1119h | 4 | R | 0.1 | 10 to 9999 |
| K-Factor L3 | 111Ah | 4 | R | 0.1 | 10 to 9999 |
| Current TDD L1 | 111Bh | 4 | R | 0.1% | 0 to 1000 |
| Current TDD L2 | 111Ch | 4 | R | 0.1% | 0 to 1000 |
| Current TDD L3 | 111Dh | 4 | R | 0.1% | 0 to 1000 |
| Voltage L12 | 110Eh | 8 | R | 0.1V/1V | 0 to Vmax |
| Voltage L23 | 110Fh | 8 | R | 0.1V/1V | 0 to Vmax |
| Voltage L31 | 1120h | 8 | R | 0.1V/1V | 0 to Vmax |

| Parameter | Data ID | Length | Direction | Unit | Range ① |
|--|---------|--------|-----------|-----------------|-------------------------|
| Average total values | | | | | |
| Total kW | 1400h | 8 | R | 0.001kW/1kW | -Pmax to Pmax |
| Total kvar | 1401h | 8 | R | 0.001kvar/1kvar | -Pmax to Pmax |
| Total kVA | 1402h | 8 | R | 0.001kVA/1kVA | 0 to Pmax |
| Total PF | 1403h | 4 | R | 0.001 | -999 to 1000 |
| Reserved | 1404h | 4 | R | | 0 |
| Reserved | 1405h | 4 | R | | 0 |
| Average auxiliary values | | | | | |
| Reserved | 1500h | 8 | R | | 0 |
| Neutral current | 1501h | 8 | R | 0.01A | 0 to Imax |
| Frequency ④ | 1502h | 4 | R | 0.01Hz | 0 to 10000 |
| Voltage unbalance | 1503h | 4 | R | 1% | 0 to 300 |
| Current unbalance | 1504h | 4 | R | 1% | 0 to 300 |
| Present demands | | | | | |
| Volt demand L1/L12 ⑥ | 1600h | 8 | R | 0.1V/1V | 0 to Vmax |
| Volt demand L2/L23 ⑥ | 1601h | 8 | R | 0.1V/1V | 0 to Vmax |
| Volt demand L3/L31 ⑥ | 1602h | 8 | R | 0.1V/1V | 0 to Vmax |
| Ampere demand L1 | 1603h | 8 | R | 0.01A | 0 to Imax |
| Ampere demand L2 | 1604h | 8 | R | 0.01A | 0 to Imax |
| Ampere demand L3 | 1605h | 8 | R | 0.01A | 0 to Imax |
| Block kW import demand (E) | 1606h | 8 | R | 0.001kW/1kW | 0 to Pmax |
| Block kvar import demand (E) | 1607h | 8 | R | 0.001kvar/1kvar | 0 to Pmax |
| Block kVA demand (E) | 1608h | 8 | R | 0.001kVA/1kVA | 0 to Pmax |
| Sliding window kW import demand (E) | 1609h | 8 | R | 0.001kW/1kW | 0 to Pmax |
| Sliding window kvar import demand (E) | 160Ah | 8 | R | 0.001kvar/1kvar | 0 to Pmax |
| Sliding window kVA demand (E) | 160Bh | 8 | R | 0.001kVA/1kVA | 0 to Pmax |
| Reserved | 160Ch | 8 | R | | 0 |
| Reserved | 160Dh | 8 | R | | 0 |
| Reserved | 160Eh | 8 | R | | 0 |
| Accumulated kW import demand (E) | 160Fh | 8 | R | 0.001kW/1kW | 0 to Pmax |
| Accumulated kvar import demand (E) | 1610h | 8 | R | 0.001kvar/1kvar | 0 to Pmax |
| Accumulated kVA demand (E) | 1611h | 8 | R | 0.001kVA/1kVA | 0 to Pmax |
| Predicted sliding window kW import demand (E) | 1612h | 8 | R | 0.001kW/1kW | 0 to Pmax |
| Predicted sliding window kvar import demand (E) | 1613h | 8 | R | 0.001kvar/1kvar | 0 to Pmax |
| Predicted sliding window kVA demand (E) | 1614h | 8 | R | 0.001kVA/1kVA | 0 to Pmax |
| PF (import) at maximum sliding window kVA demand (E) | 1615h | 4 | R | 0.001 | 0 to 1000 |
| Block kW export demand (E) | 1616h | 8 | R | 0.001kW/1kW | 0 to Pmax |
| Block kvar export demand (E) | 1617h | 8 | R | 0.001kvar/1kvar | 0 to Pmax |
| Sliding window kW export demand (E) | 1618h | 8 | R | 0.001kW/1kW | 0 to Pmax |
| Sliding window kvar export demand (E) | 1619h | 8 | R | 0.001kvar/1kvar | 0 to Pmax |
| Accumulated kW export demand (E) | 161Ah | 8 | R | 0.001kW/1kW | 0 to Pmax |
| Accumulated kvar export demand (E) | 161Bh | 8 | R | 0.001kvar/1kvar | 0 to Pmax |
| Predicted sliding window kW export demand (E) | 161Ch | 8 | R | 0.001kW/1kW | 0 to Pmax |
| Predicted sliding window kvar export demand (E) | 161Dh | 8 | R | 0.001kvar/1kvar | 0 to Pmax |
| Total energies (E) | | | | | |
| kWh import | 1700h | 8 | R | kWh | 0 to 10 ⁹ -1 |
| kWh export | 1701h | 8 | R | kWh | 0 to 10 ⁹ -1 |
| Reserved | 1702h | 8 | R | | 0 |
| Reserved | 1703h | 8 | R | | 0 |

| Parameter | Data ID | Length | Direction | Unit | Range ① |
|---|-----------------|--------|-----------|-----------------|-------------------------|
| kvarh import | 1704h | 8 | R | kvarh | 0 to 10 ⁹ -1 |
| kvarh export | 1705h | 8 | R | kvarh | 0 to 10 ⁹ -1 |
| Reserved | 1706h | 8 | R | | 0 |
| Reserved | 1707h | 8 | R | | 0 |
| kVAh total | 1708h | 8 | R | kVAh | 0 to 10 ⁹ -1 |
| Phase energies (E) | | | | | |
| kWh import L1 | 1800h | 8 | R | kWh | 0 to 10 ⁹ -1 |
| kWh import L2 | 1801h | 8 | R | kWh | 0 to 10 ⁹ -1 |
| kWh import L3 | 1802h | 8 | R | kWh | 0 to 10 ⁹ -1 |
| kvarh import (inductive) L1 | 1803h | 8 | R | kvarh | 0 to 10 ⁹ -1 |
| kvarh import (inductive) L2 | 1804h | 8 | R | kvarh | 0 to 10 ⁹ -1 |
| kvarh import (inductive) L3 | 1805h | 8 | R | kvarh | 0 to 10 ⁹ -1 |
| kVAh L1 | 1806h | 8 | R | kVAh | 0 to 10 ⁹ -1 |
| kVAh L2 | 1807h | 8 | R | kVAh | 0 to 10 ⁹ -1 |
| kVAh L3 | 1808h | 8 | R | kVAh | 0 to 10 ⁹ -1 |
| Fundamental's (H01) real-time values per phase | | | | | |
| Voltage L1/L12 | 2900h | 8 | R | 0.1V/1V | 0 to Vmax |
| Voltage L2/L23 | 2901h | 8 | R | 0.1V/1V | 0 to Vmax |
| Voltage L3/L31 | 2902h | 8 | R | 0.1V/1V | 0 to Vmax |
| Current L1 | 2903h | 8 | R | 0.01A | 0 to Imax |
| Current L2 | 2904h | 8 | R | 0.01A | 0 to Imax |
| Current L3 | 2905h | 8 | R | 0.01A | 0 to Imax |
| kW L1 | 2906h | 8 | R | 0.001kW/1kW | -Pmax to Pmax |
| kW L2 | 2907h | 8 | R | 0.001kW/1kW | -Pmax to Pmax |
| kW L3 | 2908h | 8 | R | 0.001kW/1kW | -Pmax to Pmax |
| kvar L1 | 2909h | 8 | R | 0.001kvar/1kvar | -Pmax to Pmax |
| kvar L2 | 290Ah | 8 | R | 0.001kvar/1kvar | -Pmax to Pmax |
| kvar L3 | 290Bh | 8 | R | 0.001kvar/1kvar | -Pmax to Pmax |
| kVA L1 | 290Ch | 8 | R | 0.001kVA/1kVA | 0 to Pmax |
| kVA L2 | 290Dh | 8 | R | 0.001kVA/1kVA | 0 to Pmax |
| kVA L3 | 290Eh | 8 | R | 0.001kVA/1kVA | 0 to Pmax |
| Power factor L1 | 290Fh | 4 | R | 0.001 | -999 to 1000 |
| Power factor L2 | 2910h | 4 | R | 0.001 | -999 to 1000 |
| Power factor L3 | 2911h | 4 | R | 0.001 | -999 to 1000 |
| Fundamental's (H01) real-time total values | | | | | |
| Total kW | 2a00h | 8 | R | 0.001kW/1kW | -Pmax to Pmax |
| Total kvar | 2a01h | 8 | R | 0.001kvar/1kvar | -Pmax to Pmax |
| Total kVA | 2a02h | 8 | R | 0.001kVA/1kVA | 0 to Pmax |
| Total PF | 2a03h | 4 | R | 0.001 | -999 to 1000 |
| Minimum real-time values per phase (M) | | | | | |
| Voltage L1/L12 ⑥ | 2C00h | 8 | R | 0.1V/1V | 0 to Vmax |
| Voltage L2/L23 ⑥ | 2C01h | 8 | R | 0.1V/1V | 0 to Vmax |
| Voltage L3/L31 ⑥ | 2C02h | 8 | R | 0.1V/1V | 0 to Vmax |
| Current L1 | 2C03h | 8 | R | 0.01A | 0 to Imax |
| Current L2 | 2C04h | 8 | R | 0.01A | 0 to Imax |
| Current L3 | 2C05h | 8 | R | 0.01A | 0 to Imax |
| Minimum real-time total values (M) | | | | | |
| Total kW | 2D00h | 8 | R | 0.001kW/1kW | -Pmax to Pmax |
| Total kvar | 2D01h | 8 | R | 0.001kvar/1kvar | -Pmax to Pmax |
| Total kVA | 2D02h | 8 | R | 0.001kVA/1kVA | 0 to Pmax |
| Total PF ③ | 2D03h | 4 | R | 0.001 | 0 to 1000 |
| Minimum real-time auxiliary values (M) | | | | | |
| Reserved | 2E00h | 8 | R | | 0 |
| Neutral current | 2E01h | 8 | R | 0.01A | 0 to Imax |
| Frequency ④ | 2E02h | 4 | R | 0.01Hz | 0 to 10000 |
| Minimum demands (M) - Reserved | | | | | |
| Reserved | 2F00h- 2F10h | 8 | R | | 0 |
| Maximum real-time values per phase (M) | | | | | |
| Voltage L1/L12 ⑥ | 3400h | 8 | R | 0.1V/1V | 0 to Vmax |

| Parameter | Data ID | Length | Direction | Unit | Range ① |
|---|---------|--------|-----------|-----------------|------------------------|
| Voltage L2/L23 ⑥ | 3401h | 8 | R | 0.1V/1V | 0 to Vmax |
| Voltage L3/L31 ⑥ | 3402h | 8 | R | 0.1V/1V | 0 to Vmax |
| Current L1 | 3403h | 8 | R | 0.01A | 0 to Imax |
| Current L2 | 3404h | 8 | R | 0.01A | 0 to Imax |
| Current L3 | 3405h | 8 | R | 0.01A | 0 to Imax |
| Maximum real-time total values (M) | | | | | |
| Total kW | 3500h | 8 | R | 0.001kW/1kW | -Pmax to Pmax |
| Total kvar | 3501h | 8 | R | 0.001kvar/1kvar | -Pmax to Pmax |
| Total kVA | 3502h | 8 | R | 0.001kVA/1kVA | 0 to Pmax |
| Total PF ③ | 3503h | 4 | R | 0.001 | 0 to 1000 |
| Maximum real-time auxiliary values (M) | | | | | |
| Reserved | 3600h | 8 | R | | 0 |
| Neutral current | 3601h | 8 | R | 0.01A | 0 to Imax |
| Frequency ④ | 3602h | 4 | R | 0.01Hz | 0 to 10000 |
| Maximum demands (M) | | | | | |
| Max. volt demand L1/L12 ⑥ | 3700h | 8 | R | 0.1V/1V | 0 to Vmax |
| Max. volt demand L2/L23 ⑥ | 3701h | 8 | R | 0.1V/1V | 0 to Vmax |
| Max. volt demand L3/L31 ⑥ | 3702h | 8 | R | 0.1V/1V | 0 to Vmax |
| Max. ampere demand L1 | 3703h | 8 | R | 0.01A | 0 to Imax |
| Max. ampere demand L2 | 3704h | 8 | R | 0.01A | 0 to Imax |
| Max. ampere demand L3 | 3705h | 8 | R | 0.01A | 0 to Imax |
| Reserved | 3706h | 8 | R | | 0 |
| Reserved | 3707h | 8 | R | | 0 |
| Reserved | 3708h | 8 | R | | 0 |
| Max. sliding window kW import demand (E) | 3709h | 8 | R | 0.001kW/1kW | 0 to Pmax |
| Max. sliding window kvar import demand (E) | 370Ah | 8 | R | 0.001kvar/1kvar | 0 to Pmax |
| Max. sliding window kVA demand (E) | 370Bh | 8 | R | 0.001kVA/1kVA | 0 to Pmax |
| Reserved | 370Ch | 8 | R | | 0 |
| Reserved | 370Dh | 8 | R | | 0 |
| Reserved | 370Eh | 8 | R | | 0 |
| Max. sliding window kW export demand (E) | 370Fh | 8 | R | 0.001kW/1kW | 0 to Pmax |
| Max. sliding window kvar export demand (E) | 3710h | 8 | R | 0.001kvar/1kvar | 0 to Pmax |
| TOU system parameters (E) | | | | | |
| Active tariff | 3C00h | 2 | R | | 0 to 15 |
| Active profile | 3C01h | 2 | R | | 0 to 15 |
| TOU energy register #1 (E) | | | | | |
| Tariff #1 register | 3D00h | 8 | R | ⑤ | 0 to 10 ⁹⁻¹ |
| Tariff #2 register | 3D01h | 8 | R | ⑤ | 0 to 10 ⁹⁻¹ |
| ... | ... | | | | |
| Tariff #16 register | 3D0Fh | 8 | R | ⑤ | 0 to 10 ⁹⁻¹ |
| TOU energy register #2 (E) | | | | | |
| Tariff #1 register | 3E00h | 8 | R | ⑤ | 0 to 10 ⁹⁻¹ |
| Tariff #2 register | 3E01h | 8 | R | ⑤ | 0 to 10 ⁹⁻¹ |
| ... | ... | | | | |
| Tariff #16 register | 3E0Fh | 8 | R | ⑤ | 0 to 10 ⁹⁻¹ |
| TOU energy register #3 (E) | | | | | |
| Tariff #1 register | 3F00h | 8 | R | ⑤ | 0 to 10 ⁹⁻¹ |
| Tariff #2 register | 3F01h | 8 | R | ⑤ | 0 to 10 ⁹⁻¹ |
| ... | ... | | | | |
| Tariff #16 register | 3F0Fh | 8 | R | ⑤ | 0 to 10 ⁹⁻¹ |
| TOU energy register #4 (E) | | | | | |
| Tariff #1 register | 4000h | 8 | R | ⑤ | 0 to 10 ⁹⁻¹ |
| Tariff #2 register | 4001h | 8 | R | ⑤ | 0 to 10 ⁹⁻¹ |
| ... | ... | | | | |
| Tariff #16 register | 400Fh | 8 | R | ⑤ | 0 to 10 ⁹⁻¹ |

| Parameter | Data ID | Length | Direction | Unit | Range ① |
|--|-------------|--------|-----------|------|-------------------------|
| TOU energy register #5 (E) | | | | | |
| Tariff #1 register | 4100h | 8 | R | ⑤ | 0 to 10 ⁹ -1 |
| Tariff #2 register | 4101h | 8 | R | ⑤ | 0 to 10 ⁹ -1 |
| ... | ... | | | | |
| Tariff #16 register | 410Fh | 8 | R | ⑤ | 0 to 10 ⁹ -1 |
| TOU energy register #6 (E) | | | | | |
| Tariff #1 register | 4200h | 8 | R | ⑤ | 0 to 10 ⁹ -1 |
| Tariff #2 register | 4201h | 8 | R | ⑤ | 0 to 10 ⁹ -1 |
| ... | ... | | | | |
| Tariff #16 register | 420Fh | 8 | R | ⑤ | 0 to 10 ⁹ -1 |
| TOU energy register #7 (E) | | | | | |
| Tariff #1 register | 4300h | 8 | R | ⑤ | 0 to 10 ⁹ -1 |
| Tariff #2 register | 4301h | 8 | R | ⑤ | 0 to 10 ⁹ -1 |
| ... | ... | | | | |
| Tariff #16 register | 430Fh | 8 | R | ⑤ | 0 to 10 ⁹ -1 |
| TOU energy register #8 (E) | | | | | |
| Tariff #1 register | 4400h | 8 | R | ⑤ | 0 to 10 ⁹ -1 |
| Tariff #2 register | 4401h | 8 | R | ⑤ | 0 to 10 ⁹ -1 |
| ... | ... | | | | |
| Tariff #16 register | 440Fh | 8 | R | ⑤ | 0 to 10 ⁹ -1 |
| TOU minimum demand register #1 (M) - Reserved | | | | | |
| Reserved | 4500h-450Fh | 8 | R | | 0 |
| TOU minimum demand register #2 (M) - Reserved | | | | | |
| Reserved | 4600h-460Fh | 8 | R | | 0 |
| TOU minimum demand register #3 (M) - Reserved | | | | | |
| Reserved | 4700h-470Fh | 8 | R | | 0 |
| TOU maximum demand register #1 (M) (E) | | | | | |
| Tariff #1 register | 4800h | 8 | R | ⑤ | 0 to Pmax |
| Tariff #2 register | 4801h | 8 | R | ⑤ | 0 to Pmax |
| ... | ... | | | | |
| Tariff #16 register | 480Fh | 8 | R | ⑤ | 0 to Pmax |
| TOU maximum demand register #2 (M) (E) | | | | | |
| Tariff #1 register | 4900h | 8 | R | ⑤ | 0 to Pmax |
| Tariff #2 register | 4901h | 8 | R | ⑤ | 0 to Pmax |
| ... | ... | | | | |
| Tariff #16 register | 490Fh | 8 | R | ⑤ | 0 to Pmax |
| TOU maximum demand register #3 (M) (E) | | | | | |
| Tariff #1 register | 4A00h | 8 | R | ⑤ | 0 to Pmax |
| Tariff #2 register | 4A01h | 8 | R | ⑤ | 0 to Pmax |
| ... | ... | | | | |
| Tariff #16 register | 4A0Fh | 8 | R | ⑤ | 0 to Pmax |
| TOU season tariff energy registers (E) - only as a reference for TOU profile logs | | | | | |
| Season tariff #1 register | 7000h | 8 | | ⑤ | 0 to 10 ⁹ -1 |
| Season tariff #2 register | 7001h | 8 | | ⑤ | 0 to 10 ⁹ -1 |
| ... | ... | | | | |
| Season tariff #16 register | 700Fh | 8 | | ⑤ | 0 to 10 ⁹ -1 |
| TOU season tariff maximum demand registers (E) - only as a reference for TOU profile logs | | | | | |
| Season tariff #1 register | 7100h | 8 | | ⑤ | 0 to Pmax |
| Season tariff #2 register | 7101h | 8 | | ⑤ | 0 to Pmax |
| ... | ... | | | | |
| Season tariff #16 register | 710Fh | 8 | | ⑤ | 0 to Pmax |

① For parameter limits, see Note ① to Table 4-1

② When using direct wiring (PT Ratio = 1), voltages are transmitted in 0.1 V units, currents in 0.01 A units, and powers in 0.001 kW/kvar/kVA units. For wiring via PTs (PT Ratio > 1), voltages are transmitted in 1V units, currents in 0.01 A units, and powers in 1 kW/kvar/kVA units.

③ New absolute min/max value (lag or lead).

④ The actual frequency range is 45.00 - 65.00 Hz.

⑤ The TOU energy and TOU maximum demand register unit matches the measurement unit of the input parameter for which the register is allocated.

⑥ When the 4LN3 or 3LN3 wiring mode is selected, the voltages will be line-to-neutral; for any other wiring mode, they will be line-to-line voltages.

(M) These parameters are logged to the Min/Max log.

(E) available in the PM172E.

5.3 Basic Setup Registers

Table 5-8 Basic Setup Registers

| Parameter | Register | Size | Direction | Range |
|----------------------------------|----------|------|-----------|---|
| Wiring mode ① | 8600h | 4 | R/W | 0 = 3OP2, 1 = 4LN3, 2 = 3DIR2, 3 = 4LL3, 4 = 3OP3, 5 = 3LN3, 6 = 3LL3 |
| PT ratio | 8601h | 4 | R/W | 10 to 65000 × 0.1 |
| CT primary current | 8602h | 4 | R/W | 1 to 5000 A |
| Power demand period (E) | 8603h | 4 | R/W | 1,2,5,10,15,20,30,60 min, 255 = external synchronization |
| Volt/ampere demand period | 8604h | 4 | R/W | 1 to 1800 sec |
| Averaging buffer size | 8605h | 4 | R/W | 8, 16, 32 |
| Reset enable/disable | 8606h | 4 | R/W | 0 = disable, 1 = enable |
| Reserved | 8607h | 4 | R | Read as 65535 |
| The number of demand periods (E) | 8608h | 4 | R/W | 1 to 15 |
| Reserved | 8609h | 4 | R | Read as 65535 |
| Reserved | 860Ah | 4 | R | Read as 65535 |
| Nominal frequency | 860Bh | 4 | R/W | 50, 60 Hz |
| Maximum demand load current | 860Ch | 4 | R/W | 0 to 10000 A (0 = CT primary current) |

① For the wiring mode options, see Note to Table 4-4

(E) available in the PM172E

5.4 User Selectable Options Setup

Table 5-9 User Selectable Options Registers

| Parameter | Register | Size | Direction | Range |
|-----------------------------------|----------|------|-----------|--|
| Power calculation mode | 8700h | 4 | R/W | 0 = using reactive power 1 = using non-active power |
| Energy roll value (E) ① | 8701h | 4 | R/W | 0 = 1×10 ⁴ kWh 1 = 1×10 ⁵ kWh 2 = 1×10 ⁶ kWh 3 = 1×10 ⁷ kWh 4 = 1×10 ⁸ kWh 5 = 1×10 ⁹ kWh |
| Phase energy calculation mode (E) | 8702h | 4 | R/W | 0 = disable, 1 = enable |
| Analog output option | 8703h | 4 | R/W | 0 = none 1 = 0-20 mA 2 = 4-20 mA 3 = 0-1 mA 4 = ±1 mA |
| Analog expander output ② | 8704h | 4 | R/W | 0 = none 1 = 0-20 mA 2 = 4-20 mA 3 = 0-1 mA 4 = ±1 mA |

(E) available in the PM172E (read as 65535 in the PM172P)

① For short energy readings (see Table 4-1), the maximum roll value will be 1×10^8 for positive readings and 1×10^7 for negative readings.

② Do not enable the analog expander output if the analog expander is not connected to the instrument, otherwise the computer communications will become garbled.

5.5 Communications Setup

Table 5-10 Communications Setup Registers

| Comm. Port | Parameter | Register | Size | Direction | Range |
|----------------------------|-------------------------------------|-------------|------|-----------|---|
| Port #1 | Reserved Interface | 8500h | 4 | R | Read as 65535 0 = RS-232 1 = RS-422 2 = RS-485 0 to 99 0 = 110 bps 1 = 300 bps 2 = 600 bps 3 = 1200 bps 4 = 2400 bps 5 = 4800 bps 6 = 9600 bps 7 = 19200 bps 0 = 7 bits/even parity 1 = 8 bits/no parity 2 = 8 bits/even parity 0 = no handshaking 1 = software handshaking (XON/XOFF protocol) 2 = hardware handshaking (CTS protocol) 0 = RTS signal not used 1 = RTS permanently asserted (DTR mode) 2 = RTS asserted during the transmission Read as 65535 0 = disabled, 1 = enabled (see Note ② to Table 4-1) |
| | | 8501h | 4 | R/W | |
| | Address Baud rate | 8502h | 4 | R/W | |
| | | 8503h | 4 | R/W | |
| | Data format | 8504h | 4 | R/W | |
| | Incoming flow control (handshaking) | 8505h | 4 | R/W | |
| | Outgoing flow control (RTS/DTR) | 8506h | 4 | R/W | |
| | Reserved ASCII compatibility mode ① | 8507h | 4 | R | |
| 8508h | | 4 | R/W | | |
| Port #2 | Reserved Interface | 8510h | 4 | R | |
| | | 8511h | 4 | R/W | |
| | Address Baud rate | 8512h | 4 | R/W | |
| | | 8513h | 4 | R/W | |
| | Data format | 8514h | 4 | R/W | |
| | Reserved | 8515h-8517h | 4 | R | |
| ASCII compatibility mode ① | 8518h | 4 | R/W | | |

① Changing ASCII compatibility mode for either port will cause the same setting to be applied for both ports.

When changing the instrument address, baud rate or data format, the new communications parameters will take effect 100 ms after the instrument responds to the master's request.

5.6 Alarm/Event Setpoints

Table 5-11 Setpoint Setup Locations

| Setpoint number | Registers |
|-----------------|-------------|
| Setpoint #1 | 8A00h-8A19h |
| Setpoint #2 | 8A1Ah-8A33h |
| Setpoint #3 | 8A34h-8A4Dh |
| Setpoint #4 | 8A4Eh-8A67h |
| Setpoint #5 | 8A68h-8A81h |
| Setpoint #6 | 8A82h-8A96h |
| Setpoint #7 | 8A9Ch-8AB5h |
| Setpoint #8 | 8AB6h-8ACFh |
| Setpoint #9 | 8AD0h-8AE9h |
| Setpoint #10 | 8AEAh-8B03h |
| Setpoint #11 | 8B04h-8B1Dh |
| Setpoint #12 | 8B1Eh-8B37h |
| Setpoint #13 | 8B38h-8B51h |
| Setpoint #14 | 8B52h-8B6Bh |
| Setpoint #15 | 8B6Ch-8B85h |
| Setpoint #16 | 8B86h-8B9Fh |

Table 5-12 Setpoint Setup Registers

| Parameter | Offset | Size | Direction | Range |
|-----------------------|--------|------|-----------|-------------------|
| Logical operator 1 | +0 | 4 | R/W | 0 = OR |
| Trigger ID 1 | +1 | 4 | R/W | see Table 5-13 |
| Relational operator 1 | +2 | 4 | R/W | 0 (N/A) |
| Operate limit 1 | +3 | 8 | R/W | see Table 5-13 |
| Release limit 1 | +4 | 8 | R/W | see Table 5-13 |
| Logical operator 2 | +5 | 4 | R/W | 0 = OR, 1 = AND |
| Trigger ID 2 | +6 | 4 | R/W | see Table 5-13 |
| Relational operator 2 | +7 | 4 | R/W | 0 (N/A) |
| Operate limit 2 | +8 | 8 | R/W | see Table 5-13 |
| Release limit 2 | +9 | 8 | R/W | see Table 5-13 |
| Logical operator 3 | +10 | 4 | R/W | 0 = OR, 1 = AND |
| Trigger ID 3 | +11 | 4 | R/W | see Table 5-13 |
| Relational operator 3 | +12 | 4 | R/W | 0 (N/A) |
| Operate limit 3 | +13 | 8 | R/W | see Table 5-13 |
| Release limit 3 | +14 | 8 | R/W | see Table 5-13 |
| Logical operator 4 | +15 | 4 | R/W | 0 = OR, 1 = AND |
| Trigger ID 4 | +16 | 4 | R/W | see Table 5-13 |
| Relational operator 4 | +17 | 4 | R/W | 0 (N/A) |
| Operate limit 4 | +18 | 8 | R/W | see Table 5-13 |
| Release limit 4 | +19 | 8 | R/W | see Table 5-13 |
| Action 1 | +20 | 4 | R/W | see Table 5-14 |
| Action 2 | +21 | 4 | R/W | see Table 5-14 |
| Action 3 | +22 | 4 | R/W | see Table 5-14 |
| Action 4 | +23 | 4 | R/W | see Table 5-14 |
| Operate delay | +24 | 4 | R/W | 0-9999 (x0.1 sec) |
| Release delay | +25 | 4 | R/W | 0-9999 (x0.1 sec) |
| Reserved | +26 | 4 | R | 0 |
| Reserved | +27 | 4 | R | 0 |

NOTES

1. The setpoint is disabled when the first trigger parameter ID is set to NONE. To disable the setpoint, write zero into this register.

2. When writing the setpoint registers (except the event when the setpoint is to be disabled), it is recommended to write all the setpoint registers using a single request, or to disable the setpoint before writing into separate registers. Each written value is checked for compatibility with the other setpoint parameters; if the new value does not conform to these, the request will be rejected.
3. Operate and release limits for the trigger parameters and their ranges are indicated in Table 5-13. Limits indicated as N/A are read as zeros. When writing, they can be omitted or should be written as zeros.
4. When a setpoint action is directed to a relay allocated to output energy pulses, an attempt to re-allocate it for a setpoint will result in a negative response.

Table 5-13 Setpoint Triggers

| Trigger parameter | Trigger ID | Unit ② | Range ① |
|--|------------|--------|-----------------------|
| None | 0000h | | N/A |
| Internal events (E) | | | |
| kWh import pulse | 0400h | | N/A |
| kWh export pulse | 0401h | | N/A |
| kvarh import pulse | 0403h | | N/A |
| kvarh export pulse | 0404h | | N/A |
| kvarh total pulse | 0405h | | N/A |
| kVAh total pulse | 0406h | | N/A |
| Start new demand interval | 0407h | | N/A |
| Start new tariff interval | 0408h | | N/A |
| Start new volt/ampere demand interval | 0409h | | N/A |
| Start new sliding window demand interval | 040Ah | | N/A |
| Timers (E) | | | |
| Timer #1 | 0500h | | N/A |
| Timer #2 | 0501h | | N/A |
| Status inputs | | | |
| Status input #1 ON | 0600h | | N/A |
| Status input #2 ON | 0601h | | N/A |
| Status input #1 OFF | 8600h | | N/A |
| Status input #2 OFF | 8601h | | N/A |
| Pulse inputs | | | |
| Pulse input #1 | 0700h | | N/A |
| Pulse input #2 | 0701h | | N/A |
| Phase reversal | | | |
| Positive phase rotation reversal ③ | 8901h | | N/A |
| Negative phase rotation reversal ③ | 8902h | | N/A |
| Pulse counters | | | |
| High pulse counter #1 | 0A00h | | 0 to 999999 |
| High pulse counter #2 | 0A01h | | 0 to 999999 |
| High pulse counter #3 | 0A02h | | 0 to 999999 |
| High pulse counter #4 | 0A03h | | 0 to 999999 |
| Time/Date parameters (E) | | | |
| Day of week | 0B02h | | 1-7 (1= Sun, 7=Sat) |
| Year | 0B03h | | 0 to 99 |
| Month | 0B04h | | 1 to 12 |
| Day of month | 0B05h | | 1 to 31 |
| Hour | 0B06h | | 0 to 23 |
| Minutes | 0B07h | | 0 to 59 |
| Seconds | 0B08h | | 0 to 59 |
| High/low real-time values per phase | | | |
| High current L1 | 0C03h | 0.01A | 0 to I _{max} |
| High current L2 | 0C04h | 0.01A | 0 to I _{max} |
| High current L3 | 0C05h | 0.01A | 0 to I _{max} |
| Low current L1 | 8C03h | 0.01A | 0 to I _{max} |
| Low current L2 | 8C04h | 0.01A | 0 to I _{max} |
| Low current L3 | 8C05h | 0.01A | 0 to I _{max} |

| Trigger parameter | Trigger ID | Unit ② | Range ① |
|---|------------|-----------------|------------|
| High/low real-time values on any phase | | | |
| High voltage ⑤ | 0E00h | 0.1V/1V | 0 to Vmax |
| Low voltage ⑤ | 8D00h | 0.1V/1V | 0 to Vmax |
| High current | 0E01h | 0.01A | 0 to Imax |
| Low current | 8D01h | 0.01A | 0 to Imax |
| High voltage THD | 0E07h | 0.1% | 0 to 9999 |
| High current THD | 0E08h | 0.1% | 0 to 9999 |
| High K-Factor | 0E09h | 0.1 | 10 to 9999 |
| High current TDD | 0E0Ah | 0.1% | 0 to 1000 |
| High/low real-time auxiliary values | | | |
| High frequency ④ | 1002h | 0.01Hz | 0 to 10000 |
| Low frequency ④ | 9002h | 0.01Hz | 0 to 10000 |
| High/low average values per phase | | | |
| High current L1 | 1103h | 0.01A | 0 to Imax |
| High current L2 | 1104h | 0.01A | 0 to Imax |
| High current L3 | 1105h | 0.01A | 0 to Imax |
| Low current L1 | 9103h | 0.01A | 0 to Imax |
| Low current L2 | 9104h | 0.01A | 0 to Imax |
| Low current L3 | 9105h | 0.01A | 0 to Imax |
| High/low average values on any phase | | | |
| High voltage ⑤ | 1300h | 0.1V/1V | 0 to Vmax |
| Low voltage ⑤ | 9200h | 0.1V/1V | 0 to Vmax |
| High current | 0301h | 0.01A | 0 to Imax |
| Low current | 8201h | 0.01A | 0 to Imax |
| High/low average total values | | | |
| High total kW import | 1406h | 0.001kW/1kW | 0 to Pmax |
| High total kW export | 1407h | 0.001kW/1kW | 0 to Pmax |
| High total kvar import | 1408h | 0.001kvar/1kvar | 0 to Pmax |
| High total kvar export | 1409h | 0.001kvar/1kvar | 0 to Pmax |
| High total kVA | 1402h | 0.001kVA/1kVA | 0 to Pmax |
| Low total PF lag | 9404h | 0.001 | 0 to 1000 |
| Low total PF lead | 9405h | 0.001 | 0 to 1000 |
| High/low average auxiliary values | | | |
| High neutral current | 1501h | 0.01A | 0 to Imax |
| High frequency ④ | 1502h | 0.01Hz | 0 to 10000 |
| Low frequency ④ | 9502h | 0.01Hz | 0 to 10000 |
| High present demands | | | |
| High volt demand L1/L12 ⑤ | 1600h | 0.1V/1V | 0 to Vmax |
| High volt demand L2/L23 ⑤ | 1601h | 0.1V/1V | 0 to Vmax |
| High volt demand L3/L31 ⑤ | 1602h | 0.1V/1V | 0 to Vmax |
| High ampere demand L1 | 1603h | 0.01A | 0 to Imax |
| High ampere demand L2 | 1604h | 0.01A | 0 to Imax |
| High ampere demand L3 | 1605h | 0.01A | 0 to Imax |
| High block kW import demand (E) | 1606h | 0.001kW/1kW | 0 to Pmax |
| High block kvar import demand (E) | 1607h | 0.001kvar/1kvar | 0 to Pmax |
| High block kVA demand (E) | 1608h | 0.001kVA/1kVA | 0 to Pmax |
| High sliding window kW import demand (E) | 1609h | 0.001kW/1kW | 0 to Pmax |
| High sliding window kvar import demand (E) | 160Ah | 0.001kvar/1kvar | 0 to Pmax |
| High sliding window kVA demand (E) | 160Bh | 0.001kVA/1kVA | 0 to Pmax |
| High accumulated kW import demand (E) | 160Fh | 0.001kW/1kW | 0 to Pmax |
| High accumulated kvar import demand (E) | 1610h | 0.001kvar/1kvar | 0 to Pmax |
| High accumulated kVA demand (E) | 1611h | 0.001kVA/1kVA | 0 to Pmax |
| High predicted kW import demand (E) | 1612h | 0.001kW/1kW | 0 to Pmax |
| High predicted kvar import demand (E) | 1613h | 0.001kvar/1kvar | 0 to Pmax |
| High predicted kVA demand (E) | 1614h | 0.001kVA/1kVA | 0 to Pmax |
| High block kW export demand (E) | 1616h | 0.001kW/1kW | 0 to Pmax |
| High block kvar export demand (E) | 1617h | 0.001kvar/1kvar | 0 to Pmax |
| High sliding window kW export demand (E) | 1618h | 0.001kW/1kW | 0 to Pmax |
| High sliding window kvar export demand (E) | 1619h | 0.001kvar/1kvar | 0 to Pmax |

| Trigger parameter | Trigger ID | Unit ② | Range ① |
|---|------------|-----------------|-----------|
| High accumulated kW export demand (E) | 161Ah | 0.001kW/1kW | 0 to Pmax |
| High accumulated kvar export demand (E) | 161Bh | 0.001kvar/1kvar | 0 to Pmax |
| High predicted kW export demand (E) | 161Ch | 0.001kW/1kW | 0 to Pmax |
| High predicted kvar export demand (E) | 161Dh | 0.001kvar/1kvar | 0 to Pmax |

① For parameter limits, see Note ① to Table 4-1

② When using direct wiring (PT Ratio = 1), voltages are transmitted in 0.1 V units, currents in 0.01 A units, and powers in 0.001 kW/kvar/kVA units. For wiring via PTs (PT Ratio > 1), voltages are transmitted in 1V units, currents in 0.01 A units, and powers in 1 kW/kvar/kVA units.

③ The setpoint is operated when the actual phase sequence does not match the indicated phase rotation

④ The actual frequency range is 45.00 - 65.00 Hz

⑤ When the 4LN3 or 3LN3 wiring mode is selected, the voltages will be line-to-neutral; for any other wiring mode, they will be line-to-line voltages.

(E) available in the PM172E

Table 5-14 Setpoint Actions

| Action | ID |
|---------------------------------------|-------|
| No action | 0000h |
| Operate relay #1 ① | 3000h |
| Operate relay #2 ① | 3001h |
| Increment counter #1 | 4000h |
| Increment counter #2 | 4001h |
| Increment counter #3 | 4002h |
| Increment counter #4 | 4003h |
| Clear counter #1 | 4200h |
| Clear counter #2 | 4201h |
| Clear counter #3 | 4202h |
| Clear counter #4 | 4203h |
| Clear all counters | 6400h |
| Reset total energy (E) | 6000h |
| Reset all total maximum demands (E) | 6100h |
| Reset power maximum demands (E) | 6101h |
| Reset volt/ampere maximum demands (E) | 6102h |
| Reset TOU energy (E) | 6200h |
| Reset TOU maximum demands (E) | 6300h |
| Clear Min/Max registers (E) | 6500h |
| Event log (E) ② | 7002h |
| Data log #1 (E) | 7100h |
| Data log #2 (E) | 7101h |
| Data log #3 (E) | 7102h |
| Data log #4 (E) | 7103h |
| Data log #5 (E) | 7104h |
| Data log #6 (E) | 7105h |
| Data log #7 (E) | 7106h |
| Data log #8 (E) | 7107h |

(E) available in the PM172E

① In the PM172E, operate/release actions via relays are automatically recorded to the event log whenever an electrical quantity, status input, or phase reversal trigger is used.

② Either setpoint transition (both operate and release) is recorded to the event log.

5.7 Relay Operation Control Registers

These registers allow you to manually override setpoint relay operations. Either relay may be manually forced operated or released using commands sent via communications.

NOTES

1. A relay allocated as a pulsing relay may not be manually operated or released. When a relay is allocated for pulsing, it automatically reverts to normal operation.
2. A relay is energized when forced operated, and is de-energized when forced released.

Table 5-15 Relay Operation Control Registers

| Parameter | Register | Size | Direction | Range |
|-------------------------|----------|------|-----------|----------------|
| Relay #1 control status | 8400h | 4 | R/W | see Table 5-16 |
| Relay #2 control status | 8401h | 4 | R/W | see Table 5-16 |

Table 5-16 Relay Operation Status

| Operation status | ID |
|------------------|----|
| Normal operation | 0 |
| Force operate | 1 |
| Force release | 2 |

5.8 Instrument Options Registers

Table 5-17 Instrument Options Registers

| Parameter | Register | Size | Direction | Range |
|--------------------|----------|------|-----------|----------------|
| Options 1 register | 7F00h | 4 | R | see Table 5-18 |
| Options 2 register | 7F01h | 4 | R | see Table 5-18 |

Table 5-18 Instrument Options

| Options register | Bit | Description |
|------------------|-------|---|
| Options1 | 0 | 120V option |
| | 1 | 690V option |
| | 2-3 | N/A |
| | 4 | 100% current over-range |
| | 5 | N/A |
| | 6 | Analog output 0/4-20 mA |
| | 7 | Analog output 0-1 mA |
| | 8 | Analog output ± 1 mA |
| | 9 | Relays option |
| | 10 | Digital inputs option |
| | 11 | N/A |
| | 12 | Setup is secured by a password (see Section 3.4) |
| | 13 | ASCII compatibility mode enabled (see Table 5-10) |
| | 14 | Analog expander output ± 1 mA |
| | 15 | N/A |
| Options 2 | 0-2 | Number of relays - 1 |
| | 3-6 | Number of digital inputs - 1 |
| | 7-8 | Number of analog outputs - 1 |
| | 9-13 | N/A |
| | 14-15 | Memory module size (PM172E) 10 = 512 Kbyte |

5.9 Extended Status Registers

Table 5-19 Extended Status Registers

| Parameter | Register | Size | Direction | Range |
|---------------------------|----------|------|-----------|------------------------|
| Relay status | 7D00h | 4 | R | see Table 4-12 |
| Reserved | 7D01h | 4 | R | read as 0000 |
| Status inputs | 7D02h | 4 | R | see Table 4-13 |
| Setpoint status | 7D03h | 4 | R | see Table 4-14 |
| Log status | 7D04h | 4 | R | see Table 4-15 |
| Active serial port number | 7D05h | 4 | R | 0 = Port 1, 1 = Port 2 |
| Battery status | 7D06h | 4 | R | 0 = low, 1 = normal |

5.10 Alarm Status Registers

Table 5-20 Alarm Status Registers

| Parameter | Register | Size | Direction | Range |
|-------------------------|----------|------|-----------|----------------|
| Setpoint alarm status | 7E00h | 4 | R/W | see Table 5-21 |
| Self-check alarm status | 7E01h | 4 | R/W | see Table 5-22 |

The setpoint alarm register stores the status of the operated setpoints by setting the appropriate bits to 1. The alarm status bits can be reset all together by writing zero to the setpoint alarm register. It is possible to reset each alarm status bit separately by writing back the contents of the alarm register with a corresponding alarm bit set to 0.

The self-check alarm register indicates possible problems with the instrument hardware or setup configuration. The hardware problems are indicated by the appropriate bits which are set whenever the instrument fails self-test diagnostics or in the event of loss of power. The setup configuration problems are indicated by the dedicated bit which is set when either configuration register is corrupted. In this event, the instrument will use the default configuration. The configuration corrupt bit may also be set as a result of the legal changes in the setup configuration since the instrument might implicitly change or clear other setups if they are affected by the changes made.

Hardware fault bits can be reset by writing zero to the self-check alarm register. The configuration corrupt status bit and RTC synchronization bit are also reset automatically when you change setup or update RTC either via the front panel or through communications.

Table 5-21 Setpoint Alarm Status

| Bit | Description |
|-----|-------------|
| 0 | Alarm #1 |
| 1 | Alarm #2 |
| 2 | Alarm #3 |
| 3 | Alarm #4 |
| 4 | Alarm #5 |
| 5 | Alarm #6 |
| 6 | Alarm #7 |
| 7 | Alarm #8 |
| 8 | Alarm #9 |
| 9 | Alarm #10 |
| 10 | Alarm #11 |
| 11 | Alarm #12 |
| 12 | Alarm #13 |
| 13 | Alarm #14 |
| 14 | Alarm #15 |
| 15 | Alarm #16 |

Bit meaning: 1 = setpoint has been operated

Table 5-22 Self-check Alarm Status

| Bit | Description |
|-------|-----------------------------------|
| 0 | Reserved |
| 1 | ROM error |
| 2 | RAM error |
| 3 | Watchdog timer reset |
| 4 | Sampling failure |
| 5 | Out of control trap |
| 6 | Reserved |
| 7 | Timing failure |
| 8 | Loss of power (power up) |
| 9 | External reset (warm restart) |
| 10 | Configuration corrupted |
| 11 | RTC time-synchronization required |
| 12-15 | Reserved |

5.11 Reset/Clear Registers

Table 5-23 Reset/Clear Registers

| Action | Register | Size | Direction | Range |
|---|----------|------|-----------|---|
| Clear total energy registers (E) | A000h | 4 | W | 0 |
| Clear total maximum demand registers | A001h | 4 | W | 0 = all maximum demands 1 = power demands (E) 2 = volt/ampere demands |
| Clear TOU energy registers (E) | A002h | 4 | W | 0 |
| Clear TOU demand registers (E) | A003h | 4 | W | 0 |
| Clear pulse counters (E) | A004h | 4 | W | 0 = all counters 1-4 = counter #1 - #4 |
| Clear Min/Max log | A005h | 4 | W | 0 |
| Clear event log (E) | A006h | 4 | W | 0 |
| Clear data log (E) | A007h | 4 | W | 0-7 = data log #1 - #8 16 = all data logs |
| Reserved | A008h | 4 | | |
| Reserved | A009h | 4 | | |
| Reserved | A00Ah | 4 | | |
| Restore event log read queue to the beginning (E) | A00Bh | 4 | W | 0 |
| Restore data log read queue to the beginning (E) | A00Ch | 4 | W | 0-7 = data logs #1 - #8 16-23 = monthly profile logs for TOU energy registers #1 - #8 32-34 = monthly profile logs for TOU maximum demand registers #1 - #3 48-55 = daily profile logs for TOU energy registers #1 - #8 64-66 = daily profile logs for TOU maximum demand registers #1 - #3 |
| Reserved | A00Dh | 4 | | |
| Reserved | A00Eh | 4 | | |

(E) available in the PM172E

5.12 Memory Allocation Status Registers

Table 5-24 Log Memory Status Registers

| Parameter | Register | Size | Direction | Range |
|-----------------------------------|----------|------|-----------|----------------|
| Total memory size, Bytes | A0F0h | 8 | R | 0 to 524288 |
| Free memory size, Bytes | A0F1h | 8 | R | 0 to 524288 |
| Memory partitions map | A0F2h | 8 | R | See Table 5.25 |
| Monthly profile log partition map | A0F3h | 8 | R | See Table 5.25 |
| Daily profile log partition map | A0F4h | 8 | R | See Table 5.25 |

Table 5-25 Log Partitions Allocation Map

| Memory Partition/Sub-partition | Bit |
|--|--------|
| Event log | 0 |
| Data log #1 | 1 |
| Data log #2 | 2 |
| Data log #3 | 3 |
| Data log #4 | 4 |
| Data log #5 | 5 |
| Data log #6 | 6 |
| Data log #7 | 7 |
| Data log #8 | 8 |
| Reserved | 9-31 |
| TOU Monthly Profile Log. Energy Reg. #1 | 0 |
| TOU Monthly Profile Log. Energy Reg. #2 | 1 |
| TOU Monthly Profile Log. Energy Reg. #3 | 2 |
| TOU Monthly Profile Log. Energy Reg. #4 | 3 |
| TOU Monthly Profile Log. Energy Reg. #5 | 4 |
| TOU Monthly Profile Log. Energy Reg. #6 | 5 |
| TOU Monthly Profile Log. Energy Reg. #7 | 6 |
| TOU Monthly Profile Log. Energy Reg. #8 | 7 |
| Reserved | 8 - 15 |
| TOU Monthly Profile Log. Max. Demand Reg. #1 | 16 |
| TOU Monthly Profile Log. Max. Demand Reg. #2 | 17 |
| TOU Monthly Profile Log. Max. Demand Reg. #3 | 18 |
| Reserved | 19-31 |
| TOU Daily Profile Log. Energy Reg. #1 | 0 |
| TOU Daily Profile Log. Energy Reg. #2 | 1 |
| TOU Daily Profile Log. Energy Reg. #3 | 2 |
| TOU Daily Profile Log. Energy Reg. #4 | 3 |
| TOU Daily Profile Log. Energy Reg. #5 | 4 |
| TOU Daily Profile Log. Energy Reg. #6 | 5 |
| TOU Daily Profile Log. Energy Reg. #7 | 6 |
| TOU Daily Profile Log. Energy Reg. #8 | 7 |
| TOU Daily Profile Log. Energy Reg. #9 | 8 - 15 |
| TOU Daily Profile Log. Max. Demand Reg. #1 | 16 |
| TOU Daily Profile Log. Max. Demand Reg. #2 | 17 |
| TOU Daily Profile Log. Max. Demand Reg. #3 | 18 |
| Reserved | 19-31 |

Bit meaning: 0 = a partition is not allocated; 1 = a partition is allocated

5.13 Memory Partition Status/Control Registers

Table 5-26 Memory Partition Status/Control Register Locations

| Memory Partition | Registers |
|---|-------------|
| Event log | A100h-A107h |
| Data log #1 | A108h-A10Fh |
| Data log #2 | A110h-A117h |
| Data log #3 | A118h-A11Fh |
| Data log #4 | A120h-A127h |
| Data log #5 | A128h-A12Fh |
| Data log #6 | A130h-A137h |
| Data log #7 | A138h-A13Fh |
| Data log #8 | A140h-A147h |
| Reserved | A148h-A1FFh |
| TOU Monthly Profile Log. Energy Reg. #1 | A200h-A207h |
| TOU Monthly Profile Log. Energy Reg. #2 | A208h-A20Fh |
| TOU Monthly Profile Log. Energy Reg. #3 | A210h-A217h |
| TOU Monthly Profile Log. Energy Reg. #4 | A218h-A21Fh |
| TOU Monthly Profile Log. Energy Reg. #5 | A220h-A227h |
| TOU Monthly Profile Log. Energy Reg. #6 | A228h-A22Fh |
| TOU Monthly Profile Log. Energy Reg. #7 | A230h-A237h |
| TOU Monthly Profile Log. Energy Reg. #8 | A238h-A23Fh |

| Memory Partition | Registers |
|--|-------------|
| Reserved | A240h-A27Fh |
| TOU Monthly Profile Log. Max. Demand Reg. #1 | A280h-A287h |
| TOU Monthly Profile Log. Max. Demand Reg. #2 | A288h-A28Fh |
| TOU Monthly Profile Log. Max. Demand Reg. #3 | A290h-A297h |
| Reserved | A298h-A2FFh |
| TOU Daily Profile Log. Energy Reg. #1 | A300h-A307h |
| TOU Daily Profile Log. Energy Reg. #2 | A308h-A30Fh |
| TOU Daily Profile Log. Energy Reg. #3 | A310h-A317h |
| TOU Daily Profile Log. Energy Reg. #4 | A318h-A31Fh |
| TOU Daily Profile Log. Energy Reg. #5 | A320h-A327h |
| TOU Daily Profile Log. Energy Reg. #6 | A328h-A32Fh |
| TOU Daily Profile Log. Energy Reg. #7 | A330h-A337h |
| TOU Daily Profile Log. Energy Reg. #8 | A338h-A33Fh |
| Reserved | A340h-A37Fh |
| TOU Daily Profile Log. Max. Demand Reg. #1 | A380h-A387h |
| TOU Daily Profile Log. Max. Demand Reg. #2 | A388h-A38Fh |
| TOU Daily Profile Log. Max. Demand Reg. #3 | A390h-A397h |
| Reserved | A398h-A3FFh |

If data log partition #7 is configured as a TOU monthly profile partition, registers A138h-A13Fh are mapped to registers A200h-A207h for the first TOU monthly profile sub-partition allocated for TOU energy register #1, or if this register is not configured, for the following first available TOU register.

If data log partition #8 is configured as a TOU daily profile partition, registers A140h-A147h are mapped to registers A300h-A307h for the first TOU daily profile sub-partition allocated for TOU energy register #1, or if this register is not configured, for the following first available TOU register.

Table 5-27 Memory Partition Status/Control Window Registers

| Parameter | Offset | Size | Direction | Range |
|---|--------|------|-----------|---|
| Log partition status | +0 | 4 | R | Bit-mapped register: bit 0 = 0 - non-wrap partition = 1 - wrap-around partition bit 4 = 1 - TOU monthly profile partition bit 5 = 1 - TOU daily profile partition bit 9 = 1 - reading after the end of file: the read pointer has rolled over the end of a log file, that is the file is being re-read from the beginning. This bit is cleared when the read pointer [+6] points to a new record, or either command register [+6] or [+7] is written. |
| The total number of records logged in the partition/sub-partition | +1 | 4 | R | 0 to 65535. Returns the total number of logged records available in the partition. |
| The number of the new records never read before | +2 | 4 | R | 0 to 65535. Returns the number of records from the first new one never read before and until the end of the log file. |
| The next sequence number to be used when the next log event will take place | +3 | 4 | R | 0 to 65535 (increments modulo 65536 with each log). Returns the sequence number that will be applied to the next record being logged. |
| The sequence number of the first (oldest) record in the log file | +4 | 4 | R | 0 to 65535. Returns the sequence number of the oldest record in the log file. |
| The sequence number of the first new record never read before | +5 | 4 | R | 0 to 65535. Returns the sequence number of the first new (most recent) record that has never been read. If this number is equal to the contents of register [+3], there are no newest records never read before. |

| Parameter | Offset | Size | Direction | Range |
|--|--------|------|-----------|--|
| The sequence number of the current record to be read | +6 | 4 | R/W ① | 0 to 65535. Points to the record that will be read via the partition read window. Can be overwritten to point to the desired record. |
| Command register | +7 | 4 | R/W | This is a write-only register. Write value: 0 = automatically restores the read sequence to the beginning of the log file, that is puts the read pointer to the first (oldest) record in the log file (actually, safely copies the contents of the register [+4] to the register [+6]). 1 = automatically sets the read sequence to the first new record never read before, that is puts the read pointer to the record following the last one whenever read. If there are new records in the partition, this actually copies the contents of the register [+5] to the register [+6]. If there are no new records, the register [+5] will point to the first (oldest) record in the log file as if the command register was written with zero. Read as 0. |

① If there is no record in the log file that matches the written sequence number, the instrument will respond with the exception code XP (invalid data).

5.14 Event Log Registers (Circular Access)

These registers allow you to circularly read a packet of consequent records from the event log file. From 1 to 6 event log records can be read at a time via the event log windows, which comprise registers CD80h through CDAFh. Reading from either register window always returns the next logged event record. All registers within one window must be read at once using a single request. After reading an event log window, the partition queue pointer is shifted forward until the end of the log file. After the last record has been read, the file pointer is automatically restored to the beginning of the log file so that the next read request will return the first (oldest) event. To point to an arbitrary record, use the log partition status/control registers A100h-A107h (see Section 5.13).

Table 5-28 Event Log Windows Locations

| Event log window | Registers (see Table 5-29) |
|---------------------|----------------------------|
| Event log window #1 | CD80h-CD87h |
| Event log window #2 | CD88h-CD8Fh |
| Event log window #3 | CD90h-CD97h |
| Event log window #4 | CD98h-CD9Fh |
| Event log window #5 | CDA0h-CDA7h |
| Event log window #6 | CDA8h-CDAFh |

Table 5-29 Event Log Window Registers

| Parameter | Offset | Size | Direction | Range |
|-------------------|--------|------|-----------|---|
| Status indication | +0 | 4 | R | Bit-mapped register: bit 0 = 1 - the end record is being read (the end of a log file reached) bit 1 = 1 - reading after the end of file: the read pointer has rolled over the end of a log file, i.e., the file is being re-read from the beginning. This bit is cleared when a new record is being read, or the read sequence has changed by overwriting the partition pointer. bit 8 = 1 - no records logged in the partition bit 9 = 1 - the record is corrupted bit 15 = 1 - read error (detailed by bits 8-9) |

| Parameter | Offset | Size | Direction | Range |
|--|--------|------|-----------|--|
| The record sequence number | +1 | 4 | R | 0 to 65535 (increments modulo 65536 with each log) |
| Timestamp ① | +2 | 8 | R | Local time (UNIX-style) |
| Fractional seconds portion of timestamp (milliseconds) | +3 | 4 | R | 0-990 (at 10 ms resolution) |
| Event cause | +4 | 4 | R | see Table 5-46 |
| Log value ② | +5 | 8 | R | see Table 5-46 |
| Event effect | +6 | 4 | R | see Table 5-46 |
| Reserved | +7 | 4 | R | 0 |

① Timestamp is given in local time in a UNIX-style time format: it represents the number of seconds since midnight (00:00:00), January 1, 1970. The time is valid after January 1, 2000.

② For the log value size and range, refer to Table 5-7.

NOTES:

1. If a requested record is corrupted (the redundant check fails), the record is reported with all zeros (except the sequence number) and the bits 9 and 15 in the status indication word being set to 1.
2. If a record is requested when the log file is empty, the record is reported with all zeros and bits 8 and 15 in the status indication word being set to 1.

Table 5-30 Event Log Parameters

| Event cause | Event cause code | | Log value | Event effect | |
|-------------------------------------|---|--|---|--|------------------------------------|
| | High byte: cause code | Low byte: event origin (location) | | High byte: effect code | Low byte: target code |
| Setpoint event | Trigger parameter ID high byte (see Table 5-13) | Trigger parameter ID low byte (see Table 5-13) | Trigger parameter value (see Table 5-7) | 225 (E1h) = setpoint operated 226 (E2h) = setpoint released | Setpoint number = 0-15 (00h - 0Fh) |
| Communication activity | 91 (5Bh) | Data location code (see Table 5-31) | N/A | See Table 5-32 | See Table 5-32 |
| Front panel activity | 92 (5Ch) | Data location code (see Table 5-31) | N/A | See Table 5-32 | See Table 5-32 |
| Self-check | 93 (5Dh) | Data location code (see Table 5-31) | N/A | See Table 5-32 | See Table 5-32 |
| Self-update (daylight savings time) | 94 (5Eh) | 8 = RTC | N/A | 245 (F5h) = RTC set | N/A |
| External event | 99 (63h) | 0 = power down 8 = power up | N/A | N/A | N/A |

Table 5-31 Data Location Codes

| Location code | Description |
|---------------|----------------------|
| 3 | Data keeping memory |
| 8 | Real-time clock |
| 16 | Event/alarm setpoint |

Table 5-32 Event Effect Codes

| Effect code | | Description | Target |
|-------------|-----|-----------------------------|---|
| Dec | Hex | | |
| 96 | 60h | Clear energy registers | N/A |
| 97 | 61h | Clear demand registers | 0 = all demands 1 = power demands 2 = volt/ampere demands |
| 98 | 62h | Clear TOU energy registers | N/A |
| 99 | 63h | Clear TOU demand registers | N/A |
| 100 | 64h | Clear counters | 0 = all counters, 1-4 = counter #1-#4 |
| 101 | 65h | Clear Min/Max log registers | N/A |
| 102 | 66h | Clear event log | N/A |
| 103 | 67h | Clear data log | 0-7 = log #1-#8, 16 (10h) = all data logs |
| 225 | E1h | Setpoint operated | 0-15 (00h-0Fh) = setpoint #1-#16 |
| 226 | E2h | Setpoint released | 0-15 (00h-0Fh) = setpoint #1-#16 |
| 241 | F1h | Setpoint disabled | 0-15 (00h-0Fh) = setpoint #1-#16 |
| 245 | F5h | RTC set | N/A |

5.15 Data Log Registers (Circular Access)

These registers allow you to circularly read consequent records from the event log file. Each data log file is accessed via a separate register window. Reading from either register window always returns the next logged record from the corresponding data log. All registers within one window must be read at once using a single request. After reading a log window, the partition queue pointer is shifted forward until the end of the log file. After the last record has been read, the file pointer is automatically restored to the beginning of the log file so that the next read request will return the first (oldest) record. To point to an arbitrary record, use the data log partition status/control registers (see Section 5.13).

Table 5-33 Data Log Window Locations

| Data log | Window registers |
|--|------------------|
| Data log #1 | C000h-C017h |
| Data log #2 | C018h-C02Fh |
| Data log #3 | C030h-C047h |
| Data log #4 | C048h-C05Fh |
| Data log #5 | C060h-C077h |
| Data log #6 | C078h-C08Fh |
| Data log #7 | C090h-C0A7h |
| Data log #8 | C0A8h-C0BFh |
| Reserved | C0C0h-C17Fh |
| TOU Monthly Profile Log. Energy Reg. #1 | C180h-C197h |
| TOU Monthly Profile Log. Energy Reg. #2 | C198h-C1AFh |
| TOU Monthly Profile Log. Energy Reg. #3 | C1B0h-C1C7h |
| TOU Monthly Profile Log. Energy Reg. #4 | C1C8h-C1DFh |
| TOU Monthly Profile Log. Energy Reg. #5 | C1E0h-C1F7h |
| TOU Monthly Profile Log. Energy Reg. #6 | C1F8h-C20Fh |
| TOU Monthly Profile Log. Energy Reg. #7 | C210h-C227h |
| TOU Monthly Profile Log. Energy Reg. #8 | C228h-C23Fh |
| Reserved | C240h-C2FFh |
| TOU Monthly Profile Log. Max. Demand Reg. #1 | C300h-C317h |
| TOU Monthly Profile Log. Max. Demand Reg. #2 | C318h-C32Fh |
| TOU Monthly Profile Log. Max. Demand Reg. #3 | C330h-C347h |
| Reserved | C348h-C47Fh |
| TOU Daily Profile Log. Energy Reg. #1 | C480h-C497h |
| TOU Daily Profile Log. Energy Reg. #2 | C498h-C4AFh |
| TOU Daily Profile Log. Energy Reg. #3 | C4B0h-C4C7h |
| TOU Daily Profile Log. Energy Reg. #4 | C4C8h-C4DFh |
| TOU Daily Profile Log. Energy Reg. #5 | C4E0h-C4F7h |
| TOU Daily Profile Log. Energy Reg. #6 | C4F8h-C50Fh |
| TOU Daily Profile Log. Energy Reg. #7 | C510h-C527h |
| TOU Daily Profile Log. Energy Reg. #8 | C528h-C53Fh |
| Reserved | C540h-C5FFh |
| TOU Daily Profile Log. Max. Demand Reg. #1 | C600h-C617h |
| TOU Daily Profile Log. Max. Demand Reg. #2 | C618h-C62Fh |
| TOU Daily Profile Log. Max. Demand Reg. #3 | C630h-C647h |
| Reserved | C648h-C77Fh |

If data log partition #7 is configured as a TOU monthly profile partition, registers C090h-C0A7h are mapped to registers C180h-C197h for the first TOU monthly profile sub-partition allocated for TOU energy register #1, or if this register is not configured, for the following first available TOU register.

If data log partition #8 is configured as a TOU daily profile partition, registers C0A8h-C0BFh are mapped to registers C480h-C497h for the first TOU daily profile sub-partition allocated for TOU energy register #1, or if this register is not configured, for the following first available TOU register.

Table 5-34 Data Log Read Window Registers

| Parameter | Offset | Size | Direction | Range |
|--|------------|------|-----------|---|
| Status indication | +0 | 4 | R | Bit-mapped register: bit 0 = 1 - the end record is being read (the end of a log file reached) bit 1 = 1 - reading after the end of file: the read pointer has rolled over the end of a log file, i.e., the file is being re-read from the beginning. This bit is cleared when a new record is being read, or the read sequence has changed by overwriting the partition pointer. bit 8 = 1 - no records logged in the partition bit 9 = 1 - the record is corrupted bit 15 = 1 - read error (detailed by bits 8-9) |
| The record sequence number | +1 | 4 | R | 0 to 65535 (increments modulo 65536 with each log) |
| Timestamp ① | +2 | 8 | R | Local time (UNIX-style) |
| Fractional seconds portion of timestamp (milliseconds) | +3 | 4 | R | 0-990 (at 10 ms resolution) |
| Event setpoint ID | +4 | 4 | R | 0 (TOU profile log), 1 to 16 |
| Parameter #1 value | +5 | 8 | R | see Table 5-7 |
| Parameter #2 value | +6 | 8 | R | see Table 5-7 |
| Parameter #3 value | +7 | 8 | R | see Table 5-7 |
| Parameter #4 value | +8 | 8 | R | see Table 5-7 |
| Parameter #5 value | +9 | 8 | R | see Table 5-7 |
| Parameter #6 value | +10 | 8 | R | see Table 5-7 |
| Parameter #7 value | +11 | 8 | R | see Table 5-7 |
| Parameter #8 value | +12 | 8 | R | see Table 5-7 |
| Parameter #9 value | +13 | 8 | R | see Table 5-7 |
| Parameter #10 value | +14 | 8 | R | see Table 5-7 |
| Parameter #12 value | +15 | 8 | R | see Table 5-7 |
| Parameter #13 value | +16 | 8 | R | see Table 5-7 |
| Parameter #13 value | +17 | 8 | R | see Table 5-7 |
| Parameter #14 value | +18 | 8 | R | see Table 5-7 |
| Parameter #15 value | +19 | 8 | R | see Table 5-7 |
| Parameter #16 value | +20 | 8 | R | see Table 5-7 |
| Reserved | +21 to +23 | | R | 0 |

① Timestamp is given in local time in a UNIX-style time format: it represents the number of seconds since midnight (00:00:00), January 1, 1970. The time is valid after January 1, 2000.

NOTES:

1. If a requested record is corrupted (the redundant check fails), the record is reported with all zeros (except the sequence number) and bits 9 and 15 in the status indication word being set to 1.
2. If a record is requested when the log file is empty, the record is reported with all zeros and bits 8 and 15 in the status indication word being set to 1.
3. The parameters that reside outside of the specified partition record size will be read as zeros.

5.16 Min/Max Log Registers

These registers allow you to read time-stamped Min/Max log records using direct read requests.

Table 5-35 Min/Max Log Registers

| Parameter | Register | Size | Unit | Range |
|---|----------|------|-----------------|---------------|
| Minimum real-time values per phase | | | | |
| Min. Voltage L1/L12 ⑥ | B000h | 8 | 0.1V/1V | 0 to Vmax |
| Timestamp | B001h | 8 | | |
| Min. Voltage L2/L23 ⑥ | B002h | 8 | 0.1V/1V | 0 to Vmax |
| Timestamp | B003h | 8 | | |
| Min. Voltage L3/L31 ⑥ | B004h | 8 | 0.1V/1V | 0 to Vmax |
| Timestamp | B005h | 8 | | |
| Min. Current L1 | B006h | 8 | 0.01A | 0 to Imax |
| Timestamp | B007h | 8 | | |
| Min. Current L2 | B008h | 8 | 0.01A | 0 to Imax |
| Timestamp | B009h | 8 | | |
| Min. Current L3 | B00Ah | 8 | 0.01A | 0 to Imax |
| Timestamp | B00Bh | 8 | | |
| Minimum real-time total values | | | | |
| Min. Total kW | B080h | 8 | 0.001kW/1kW | -Pmax to Pmax |
| Timestamp | B081h | 8 | | |
| Min. Total kvar | B082h | 8 | 0.001kvar/1kvar | -Pmax to Pmax |
| Timestamp | B083h | 8 | | |
| Min. Total kVA | B084h | 8 | 0.001kVA/1kVA | 0 to Pmax |
| Timestamp | B085h | 8 | | |
| Total PF ③ | B086h | 4 | 0.001 | 0 to 1000 |
| Timestamp | B087h | 8 | | |
| Minimum real-time auxiliary values | | | | |
| Reserved | B100h | 8 | | 0 |
| Timestamp | B101h | 8 | | |
| Min. Neutral current | B102h | 8 | 0.01A | 0 to Imax |
| Timestamp | B103h | 8 | | |
| Min. Frequency ④ | B104h | 4 | 0.01Hz | 0 to 10000 |
| Timestamp | B105h | 8 | | |
| Maximum real-time values per phase | | | | |
| Max. Voltage L1/L12 ⑥ | B200h | 8 | 0.1V/1V | 0 to Vmax |
| Timestamp | B201h | 8 | | |
| Max. Voltage L2/L23 ⑥ | B202h | 8 | 0.1V/1V | 0 to Vmax |
| Timestamp | B203h | 8 | | |
| Max. Voltage L3/L31 ⑥ | B204h | 8 | 0.1V/1V | 0 to Vmax |
| Timestamp | B205h | 8 | | |
| Max. Current L1 | B206h | 8 | 0.01A | 0 to Imax |
| Timestamp | B207h | 8 | | |
| Max. Current L2 | B208h | 8 | 0.01A | 0 to Imax |
| Timestamp | B209h | 8 | | |
| Max. Current L3 | B20Ah | 8 | 0.01A | 0 to Imax |
| Timestamp | B20Bh | 8 | | |
| Maximum real-time total values | | | | |
| Max. Total kW | B280h | 8 | 0.001kW/1kW | -Pmax to Pmax |
| Timestamp | B281h | 8 | | |
| Max. Total kvar | B282h | 8 | 0.001kvar/1kvar | -Pmax to Pmax |
| Timestamp | B283h | 8 | | |
| Total kVA | B284h | 8 | 0.001kVA/1kVA | 0 to Pmax |
| Timestamp | B285h | 8 | | |
| Max. Total PF ③ | B286h | 4 | 0.001 | 0 to 1000 |
| Timestamp | B287h | 8 | | |
| Maximum real-time auxiliary values | | | | |
| Reserved | B300h - | 8 | | 0 |
| | B301h | 8 | | |
| Max. Neutral current | B302h | 8 | 0.01A | 0 to Imax |

| Parameter | Register | Size | Unit | Range |
|---|------------------|--------|---------------|------------|
| Timestamp | B303h | 8 | | |
| Max. Frequency ④ | B304h | 4 | 0.01Hz | 0 to 10000 |
| Timestamp | B305h | 8 | | |
| Maximum demands (M) | | | | |
| Max. volt demand L1/L12 ⑥ | B380h | 8 | 0.1V/1V | 0 to Vmax |
| Timestamp | B381h | 8 | | |
| Max. volt demand L2/L23 ⑥ | B382h | 8 | 0.1V/1V | 0 to Vmax |
| Timestamp | B383h | 8 | | |
| Max. volt demand L3/L31 ⑥ | B384h | 8 | 0.1V/1V | 0 to Vmax |
| Timestamp | B385h | 8 | | |
| Max. ampere demand L1 | B386h | 8 | 0.01A | 0 to Imax |
| Timestamp | B387h | 8 | | |
| Max. ampere demand L2 | B388h | 8 | 0.01A | 0 to Imax |
| Timestamp | B389h | 8 | | |
| Max. ampere demand L3 | B38Ah | 8 | 0.01A | 0 to Imax |
| Timestamp | B38Bh | 8 | | |
| Reserved | B38Ch - B38Dh | 8 8 | | 0 |
| Reserved | B38Eh - B38Fh | 8 8 | | 0 |
| Reserved | B390h - B391h | 8 8 | | 0 |
| Max. sliding window kW import demand (E) | B392h | 8 | 0.001kW/1kW | 0 to Pmax |
| Timestamp | B393h | 8 | | |
| Reserved | B394h - B395h | 8 8 | | |
| Max. sliding window kVA demand (E) | B396h | 8 | 0.001kVA/1kVA | 0 to Pmax |
| Timestamp | B397h | 8 | | |
| Reserved | B398h - B399h | 8 8 | | 0 |
| Reserved | B39Ah - B39Bh | 8 8 | | 0 |
| Reserved | B39Ch - B39Dh | 8 8 | | 0 |
| Max. sliding window kW export demand (E) | B39Eh | 8 | 0.001kW/1kW | 0 to Pmax |
| Timestamp | B39Fh | 8 | | |
| TOU maximum demand register #1 (E) | | | | |
| Max. Demand Tariff #1 register | B480h | 8 | ⑤ | 0 to Pmax |
| Timestamp | B481h | 8 | | |
| Max. Demand Tariff #2 register | B482h | 8 | ⑤ | 0 to Pmax |
| Timestamp | B483h | 8 | | |
| ... | | | | |
| Max. Demand Tariff #16 register | B49Eh | 8 | ⑤ | 0 to Pmax |
| Timestamp | B49Fh | 8 | | |
| TOU maximum demand register #2 (E) | | | | |
| Max. Demand Tariff #1 register | B500h | 8 | ⑤ | 0 to Pmax |
| Timestamp | B501h | 8 | | |
| Max. Demand Tariff #2 register | B502h | 8 | ⑤ | 0 to Pmax |
| Timestamp | B503h | 8 | | |
| ... | | | | |
| Max. Demand Tariff #16 register | B51Eh | 8 | ⑤ | 0 to Pmax |
| Timestamp | B51Fh | 8 | | |
| TOU maximum demand register #3 (E) | | | | |
| Max. Demand Tariff #1 register | B580h | 8 | ⑤ | 0 to Pmax |
| Timestamp | B581h | 8 | | |
| Max. Demand Tariff #2 register | B582h | 8 | ⑤ | 0 to Pmax |
| Timestamp | B583h | 8 | | |
| ... | | | | |
| Max. Demand Tariff #16 register | B59Eh | 8 | ⑤ | 0 to Pmax |
| Timestamp | B59Fh | 8 | | |

Timestamp is given in local time in a UNIX-style time format: it represents the number of seconds since midnight (00:00:00), January 1, 1970. The time is valid after January 1, 2000.

- ① For parameter limits, see Note ① to Table 4-1
- ② When using direct wiring (PT Ratio = 1), voltages are transmitted in 0.1 V units, currents in 0.01 A units, and powers in 0.001 kW/kvar/kVA units. For wiring via PTs (PT Ratio > 1), voltages are transmitted in 1V units, currents in 0.01 A units, and powers in 1 kW/kvar/kVA units.
- ③ New absolute min/max value (lag or lead).
- ④ The actual frequency range is 45.00 - 65.00 Hz.
- ⑤ The TOU maximum demand register unit matches the measurement unit of the input parameter for which the register is allocated.
- ⑥ When the 4LN3 or 3LN3 wiring mode is selected, the voltages will be line-to-neutral; for any other wiring mode, they will be line-to-line voltages.

5.17 Digital Inputs Allocation Registers

Table 5-36 Digital Inputs Allocation Registers

| Parameter | Register | Size | Direction | Range |
|--|----------|------|-----------|----------------|
| Status inputs allocation mask | 8900h | 4 | R ① | See Table 5-37 |
| Pulse inputs allocation mask | 8901h | 4 | R/W | See Table 5-37 |
| Not used | 8902h | 4 | R ① | Read as 0 |
| External demand synchronization input mask (E) | 8903h | 4 | R/W | See Table 5-37 |
| Time synchronization input mask | 8904h | 4 | R/W | See Table 5-37 |

① Writing to these locations is ignored. No error will occur.

(E) available in the PM172E

NOTES

- All digital inputs that were not allocated as pulse inputs will be automatically configured as status inputs.
- A digital input allocated for the external demand synchronization pulse or time synchronization pulse will be automatically configured as a pulse input.

Table 5-37 Digital Inputs Allocation Mask

| Bit number | Description |
|------------|--------------------------------------|
| 0 | Discrete input # 1 allocation status |
| 1 | Discrete input # 2 allocation status |
| 2-15 | Not used |

Bit meaning: 0 = input not allocated, 1 = input allocated to the group

5.18 Time Zone Information Registers

Table 5-38 Time Zone Registers

| Parameter | Register | Size | Direction | Range |
|------------------------------------|----------|------|-----------|--|
| Daylight savings time (DST) option | 8C00h | 4 | R/W | 0 = disable DST (use standard time only), 1 = enable DST |
| DST start month | 8C01h | 4 | R/W | 1 - 12 |
| DST start week of the month | 8C02h | 4 | R/W | 1 - 4 = 1st, 2nd, 3rd and 4th week, 5 = the last weekday in the month |
| DST start weekday | 8C03h | 4 | R/W | 1-7 (1= Sun, 7 = Sat) |
| DST end month | 8C04h | 4 | R/W | 1 - 12 |
| DST end week of the month | 8C05h | 4 | R/W | 1 - 4 = 1st, 2nd, 3rd and 4th week, 5 = the last weekday in the month |
| DST end weekday | 8C06h | 4 | R/W | 1-7 (1= Sun, 7 = Sat) |

5.19 Communications Password Register

Table 5-39 Password Register

| Parameter | Register | Size | Direction | Range |
|-------------------------|----------|------|-----------|--|
| Communications password | FF00h | 4 | R/W | Write: 0 to 65535 Read: 0 = access permitted 65535 = authorization required |

