



Advanced Power Meter

EM235/PM335 PRO

Modbus Communications Protocol

Reference Guide

Every effort has been made to ensure that the material herein is complete and accurate. However, the manufacturer is not responsible for any mistakes in printing or faulty instructions contained in this book. Notification of any errors or misprints will be received with appreciation.

For further information regarding a particular installation, operation or maintenance of equipment, contact the manufacturer or your local representative or distributor.

REVISION HISTORY

| | | |
|----|-----------|------------------------|
| A1 | Jan-2021 | Initial release |
| A2 | Jun-2022 | Second updated release |
| A3 | July-2022 | Third updated release |
| A4 | July-2024 | Fourth updated release |

Modbus is a trademark of Schneider Electric.

Table of Contents

| | | |
|------------------|--|------------|
| Chapter 1 | General | 4 |
| Chapter 2 | Modbus Protocol Implementation | 5 |
| 2.1 | Transmission Modes | 5 |
| 2.2 | Address Field | 5 |
| 2.3 | Function Field | 5 |
| 2.4 | Exception Responses | 5 |
| 2.5 | Modbus Register Addresses | 6 |
| 2.6 | Data Formats | 6 |
| 2.6.1 | 16-bit Scaled Integer Format | 6 |
| 2.6.2 | 32-bit Long Integer Format | 8 |
| 2.6.3 | 32-bit Modulo-10000 Format | 9 |
| 2.7 | User Assignable Registers | 9 |
| 2.8 | Password Protection | 10 |
| 2.9 | Data Recording and File Transfers | 10 |
| 2.9.1 | Log File Organization | 10 |
| 2.9.2 | File Transfers | 12 |
| 2.10 | TCP Notification Client | 14 |
| Chapter 3 | Modbus Register Map | 16 |
| 3.1 | Modbus Setup Registers | 16 |
| 3.2 | 16-bit Scaled Analog Values – Basic Register Set | 17 |
| 3.3 | 16-bit Scaled Analog Values | 19 |
| 3.4 | 32-bit Binary and Analog Values | 57 |
| 3.5 | Minimum/Maximum Log Registers | 121 |
| 3.6 | Device Control and Status Registers | 137 |
| 3.7 | Device Setup Register | 144 |
| 3.8 | Expansion I/O Slots Configuration | 190 |
| 3.8.1 | I/O Module Type | 192 |
| 3.9 | File Transfer Blocks | 194 |
| 3.9.1 | File Response Blocks | 196 |
| 3.9.2 | File Response Block Alias | 203 |
| 3.10 | Billing/TOU Daily and Monthly Profile Data Logs | 205 |
| Chapter 4 | Data Scales and Units | 208 |
| Chapter 5 | Data Formats | 209 |

Chapter 1 General

This document specifies a subset of the Modbus communications protocol used to transfer data between a master computer station and EM235/PM335 PRO. The document provides the complete information necessary to develop third-party communications software capable of communication with EM235/PM335 PRO. Refer to the EM235/PM335 PRO Installation & Operation Manual for more information on communication connections and configuring communication parameters in your device.

Chapter 2 Modbus Protocol Implementation

For detailed information on the Modbus protocol, message framing and error checking, refer to the Modbus Protocol Reference Guide. It can be downloaded from the Modbus-IDA Website at <http://www.modbus.org/>. The following paragraphs outline some issues concerning the implementation of the Modbus protocol in the EM235/PM335 PRO.

2.1 Transmission Modes

EM235/PM335 PRO can be set up to communicate on a serial Modbus network using either RTU, or ASCII serial transmission mode, and via the Internet using Modbus/TCP mode. Refer to EM235/PM335 PRO Operation Manual for information on selecting the transmission mode in your device.

2.2 Address Field

The address field contains a user assigned address of the instrument (1-247) on a Modbus network. Broadcast mode using address 0 is not supported.

When communicating via the Internet, the address field is not checked and is returned in the response message header.

2.3 Function Field

The Modbus functions implemented in EM235/PM335 PRO are shown in Table 2-1. Function 04 can be used in the same context as function 03.

Table 2-1 Modbus Function Codes

| Code (decimal) | Meaning in Modbus | Action |
|-----------------|---------------------------|------------------------------|
| 03 | Read holding registers | Read multiple registers |
| 04 | Read input registers | Read multiple registers |
| 06 | Preset single register | Write single register |
| 16 | Preset multiple registers | Write multiple registers |
| 22 | Mask write | Set or clear individual bits |
| 08 ¹ | Loop-back test | Communications test |

² EM235/PM335 PRO supports only diagnostic code 0 – return query data.

2.4 Exception Responses

The instrument sends an exception response when an error is detected in the received message. To indicate that the response is notification of an error, the high order bit of the function code is set to 1.

Implemented exception response codes:

- 01-** Illegal function
- 02-** Illegal data address
- 03-** Illegal data value
- 04-** Device failure

When the character framing, parity, or redundancy check detects a communication error, processing of the master's request stops. The instrument will not act on or respond to the message.

2.5 Modbus Register Addresses

EM235/PM335 PRO Modbus registers are numbered in the range of 0 to 65535. From the Modbus applications, EM235/PM335 PRO Modbus registers can be accessed by simulating holding registers of the Modicon 584, 884 or 984 Programmable Controller, using a 5-digit "4XXXX" or 6-digit "4XXXXX" addressing scheme. To map the EM235/PM335 PRO register address to the range of the Modbus holding registers, add a value of 40001 to EM235/PM335 PRO register address. When a register address exceeds 9999, use a 6-digit addressing scheme by adding 400001 to EM235/PM335 PRO register address.

2.6 Data Formats

EM235/PM335 PRO uses three data formats to pass data between a master application and the instrument: 16-bit short integer, 32-bit long integer and 32-bit modulo-10000 formats. Binary values and counters are always transmitted in 32-bit registers, while analog values can be read both in 32-bit and in 16-bit scaled registers.

Analog registers 256 through 308 and 4320 through 10751 contain scaled 16-bit values.

2.6.1 16-bit Scaled Integer Format

16-bit scaled data is transmitted in a single 16-bit Modbus register as unsigned (UINT16) integer (whole) numbers using the linear conversion to accommodate large-scale and fractional numbers to a 16-bit register format. The linear conversion uses two scales to read the raw data from the device and convert it into engineering units: the device original engineering scale and the Modbus conversion scale.

When transmitting measured data, the device scales it into the range of Modbus Low and High conversion scales. To reconstruct data in the original engineering units, perform the reverse conversion according to the following formula:

$$\text{Engineering_Units} = \frac{\text{Raw_Data} \times (\text{ENG_HI} - \text{ENG_LO})}{\text{RAW_HI} - \text{RAW_LO}} + \text{ENG_LO}$$

where:

- ENG_LO and ENG_HI - reading low and high scales in engineering units
- RAW_LO and RAW_HI - raw data low and high scales (by default, 0 and 9999)
- Raw_Data - raw input data in the range of RAW_LO to RAW_HI
- Engineering_Units - true value in engineering units

The default Modbus conversion scales are 0 for the low scale and 9999 for the high scale. This means that the scaled analog data is always transmitted in the range of 0 to 9999. The Modbus conversion scales can be changed through communications via registers 240 and 241.

The engineering scales are separately indicated for each scaled 16-bit register. For data scales and measurement units that depend on the device input scales (such as volts, amps and powers), refer to Chapter 4 "Data Scales and Units".

Conversion Examples

1. Voltage readings

a) Assume device settings (direct wiring): PT ratio = 1.

Voltage engineering scales (see Chapter 4):

$$HI_ENG = V_{max} = 828.0 \times PT \text{ ratio} = 828.0 \times 1 = 828.0V$$

$$LO_ENG = 0V$$

If the raw data reading is 1449 then the voltage reading in engineering units will be as follows:

$$\text{Volts reading} = 1449 \times (828.0 - 0)/(9999 - 0) + 0 = 120.0V$$

b) Assume device settings (wiring via PT): PT ratio = 14,400V : 120V = 120.

Voltage engineering scales (see Chapter 4):

$$HI_ENG = V_{max} = 828.0 \times PT \text{ ratio} = 828 \times 120 = 99,360V$$

$$LO_ENG = 0V$$

If the raw data reading is 1449 then the voltage reading in engineering units will be as follows:

$$\text{Volts reading} = 1449 \times (99360 - 0)/(9999 - 0) + 0 = 14,399V$$

2. Current readings

Assume device settings: CT primary current = 200A; current input overload = 200% (10A).

Current engineering scales (see Chapter 4):

$$HI_ENG = I_{max} = CT \text{ primary current} \times 4 = 800.00A$$

$$LO_ENG = 0A$$

If the raw data reading is 250 then the current reading in engineering units will be as follows:

$$\text{Amps reading} = 250 \times (800.00 - 0)/(9999 - 0) + 0 = 10.00A$$

3. Power readings

a) Assume device settings (direct wiring): PT = 1; CT primary current = 200A; current input overload = 200% (10A).

Active Power engineering scales (rounded to whole kW, see Chapter 4):

$$HI_ENG = P_{max} = V_{max} \times I_{max} \times 2 = (828.0 \times 1) \times (200.00 \times 4) \times 2 = 1,324,800 \text{ W} = 1325 \text{ kW}$$

$$LO_ENG = -P_{max} = -1325 \text{ kW}$$

If the raw data reading is 5500 then the power reading in engineering units will be as follows:

$$\text{Watts reading} = 5500 \times (1325 - (-1325))/(9999 - 0) + (-1325) = 132.6 \text{ kW}$$

If the raw data reading is 500 then the power reading in engineering units will be as follows:

$$\text{Watts reading} = 500 \times (1325 - (-1325))/(9999 - 0) + (-1325) = -1192.5 \text{ kW}$$

b) Assume device settings (wiring via PT): PT = 120; CT primary current = 200A; current input overload = 400% (20A).

Active Power engineering scales (rounded to whole kW, see Chapter 4):

$$\text{HI_ENG} = P_{\text{max}} = V_{\text{max}} \times I_{\text{max}} \times 2 = (828 \times 120) \times (200.00 \times 4) \times 2/1000 = 158976 \text{ kW}$$

$$\text{LO_ENG} = -P_{\text{max}} = -158976 \text{ kW}$$

If the raw data reading is 5500 then the power reading in engineering units will be as follows:

$$\text{Watts reading} = 5500 \times (158976 - (-158976))/(9999 - 0) + (-158976) = 15915 \text{ kW}$$

If the raw data reading is 500 then the power reading in engineering units will be as follows:

$$\text{Watts reading} = 500 \times (158976 - (-158976))/(9999 - 0) + (-158976) = -143077 \text{ kW}$$

4. Power Factor readings

Power factor engineering scales (see Chapter 4):

$$\text{HI_ENG} = 1.000.$$

$$\text{LO_ENG} = -1.000.$$

If the raw data reading is 8900 then the power factor in engineering units will be as follows:

$$\text{Power factor reading} = 8900 \times (1.000 - (-1.000))/(9999 - 0) + (-1.000) = 0.78$$

2.6.2 32-bit Long Integer Format

32-bit long integer data is transmitted in two adjacent 16-bit Modbus registers as unsigned (UINT32) or signed (INT32) whole numbers. The first register contains the low-order word (lower 16 bits) and the second register contains the high order word (higher 16 bits). The low-order word always starts at an even Modbus address. The value range for unsigned data is 0 to 4,294,967,295; for signed data the range is -2,147,483,648 to 2,147,483,647.

If your Modbus driver does not support a 32-bit long integer format, you can read the two 16-bit registers separately, and then convert them into a 32-bit value as follows (using C notation):

$$\text{32-bit value} = (\text{signed short})\text{high_order_register} \times 65536L + (\text{unsigned short})\text{low_order_register}$$

Examples

1. Unsigned 32-bit Values

If you read unsigned Voltage V1 of 69,000V from registers 13952-13953, then the register readings will be as follows:

$$(13952) = 3464$$

$$(13953) = 1$$

The 32-bit value is $(1 \times 65536 + 3464) = 69000V$.

2. Signed 32-bit Values

If you read signed kW of -789kW from registers 14336-14337, then the register readings will be:

(14336) = 64747 (unsigned)

(14337) = 65535 (unsigned) or -1(signed value).

To take the high order register as a signed value, compare it with 32767. If the value is less or equal to 32767, use it as is. If it is greater than 32767, then this is a negative number in a two's complement code (like in our example) – just subtract it from 65536 to get the original negative value.

The 32-bit reading is $(-1 \times 65536 + 64747) = -789\text{kW}$.

Fractional 32-bit data is transmitted using decimal scaling to pass fractional numbers in integer format. Fractional numbers are pre-multiplied by 10 to the power N, where N is the number of digits in the fractional part. For example, the frequency reading of 50.01 Hz is transmitted as 5001, having been pre-multiplied by 100.

Whenever a data register contains a fractional number, the register measurement unit is given with a multiplier $\times 0.1$, $\times 0.01$ or $\times 0.001$, showing the weight of the least significant decimal digit. To get an actual fractional number with specified precision, multiply the register value by the given multiplier. To write a fractional number into the register, divide the number by the given multiplier.

2.6.3 32-bit Modulo-10000 Format

Energy counters 287-294 and 301-302 are read in two contiguous 16-bit registers in a modulo-10000 format. The first (low order) register contains the value mod 10000, and the second (high order) register contains the value/10000. To get the true energy reading, the high order register value should be multiplied by 10,000 and added to the low order register.

2.7 User Assignable Registers

EM235/PM335 PRO provides 120 user assignable registers in the address range of 0 to 119. You can re-map any register available in the device to any assignable register so that Modbus registers that reside at different locations may be simply accessed using a single request by re-mapping them to adjacent addresses.

The actual addresses of the assignable registers, which are accessed via addresses 0 through 119, are specified in the register map (registers 120 through 239), where register 120 contains the actual address of the register accessed via register 0, register 121 contains the actual address of the register accessed via register 1, and so on. The assignable registers and the map registers themselves may not be re-mapped.

Initially these registers are reserved and none of them points to an actual register address. To build your own register map, write to map registers 120 to 239 the actual addresses you want to read from or write to via the assignable area (registers 0 to 119). 32-bit long registers should always be aligned at even addresses. For example, to read registers 4672 (1-second V1 voltage, scaled short integer) and 14720-14721 (kWh Import, long integer) via registers 0-2, do the following:

- write 14720 to register 120
- write 14721 to register 121
- write 4672 to register 122

Reading from registers 0-2 will return the kWh reading in registers 0 (low 16 bits) and 1 (high 16 bits), and the voltage reading in register 2.

2.8 Password Protection

EM235/PM335 PRO has a password protection for setups, cumulative registers and log files from being changed or cleared via communications. Refer to EM235/PM335 EM235/PM335 PRO Operation Manual for details.

A user password must be written into the 32-bit device authorization register (44378-44379) before another write request is issued. If the correct password is not supplied, the meter will respond to all write requests directed to the meter setup and reset registers with the exception code 01 (illegal operation). It is recommended to clear the authorization register after you have completed your changes in order to activate password protection.

2.9 Data Recording and File Transfers

2.9.1 Log File Organization

Historical files are stored in flash memory. Memory space is allocated for each file statically when you set up your files and will not change unless you re-organize files.

Data records in a file are arranged in the order of their recording. Each record has a unique 16-bit sequence number that is incremented modulo 65536 with each new record. The sequence number can be used to point to a particular record in the file, or to check the sequence of records when uploading files from the device.

Each file has a write position pointer that indicates the place where the next record will be recorded, and a read position pointer that indicates the place from where the current record will be read. Both pointers show sequence numbers of the records they point to rather than record offsets in the file.

After acknowledging a record you have read, the read pointer automatically advances to the next record in the file. When the read pointer gets to the record to which the file write pointer points, the end-of-file (EOF) flag is set. It is automatically cleared when a new record is added to the file, or when you explicitly move the read pointer to any record within a file.

If a file has a wrap-around attribute (circular file), the most recent records can overwrite the oldest records. When this happens at the current read position, the read pointer automatically advances forward in order to point to the oldest record in the file.

EM235/PM335 PRO keeps a separate read pointer for each communication port so that access to the same file through a different port will not affect current active sessions for other ports.

Multi-section Files

Log files can have one or more (up to 32) sections for multi-channel recording. An ordinal file consists of a single section. Some files, such as TOU profile log files and waveform log files, are arranged as multi-section files.

A multi-section file is subdivided into multiple sections of the same structure, one section per recording channel. The number of sections in each file is defined at the time you set up your files and may not change unless you re-organize the file. Sections within a multi-section file can be addressed by a section number, or by a section channel ID.

A multi-section file has a single write position pointer for all sections and stores data in all sections simultaneously. This means that records with the same sequence number in all sections are associated with the same event. A multi-section file has also a single read position pointer for all sections.

Data Log Files

Conventional data log files can store up to 16 measured parameters per a record. Any data measured by the device can be stored in the log file. The number of parameters that each record will hold and the list of parameters you want to be recorded in the file can be selected through the Data log setup registers for a particular file.

Recording data to data log files can be triggered through the setpoints, either on a time basis, or upon any event detected by the setpoints.

TOU Profile Log Files

Data log files #15 and #16 can be configured for monthly and daily profile logs of the energy usage and maximum demand registers. A profile log file is organized as a multi-section file that has a separate section for each energy and maximum demand register. See Section 3.18 for more information on the file record structure. A file record stores all tariff data for each configured Billing/TOU register.

The number of sections is taken automatically from the Billing/TOU Registers setup. In order to correctly allocate memory space, configure your TOU registers before you set up TOU profile files.

Since each Billing/TOU energy register has a shadow maximum demand register, the number of sections in the file will be twice the number of the allocated Billing/TOU registers.

Power Quality Statistics Log Files

Data log files #9 and #10 are configured to store the power quality statistics data on a daily or weekly basis. They are organized as multi-section files. See Sections 3.10-3.17 for more information on the file record structure. You can review the list of parameters recorded to the files through the file info request/response blocks using info requests with variation 2 (see Section 3.9).

Waveform Log Files

Waveform log files are organized as multi-section files that store data for each recording channel in a separate section. A waveform log file can record up to 11 channels simultaneously: eight AC channels (four voltages and four currents), and 3x16 digital inputs DI1:16, DI17:32, DI33:48 that are recorded as three 16-bit analog channels. In devices with a fast AI option, a file can additionally record 16 analog input channels.

The number of sections, or channels, that a file can store, is defined in the file setup. The waveform log setup allows selecting channels that a file will record. All selected channels are recorded in successive file sections.

A waveform file has a single read pointer for all sections, so that data from all channels of a single record can be read together without repositioning the file pointer. When you point to a particular file record, data from all sections related to the same event are all available for a read. Moreover, EM235/PM335 PRO takes all channel data for the currently accessed record to a separate buffer, so that even when the record is overwritten at the time of reading, you are still prevented from receiving partially updated data. You can also read a file in a common sequential manner section-by-section.

A single waveform record for a channel can contain up to 512 points of the sampled input signal. DI and AI channels are sampled at different rates than AC channels and may contain fewer points than the corresponding AC records. Refer to the sampling rate field in the channel records to correctly set up the time scale for the DI and AI waveforms. If the record contains less than 512 points, the value of unused points is unpredictable.

If a waveform log is configured to record more samples per event than a single record can hold, the waveform recorder will store as many records per event as required to record the entire event. All waveform records related to the event are merged in a series and have the same series number, so that they can all be plotted together. Each record within a series has a unique serial number that allows tracking the sequence of records in the series. A single waveform series can hold up to 347,136 points (10,848 cycles at a rate of 32 samples per cycle) of a sampled AC signal.

2.9.2 File Transfers

File transfer protocol provides both data transfer and information services. File transfer is performed through two blocks of registers: a 32-word master request block and a 1792-word read-only file response block. After a master application has written the request into the file request block, the requested data is available for a read through the file response block registers. File transfer functions allow changing the file or section position in order to point to the desired record.

The information service uses separate 8-word file info request and 200-word file info response blocks. The extended file information is available including current file pointers' positions, file contents, the number of records in the file, allocated file size, time of file creation, time of the last file update and reset, and more.

Common File Transfer

Log files can be read either in a sequence record-by-record, or in a random order. Each Read-File request fills the file response block with the data of the record pointed to by the file (or section) read pointer. If you want to begin reading a file from a particular record, which sequence number is known, you can change the pointer position by issuing the Set-File-Position request with the desired sequence number. If you want to read a file from the beginning, send the Reset-File-Position request that moves the pointer to the oldest file record. If you do not change the file position, then you will continue reading the file from the record following the one you have read the last time you accessed the file.

You need not explicitly move the file position to the following record if you want to continue reading a file in sequence after you have uploaded the current record. Instead, issue an acknowledgment request that automatically advances the file pointer to the next record, and then read the record data through the file response block.

The file response block can contain more than one record. The number of records available in the block and the file record size in words are always reported in the block heading. There are no special rules on how to read records from the file transfer block. You can read a single record or all records together, or begin reading from the last record and end with the first record. However, you should remember: 1) after an acknowledgment, the file position moves to the record following the last one you have accessed in the file transfer block; and 2) data in the file transfer block does not change until you either issue an acknowledgment, or explicitly change the file position by the Set-File-Position or Reset-File-Position requests.

The file transfer is completed after you have read the last record of the file. Before storing a file record to your database, always check bit 9 in the record status word, which contains the end-of-file (EOF) flag. This bit set to 1 indicates that the file read pointer does not point to any record within the file, and you should not store any record that has this bit set. The EOF flag is set only after you have acknowledged the last record of the file, so that testing for end-of-file requires one extra read. If you wish to stop the transfer just after storing the last file record, acknowledge the record and check bit 0 in the record status word. Bit 0 is set to 1 only once when you read the last record of the file.

The following gives a summary of steps you should do to read an ordinal log file:

1. If you want to begin reading a file from a particular record or from the first record, use either the Set-File-Position request with the desired record sequence number, or the Reset-File-Position request. Preset a section number and channel ID to zero.
2. Write the Read-File request with a section number and channel ID set to zero.
3. Read the record data from the file response block.
4. Write an acknowledgment for the file. You need not fill all the request fields: only the file function is required. The file pointer will be moved to the next file record.

Repeat steps 3-4 until all the file records are read.

Reading Multi-section Data Log Files

In a multi-section data log file, all user requests including an acknowledgment, the Read-File, Set-File-Position and Reset-File-Position requests, relate to a particular file section rather than to the file itself. The only request that affects the entire file is the Erase-File that clears all the file sections together.

A file section can be requested either by a section number, or by a section channel ID. If you use a channel ID, preset the section number field to 0xFFFF. If a section number is specified, the channel ID field will not be checked. The device returns both fields in the response block heading, so you can always identify what channel data is being read from the present file section. If you want to know which channels are recorded to the file sections, check the file channel mask in the file info block. This is a bitmap that contains one in a bit position if a channel with an ID equal to the bit number is recorded to the file, and contains zero if it is not.

The following gives a summary of steps for reading a multi-section data log file:

1. If you wish to begin reading a file section from a particular record or from the first record, use either the Set-File-Position request with the desired record sequence number, or the Reset-File-Position request. Specify either a section number, or the channel ID for the section from where you want to read data. If you use a channel ID, preset the section number field to 0xFFFF.
2. Write the Read-File request with the section number and channel ID as shown in the previous step.
3. Read the record data from the file response block.
4. Write an acknowledgment for the file. The file section pointer will be moved to the next record.

Repeat steps 3-4 until all the section records are read.

Reading Multi-section Waveform Files

Waveform files can be read as conventional multi-section files in the order described above. Another way is to take advantage of the fact that waveform files have a single read pointer for all file sections, so you can read records of all the channels related to the same event at once without repositioning the file pointer. The following gives a summary of steps for reading waveform files:

1. If you want to begin reading a file from a particular record or from the first record, use either the Set-File-Position request with the desired record sequence number, or the Reset-File-Position request. Preset the section field to zero.
2. Write the Read-File request. Address your request to the first file section (its number is always zero), or to the first file channel (if you know channel's ID). If you use a channel ID, preset the section number field to 0xFFFF.
3. Read the channel's data from the file response block. Store the received record's sequence number.
4. Write the Read-File request for the next file section or channel using the stored record sequence number. The file response block will be refilled with the data for the requested channel that is related to the record with the same sequence number.
5. Repeat steps 3, 4 until all the channel records with the current sequence number are read.
6. Write an acknowledgment. The file pointer will be moved to the next record.

Repeat steps 2-6 until all the file records are read.

Reading Real-time Waveforms

Real-time waveforms are accessed through the same transfer blocks just like the waveform log files by addressing file 128. Writing the Read-File request for file 128 provides a simultaneous capture of 6 real-time waveform records – three voltage and three current waveforms – into a communication buffer that can be read through the common file response block. The following gives a summary of steps for reading real-time waveforms:

1. Write the Read-File request for file 128. Address you request to the first file section (its number is always zero), or to the first file channel (if you know channel's ID). If you use a channel ID, preset the section number field to 0xFFFF.
2. Read the channel's data from the file response block.
3. Write the Read-File request for the next file section or channel. The file response block will be refilled with the data for the requested channel.
4. Repeat steps 3, 4 until all the channel records are read.

Write an acknowledgment to release the buffer.

2.10 TCP Notification Client

The TCP notification client can establish connections with a remote Modbus/TCP server and send notification messages either on events, or periodically on a time basis.

Notification messages are sent via a block of 24 Modbus registers using write function 16. The following table shows the message exchange structure.

| Modbus Register Offset | Description | Type | Comment |
|------------------------|--|--------|--|
| +0-1 | Device serial number | UINT32 | |
| +2-4 | Device MAC address | CHAR6 | |
| +5 | Device address | UINT16 | 1 for Ethernet, COM5 port address for GPRS |
| +6-7 | Device IP address | UINT32 | Network byte order |
| +8 | Event type | UINT16 | See F22 in Section 5 |
| +9 | Event sequence number | UINT16 | |
| +10-11 | Start event timestamp, seconds | UINT32 | Local time since Jan 1, 1970 |
| +12-13 | Start event timestamp, seconds fraction, in microseconds | UINT32 | |
| +14-15 | End event timestamp, seconds | UINT32 | Local time since Jan 1, 1970 |
| +16-17 | End event timestamp, seconds fraction, in microseconds | UINT32 | |
| +18 | Not used | UINT16 | Written as 0 |
| +19 | Critical trigger ID | UINT16 | See Table below |
| +20-21 | Critical trigger value | UINT32 | See Table below |
| +22-23 | Reserved | UINT32 | Written as 0 |

The reported trigger type and value depend on the event source and are described in the following table.

| Event Source | Trigger Type | Trigger Value |
|-----------------|---|---|
| Setpoint events | Critical Setpoint trigger caused Setpoint operation or release (see F12 in Section 5) | Trigger entering or return value |
| PQ events | PQ event trigger. For 15olyphaser events, the worst phase is reported (see Generic Data in Section 3.4) | Maximum fault magnitude on the reported phase |
| Fault events | Current phase with highest recorded fault current (see Generic Data in Section 3.4) | Maximum fault current magnitude on the reported phase |

After receiving a write acknowledgement from a server, a TCP connection is still open for 10 seconds (20 seconds via GPRS) to give the server an opportunity to access meter registers through an open socket. It may help you access the meter from outside your local network when the server is located on another network, or when using wireless GPRS communications. The notification client will respond to all server requests as if it were a regular incoming connection.

In case a client connection is not used for following data transfers, it is recommended for the server to close the connection immediately after sending a write acknowledgement; otherwise there will be a 10-second delay before the next notification may be sent.

If there is no activity on the connection socket, it will be closed in 10 seconds. In the event a connection attempt was unsuccessful, the notification client retries two more times before announcing a connection failure.

The server's IP address, port number and starting Modbus register address are programmable in the meter. To configure and enable the notification client in your meter via PAS, select Communication Setup in the Meter Setup menu, and click on the TCP Notification Client Setup tab.

Client connections are triggered via programmable setpoints. To send event notifications to a server, configure a Setpoint to respond to desired triggers or to periodic time events and add the "Send notification" action to the end of the Setpoint actions list.

Setpoint operation events triggered by regular analog and digital triggers are reported twice – when the event starts and when it ends, except of the pulsed events and time triggers that will be reported once. In the start notification message, the event end timestamp is zeroed, and the critical trigger value indicates its entering value, while the second notification message gives both the event start and end time and shows the trigger return value.

In case of triggering notifications with events generated by the PQ and Fault recorders, like the PQ EVENT, FAULT EVENT, EXTERNAL TRIGGER or FAULT DETECTED triggers, the recorded power quality or/and corresponding fault events are reported instead of Setpoint-triggered notifications. Notification messages contain the fault event start and end time, a critical phase and the maximum fault magnitude on the reported phase. If regular triggers are added to the Setpoint triggers list, then the Setpoint operation events will also be reported.

Chapter 3 Modbus Register Map

3.1 Modbus Setup Registers

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|------------------------------------|----------|--------------------------------|--|-------|--------|-----|-------|
| Modbus Assignable Registers | | | | | | | |
| 0-119 | | | | | | | |
| +0 | | Register 0 contents | 0-65535 | | UINT16 | R/W | |
| +1 | | Register 1 contents | 0-65535 | | UINT16 | R/W | |
| | | ... | | | | | |
| +119 | | Register 119 contents | 0-65535 | | UINT16 | R/W | |
| Assignable Registers Map | | | | | | | |
| 120-239 | | | | | | | |
| +0 | | Register 0 address | 0-65535 | | UINT16 | R/W | |
| +1 | | Register 1 address | 0-65535 | | UINT16 | R/W | |
| | | | | | | | |
| +119 | | Register 119 address | 0-65535 | | UINT16 | R/W | |
| Modbus Conversion Scales | | | | | | | |
| 240 | | Low raw scale | 0-65535 (default 0) | | UINT16 | R/W | |
| 241 | | High raw scale | 1023-65535 (default 9999) | | UINT16 | R/W | |
| 242 | | Voltage scale, secondary volts | 60-828 (default 828V) | 1V | UINT16 | R/W | |
| 243 | | Current scale, secondary amps | 10-200 (default CT secondary current x Current Overload) | ×0.1A | UINT16 | R/W | |

3.2 16-bit Scaled Analog Values – Basic Register Set

| Address | Point ID | Description | Low and High Scales ² | Units ² | Type | R/W | Notes |
|---------|----------|---|-------------------------------------|--------------------|--------|-----|------------------|
| 256-308 | | 1-Second Values | | | | | |
| +0 | 0x1100 | V1/V12 voltage | 0-Vmax | U1 | UINT16 | R | 1, DC-applicable |
| +1 | 0x1101 | V2/V23 voltage | 0-Vmax | U1 | UINT16 | R | 1, DC-applicable |
| +2 | 0x1102 | V3/V31 voltage | 0-Vmax | U1 | UINT16 | R | 1, DC-applicable |
| +3 | 0x1103 | I1 current | 0-I _{max} | U2 | UINT16 | R | DC-applicable |
| +4 | 0x1104 | I2 current | 0-I _{max} | U2 | UINT16 | R | DC-applicable |
| +5 | 0x1105 | I3 current | 0-I _{max} | U2 | UINT16 | R | DC-applicable |
| +6 | 0x1106 | kW L1 | -P _{max} -P _{max} | U3 | INT16 | R | DC-applicable |
| +7 | 0x1107 | kW L2 | -P _{max} -P _{max} | U3 | INT16 | R | DC-applicable |
| +8 | 0x1108 | kW L3 | -P _{max} -P _{max} | U3 | INT16 | R | DC-applicable |
| +9 | 0x1109 | kvar L1 | -P _{max} -P _{max} | U3 | INT16 | R | |
| +10 | 0x110A | kvar L2 | -P _{max} -P _{max} | U3 | INT16 | R | |
| +11 | 0x110B | kvar L3 | -P _{max} -P _{max} | U3 | INT16 | R | |
| +12 | 0x110C | kVA L1 | -P _{max} -P _{max} | U3 | UINT16 | R | |
| +13 | 0x110D | kVA L2 | -P _{max} -P _{max} | U3 | UINT16 | R | |
| +14 | 0x110E | kVA L3 | -P _{max} -P _{max} | U3 | UINT16 | R | |
| +15 | 0x110F | Power factor L1 | -1.000-1.000 | 0.001 | INT16 | R | |
| +16 | 0x1110 | Power factor L2 | -1.000-1.000 | 0.001 | INT16 | R | |
| +17 | 0x1111 | Power factor L3 | -1.000-1.000 | 0.001 | INT16 | R | |
| +18 | 0x1403 | Total PF | -1.000-1.000 | 0.001 | INT16 | R | |
| +19 | 0x1400 | Total kW | -P _{max} -P _{max} | U3 | INT16 | R | |
| +20 | 0x1401 | Total kvar | -P _{max} -P _{max} | U3 | INT16 | R | |
| +21 | 0x1402 | Total kVA | -P _{max} -P _{max} | U3 | UINT16 | R | |
| +22 | 0x1501 | In current | 0-I _{max} | U2 | UINT16 | R | |
| +23 | 0x1502 | Frequency | 45.00-65.00 | 0.01Hz | UINT16 | R | |
| +24 | 0x3709 | Maximum kW import sliding window demand | -P _{max} -P _{max} | U3 | UINT16 | R | |
| +25 | 0x160F | kW import accumulated demand | -P _{max} -P _{max} | U3 | UINT16 | R | |

| Address | Point ID | Description | Low and High Scales ² | Units ² | Type | R/W | Notes |
|---------|----------|---|----------------------------------|--------------------|--------|-----|------------------|
| +26 | 0x370B | Maximum kVA sliding window demand | -Pmax-Pmax | U3 | UINT16 | R | |
| +27 | 0x1611 | kVA accumulated demand | -Pmax-Pmax | U3 | UINT16 | R | |
| +28 | 0x3703 | I1 Maximum ampere demand | 0-I _{max} | U2 | UINT16 | R | |
| +29 | 0x3704 | I2 Maximum ampere demand | 0-I _{max} | U2 | UINT16 | R | |
| +30 | 0x3705 | I3 Maximum ampere demand | 0-I _{max} | U2 | UINT16 | R | |
| +31 | | kWh import (low) | 0-9999 | U5 | UINT16 | R | 6, DC-applicable |
| +32 | | kWh import (high) | 0-9999 | U5×10,000 | UINT16 | R | 6, DC-applicable |
| +33 | | kWh export (low) | 0-9999 | U5 | UINT16 | R | 6, DC-applicable |
| +34 | | kWh export (high) | 0-9999 | U5×10,000 | UINT16 | R | 6, DC-applicable |
| +35 | | +kvarh net (low) | 0-9999 | U5 | UINT16 | R | 4, 6 |
| +36 | | +kvarh net (high) | 0-9999 | U5×10,000 | UINT16 | R | 4, 6 |
| +37 | | -kvarh net (low) | 0-9999 | U5 | UINT16 | R | 5, 6 |
| +38 | | -kvarh net (high) | 0-9999 | U5×10,000 | UINT16 | R | 5, 6 |
| +39 | 0x1112 | V1/V12 voltage THD | 0-999.9 | 0.1% | UINT16 | R | 3, DC-applicable |
| +40 | 0x1113 | V2/V23 voltage THD | 0-999.9 | 0.1% | UINT16 | R | 3, DC-applicable |
| +41 | 0x1114 | V3/V31 voltage THD | 0-999.9 | 0.1% | UINT16 | R | 3, DC-applicable |
| +42 | 0x1115 | I1 current THD | 0-999.9 | 0.1% | UINT16 | R | 3, DC-applicable |
| +43 | 0x1116 | I2 current THD | 0-999.9 | 0.1% | UINT16 | R | 3, DC-applicable |
| +44 | 0x1117 | I3 current THD | 0-999.9 | 0.1% | UINT16 | R | 3, DC-applicable |
| +45 | | kVAh (low) | 0-9999 | U5 | UINT16 | R | 6 |
| +46 | | kVAh (high) | 0-9999 | U5×10,000 | UINT16 | R | 6 |
| +47 | 0x1609 | Present kW import sliding window demand | -Pmax-Pmax | U3 | UINT16 | R | DC-applicable |
| +48 | 0x160B | Present kVA sliding window demand | -Pmax-Pmax | U3 | UINT16 | R | |
| +49 | 0x1615 | PF (import) at Max. kVA sliding window demand | 0-1.000 | 0.001 | UINT16 | R | |
| +50 | 0x111B | I1 current TDD | 0-100.0 | 0.1% | UINT16 | R | 3 |
| +51 | 0x111C | I2 current TDD | 0-100.0 | 0.1% | UINT16 | R | 3 |
| +52 | 0x111D | I3 current TDD | 0-100.0 | 0.1% | UINT16 | R | 3 |

NOTES:

¹When the 4LN3, 3LN3 or 3BLN3 wiring mode is selected, the voltages will be line-to-neutral; for any other wiring mode, they will be line-to-line voltages.

²For volts, amps and power scales refer to Chapter 4 "Data Scales and Units".

³On a 3-s interval.

⁴Positive readings of kvarh net

⁵Negative readings of kvarh net

⁶If you use these energy registers instead of 32-bit registers, limit the energy roll value to 8 digits (see Advanced Device Setup) to avoid early overflow.

3.3 16-bit Scaled Analog Values

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-----------|----------|-------------------------|----------------------------------|--------------------|--------|-----|------------------|
| 4320-4344 | | 1/2-Cycle Values | | | | | |
| +0 | 0x0B80 | V1 voltage | 0-Vmax | U1 | UINT16 | R | 1, DC-applicable |
| +1 | 0x0B81 | V2 voltage | 0-Vmax | U1 | UINT16 | R | 1, DC-applicable |
| +2 | 0x0B82 | V3 voltage | 0-Vmax | U1 | UINT16 | R | 1, DC-applicable |
| +3 | 0x0B83 | Not used | 0 | 0 | UINT16 | R | |
| +4 | 0x0B84 | V12 voltage | 0-Vmax | U1 | UINT16 | R | |
| +5 | 0x0B85 | V23 voltage | 0-Vmax | U1 | UINT16 | R | |
| +6 | 0x0B86 | V31 voltage | 0-Vmax | U1 | UINT16 | R | |
| +7 | 0x0B87 | I1 current | 0-I _{max} | U2 | UINT16 | R | DC-applicable |
| +8 | 0x0B88 | I2 current | 0-I _{max} | U2 | UINT16 | R | DC-applicable |
| +9 | 0x0B89 | I3 current | 0-I _{max} | U2 | UINT16 | R | DC-applicable |
| +10 | 0x0B8A | I4 current | 0-I _{4max} | U2 | UINT16 | R | DC-applicable |
| +11 | 0x0B8B | I _n current | 0-I _{max} | U2 | UINT16 | R | |
| +12 | 0x0B97 | Not used | 0 | 0 | UINT16 | R | |
| +13 | 0x0B97 | Not used | 0 | 0 | UINT16 | R | |
| +14 | 0x0B97 | Not used | 0 | 0 | UINT16 | R | |
| +15 | 0x0B97 | Not used | 0 | 0 | UINT16 | R | |
| +16 | 0x0B97 | Not used | 0 | 0 | UINT16 | R | |
| +17 | 0x0B91 | Zero-sequence voltage | 0-Vmax | U1 | UINT16 | R | |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-----------|----------|-----------------------------|----------------------------------|--------------------|--------|-----|------------------|
| +18 | 0x0B92 | Zero-sequence current | 0-lmax | U2 | UINT16 | R | |
| +19 | 0x0B93 | Ix Zero-sequence current | 0-lxmax | U2 | UINT16 | R | |
| +20 | 0x0B94 | Voltage unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +21 | 0x0B95 | Current unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +22 | 0x0B96 | Ix current unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +23 | 0x0B97 | Not used | 0 | 0 | UINT16 | R | |
| +24 | 0x0B98 | Frequency (1-cycle) | 0-100.00 | 0.01Hz | UINT16 | R | |
| +25 | 0x0B99 | Not used | 0 | 0 | UINT16 | R | |
| +26 | 0x0B9A | Not used | 0 | 0 | UINT16 | R | |
| +27 | 0x0B9B | I leakage current | 0-lmax | U2 | UINT16 | R | |
| 4352-4387 | | 1-Cycle Phase Values | | | | | |
| +0 | 0x0C00 | V1 voltage | 0-Vmax | U1 | UINT16 | R | 1, DC-applicable |
| +1 | 0x0C01 | V2 voltage | 0-Vmax | U1 | UINT16 | R | 1, DC-applicable |
| +2 | 0x0C02 | V3 voltage | 0-Vmax | U1 | UINT16 | R | 1, DC-applicable |
| +3 | 0x0C03 | I1 current | 0-lmax | U2 | UINT16 | R | DC-applicable |
| +4 | 0x0C04 | I2 current | 0-lmax | U2 | UINT16 | R | DC-applicable |
| +5 | 0x0C05 | I3 current | 0-lmax | U2 | UINT16 | R | DC-applicable |
| +6 | 0x0C06 | kW L1 | -Pmax-Pmax | U3 | INT16 | R | DC-applicable |
| +7 | 0x0C07 | kW L2 | -Pmax-Pmax | U3 | INT16 | R | DC-applicable |
| +8 | 0x0C08 | kW L3 | -Pmax-Pmax | U3 | INT16 | R | DC-applicable |
| +9 | 0x0C09 | kvar L1 | -Pmax-Pmax | U3 | INT16 | R | |
| +10 | 0x0C0A | kvar L2 | -Pmax-Pmax | U3 | INT16 | R | |
| +11 | 0x0C0B | kvar L3 | -Pmax-Pmax | U3 | INT16 | R | |
| +12 | 0x0C0C | kVA L1 | 0-Pmax | U3 | UINT16 | R | |
| +13 | 0x0C0D | kVA L2 | 0-Pmax | U3 | UINT16 | R | |
| +14 | 0x0C0E | kVA L3 | 0-Pmax | U3 | UINT16 | R | |
| +15 | 0x0C0F | Power factor L1 | -1.000-1.000 | 0.001 | INT16 | R | |
| +16 | 0x0C10 | Power factor L2 | -1.000-1.000 | 0.001 | INT16 | R | |
| +17 | 0x0C11 | Power factor L3 | -1.000-1.000 | 0.001 | INT16 | R | |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-----------|----------|---------------------------------|-------------------------------------|--------------------|--------|-----|---------------|
| +18 | 0x0C12 | V1 voltage THD | 0-999.9 | 0.1% | UINT16 | R | 2, 4 |
| +19 | 0x0C13 | V2 voltage THD | 0-999.9 | 0.1% | UINT16 | R | 2, 4 |
| +20 | 0x0C14 | V3 voltage THD | 0-999.9 | 0.1% | UINT16 | R | 2, 4 |
| +21 | 0x0C15 | I1 current THD | 0-999.9 | 0.1% | UINT16 | R | 4 |
| +22 | 0x0C16 | I2 current THD | 0-999.9 | 0.1% | UINT16 | R | 4 |
| +23 | 0x0C17 | I3 current THD | 0-999.9 | 0.1% | UINT16 | R | 4 |
| +24 | 0x0C18 | I1 K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | 4 |
| +25 | 0x0C19 | I2 K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | 4 |
| +26 | 0x0C1A | I3 K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | 4 |
| +27 | 0x0C1B | I1 current TDD | 0-100.0 | 0.1% | UINT16 | R | 4 |
| +28 | 0x0C1C | I2 current TDD | 0-100.0 | 0.1% | UINT16 | R | 4 |
| +29 | 0x0C1D | I3 current TDD | 0-100.0 | 0.1% | UINT16 | R | 4 |
| +30 | 0x0C1E | V12 voltage | 0-Vmax | U1 | UINT16 | R | |
| +31 | 0x0C1F | V23 voltage | 0-Vmax | U1 | UINT16 | R | |
| +32 | 0x0C20 | V31 voltage | 0-Vmax | U1 | UINT16 | R | |
| +33 | 0x0C21 | Not used | 0 | 0 | UINT16 | R | |
| +34 | 0x0C22 | Not used | 0 | 0 | UINT16 | R | |
| +35 | 0x0C23 | Not used | 0 | 0 | UINT16 | R | |
| 4416-4429 | | 1-Cycle Low Phase Values | | | | | |
| +0 | 0x0D00 | Low L-N voltage | 0-Vmax | U1 | UINT16 | R | |
| +1 | 0x0D01 | Low current | 0-I _{max} | U2 | UINT16 | R | |
| +2 | 0x0D02 | Low kW | -P _{max} -P _{max} | U3 | INT16 | R | DC-applicable |
| +3 | 0x0D03 | Low kvar | -P _{max} -P _{max} | U3 | INT16 | R | |
| +4 | 0x0D04 | Low kVA | 0-P _{max} | U3 | UINT16 | R | |
| +5 | 0x0D05 | Low PF Lag | 0-1.000 | 0.001 | UINT16 | R | |
| +6 | 0x0D06 | Low PF Lead | 0-1.000 | 0.001 | UINT16 | R | |
| +7 | 0x0D07 | Low voltage THD | 0-999.9 | 0.1% | UINT16 | R | 2, 4 |
| +8 | 0x0D08 | Low current THD | 0-999.9 | 0.1% | UINT16 | R | 4 |
| +9 | 0x0D09 | Low K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | 4 |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-----------|----------|----------------------------------|----------------------------------|--------------------|--------|-----|---------------|
| +10 | 0x0D0A | Low current TDD | 0-100.0 | 0.1% | UINT16 | R | 4 |
| +11 | 0x0D0B | Low L-L voltage | 0-Vmax | U1 | UINT16 | R | |
| +12 | 0x0D0C | Low voltage interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | 2, 4 |
| +13 | 0x0D0D | Low current interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | 4 |
| 4448-4463 | | 1/2-Cycle Analog Inputs | | | | | |
| +0 | 0x0D80 | Analog input AI1 | AI1min-AI1max | | UINT16 | R | |
| +1 | 0x0D81 | Analog input AI2 | AI2min-AI2max | | UINT16 | R | |
| | | ... | | | | | |
| +15 | 0x0D8F | Analog input AI16 | AI16min-AI16max | | UINT16 | R | |
| 4480-4493 | | 1-Cycle High Phase Values | | | | | |
| +0 | 0x0E00 | High L-N voltage | 0-Vmax | U1 | UINT16 | R | |
| +1 | 0x0E01 | High current | 0-Imax | U2 | UINT16 | R | |
| +2 | 0x0E02 | High kW | -Pmax-Pmax | U3 | INT16 | R | DC-applicable |
| +3 | 0x0E03 | High kvar | -Pmax-Pmax | U3 | INT16 | R | |
| +4 | 0x0E04 | High kVA | 0-Pmax | U3 | UINT16 | R | |
| +5 | 0x0E05 | High PF Lag | 0-1.000 | 0.001 | UINT16 | R | |
| +6 | 0x0E06 | High PF Lead | 0-1.000 | 0.001 | UINT16 | R | |
| +7 | 0x0E07 | High voltage THD | 0-999.9 | 0.1% | UINT16 | R | 2, 4 |
| +8 | 0x0E08 | High current THD | 0-999.9 | 0.1% | UINT16 | R | 4 |
| +9 | 0x0E09 | High K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | 4 |
| +10 | 0x0E0A | High current TDD | 0-100.0 | 0.1% | UINT16 | R | 4 |
| +11 | 0x0E0B | High L-L voltage | 0-Vmax | U1 | UINT16 | R | |
| +12 | 0x0E0C | High voltage interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | 2, 4 |
| +13 | 0x0E0D | High current interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | 4 |
| 4512-4527 | | 1-Second Analog Inputs | | | | | |
| +0 | 0x0E80 | Analog input AI1 | AI1min-AI1max | | UINT16 | R | |
| +1 | 0x0E81 | Analog input AI2 | AI2min-AI2max | | UINT16 | R | |
| | | ... | | | | | |
| +15 | 0x0E8F | Analog input AI16 | AI16min-AI16max | | UINT16 | R | |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-----------|----------|--------------------------------------|----------------------------------|--------------------|--------|-----|---------------|
| 4544-4557 | | 1-Cycle Total Values | | | | | |
| +0 | 0x0F00 | Total kW | -Pmax-Pmax | U3 | INT16 | R | DC-applicable |
| +1 | 0x0F01 | Total kvar | -Pmax-Pmax | U3 | INT16 | R | |
| +2 | 0x0F02 | Total kVA | 0-Pmax | U3 | UINT16 | R | |
| +3 | 0x0F03 | Total PF | -1.000-1.000 | 0.001 | INT16 | R | |
| +4 | 0x0F04 | Total PF lag | 0-1.000 | 0.001 | UINT16 | R | |
| +5 | 0x0F05 | Total PF lead | 0-1.000 | 0.001 | UINT16 | | |
| +6 | 0x0F06 | Total kW import | 0-Pmax | U3 | UINT16 | | DC-applicable |
| +7 | 0x0F07 | Total kW export | 0-Pmax | U3 | UINT16 | R | DC-applicable |
| +8 | 0x0F08 | Total kvar import | 0-Pmax | U3 | UINT16 | R | |
| +9 | 0x0F09 | Total kvar export | 0-Pmax | U3 | UINT16 | R | |
| +10 | 0x0F0A | 3-phase average L-N voltage | 0-Vmax | U1 | UINT16 | R | |
| +11 | 0x0F0B | 3-phase average L-L voltage | 0-Vmax | U1 | UINT16 | R | |
| +12 | 0x0F0C | 3-phase average current | 0-Imax | U2 | UINT16 | R | |
| +13 | 0x0F0D | Not used | 0 | 0 | UINT16 | R | |
| 4608-4616 | | 1-Cycle Auxiliary Values | | | | | |
| +0 | 0x1000 | I4 current | 0-I4max | U2 | UINT16 | R | DC-applicable |
| +1 | 0x1001 | In current | 0-Imax | U2 | UINT16 | R | |
| +2 | 0x1002 | Frequency | 0-100.00 | 0.01Hz | UINT16 | R | |
| +3 | 0x1003 | Voltage unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +4 | 0x1004 | Current unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +5 | 0x1005 | Not used | | | UINT16 | R | |
| +6 | 0x1006 | Not used | 0 | 0 | UINT16 | R | |
| +7 | 0x1007 | Not used | 0 | 0 | UINT16 | R | |
| +8 | 0x1008 | Frequency (3 decimals) | 0-100.000 | 0.001Hz | UINT16 | R | |
| +9 | 0x1009 | I leakage current | 0-Imax | U2 | UINT16 | R | |
| +10 | 0x100A | Frequency over 4 cycles (3 decimals) | 0-100.000 | 0.001Hz | UINT16 | R | |
| 4640-4663 | | Fundamental Phasor Values | | | | | |
| +0 | 0x1080 | V1 voltage magnitude | 0-Vmax | U1 | UINT16 | R | 2 |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-----------|----------|------------------------------|----------------------------------|--------------------|--------|-----|------------------|
| +1 | 0x1081 | V2 voltage magnitude | 0-Vmax | U1 | UINT16 | R | 2 |
| +2 | 0x1082 | V3 voltage magnitude | 0-Vmax | U1 | UINT16 | R | 2 |
| +3 | 0x1083 | Not used | 0 | 0 | UINT16 | R | |
| +4 | 0x1084 | I1 current magnitude | 0-Imax | U2 | UINT16 | R | |
| +5 | 0x1085 | I2 current magnitude | 0-Imax | U2 | UINT16 | R | |
| +6 | 0x1086 | I3 current magnitude | 0-Imax | U2 | UINT16 | R | |
| +7 | 0x1087 | I4 current magnitude | 0-Imax | U2 | UINT16 | R | |
| +8 | 0x1088 | V1 voltage angle | -180.0-180.0 | 0.1° | INT16 | R | 2 |
| +9 | 0x1089 | V2 voltage angle | -180.0-180.0 | 0.1° | INT16 | R | 2 |
| +10 | 0x108A | V3 voltage angle | -180.0-180.0 | 0.1° | INT16 | R | 2 |
| +11 | 0x108B | Not used | 0 | 0 | UINT16 | R | |
| +12 | 0x108C | I1 current angle | -180.0-180.0 | 0.1° | INT16 | R | |
| +13 | 0x108D | I2 current angle | -180.0-180.0 | 0.1° | INT16 | R | |
| +14 | 0x108E | I3 current angle | -180.0-180.0 | 0.1° | INT16 | R | |
| +15 | 0x108F | I4 current angle | -180.0-180.0 | 0.1° | INT16 | R | |
| +16 | 0x1090 | Not used | 0 | 0 | UINT16 | R | |
| +17 | 0x1091 | Not used | 0 | 0 | UINT16 | R | |
| +18 | 0x1092 | Not used | 0 | 0 | UINT16 | R | |
| +19 | 0x1093 | Not used | 0 | 0 | UINT16 | R | |
| +20 | 0x1094 | Not used | 0 | 0 | UINT16 | R | |
| +21 | 0x1095 | Not used | 0 | 0 | UINT16 | R | |
| +22 | 0x1096 | Not used | 0 | 0 | UINT16 | R | |
| +23 | 0x1097 | Not used | 0 | 0 | UINT16 | R | |
| 4672-4710 | | 1-Second Phase Values | | | | | |
| +0 | 0x1100 | V1 voltage | 0-Vmax | U1 | UINT16 | R | 1, DC-applicable |
| +1 | 0x1101 | V2 voltage | 0-Vmax | U1 | UINT16 | R | 1, DC-applicable |
| +2 | 0x1102 | V3 voltage | 0-Vmax | U1 | UINT16 | R | 1, DC-applicable |
| +3 | 0x1103 | I1 current | 0-Imax | U2 | UINT16 | R | DC-applicable |
| +4 | 0x1104 | I2 current | 0-Imax | U2 | UINT16 | R | DC-applicable |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|---------|----------|-----------------|-------------------------------------|--------------------|--------|-----|---------------|
| +5 | 0x1105 | I3 current | 0-I _{max} | U2 | UINT16 | R | DC-applicable |
| +6 | 0x1106 | kW L1 | -P _{max} -P _{max} | U3 | INT16 | R | DC-applicable |
| +7 | 0x1107 | kW L2 | -P _{max} -P _{max} | U3 | INT16 | R | DC-applicable |
| +8 | 0x1108 | kW L3 | -P _{max} -P _{max} | U3 | INT16 | R | DC-applicable |
| +9 | 0x1109 | kvar L1 | -P _{max} -P _{max} | U3 | INT16 | R | |
| +10 | 0x110A | kvar L2 | -P _{max} -P _{max} | U3 | INT16 | R | |
| +11 | 0x110B | kvar L3 | -P _{max} -P _{max} | U3 | INT16 | R | |
| +12 | 0x110C | kVA L1 | 0-P _{max} | U3 | UINT16 | R | |
| +13 | 0x110D | kVA L2 | 0-P _{max} | U3 | UINT16 | R | |
| +14 | 0x110E | kVA L3 | 0-P _{max} | U3 | UINT16 | R | |
| +15 | 0x110F | Power factor L1 | -1.000-1.000 | 0.001 | INT16 | R | |
| +16 | 0x1110 | Power factor L2 | -1.000-1.000 | 0.001 | INT16 | R | |
| +17 | 0x1111 | Power factor L3 | -1.000-1.000 | 0.001 | INT16 | R | |
| +18 | 0x1112 | V1 voltage THD | 0-999.9 | 0.1% | UINT16 | R | 2, 5 |
| +19 | 0x1113 | V2 voltage THD | 0-999.9 | 0.1% | UINT16 | R | 2, 5 |
| +20 | 0x1114 | V3 voltage THD | 0-999.9 | 0.1% | UINT16 | R | 2, 5 |
| +21 | 0x1115 | I1 current THD | 0-999.9 | 0.1% | UINT16 | R | 5 |
| +22 | 0x1116 | I2 current THD | 0-999.9 | 0.1% | UINT16 | R | 5 |
| +23 | 0x1117 | I3 current THD | 0-999.9 | 0.1% | UINT16 | R | 5 |
| +24 | 0x1118 | I1 K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | 5 |
| +25 | 0x1119 | I2 K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | 5 |
| +26 | 0x111A | I3 K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | 5 |
| +27 | 0x111B | I1 current TDD | 0-100.0 | 0.1% | UINT16 | R | 5 |
| +28 | 0x111C | I2 current TDD | 0-100.0 | 0.1% | UINT16 | R | 5 |
| +29 | 0x111D | I3 current TDD | 0-100.0 | 0.1% | UINT16 | R | 5 |
| +30 | 0x111E | V12 voltage | 0-V _{max} | U1 | UINT16 | R | |
| +31 | 0x111F | V23 voltage | 0-V _{max} | U1 | UINT16 | R | |
| +32 | 0x1120 | V31 voltage | 0-V _{max} | U1 | UINT16 | R | |
| +33 | 0x1121 | Not used | 0 | 0 | UINT16 | R | |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-----------|----------|----------------------------------|----------------------------------|--------------------|--------|-----|---------------|
| +34 | 0x1122 | Not used | 0 | 0 | UINT16 | R | |
| +35 | 0x1123 | Not used | 0 | 0 | UINT16 | R | |
| +36 | 0x1124 | Not used | 0 | 0 | UINT16 | R | |
| +37 | 0x1125 | Not used | 0 | 0 | UINT16 | R | |
| +38 | 0x1126 | Not used | 0 | 0 | UINT16 | R | |
| 4736-4749 | | 1-Second Low Phase Values | | | | | |
| +0 | 0x1200 | Low L-N voltage | 0-Vmax | U1 | UINT16 | R | |
| +1 | 0x1201 | Low current | 0-Imax | U2 | UINT16 | R | |
| +2 | 0x1202 | Low kW | -Pmax-Pmax | U3 | INT16 | R | DC-applicable |
| +3 | 0x1203 | Low kvar | -Pmax-Pmax | U3 | INT16 | R | |
| +4 | 0x1204 | Low kVA | 0-Pmax | U3 | UINT16 | R | |
| +5 | 0x1205 | Low PF Lag | 0-1.000 | 0.001 | UINT16 | R | |
| +6 | 0x1206 | Low PF Lead | 0-1.000 | 0.001 | UINT16 | R | |
| +7 | 0x1207 | Low voltage THD | 0-999.9 | 0.1% | UINT16 | R | 2, 5 |
| +8 | 0x1208 | Low current THD | 0-999.9 | 0.1% | UINT16 | R | 5 |
| +9 | 0x1209 | Low K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | 5 |
| +10 | 0x120A | Low current TDD | 0-100.0 | 0.1% | UINT16 | R | 5 |
| +11 | 0x120B | Low L-L voltage | 0-Vmax | U1 | UINT16 | R | |
| +12 | 0x120C | Low voltage interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | 2, 5 |
| +13 | 0x120D | Low current interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | 5 |
| 4768-4783 | | 3-Second Powers | | | | | |
| +0 | 0x1280 | kW L1 | -Pmax-Pmax | U3 | INT16 | R | DC-applicable |
| +1 | 0x1281 | kW L2 | -Pmax-Pmax | U3 | INT16 | R | DC-applicable |
| +2 | 0x1282 | kW L3 | -Pmax-Pmax | U3 | INT16 | R | DC-applicable |
| +3 | 0x1283 | kvar L1 | -Pmax-Pmax | U3 | INT16 | R | |
| +4 | 0x1284 | kvar L2 | -Pmax-Pmax | U3 | INT16 | R | |
| +5 | 0x1285 | kvar L3 | -Pmax-Pmax | U3 | INT16 | R | |
| +6 | 0x1286 | kVA L1 | 0-Pmax | U3 | UINT16 | R | |
| +7 | 0x1287 | kVA L2 | 0-Pmax | U3 | UINT16 | R | |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-----------|----------|-----------------------------------|----------------------------------|--------------------|--------|-----|---------------|
| +8 | 0x1288 | kVA L3 | 0-Pmax | U3 | UINT16 | R | |
| +9 | 0x1289 | Power factor L1 | -1.000-1.000 | 0.001 | INT16 | R | |
| +10 | 0x128A | Power factor L2 | -1.000-1.000 | 0.001 | INT16 | R | |
| +11 | 0x128B | Power factor L3 | -1.000-1.000 | 0.001 | INT16 | R | |
| +12 | 0x128C | Total kW | -Pmax-Pmax | U3 | INT16 | R | DC-applicable |
| +13 | 0x128D | Total kvar | -Pmax-Pmax | U3 | INT16 | R | |
| +14 | 0x128E | Total kVA | 0-Pmax | U3 | UINT16 | R | |
| +15 | 0x128F | Total PF | -1.000-1.000 | 0.001 | INT16 | R | |
| 4800-4813 | | 1-Second High Phase Values | | | | | |
| +0 | 0x1300 | High L-N voltage | 0-Vmax | U1 | UINT16 | R | |
| +1 | 0x1301 | High current | 0-Imax | U2 | UINT16 | R | |
| +2 | 0x1302 | High kW | -Pmax-Pmax | U3 | INT16 | R | DC-applicable |
| +3 | 0x1303 | High kvar | -Pmax-Pmax | U3 | INT16 | R | |
| +4 | 0x1304 | High kVA | 0-Pmax | U3 | UINT16 | R | |
| +5 | 0x1305 | High PF Lag | 0-1.000 | 0.001 | UINT16 | R | |
| +6 | 0x1306 | High PF Lead | 0-1.000 | 0.001 | UINT16 | R | |
| +7 | 0x1307 | High voltage THD | 0-999.9 | 0.1% | UINT16 | R | 2, 5 |
| +8 | 0x1308 | High current THD | 0-999.9 | 0.1% | UINT16 | R | 5 |
| +9 | 0x1309 | High K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | 5 |
| +10 | 0x130A | High current TDD | 0-100.0 | 0.1% | UINT16 | R | 5 |
| +11 | 0x130B | High L-L voltage | 0-Vmax | U1 | UINT16 | R | |
| +12 | 0x130C | High voltage interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | 2, 5 |
| +13 | 0x130D | High current interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | 5 |
| 4864-4877 | | 1-Second Total Values | | | | | |
| +0 | 0x1400 | Total kW | -Pmax-Pmax | U3 | INT16 | R | DC-applicable |
| +1 | 0x1401 | Total kvar | -Pmax-Pmax | U3 | INT16 | R | |
| +2 | 0x1402 | Total kVA | 0-Pmax | U3 | UINT16 | R | |
| +3 | 0x1403 | Total PF | -1.000-1.000 | 0.001 | INT16 | R | |
| +4 | 0x1404 | Total PF lag | 0-1.000 | 0.001 | UINT16 | R | |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-----------|----------|----------------------------------|----------------------------------|--------------------|--------|-----|---------------|
| +5 | 0x1405 | Total PF lead | 0-1.000 | 0.001 | UINT16 | | |
| +6 | 0x1406 | Total kW import | 0-Pmax | U3 | UINT16 | | DC-applicable |
| +7 | 0x1407 | Total kW export | 0-Pmax | U3 | UINT16 | R | DC-applicable |
| +8 | 0x1408 | Total kvar import | 0-Pmax | U3 | UINT16 | R | |
| +9 | 0x1409 | Total kvar export | 0-Pmax | U3 | UINT16 | R | |
| +10 | 0x140A | 3-phase average L-N voltage | 0-Vmax | U1 | UINT16 | R | |
| +11 | 0x140B | 3-phase average L-L voltage | 0-Vmax | U1 | UINT16 | R | |
| +12 | 0x140C | 3-phase average current | 0-Imax | U2 | UINT16 | R | |
| +13 | 0x140D | Not used | 0 | 0 | UINT16 | R | |
| 4928-4938 | | 1-Second Auxiliary Values | | | | | |
| +0 | 0x1500 | I4 current | 0-I4max | U2 | UINT16 | R | DC-applicable |
| +1 | 0x1501 | In current | 0-Imax | U2 | UINT16 | R | |
| +2 | 0x1502 | Frequency | 0-100.00 | 0.01Hz | UINT16 | R | |
| +3 | 0x1503 | Voltage unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +4 | 0x1504 | Current unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +5 | 0x1505 | Not used | | | UINT16 | R | |
| +6 | 0x1506 | Not used | 0 | 0 | UINT16 | R | |
| +7 | 0x1507 | Not used | 0 | 0 | UINT16 | R | |
| +8 | 0x1508 | Not used | 0 | 0 | UINT16 | R | |
| +9 | 0x1509 | Internal temperature | -200.0 to 200.0 | 0.1°C | UINT16 | R | |
| +10 | 0x150A | Frequency (3 decimals) | 0-100.000 | 0.001Hz | UINT16 | R | |
| +11 | 0x150B | Vbatt | 0-3.5V | 0.001V | UINT16 | R | |
| +12 | 0x150C | Internal temperature | -200.0 to 200.0 | 0.1°C | UINT16 | R | |
| +13 | 0x150D | Frequency (4 decimals) | 0-100.000 | 0.0001Hz | UINT16 | R | |
| +14 | 0x150E | I leakage current | 0-Imax | U2 | UINT16 | R | |
| +15 | 0x150F | V3xI4kW | -Pmax-Pmax | U3 | INT16 | R | DC-applicable |
| 4960-4971 | | Present Harmonic Demands | | | | | |
| +0 | 0x1580 | V1 THD demand | 0-999.9 | 0.1% | UINT16 | R | 2 |
| +1 | 0x1581 | V2 THD demand | 0-999.9 | 0.1% | UINT16 | R | 2 |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-----------|----------|-----------------------------------|----------------------------------|--------------------|--------|-----|------------------|
| +2 | 0x1582 | V3 THD demand | 0-999.9 | 0.1% | UINT16 | R | 2 |
| +3 | 0x1583 | Not used | 0 | 0 | UINT16 | R | |
| +4 | 0x1584 | I1 THD demand | 0-999.9 | 0.1% | UINT16 | R | |
| +5 | 0x1585 | I2 THD demand | 0-999.9 | 0.1% | UINT16 | R | |
| +6 | 0x1586 | I3 THD demand | 0-999.9 | 0.1% | UINT16 | R | |
| +7 | 0x1587 | I4 THD demand | 0-999.9 | 0.1% | UINT16 | R | |
| +8 | 0x1588 | I1 TDD demand | 0-100.0 | 0.1% | UINT16 | R | |
| +9 | 0x1589 | I2 TDD demand | 0-100.0 | 0.1% | UINT16 | R | |
| +10 | 0x158A | I3 TDD demand | 0-100.0 | 0.1% | UINT16 | R | |
| +11 | 0x158B | I4 TDD demand | 0-100.0 | 0.1% | UINT16 | R | |
| 4992-5026 | | Present Demands | | | | | |
| +0 | 0x1600 | V1 Volt demand | 0-Vmax | U1 | UINT16 | R | 2, DC-applicable |
| +1 | 0x1601 | V2 Volt demand | 0-Vmax | U1 | UINT16 | R | 2, DC-applicable |
| +2 | 0x1602 | V3 Volt demand | 0-Vmax | U1 | UINT16 | R | 2, DC-applicable |
| +3 | 0x1603 | I1 Ampere demand | 0-Imax | U2 | UINT16 | R | DC-applicable |
| +4 | 0x1604 | I2 Ampere demand | 0-Imax | U2 | UINT16 | R | DC-applicable |
| +5 | 0x1605 | I3 Ampere demand | 0-Imax | U2 | UINT16 | R | DC-applicable |
| +6 | 0x1606 | kW import block demand | 0-Pmax | U3 | UINT16 | R | DC-applicable |
| +7 | 0x1607 | kvar import block demand | 0-Pmax | U3 | UINT16 | R | |
| +8 | 0x1608 | kVA block demand | 0-Pmax | U3 | UINT16 | R | |
| +9 | 0x1609 | kW import sliding window demand | 0-Pmax | U3 | UINT16 | R | DC-applicable |
| +10 | 0x160A | kvar import sliding window demand | 0-Pmax | U3 | UINT16 | R | |
| +11 | 0x160B | kVA sliding window demand | 0-Pmax | U3 | UINT16 | R | |
| +12 | 0x160C | Not used | 0 | | UINT16 | R | |
| +13 | 0x160D | Not used | 0 | | UINT16 | R | |
| +14 | 0x160E | Not used | 0 | | UINT16 | R | |
| +15 | 0x160F | kW import accumulated demand | 0-Pmax | U3 | UINT16 | R | DC-applicable |
| +16 | 0x1610 | kvar import accumulated demand | 0-Pmax | U3 | UINT16 | R | |
| +17 | 0x1611 | kVA accumulated demand | 0-Pmax | U3 | UINT16 | R | |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-----------|----------|---|----------------------------------|--------------------|--------|-----|---------------|
| +18 | 0x1612 | kW import predicted sliding window demand | 0-Pmax | U3 | UINT16 | R | DC-applicable |
| +19 | 0x1613 | kvar import predicted sliding window demand | 0-Pmax | U3 | UINT16 | R | |
| +20 | 0x1614 | kVA predicted sliding window demand | 0-Pmax | U3 | UINT16 | R | |
| +21 | 0x1615 | PF (import) at Max. kVA sliding window demand | 0-1.000 | 0.001 | UINT16 | R | |
| +22 | 0x1616 | kW export block demand | 0-Pmax | U3 | UINT16 | R | DC-applicable |
| +23 | 0x1617 | kvar export block demand | 0-Pmax | U3 | UINT16 | R | |
| +24 | 0x1618 | kW export sliding window demand | 0-Pmax | U3 | UINT16 | R | DC-applicable |
| +25 | 0x1619 | kvar export sliding window demand | 0-Pmax | U3 | UINT16 | R | |
| +26 | 0x161A | kW export accumulated demand | 0-Pmax | U3 | UINT16 | R | DC-applicable |
| +27 | 0x161B | kvar export accumulated demand | 0-Pmax | U3 | UINT16 | R | |
| +28 | 0x161C | kW export predicted sliding window demand | 0-Pmax | U3 | UINT16 | R | DC-applicable |
| +29 | 0x161D | kvar export predicted sliding window demand | 0-Pmax | U3 | UINT16 | R | |
| +30 | 0x161E | Not used | 0 | | UINT16 | R | |
| +31 | 0x161F | Not used | 0 | | UINT16 | R | |
| +32 | 0x1620 | Not used | 0 | 0 | UINT16 | R | |
| +33 | 0x1621 | I4 ampere demand | 0-I _{max} | U2 | UINT16 | R | DC-applicable |
| +34 | 0x1622 | I _n ampere demand | 0-I _{max} | U2 | UINT16 | R | |
| 5152-5161 | | Symmetrical Components | | | | | |
| +0 | 0x1880 | Positive-sequence voltage | 0-V _{max} | U1 | UINT16 | R | |
| +1 | 0x1881 | Negative-sequence voltage | 0-V _{max} | U1 | UINT16 | R | |
| +2 | 0x1882 | Zero-sequence voltage | 0-V _{max} | U1 | UINT16 | R | |
| +3 | 0x1883 | Negative-sequence voltage unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +4 | 0x1884 | Zero-sequence voltage unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +5 | 0x1885 | Positive-sequence current | 0-I _{max} | U2 | UINT16 | R | |
| +6 | 0x1886 | Negative-sequence current | 0-I _{max} | U2 | UINT16 | R | |
| +7 | 0x1887 | Zero-sequence current | 0-I _{max} | U2 | UINT16 | R | |
| +8 | 0x1888 | Negative-sequence current unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +9 | 0x1889 | Zero-sequence current unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| 5184-5246 | | V1 Harmonics | | | | | 2, 7 |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-----------|----------|------------------------|----------------------------------|--------------------|--------|-----|-------|
| +0 | 0x1900 | H01 Harmonic magnitude | 0-100.00 | 0.01% | UINT16 | R | |
| +1 | 0x1901 | H02 Harmonic magnitude | 0-100.00 | 0.01% | UINT16 | R | |
| | | ... | | | | | |
| +62 | 0x193E | H63 Harmonic magnitude | 0-100.00 | 0.01% | UINT16 | R | |
| 5248-5310 | | V2 Harmonics | | | | | 2, 7 |
| +0 | 0x1A00 | H01 Harmonic magnitude | 0-100.00 | 0.01% | UINT16 | R | |
| +1 | 0x1A01 | H02 Harmonic magnitude | 0-100.00 | 0.01% | UINT16 | R | |
| | | ... | | | | | |
| +62 | 0x1A3E | H63 Harmonic magnitude | 0-100.00 | 0.01% | UINT16 | R | |
| 5312-5374 | | V3 Harmonics | | | | | 2, 7 |
| +0 | 0x1B00 | H01 Harmonic magnitude | 0-100.00 | 0.01% | UINT16 | R | |
| +1 | 0x1B01 | H02 Harmonic magnitude | 0-100.00 | 0.01% | UINT16 | R | |
| | | ... | | | | | |
| +62 | 0x1B3E | H63 Harmonic magnitude | 0-100.00 | 0.01% | UINT16 | R | |
| 6144-6206 | | Not used | 0 | 0 | UINT16 | R | 7 |
| +0 | 0x2800 | Not used | 0 | 0 | UINT16 | R | |
| +1 | 0x2801 | Not used | 0 | 0 | UINT16 | R | |
| | | ... | | | | | |
| +62 | 0x283E | Not used | 0 | 0 | UINT16 | R | |
| 5376-5438 | | I1 Harmonics | | | | | 7 |
| +0 | 0x1C00 | H01 Harmonic magnitude | 0-100.00 | 0.01% | UINT16 | R | |
| +1 | 0x1C01 | H02 Harmonic magnitude | 0-100.00 | 0.01% | UINT16 | R | |
| | | ... | | | | | |
| +62 | 0x1C3E | H63 Harmonic magnitude | 0-100.00 | 0.01% | UINT16 | R | |
| 5440-5502 | | I2 Harmonics | | | | | 7 |
| +0 | 0x1D00 | H01 Harmonic magnitude | 0-100.00 | 0.01% | UINT16 | R | |
| +1 | 0x1D01 | H02 Harmonic magnitude | 0-100.00 | 0.01% | UINT16 | R | |
| | | ... | | | | | |
| +62 | 0x1D3E | H63 Harmonic magnitude | 0-100.00 | 0.01% | UINT16 | R | |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-----------|----------|---|----------------------------------|--------------------|--------|-----|-------|
| 5504-5566 | | I3 Harmonics | | | | | 7 |
| +0 | 0x1E00 | H01 Harmonic magnitude | 0-100.00 | 0.01% | UINT16 | R | |
| +1 | 0x1E01 | H02 Harmonic magnitude | 0-100.00 | 0.01% | UINT16 | R | |
| | | ... | | | | | |
| +62 | 0x1E3E | H63 Harmonic magnitude | 0-100.00 | 0.01% | UINT16 | R | |
| 6336-6398 | | I4 Harmonics | | | | | 7 |
| +0 | 0x2B00 | H01 Harmonic magnitude | 0-100.00 | 0.01% | UINT16 | R | |
| +1 | 0x2B01 | H02 Harmonic magnitude | 0-100.00 | 0.01% | UINT16 | R | |
| | | ... | | | | | |
| +62 | 0x2B3E | H63 Harmonic magnitude | 0-100.00 | 0.01% | UINT16 | R | |
| 5568-5599 | | V1 Harmonic Voltages (odd harmonics) | | | | | 2 |
| +0 | 0x1F00 | H01 Harmonic voltage | 0-Vmax | U1 | UINT16 | R | |
| +1 | 0x1F01 | H03 Harmonic voltage | 0-Vmax | U1 | UINT16 | R | |
| | | ... | | | | | |
| +31 | 0x1F1E | H63 Harmonic voltage | 0-Vmax | U1 | UINT16 | R | |
| 5632-5663 | | V2 Harmonic Voltages (odd harmonics) | | | | | 2 |
| +0 | 0x2000 | H01 Harmonic voltage | 0-Vmax | U1 | UINT16 | R | |
| +1 | 0x2001 | H03 Harmonic voltage | 0-Vmax | U1 | UINT16 | R | |
| | | ... | | | | | |
| +31 | 0x201E | H63 Harmonic voltage | 0-Vmax | U1 | UINT16 | R | |
| 5696-5727 | | V3 Harmonic Voltages (odd harmonics) | | | | | 2 |
| +0 | 0x2100 | H01 Harmonic voltage | 0-Vmax | U1 | UINT16 | R | |
| +1 | 0x2101 | H03 Harmonic voltage | 0-Vmax | U1 | UINT16 | R | |
| | | ... | | | | | |
| +31 | 0x211E | H63 Harmonic voltage | 0-Vmax | U1 | UINT16 | R | |
| 6720-6751 | | Not used | 0 | 0 | UINT16 | R | |
| +0 | 0x3100 | Not used | 0 | 0 | UINT16 | R | |
| +1 | 0x3101 | Not used | 0 | 0 | UINT16 | R | |
| | | ... | | | | | |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-----------|----------|---|----------------------------------|--------------------|--------|-----|-------|
| +62 | 0x311E | Not used | 0 | 0 | UINT16 | R | |
| 5760-5791 | | I1 Harmonic Currents (odd harmonics) | | | | | |
| +0 | 0x2200 | H01 Harmonic current | 0-lmax | U2 | UINT16 | R | |
| +1 | 0x2201 | H03 Harmonic current | 0-lmax | U2 | UINT16 | R | |
| | | ... | | | | | |
| +31 | 0x221E | H63 Harmonic current | 0-lmax | U2 | UINT16 | R | |
| 5824-5855 | | I2 Harmonic Currents (odd harmonics) | | | | | |
| +0 | 0x2300 | H01 Harmonic current | 0-lmax | U2 | UINT16 | R | |
| +1 | 0x2301 | H03 Harmonic current | 0-lmax | U2 | UINT16 | R | |
| | | ... | | | | | |
| +31 | 0x231E | H63 Harmonic current | 0-lmax | U2 | UINT16 | R | |
| 5888-5919 | | I3 Harmonic Currents (odd harmonics) | | | | | |
| +0 | 0x2400 | H01 Harmonic current | 0-lmax | U2 | UINT16 | R | |
| +1 | 0x2401 | H03 Harmonic current | 0-lmax | U2 | UINT16 | R | |
| | | ... | | | | | |
| +31 | 0x241E | H63 Harmonic current | 0-lmax | U2 | UINT16 | R | |
| 6784-6815 | | I4 Harmonic Currents (odd harmonics) | | | | | |
| +0 | 0x3200 | H01 Harmonic current | 0-lmax | U2 | UINT16 | R | |
| +1 | 0x3201 | H03 Harmonic current | 0-lmax | U2 | UINT16 | R | |
| | | ... | | | | | |
| +31 | 0x321E | H63 Harmonic current | 0-lmax | U2 | UINT16 | R | |
| 5952-5983 | | Total Harmonic kW (odd harmonics) | | | | | |
| +0 | 0x2500 | H01 Harmonic kW | -Pmax –Pmax | U3 | INT16 | R | |
| +1 | 0x2501 | H03 Harmonic kW | -Pmax –Pmax | U3 | INT16 | R | |
| | | ... | | | | | |
| +31 | 0x251E | H63 Harmonic kW | -Pmax –Pmax | U3 | INT16 | R | |
| 6016-6047 | | Total Harmonic kvar (odd harmonics) | | | | | |
| +0 | 0x2600 | H01 Harmonic kvar | -Pmax –Pmax | U3 | INT16 | R | |
| +1 | 0x2601 | H03 Harmonic kvar | -Pmax –Pmax | U3 | INT16 | R | |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-----------|----------|--|----------------------------------|--------------------|--------|-----|------------------|
| | | ... | | | | | |
| +31 | 0x261E | H63 Harmonic kvar | -Pmax -Pmax | U3 | INT16 | R | |
| 6080-6111 | | Total Harmonic Power Factor (odd harmonics) | | | | | |
| +0 | 0x2700 | H01 Harmonic PF | -1.000-1.000 | 0.001 | INT16 | R | |
| +1 | 0x2701 | H03 Harmonic PF | -1.000-1.000 | 0.001 | INT16 | R | |
| | | ... | | | | | |
| +31 | 0x271E | H63 Harmonic PF | -1.000-1.000 | 0.001 | INT16 | R | |
| 6240-6245 | | Not used | 0 | 0 | UINT16 | R | Phase II |
| +0 | 0x2980 | Not used | 0 | 0 | UINT16 | R | 2 |
| +1 | 0x2981 | Not used | 0 | 0 | UINT16 | R | 2 |
| +2 | 0x2982 | Not used | 0 | 0 | UINT16 | R | 2 |
| +3 | 0x2983 | Not used | 0 | 0 | UINT16 | R | 2 |
| +4 | 0x2984 | Not used | 0 | 0 | UINT16 | R | 2 |
| +5 | 0x2985 | Not used | 0 | 0 | UINT16 | R | 2 |
| 6400-6435 | | Minimum 1-Cycle Phase Values | | | | | |
| +0 | 0x2C00 | V1 voltage | 0-Vmax | U1 | UINT16 | R | 1, DC-applicable |
| +1 | 0x2C01 | V2 voltage | 0-Vmax | U1 | UINT16 | R | 1, DC-applicable |
| +2 | 0x2C02 | V3 voltage | 0-Vmax | U1 | UINT16 | R | 1, DC-applicable |
| +3 | 0x2C03 | I1 current | 0-Imax | U2 | UINT16 | R | DC-applicable |
| +4 | 0x2C04 | I2 current | 0-Imax | U2 | UINT16 | R | DC-applicable |
| +5 | 0x2C05 | I3 current | 0-Imax | U2 | UINT16 | R | DC-applicable |
| +6 | 0x2C06 | kW L1 | -Pmax-Pmax | U3 | INT16 | R | DC-applicable |
| +7 | 0x2C07 | kW L2 | -Pmax-Pmax | U3 | INT16 | R | DC-applicable |
| +8 | 0x2C08 | kW L3 | -Pmax-Pmax | U3 | INT16 | R | DC-applicable |
| +9 | 0x2C09 | kvar L1 | -Pmax-Pmax | U3 | INT16 | R | |
| +10 | 0x2C0A | kvar L2 | -Pmax-Pmax | U3 | INT16 | R | |
| +11 | 0x2C0B | kvar L3 | -Pmax-Pmax | U3 | INT16 | R | |
| +12 | 0x2C0C | kVA L1 | 0-Pmax | U3 | UINT16 | R | |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-----------|----------|-------------------------------------|----------------------------------|--------------------|--------|-----|----------------|
| +13 | 0x2C0D | kVA L2 | 0-Pmax | U3 | UINT16 | R | |
| +14 | 0x2C0E | kVA L3 | 0-Pmax | U3 | UINT16 | R | |
| +15 | 0x2C0F | Power factor L1 | 0-1.000 | 0.001 | UINT16 | R | Absolute value |
| +16 | 0x2C10 | Power factor L2 | 0-1.000 | 0.001 | UINT16 | R | Absolute value |
| +17 | 0x2C11 | Power factor L3 | 0-1.000 | 0.001 | UINT16 | R | Absolute value |
| +18 | 0x2C12 | V1 voltage THD | 0-9999 | 0.1% | UINT16 | R | 2, 4 |
| +19 | 0x2C13 | V2 voltage THD | 0-9999 | 0.1% | UINT16 | R | 2, 4 |
| +20 | 0x2C14 | V3 voltage THD | 0-999.9 | 0.1% | UINT16 | R | 2, 4 |
| +21 | 0x2C15 | I1 current THD | 0-999.9 | 0.1% | UINT16 | R | 4 |
| +22 | 0x2C16 | I2 current THD | 0-999.9 | 0.1% | UINT16 | R | 4 |
| +23 | 0x2C17 | I3 current THD | 0-999.9 | 0.1% | UINT16 | R | 4 |
| +24 | 0x2C18 | I1 K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | 4 |
| +25 | 0x2C19 | I2 K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | 4 |
| +26 | 0x2C1A | I3 K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | 4 |
| +27 | 0x2C1B | I1 current TDD | 0-100.0 | 0.1% | UINT16 | R | 4 |
| +28 | 0x2C1C | I2 current TDD | 0-100.0 | 0.1% | UINT16 | R | 4 |
| +29 | 0x2C1D | I3 current TDD | 0-100.0 | 0.1% | UINT16 | R | 4 |
| +30 | 0x2C1E | V12 voltage | 0-Vmax | U1 | UINT16 | R | |
| +31 | 0x2C1F | V23 voltage | 0-Vmax | U1 | UINT16 | R | |
| +32 | 0x2C20 | V31 voltage | 0-Vmax | U1 | UINT16 | R | |
| +33 | 0x2C21 | Not used | 0 | 0 | UINT16 | R | |
| +34 | 0x2C22 | Not used | 0 | 0 | UINT16 | R | |
| +35 | 0x2C23 | Not used | 0 | 0 | UINT16 | R | |
| 6464-6469 | | Minimum 1-Cycle Total Values | | | | | |
| +0 | 0x2D00 | Total kW | -Pmax-Pmax | U3 | INT16 | R | DC-applicable |
| +1 | 0x2D01 | Total kvar | -Pmax-Pmax | U3 | INT16 | R | |
| +2 | 0x2D02 | Total kVA | 0-Pmax | U3 | UINT16 | R | |
| +3 | 0x2D03 | Total PF | 0-1.000 | 0.001 | UINT16 | R | Absolute value |
| +4 | 0x2D04 | Total PF lag | 0-1.000 | 0.001 | UINT16 | R | |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-----------|----------|--|----------------------------------|--------------------|--------|-----|------------------|
| +5 | 0x2D05 | Total PF lead | 0-1.000 | 0.001 | UINT16 | R | |
| 6528-6538 | | Minimum 1-Cycle Auxiliary Values | | | | | |
| +0 | 0x2E00 | I4 current | 0-I4max | U2 | UINT16 | R | DC-applicable |
| +1 | 0x2E01 | In current | 0-Imax | U2 | UINT16 | R | |
| +2 | 0x2E02 | Frequency | 0-100.00 | 0.01Hz | UINT16 | R | |
| +3 | 0x2E03 | Voltage unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +4 | 0x2E04 | Current unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +5 | 0x2E05 | Not used | | | UINT16 | R | |
| +6 | 0x2E06 | Not used | 0 | 0 | UINT16 | R | |
| +7 | 0x2E07 | Not used | 0 | 0 | UINT16 | R | |
| +8 | 0x2E08 | Not used | 0 | 0 | UINT16 | R | |
| +9 | 0x2E09 | Not used | 0 | 0 | UINT16 | R | |
| +10 | 0x2E0A | Not used | 0 | 0 | UINT16 | R | |
| 6560-6575 | | Minimum Analog Inputs | | | | | |
| +0 | 0x2E80 | Analog input AI1 | AI1min-AI1max | | UINT16 | R | |
| +1 | 0x2E81 | Analog input AI2 | AI2min-AI2max | | UINT16 | R | |
| | | ... | | | | | |
| +15 | 0x2E8F | Analog input AI16 | AI16min-AI16max | | UINT16 | R | |
| 6656-6671 | | Programmable Min/Max Minimum Values | | | | | |
| +0 | 0x3000 | Min/Max Register #1 | | | UINT16 | R | |
| +1 | 0x3001 | Min/Max Register #2 | | | UINT16 | R | |
| | | ... | | | | | |
| +15 | 0x300F | Min/Max Register #16 | | | UINT16 | R | |
| 6912-6947 | | Maximum 1-Cycle Phase Values | | | | | |
| +0 | 0x3400 | V1 voltage | 0-Vmax | U1 | UINT16 | R | 1, DC-applicable |
| +1 | 0x3401 | V2 voltage | 0-Vmax | U1 | UINT16 | R | 1, DC-applicable |
| +2 | 0x3402 | V3 voltage | 0-Vmax | U1 | UINT16 | R | 1, DC-applicable |
| +3 | 0x3403 | I1 current | 0-Imax | U2 | UINT16 | R | DC-applicable |
| +4 | 0x3404 | I2 current | 0-Imax | U2 | UINT16 | R | DC-applicable |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|---------|----------|-----------------|-------------------------------------|--------------------|--------|-----|----------------|
| +5 | 0x3405 | I3 current | 0-I _{max} | U2 | UINT16 | R | DC-applicable |
| +6 | 0x3406 | kW L1 | -P _{max} -P _{max} | U3 | INT16 | R | DC-applicable |
| +7 | 0x3407 | kW L2 | -P _{max} -P _{max} | U3 | INT16 | R | DC-applicable |
| +8 | 0x3408 | kW L3 | -P _{max} -P _{max} | U3 | INT16 | R | DC-applicable |
| +9 | 0x3409 | kvar L1 | -P _{max} -P _{max} | U3 | INT16 | R | |
| +10 | 0x340A | kvar L2 | -P _{max} -P _{max} | U3 | INT16 | R | |
| +11 | 0x340B | kvar L3 | -P _{max} -P _{max} | U3 | INT16 | R | |
| +12 | 0x340C | kVA L1 | 0-P _{max} | U3 | UINT16 | R | |
| +13 | 0x340D | kVA L2 | 0-P _{max} | U3 | UINT16 | R | |
| +14 | 0x340E | kVA L3 | 0-P _{max} | U3 | UINT16 | R | |
| +15 | 0x340F | Power factor L1 | 0-1.000 | 0.001 | UINT16 | R | Absolute value |
| +16 | 0x3410 | Power factor L2 | 0-1.000 | 0.001 | UINT16 | R | Absolute value |
| +17 | 0x3411 | Power factor L3 | 0-1.000 | 0.001 | UINT16 | R | Absolute value |
| +18 | 0x3412 | V1 voltage THD | 0-999.9 | 0.1% | UINT16 | R | 2, 4 |
| +19 | 0x3413 | V2 voltage THD | 0-999.9 | 0.1% | UINT16 | R | 2, 4 |
| +20 | 0x3414 | V3 voltage THD | 0-999.9 | 0.1% | UINT16 | R | 2, 4 |
| +21 | 0x3415 | I1 current THD | 0-999.9 | 0.1% | UINT16 | R | 4 |
| +22 | 0x3416 | I2 current THD | 0-999.9 | 0.1% | UINT16 | R | 4 |
| +23 | 0x3417 | I3 current THD | 0-999.9 | 0.1% | UINT16 | R | 4 |
| +24 | 0x3418 | I1 K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | 4 |
| +25 | 0x3419 | I2 K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | 4 |
| +26 | 0x341A | I3 K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | 4 |
| +27 | 0x341B | I1 current TDD | 0-100.0 | 0.1% | UINT16 | R | 4 |
| +28 | 0x341C | I2 current TDD | 0-100.0 | 0.1% | UINT16 | R | 4 |
| +29 | 0x341D | I3 current TDD | 0-100.0 | 0.1% | UINT16 | R | 4 |
| +30 | 0x341E | V12 voltage | 0-V _{max} | U1 | UINT16 | R | |
| +31 | 0x341F | V23 voltage | 0-V _{max} | U1 | UINT16 | R | |
| +32 | 0x3420 | V31 voltage | 0-V _{max} | U1 | UINT16 | R | |
| +33 | 0x3421 | Not used | 0 | 0 | UINT16 | R | |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|------------|----------|---|----------------------------------|--------------------|--------|-----|------------------|
| +34 | 0x3422 | Not used | 0 | 0 | UINT16 | R | |
| +35 | 0x3423 | Not used | 0 | 0 | UINT16 | R | |
| 6976-6981 | | Maximum 1-Cycle Total Values | | | | | |
| +0 | 0x3500 | Total kW | -Pmax-Pmax | U3 | INT16 | R | DC-applicable |
| +1 | 0x3501 | Total kvar | -Pmax-Pmax | U3 | INT16 | R | |
| +2 | 0x3502 | Total kVA | 0-Pmax | U3 | UINT16 | R | |
| +3 | 0x3503 | Total PF | 0-1.000 | 0.001 | UINT16 | R | Absolute value |
| +4 | 0x3504 | Total PF lag | 0-1.000 | 0.001 | UINT16 | R | |
| +5 | 0x3505 | Total PF lead | 0-1.000 | 0.001 | UINT16 | R | |
| 7040-7050 | | Maximum 1-Cycle Auxiliary Values | | | | | |
| +0 | 0x3600 | I4 current | 0-I4max | U2 | UINT16 | R | DC-applicable |
| +1 | 0x3601 | In current | 0-Imax | U2 | UINT16 | R | |
| +2 | 0x3602 | Frequency | 0-100.00 | 0.01Hz | UINT16 | R | |
| +3 | 0x3603 | Voltage unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +4 | 0x3604 | Current unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +5 | 0x3605 | Not used | | | UINT16 | R | |
| +6 | 0x3606 | Not used | 0 | 0 | UINT16 | R | |
| +7 | 0x3607 | Not used | 0 | 0 | UINT16 | R | |
| +8 | 0x3608 | Not used | 0 | 0 | UINT16 | R | |
| +9 | 0x3609 | Not used | 0 | 0 | UINT16 | R | |
| +10 | 0x360A | Not used | 0 | 0 | UINT16 | R | |
| 7072-7087 | | Maximum Analog Inputs | | | | | |
| +0 | 0x3680 | Analog input AI1 | AI1min-AI1max | | UINT16 | R | |
| +1 | 0x3681 | Analog input AI2 | AI2min-AI2max | | UINT16 | R | |
| | | ... | | | | | |
| +15 | 0x368F | Analog input AI16 | AI16min-AI16max | | UINT16 | R | |
| 7104-71025 | | Maximum Demands | | | | | |
| +0 | 0x3700 | V1 Maximum volt demand | 0-Vmax | U1 | UINT16 | R | 2, DC-applicable |
| +1 | 0x3701 | V2 Maximum volt demand | 0-Vmax | U1 | UINT16 | R | 2, DC-applicable |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-----------|----------|--|----------------------------------|--------------------|--------|-----|------------------|
| +2 | 0x3702 | V3 Maximum volt demand | 0-Vmax | U1 | UINT16 | R | 2, DC-applicable |
| +3 | 0x3703 | I1 Maximum ampere demand | 0-I _{max} | U2 | UINT16 | R | DC-applicable |
| +4 | 0x3704 | I2 Maximum ampere demand | 0-I _{max} | U2 | UINT16 | R | DC-applicable |
| +5 | 0x3705 | I3 Maximum ampere demand | 0-I _{max} | U2 | UINT16 | R | DC-applicable |
| +6 | 0x3706 | Not used | 0 | | UINT16 | R | |
| +7 | 0x3707 | Not used | 0 | | UINT16 | R | |
| +8 | 0x3708 | Not used | 0 | | UINT16 | R | |
| +9 | 0x3709 | Maximum kW import sliding window demand | 0-P _{max} | U3 | UINT16 | R | DC-applicable |
| +10 | 0x370A | Maximum kvar import sliding window demand | 0-P _{max} | U3 | UINT16 | R | |
| +11 | 0x370B | Maximum kVA sliding window demand | 0-P _{max} | U3 | UINT16 | R | |
| +12 | 0x370C | Not used | 0 | | UINT16 | R | |
| +13 | 0x370D | Not used | 0 | | UINT16 | R | |
| +14 | 0x370E | Not used | 0 | | UINT16 | R | |
| +15 | 0x370F | Maximum kW export sliding window demand | 0-P _{max} | U3 | UINT16 | R | DC-applicable |
| +16 | 0x3710 | Maximum kvar export sliding window demand | 0-P _{max} | U3 | UINT16 | R | |
| +17 | 0x3711 | Not used | 0 | | UINT16 | R | |
| +18 | 0x3712 | Not used | 0 | | UINT16 | R | |
| +19 | 0x3713 | Not used | 0 | 0 | UINT16 | R | |
| +20 | 0x3714 | I4 Maximum ampere demand | 0-I _{4max} | U2 | UINT16 | R | DC-applicable |
| +21 | 0x3715 | I _n Maximum ampere demand | 0-I _{max} | U2 | UINT16 | R | |
| 7168-7183 | | Programmable Min/Max Maximum Values | | | | | |
| +0 | 0x3800 | Min/Max Register #1 | | | UINT16 | R | |
| +1 | 0x3801 | Min/Max Register #2 | | | UINT16 | R | |
| | | ... | | | | | |
| +15 | 0x380F | Min/Max Register #16 | | | UINT16 | R | |
| 7200-7211 | | Maximum Harmonic Demands | | | | | |
| +0 | 0x3880 | V1 THD demand | 0-999.9 | 0.1% | UINT16 | R | 2 |
| +1 | 0x3881 | V2 THD demand | 0-999.9 | 0.1% | UINT16 | R | 2 |
| +2 | 0x3882 | V3 THD demand | 0-999.9 | 0.1% | UINT16 | R | 2 |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-----------|----------|-------------------------------------|----------------------------------|--------------------|--------|-----|-----------------------------|
| +3 | 0x3883 | Not used | 0 | 0 | UINT16 | R | |
| +4 | 0x3884 | I1 THD demand | 0-999.9 | 0.1% | UINT16 | R | |
| +5 | 0x3885 | I2 THD demand | 0-999.9 | 0.1% | UINT16 | R | |
| +6 | 0x3886 | I3 THD demand | 0-999.9 | 0.1% | UINT16 | R | |
| +7 | 0x3887 | I4 THD demand | 0-999.9 | 0.1% | UINT16 | R | |
| +8 | 0x3888 | I1 TDD demand | 0-100.0 | 0.1% | UINT16 | R | |
| +9 | 0x3889 | I2 TDD demand | 0-100.0 | 0.1% | UINT16 | R | |
| +10 | 0x388A | I3 TDD demand | 0-100.0 | 0.1% | UINT16 | R | |
| +11 | 0x388B | I4 TDD demand | 0-100.0 | 0.1% | UINT16 | R | |
| 7232-7263 | | Maximum Analog Input Demands | | | | | |
| +0 | 0x3900 | Analog input AI1+ | AI1min-AI1max | | UINT16 | R | Positive AI readings demand |
| +1 | 0x3901 | Analog input AI2+ | AI2min-AI2max | | UINT16 | R | |
| | | ... | | | | | |
| +15 | 0x390F | Analog input AI16+ | AI16min-AI16max | | UINT16 | R | |
| +16 | 0x3910 | Analog input AI1- | AI1min-AI1max | | UINT16 | R | Negative AI readings demand |
| +17 | 0x3911 | Analog input AI2- | AI2min-AI2max | | UINT16 | R | |
| | | ... | | | | | |
| +31 | 0x391F | Analog input AI16- | AI16min-AI16max | | UINT16 | R | |
| 7296-7327 | | Present Analog Input Demands | | | | | |
| +0 | 0x3A00 | Analog input AI1+ | AI1min-AI1max | | UINT16 | R | Positive AI readings demand |
| +1 | 0x3A01 | Analog input AI2+ | AI2min-AI2max | | UINT16 | R | |
| | | ... | | | | | |
| +15 | 0x3A0F | Analog input AI16+ | AI16min-AI16max | | UINT16 | R | |
| +16 | 0x3A10 | Analog input AI1- | AI1min-AI1max | | UINT16 | R | Negative AI readings demand |
| +17 | 0x3A11 | Analog input AI2- | AI2min-AI2max | | UINT16 | R | |
| | | ... | | | | | |
| +31 | 0x3A1F | Analog input AI16- | AI16min-AI16max | | UINT16 | R | |
| 7360-7375 | | 1-Cycle Analog Inputs | | | | | |
| +0 | 0x3B00 | Analog input AI1 | AI1min-AI1max | | UINT16 | R | |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-----------|----------|---|----------------------------------|--------------------|--------|-----|-------|
| +1 | 0x3B01 | Analog input AI2 | AI2min-AI2max | | UINT16 | R | |
| | | ... | | | | | |
| +15 | 0x3B0F | Analog input AI16 | AI16min-AI16max | | UINT16 | R | |
| 7392-7407 | | Raw Analog Inputs | | | | | |
| +0 | 0x3B80 | Analog input AI1 | 0-4095 | | UINT16 | R | |
| +1 | 0x3B81 | Analog input AI2 | 0-4095 | | UINT16 | R | |
| | | ... | | | | | |
| +15 | 0x3B8F | Analog input AI16 | 0-4095 | | UINT16 | R | |
| 7456-7471 | | Scaled Analog Outputs | | | | | |
| +0 | 0x3C80 | Analog input AO1 | 0-4095 | | UINT16 | R/W | |
| +1 | 0x3C81 | Analog input AO2 | 0-4095 | | UINT16 | R/W | |
| | | ... | | | | | |
| +15 | 0x3C8F | Analog input AO16 | 0-4095 | | UINT16 | R/W | |
| 8000-8015 | | Billing Summary Accumulated Demands | | | | | |
| +0 | 0x4500 | Summary register #1 | 0-Pmax | U3 | UINT16 | R | |
| +1 | 0x4501 | Summary register #2 | 0-Pmax | U3 | UINT16 | R | |
| | | ... | | | | | |
| +15 | 0x4503 | Summary register #16 | 0-Pmax | U3 | UINT16 | R | |
| 8032-8047 | | Billing Summary Block Demands | | | | | |
| +0 | 0x4580 | Summary register #1 | 0-Pmax | U3 | UINT16 | R | |
| +1 | 0x4581 | Summary register #2 | 0-Pmax | U3 | UINT16 | R | |
| | | ... | | | | | |
| +15 | 0x4583 | Summary register #16 | 0-Pmax | U3 | UINT16 | R | |
| 8064-8079 | | Billing Summary Sliding Window Demands | | | | | |
| +0 | 0x4600 | Summary register #1 | 0-Pmax | U3 | UINT16 | R | |
| +1 | 0x4601 | Summary register #2 | 0-Pmax | U3 | UINT16 | R | |
| | | ... | | | | | |
| +15 | 0x4603 | Summary register #16 | 0-Pmax | U3 | UINT16 | R | |
| 8160-8175 | | Billing Summary Maximum Demands | | | | | |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-----------|----------|---|----------------------------------|--------------------|--------|-----|-------|
| +0 | 0x4780 | Summary register #1 | 0-Pmax | U3 | UINT16 | R | |
| +1 | 0x4781 | Summary register #2 | 0-Pmax | U3 | UINT16 | R | |
| | | ... | | | | | |
| +15 | 0x4783 | Summary register #16 | 0-Pmax | U3 | UINT16 | R | |
| 8192-8207 | | Billing TOU Maximum Demand Register #1 | | | | | |
| +0 | 0x4800 | Tariff #1 register | 0-Pmax | U3 | UINT16 | R | |
| +1 | 0x4801 | Tariff #2 register | 0-Pmax | U3 | UINT16 | R | |
| | | ... | | | | R | |
| +15 | 0x480F | Tariff #16 register | 0-Pmax | U3 | UINT16 | R | |
| 8256-8271 | | Billing TOU Maximum Demand Register #2 | | | | | |
| +0 | 0x4900 | Tariff #1 register | 0-Pmax | U3 | UINT16 | R | |
| +1 | 0x4901 | Tariff #2 register | 0-Pmax | U3 | UINT16 | R | |
| | | ... | | | | R | |
| +15 | 0x490F | Tariff #16 register | 0-Pmax | U3 | UINT16 | R | |
| 8320-8335 | | Billing TOU Maximum Demand Register #3 | | | | | |
| +0 | 0x4A00 | Tariff #1 register | 0-Pmax | U3 | UINT16 | R | |
| +1 | 0x4A01 | Tariff #2 register | 0-Pmax | U3 | UINT16 | R | |
| | | ... | | | | R | |
| +15 | 0x4A0F | Tariff #16 register | 0-Pmax | U3 | UINT16 | R | |
| 8224-8239 | | Billing TOU Maximum Demand Register #4 | | | | | |
| +0 | 0x4880 | Tariff #1 register | 0-Pmax | U3 | UINT16 | R | |
| +1 | 0x4881 | Tariff #2 register | 0-Pmax | U3 | UINT16 | R | |
| | | ... | | | | R | |
| +15 | 0x488F | Tariff #16 register | 0-Pmax | U3 | UINT16 | R | |
| 8288-8303 | | Billing TOU Maximum Demand Register #5 | | | | | |
| +0 | 0x4980 | Tariff #1 register | 0-Pmax | U3 | UINT16 | R | |
| +1 | 0x4981 | Tariff #2 register | 0-Pmax | U3 | UINT16 | R | |
| | | ... | | | | R | |
| +15 | 0x498F | Tariff #16 register | 0-Pmax | U3 | UINT16 | R | |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-----------|----------|--|----------------------------------|--------------------|--------|-----|-------|
| 8352-8367 | | Billing TOU Maximum Demand Register #6 | | | | | |
| +0 | 0x4A80 | Tariff #1 register | 0-Pmax | U3 | UINT16 | R | |
| +1 | 0x4A81 | Tariff #2 register | 0-Pmax | U3 | UINT16 | R | |
| | | ... | | | | R | |
| +15 | 0x4A8F | Tariff #16 register | 0-Pmax | U3 | UINT16 | R | |
| 8896-8911 | | Billing TOU Maximum Demand Register #7 | | | | | |
| +0 | 0x5300 | Tariff #1 register | 0-Pmax | U3 | UINT16 | R | |
| +1 | 0x5301 | Tariff #2 register | 0-Pmax | U3 | UINT16 | R | |
| | | ... | | | | R | |
| +15 | 0x530F | Tariff #16 register | 0-Pmax | U3 | UINT16 | R | |
| 8928-8943 | | Billing TOU Maximum Demand Register #8 | | | | | |
| +0 | 0x5380 | Tariff #1 register | 0-Pmax | U3 | UINT16 | R | |
| +1 | 0x5381 | Tariff #2 register | 0-Pmax | U3 | UINT16 | R | |
| | | ... | | | | R | |
| +15 | 0x538F | Tariff #16 register | 0-Pmax | U3 | UINT16 | R | |
| 8960-8975 | | Billing TOU Maximum Demand Register #9 | | | | | |
| +0 | 0x5400 | Tariff #1 register | 0-Pmax | U3 | UINT16 | R | |
| +1 | 0x5401 | Tariff #2 register | 0-Pmax | U3 | UINT16 | R | |
| | | ... | | | | R | |
| +15 | 0x540F | Tariff #16 register | 0-Pmax | U3 | UINT16 | R | |
| 8992-9007 | | Billing TOU Maximum Demand Register #10 | | | | | |
| +0 | 0x5480 | Tariff #1 register | 0-Pmax | U3 | UINT16 | R | |
| +1 | 0x5481 | Tariff #2 register | 0-Pmax | U3 | UINT16 | R | |
| | | ... | | | | R | |
| +15 | 0x548F | Tariff #16 register | 0-Pmax | U3 | UINT16 | R | |
| 9024-9039 | | Billing TOU Maximum Demand Register #11 | | | | | |
| +0 | 0x5500 | Tariff #1 register | 0-Pmax | U3 | UINT16 | R | |
| +1 | 0x5501 | Tariff #2 register | 0-Pmax | U3 | UINT16 | R | |
| | | ... | | | | R | |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|------------|----------|--|----------------------------------|--------------------|--------|-----|---------|
| +15 | 0x550F | Tariff #16 register | 0-Pmax | U3 | UINT16 | R | |
| 9056-9071 | | Billing TOU Maximum Demand Register #12 | | | | | |
| +0 | 0x5580 | Tariff #1 register | 0-Pmax | U3 | UINT16 | R | |
| +1 | 0x5581 | Tariff #2 register | 0-Pmax | U3 | UINT16 | R | |
| | | ... | | | | R | |
| +15 | 0x558F | Tariff #16 register | 0-Pmax | U3 | UINT16 | R | |
| 9088-9103 | | Billing TOU Maximum Demand Register #13 | | | | | |
| +0 | 0x5600 | Tariff #1 register | 0-Pmax | U3 | UINT16 | R | |
| +1 | 0x5601 | Tariff #2 register | 0-Pmax | U3 | UINT16 | R | |
| | | ... | | | | R | |
| +15 | 0x560F | Tariff #16 register | 0-Pmax | U3 | UINT16 | R | |
| 9120-9135 | | Billing TOU Maximum Demand Register #14 | | | | | |
| +0 | 0x5680 | Tariff #1 register | 0-Pmax | U3 | UINT16 | R | |
| +1 | 0x5681 | Tariff #2 register | 0-Pmax | U3 | UINT16 | R | |
| | | ... | | | | R | |
| +15 | 0x568F | Tariff #16 register | 0-Pmax | U3 | UINT16 | R | |
| 9152-9167 | | Billing TOU Maximum Demand Register #15 | | | | | |
| +0 | 0x5700 | Tariff #1 register | 0-Pmax | U3 | UINT16 | R | |
| +1 | 0x5701 | Tariff #2 register | 0-Pmax | U3 | UINT16 | R | |
| | | ... | | | | R | |
| +15 | 0x570F | Tariff #16 register | 0-Pmax | U3 | UINT16 | R | |
| 9184-9199 | | Billing TOU Maximum Demand Register #16 | | | | | |
| +0 | 0x5780 | Tariff #1 register | 0-Pmax | U3 | UINT16 | R | |
| +1 | 0x5781 | Tariff #2 register | 0-Pmax | U3 | UINT16 | R | |
| | | ... | | | | R | |
| +15 | 0x578F | Tariff #16 register | 0-Pmax | U3 | UINT16 | R | |
| 9984-10046 | | V1/V12 Harmonic Angles | | | | | 2, 4, 6 |
| +0 | 0x6400 | H01 Harmonic angle | -180.0-180.0 | 0.1° | INT16 | R | |
| +1 | 0x6401 | H02 Harmonic angle | -180.0-180.0 | 0.1° | INT16 | R | |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|-------------------------------|----------------------------------|--------------------|--------|-----|---------|
| | | ... | | | | | |
| +62 | 0x643E | H63 Harmonic angle | -180.0-180.0 | 0.1° | INT16 | R | |
| 10048-10110 | | V2/V23 Harmonic Angles | | | | | 2, 4, 6 |
| +0 | 0x6500 | H01 Harmonic angle | -180.0-180.0 | 0.1° | INT16 | R | |
| +1 | 0x6501 | H02 Harmonic angle | -180.0-180.0 | 0.1° | INT16 | R | |
| | | ... | | | | | |
| +62 | 0x653E | H63 Harmonic angle | -180.0-180.0 | 0.1° | INT16 | R | |
| 10112-10174 | | V3/V31 Harmonic Angles | | | | | 2, 4, 6 |
| +0 | 0x6600 | H01 Harmonic angle | -180.0-180.0 | 0.1° | INT16 | R | |
| +1 | 0x6601 | H02 Harmonic angle | -180.0-180.0 | 0.1° | INT16 | R | |
| | | ... | | | | | |
| +62 | 0x663E | H63 Harmonic angle | -180.0-180.0 | 0.1° | INT16 | R | |
| 10176-10238 | | V4 Harmonic Angles | | | | | |
| +0 | 0x6700 | Not used | 0 | 0 | UINT16 | R | |
| +1 | 0x6701 | Not used | 0 | 0 | UINT16 | R | |
| | | ... | | | | | |
| +62 | 0x673E | Not used | 0 | 0 | UINT16 | R | |
| 10240-10302 | | I1 Harmonic Angles | | | | | |
| +0 | 0x6800 | H01 Harmonic angle | -180.0-180.0 | 0.1° | INT16 | R | |
| +1 | 0x6801 | H02 Harmonic angle | -180.0-180.0 | 0.1° | INT16 | R | |
| | | ... | | | | | |
| +62 | 0x683E | H63 Harmonic angle | -180.0-180.0 | 0.1° | INT16 | R | |
| 10304-10366 | | I2 Harmonic Angles | | | | | 4, 6 |
| +0 | 0x6900 | H01 Harmonic angle | -180.0-180.0 | 0.1° | INT16 | R | |
| +1 | 0x6901 | H02 Harmonic angle | -180.0-180.0 | 0.1° | INT16 | R | |
| | | ... | | | | | |
| +62 | 0x693E | H63 Harmonic angle | -180.0-180.0 | 0.1° | INT16 | R | |
| 10368-10430 | | I3 Harmonic Angles | | | | | 4, 6 |
| +0 | 0x6A00 | H01 Harmonic angle | -180.0-180.0 | 0.1° | INT16 | R | |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|--|----------------------------------|--------------------|--------|-----|------------------|
| +1 | 0x6A01 | H02 Harmonic angle | -180.0-180.0 | 0.1° | INT16 | R | |
| | | ... | | | | | |
| +62 | 0x6A3E | H63 Harmonic angle | -180.0-180.0 | 0.1° | INT16 | R | |
| 10432-10494 | | I4 Harmonic Angles | | | | | 4, 6 |
| +0 | 0x6B00 | H01 Harmonic angle | -180.0-180.0 | 0.1° | INT16 | R | |
| +1 | 0x6B01 | H02 Harmonic angle | -180.0-180.0 | 0.1° | INT16 | R | |
| | | ... | | | | | |
| +62 | 0x6B3E | H63 Harmonic angle | -180.0-180.0 | 0.1° | INT16 | R | |
| 10496-10522 | | 0.2-Second RMS and Auxiliary Values | | | | | |
| +0 | 0x6C00 | V1 voltage | 0-Vmax | U1 | UINT16 | R | 1, DC-applicable |
| +1 | 0x6C01 | V2 voltage | 0-Vmax | U1 | UINT16 | R | 1, DC-applicable |
| +2 | 0x6C02 | V3 voltage | 0-Vmax | U1 | UINT16 | R | 1, DC-applicable |
| +3 | 0x6C03 | Not used | 0 | 0 | UINT16 | R | |
| +4 | 0x6C04 | V12 voltage | 0-Vmax | U1 | UINT16 | R | |
| +5 | 0x6C05 | V23 voltage | 0-Vmax | U1 | UINT16 | R | |
| +6 | 0x6C06 | V31 voltage | 0-Vmax | U1 | UINT16 | R | |
| +7 | 0x6C07 | I1 current | 0-I _{max} | U2 | UINT16 | R | DC-applicable |
| +8 | 0x6C08 | I2 current | 0-I _{max} | U2 | UINT16 | R | DC-applicable |
| +9 | 0x6C09 | I3 current | 0-I _{max} | U2 | UINT16 | R | DC-applicable |
| +10 | 0x6C0A | I4 current | 0-I _{4max} | U2 | UINT16 | R | DC-applicable |
| +11 | 0x6C0B | I _n current | 0-I _{max} | U2 | UINT16 | R | |
| +12 | 0x6C0C | Not used | 0 | 0 | UINT16 | R | |
| +13 | 0x6C0D | Not used | 0 | 0 | UINT16 | R | |
| +14 | 0x6C0E | Not used | 0 | 0 | UINT16 | R | |
| +15 | 0x6C0F | Not used | 0 | 0 | UINT16 | R | |
| +16 | 0x6C10 | I _x current | 0-I _{xmax} | U2 | UINT16 | R | |
| +17 | 0x6C11 | Zero-sequence voltage | 0-Vmax | U1 | UINT16 | R | |
| +18 | 0x6C12 | Zero-sequence current | 0-I _{max} | U2 | UINT16 | R | |
| +19 | 0x6C13 | I _x Zero-sequence current | 0-I _{xmax} | U2 | UINT16 | R | |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|--|----------------------------------|--------------------|--------|-----|------------------|
| +20 | 0x6C14 | Voltage unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +21 | 0x6C15 | Current unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +22 | 0x6C16 | Ix current unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +23 | 0x6C17 | Not used | | | UINT16 | R | |
| +24 | 0x6C18 | Frequency | 0-100.00 | 0.01Hz | UINT16 | R | |
| +25 | 0x6C19 | Positive-sequence voltage | 0-Vmax | U1 | UINT16 | R | |
| +26 | 0x6C1A | Zero-sequence voltage unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +27 | 0x6C1B | I leakage current | 0-I _{max} | U2 | UINT16 | R | |
| 10528-10554 | | 3-Second RMS and Auxiliary Values | | | | | |
| +0 | 0x6C80 | V1 voltage | 0-Vmax | U1 | UINT16 | R | 1, DC-applicable |
| +1 | 0x6C81 | V2 voltage | 0-Vmax | U1 | UINT16 | R | 1, DC-applicable |
| +2 | 0x6C82 | V3 voltage | 0-Vmax | U1 | UINT16 | R | 1, DC-applicable |
| +3 | 0x6C83 | Not used | 0 | 0 | UINT16 | R | |
| +4 | 0x6C84 | V12 voltage | 0-Vmax | U1 | UINT16 | R | |
| +5 | 0x6C85 | V23 voltage | 0-Vmax | U1 | UINT16 | R | |
| +6 | 0x6C86 | V31 voltage | 0-Vmax | U1 | UINT16 | R | |
| +7 | 0x6C87 | I1 current | 0-I _{max} | U2 | UINT16 | R | DC-applicable |
| +8 | 0x6C88 | I2 current | 0-I _{max} | U2 | UINT16 | R | DC-applicable |
| +9 | 0x6C89 | I3 current | 0-I _{max} | U2 | UINT16 | R | DC-applicable |
| +10 | 0x6C8A | I4 current | 0-I _{4max} | U2 | UINT16 | R | DC-applicable |
| +11 | 0x6C8B | I _n current | 0-I _{max} | U2 | UINT16 | R | |
| +12 | 0x6C8C | Not used | 0 | 0 | UINT16 | R | |
| +13 | 0x6C8D | Not used | 0 | 0 | UINT16 | R | |
| +14 | 0x6C8E | Not used | 0 | 0 | UINT16 | R | |
| +15 | 0x6C8F | Not used | 0 | 0 | UINT16 | R | |
| +16 | 0x6C90 | I _x current | 0-I _{xmax} | U2 | UINT16 | R | |
| +17 | 0x6C91 | Zero-sequence voltage | 0-Vmax | U1 | UINT16 | R | |
| +18 | 0x6C92 | Zero-sequence current | 0-I _{max} | U2 | UINT16 | R | |
| +19 | 0x6C93 | I _x Zero-sequence current | 0-I _{xmax} | U2 | UINT16 | R | |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|---|----------------------------------|--------------------|--------|-----|------------------|
| +20 | 0x6C94 | Voltage unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +21 | 0x6C95 | Current unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +22 | 0x6C96 | Ix current unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +23 | 0x6C97 | Not used | | | UINT16 | R | |
| +24 | 0x6C98 | Frequency | 0-100.00 | 0.01Hz | UINT16 | R | |
| +25 | 0x6C99 | Positive-sequence voltage | 0-Vmax | U1 | UINT16 | R | |
| +26 | 0x6C9A | Zero-sequence voltage unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +27 | 0x6C9B | I leakage current | 0-I _{max} | U2 | UINT16 | R | |
| 11136-11162 | | 1-Minute RMS and Auxiliary Values (GOST) | | | | | |
| +0 | 0x7600 | V1 voltage | 0-Vmax | U1 | UINT16 | R | 1, DC-applicable |
| +1 | 0x7601 | V2 voltage | 0-Vmax | U1 | UINT16 | R | 1, DC-applicable |
| +2 | 0x7602 | V3 voltage | 0-Vmax | U1 | UINT16 | R | 1, DC-applicable |
| +3 | 0x7603 | Not used | 0 | 0 | UINT16 | R | |
| +4 | 0x7604 | V12 voltage | 0-Vmax | U1 | UINT16 | R | |
| +5 | 0x7605 | V23 voltage | 0-Vmax | U1 | UINT16 | R | |
| +6 | 0x7606 | V31 voltage | 0-Vmax | U1 | UINT16 | R | |
| +7 | 0x7607 | I1 current | 0-I _{max} | U2 | UINT16 | R | DC-applicable |
| +8 | 0x7608 | I2 current | 0-I _{max} | U2 | UINT16 | R | DC-applicable |
| +9 | 0x7609 | I3 current | 0-I _{max} | U2 | UINT16 | R | DC-applicable |
| +10 | 0x760A | I4 current | 0-I _{4max} | U2 | UINT16 | R | DC-applicable |
| +11 | 0x760B | I _n current | 0-I _{max} | U2 | UINT16 | R | |
| +12 | 0x760C | Not used | 0 | 0 | UINT16 | R | |
| +13 | 0x760D | Not used | 0 | 0 | UINT16 | R | |
| +14 | 0x760E | Not used | 0 | 0 | UINT16 | R | |
| +15 | 0x760F | Not used | 0 | 0 | UINT16 | R | |
| +16 | 0x7610 | Not used | 0 | 0 | UINT16 | R | |
| +17 | 0x7611 | Zero-sequence voltage | 0-Vmax | U1 | UINT16 | R | |
| +18 | 0x7612 | Zero-sequence current | 0-I _{max} | U2 | UINT16 | R | |
| +19 | 0x7613 | I _x Zero-sequence current | 0-I _{xmax} | U2 | UINT16 | R | |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|---|----------------------------------|--------------------|--------|-----|------------------|
| +20 | 0x7614 | Voltage unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +21 | 0x7615 | Current unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +22 | 0x7616 | Ix current unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +23 | 0x7617 | Reserved | 0 | | UINT16 | R | |
| +24 | 0x7618 | Frequency | 0-100.00 | 0.01Hz | UINT16 | R | |
| +25 | 0x7619 | Positive-sequence voltage | 0-Vmax | U1 | UINT16 | R | |
| +26 | 0x761A | Zero-sequence voltage unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +27 | 0x761B | I leakage current | 0-I _{max} | U2 | UINT16 | R | |
| 10560-10586 | | 10-Minute RMS and Auxiliary Values | | | | | |
| +0 | 0x6D00 | V1 voltage | 0-Vmax | U1 | UINT16 | R | 1, DC-applicable |
| +1 | 0x6D01 | V2 voltage | 0-Vmax | U1 | UINT16 | R | 1, DC-applicable |
| +2 | 0x6D02 | V3 voltage | 0-Vmax | U1 | UINT16 | R | 1, DC-applicable |
| +3 | 0x6D03 | Not used | 0 | 0 | UINT16 | R | |
| +4 | 0x6D04 | V12 voltage | 0-Vmax | U1 | UINT16 | R | |
| +5 | 0x6D05 | V23 voltage | 0-Vmax | U1 | UINT16 | R | |
| +6 | 0x6D06 | V31 voltage | 0-Vmax | U1 | UINT16 | R | |
| +7 | 0x6D07 | I1 current | 0-I _{max} | U2 | UINT16 | R | DC-applicable |
| +8 | 0x6D08 | I2 current | 0-I _{max} | U2 | UINT16 | R | DC-applicable |
| +9 | 0x6D09 | I3 current | 0-I _{max} | U2 | UINT16 | R | DC-applicable |
| +10 | 0x6D0A | I4 current | 0-I _{4max} | U2 | UINT16 | R | DC-applicable |
| +11 | 0x6D0B | I _n current | 0-I _{max} | U2 | UINT16 | R | |
| +12 | 0x6D0C | Not used | 0 | 0 | UINT16 | R | |
| +13 | 0x6D0D | Not used | 0 | 0 | UINT16 | R | |
| +14 | 0x6D0E | Not used | 0 | 0 | UINT16 | R | |
| +15 | 0x6D0F | Not used | 0 | 0 | UINT16 | R | |
| +16 | 0x6D10 | Not used | 0 | 0 | UINT16 | R | |
| +17 | 0x6D11 | Zero-sequence voltage | 0-Vmax | U1 | UINT16 | R | |
| +18 | 0x6D12 | Zero-sequence current | 0-I _{max} | U2 | UINT16 | R | |
| +19 | 0x6D13 | I _x Zero-sequence current | 0-I _{xmax} | U2 | UINT16 | R | |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|--|----------------------------------|--------------------|--------|-----|---------------|
| +20 | 0x6D14 | Voltage unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +21 | 0x6D15 | Current unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +22 | 0x6D16 | Ix current unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +23 | 0x6D17 | Not used | | | UINT16 | R | |
| +24 | 0x6D18 | Frequency | 0-100.00 | 0.01Hz | UINT16 | R | |
| +25 | 0x6D19 | Positive-sequence voltage | 0-Vmax | U1 | UINT16 | R | |
| +26 | 0x6D1A | Zero-sequence voltage unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +27 | 0x6D1B | I leakage current | 0-I _{max} | U2 | UINT16 | R | |
| 10592-10618 | | 2-Hour RMS and Auxiliary Values | | | | | |
| +0 | 0x6D80 | V1 voltage | 0-Vmax | U1 | UINT16 | R | DC-applicable |
| +1 | 0x6D81 | V2 voltage | 0-Vmax | U1 | UINT16 | R | DC-applicable |
| +2 | 0x6D82 | V3 voltage | 0-Vmax | U1 | UINT16 | R | DC-applicable |
| +3 | 0x6D83 | Not used | 0 | | UINT16 | R | |
| +4 | 0x6D84 | V12 voltage | 0-Vmax | U1 | UINT16 | R | |
| +5 | 0x6D85 | V23 voltage | 0-Vmax | U1 | UINT16 | R | |
| +6 | 0x6D86 | V31 voltage | 0-Vmax | U1 | UINT16 | R | |
| +7 | 0x6D87 | I1 current | 0-I _{max} | U2 | UINT16 | R | DC-applicable |
| +8 | 0x6D88 | I2 current | 0-I _{max} | U2 | UINT16 | R | DC-applicable |
| +9 | 0x6D89 | I3 current | 0-I _{max} | U2 | UINT16 | R | DC-applicable |
| +10 | 0x6D8A | I4 current | 0-I _{4max} | U2 | UINT16 | R | DC-applicable |
| +11 | 0x6D8B | I _n current | 0-I _{max} | U2 | UINT16 | R | |
| +12 | 0x6D8C | Not used | 0 | 0 | UINT16 | R | |
| +13 | 0x6D8D | Not used | 0 | 0 | UINT16 | R | |
| +14 | 0x6D8E | Not used | 0 | 0 | UINT16 | R | |
| +15 | 0x6D8F | Not used | 0 | 0 | UINT16 | R | |
| +16 | 0x6D90 | Not used | 0 | 0 | UINT16 | R | |
| +17 | 0x6D91 | Zero-sequence voltage | 0-Vmax | U1 | UINT16 | R | |
| +18 | 0x6D92 | Zero-sequence current | 0-I _{max} | U2 | UINT16 | R | |
| +19 | 0x6D93 | I _x Zero-sequence current | 0-I _{xmax} | U2 | UINT16 | R | |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|---------------------------------|----------------------------------|--------------------|--------|-----|-------|
| +20 | 0x6D94 | Voltage unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +21 | 0x6D95 | Current unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +22 | 0x6D96 | Ix current unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +23 | 0x6D97 | Not used | | | UINT16 | R | |
| +24 | 0x6D98 | Frequency | 0-100.00 | 0.01Hz | UINT16 | R | |
| +25 | 0x6D99 | Positive-sequence voltage | 0-Vmax | U1 | UINT16 | R | |
| +26 | 0x6D9A | Zero-sequence voltage unbalance | 0-300.0 | 0.1% | UINT16 | R | |
| +27 | 0x6D9B | I leakage current | 0-I _{max} | U2 | UINT16 | R | |
| 10624-10655 | | 0.2-Second Harmonics | | | | | |
| +0 | 0x6E00 | V1 THD | 0-999.9 | 0.1% | UINT16 | R | |
| +1 | 0x6E01 | V2 THD | 0-999.9 | 0.1% | UINT16 | R | |
| +2 | 0x6E02 | V3 THD | 0-999.9 | 0.1% | UINT16 | R | |
| +3 | 0x6E03 | Not used | 0 | 0 | UINT16 | R | |
| +4 | 0x6E04 | I1 THD | 0-999.9 | 0.1% | UINT16 | R | |
| +5 | 0x6E05 | I2 THD | 0-999.9 | 0.1% | UINT16 | R | |
| +6 | 0x6E06 | I3 THD | 0-999.9 | 0.1% | UINT16 | R | |
| +7 | 0x6E07 | I4 THD | 0-999.9 | 0.1% | UINT16 | R | |
| +8 | 0x6E08 | V1 interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | |
| +9 | 0x6E09 | V2 interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | |
| +10 | 0x6E0A | V3 interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | |
| +11 | 0x6E0B | Not used | 0 | 0 | UINT16 | R | |
| +12 | 0x6E0C | I1 interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | |
| +13 | 0x6E0D | I2 interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | |
| +14 | 0x6E0E | I3 interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | |
| +15 | 0x6E0F | I4 interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | |
| +16 | 0x6E10 | I1 TDD | 0-100.0 | 0.1% | UINT16 | R | |
| +17 | 0x6E11 | I2 TDD | 0-100.0 | 0.1% | UINT16 | R | |
| +18 | 0x6E12 | I3 TDD | 0-100.0 | 0.1% | UINT16 | R | |
| +19 | 0x6E13 | I4 TDD | 0-100.0 | 0.1% | UINT16 | R | |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|---------------------------|----------------------------------|--------------------|--------|-----|-------|
| +20 | 0x6E14 | I1 K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | |
| +21 | 0x6E15 | I2 K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | |
| +22 | 0x6E16 | I3 K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | |
| +23 | 0x6E17 | I4 K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | |
| +24 | 0x6E18 | V1 Crest Factor | 0-100.00 | 0.01 | UINT16 | R | 2 |
| +25 | 0x6E19 | V2 Crest Factor | 0-100.00 | 0.01 | UINT16 | R | 2 |
| +26 | 0x6E1A | V3 Crest Factor | 0-100.00 | 0.01 | UINT16 | R | 2 |
| +27 | 0x6E1B | Not used | 0 | 0 | UINT16 | R | |
| +28 | 0x6E1C | I1 Crest Factor | 0-100.00 | 0.01 | UINT16 | R | |
| +29 | 0x6E1D | I2 Crest Factor | 0-100.00 | 0.01 | UINT16 | R | |
| +30 | 0x6E1E | I3 Crest Factor | 0-100.00 | 0.01 | UINT16 | R | |
| +31 | 0x6E1F | I4 Crest Factor | 0-100.00 | 0.01 | UINT16 | R | |
| 10656-10687 | | 3-Second Harmonics | | | | | |
| +0 | 0x6E80 | V1 THD | 0-999.9 | 0.1% | UINT16 | R | 2 |
| +1 | 0x6E81 | V2 THD | 0-999.9 | 0.1% | UINT16 | R | 2 |
| +2 | 0x6E82 | V3 THD | 0-999.9 | 0.1% | UINT16 | R | 2 |
| +3 | 0x6E83 | Not used | 0 | 0 | UINT16 | R | |
| +4 | 0x6E84 | I1 THD | 0-999.9 | 0.1% | UINT16 | R | |
| +5 | 0x6E85 | I2 THD | 0-999.9 | 0.1% | UINT16 | R | |
| +6 | 0x6E86 | I3 THD | 0-999.9 | 0.1% | UINT16 | R | |
| +7 | 0x6E87 | I4 THD | 0-999.9 | 0.1% | UINT16 | R | |
| +8 | 0x6E88 | V1 interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | 2 |
| +9 | 0x6E89 | V2 interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | 2 |
| +10 | 0x6E8A | V3 interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | 2 |
| +11 | 0x6E8B | Not used | 0 | 0 | UINT16 | R | |
| +12 | 0x6E6E | I1 interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | |
| +13 | 0x6E8D | I2 interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | |
| +14 | 0x6E8E | I3 interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | |
| +15 | 0x6E8F | I4 interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|----------------------------|----------------------------------|--------------------|--------|-----|-------|
| +16 | 0x6E90 | I1 TDD | 0-100.0 | 0.1% | UINT16 | R | |
| +17 | 0x6E91 | I2 TDD | 0-100.0 | 0.1% | UINT16 | R | |
| +18 | 0x6E92 | I3 TDD | 0-100.0 | 0.1% | UINT16 | R | |
| +19 | 0x6E93 | I4 TDD | 0-100.0 | 0.1% | UINT16 | R | |
| +20 | 0x6E94 | I1 K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | |
| +21 | 0x6E95 | I2 K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | |
| +22 | 0x6E96 | I3 K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | |
| +23 | 0x6E97 | I4 K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | |
| +24 | 0x6E98 | V1 Crest Factor | 0-100.00 | 0.01 | UINT16 | R | 2 |
| +25 | 0x6E99 | V2 Crest Factor | 0-100.00 | 0.01 | UINT16 | R | 2 |
| +26 | 0x6E9A | V3 Crest Factor | 0-100.00 | 0.01 | UINT16 | R | 2 |
| +27 | 0x6E9B | Not used | 0 | 0 | UINT16 | R | |
| +28 | 0x6E9C | I1 Crest Factor | 0-100.00 | 0.01 | UINT16 | R | |
| +29 | 0x6E9D | I2 Crest Factor | 0-100.00 | 0.01 | UINT16 | R | |
| +30 | 0x6E9E | I3 Crest Factor | 0-100.00 | 0.01 | UINT16 | R | |
| +31 | 0x6E9F | I4 Crest Factor | 0-100.00 | 0.01 | UINT16 | R | |
| 10688-10719 | | 10-Minute Harmonics | | | | | |
| +0 | 0x6F00 | V1 THD | 0-999.9 | 0.1% | UINT16 | R | 2 |
| +1 | 0x6F01 | V2 THD | 0-999.9 | 0.1% | UINT16 | R | 2 |
| +2 | 0x6F02 | V3 THD | 0-999.9 | 0.1% | UINT16 | R | 2 |
| +3 | 0x6F03 | Not used | 0 | 0 | UINT16 | R | |
| +4 | 0x6F04 | I1 THD | 0-999.9 | 0.1% | UINT16 | R | |
| +5 | 0x6F05 | I2 THD | 0-999.9 | 0.1% | UINT16 | R | |
| +6 | 0x6F06 | I3 THD | 0-999.9 | 0.1% | UINT16 | R | |
| +7 | 0x6F07 | I4 THD | 0-999.9 | 0.1% | UINT16 | R | |
| +8 | 0x6F08 | V1 interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | 2 |
| +9 | 0x6F09 | V2 interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | 2 |
| +10 | 0x6F0A | V3 interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | 2 |
| +11 | 0x6F0B | Not used | 0 | 0 | UINT16 | R | |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|-------------------------|----------------------------------|--------------------|--------|-----|-------|
| +12 | 0x6F0C | I1 interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | |
| +13 | 0x6F0D | I2 interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | |
| +14 | 0x6F0E | I3 interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | |
| +15 | 0x6F0F | I4 interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | |
| +16 | 0x6F10 | I1 TDD | 0-100.0 | 0.1% | UINT16 | R | |
| +17 | 0x6F11 | I2 TDD | 0-100.0 | 0.1% | UINT16 | R | |
| +18 | 0x6F12 | I3 TDD | 0-100.0 | 0.1% | UINT16 | R | |
| +19 | 0x6F13 | I4 TDD | 0-100.0 | 0.1% | UINT16 | R | |
| +20 | 0x6F14 | I1 K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | |
| +21 | 0x6F15 | I2 K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | |
| +22 | 0x6F16 | I3 K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | |
| +23 | 0x6F17 | I4 K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | |
| +24 | 0x6F18 | V1 Crest Factor | 0-100.00 | 0.01 | UINT16 | R | 2 |
| +25 | 0x6F19 | V2 Crest Factor | 0-100.00 | 0.01 | UINT16 | R | 2 |
| +26 | 0x6F1A | V3 Crest Factor | 0-100.00 | 0.01 | UINT16 | R | 2 |
| +27 | 0x6F1B | V4 Crest Factor | 0-100.00 | 0.01 | UINT16 | R | |
| +28 | 0x6F1C | I1 Crest Factor | 0-100.00 | 0.01 | UINT16 | R | |
| +29 | 0x6F1D | I2 Crest Factor | 0-100.00 | 0.01 | UINT16 | R | |
| +30 | 0x6F1E | I3 Crest Factor | 0-100.00 | 0.01 | UINT16 | R | |
| +31 | 0x6F1F | I4 Crest Factor | 0-100.00 | 0.01 | UINT16 | R | |
| 10720-10751 | | 2-Hour Harmonics | | | | | |
| +0 | 0x6F80 | V1 THD | 0-999.9 | 0.1% | UINT16 | R | 2 |
| +1 | 0x6F81 | V2 THD | 0-999.9 | 0.1% | UINT16 | R | |
| +2 | 0x6F82 | V3 THD | 0-999.9 | 0.1% | UINT16 | R | |
| +3 | 0x6F83 | Not used | 0 | 0 | UINT16 | R | |
| +4 | 0x6F84 | I1 THD | 0-999.9 | 0.1% | UINT16 | R | |
| +5 | 0x6F85 | I2 THD | 0-999.9 | 0.1% | UINT16 | R | |
| +6 | 0x6F86 | I3 THD | 0-999.9 | 0.1% | UINT16 | R | |
| +7 | 0x6F87 | I4 THD | 0-999.9 | 0.1% | UINT16 | R | |

| Address | Point ID | Description | Low and High Scales ³ | Units ³ | Type | R/W | Notes |
|---------|----------|-----------------------|----------------------------------|--------------------|--------|-----|-------|
| +8 | 0x6F88 | V1 interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | |
| +9 | 0x6F89 | V2 interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | |
| +10 | 0x6F8A | V3 interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | |
| +11 | 0x6F8B | Not used | 0 | 0 | UINT16 | R | |
| +12 | 0x6F8C | I1 interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | |
| +13 | 0x6F8D | I2 interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | |
| +14 | 0x6F8E | I3 interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | |
| +15 | 0x6F8F | I4 interharmonics THD | 0-999.9 | 0.1% | UINT16 | R | |
| +16 | 0x6F90 | I1 TDD | 0-100.0 | 0.1% | UINT16 | R | |
| +17 | 0x6F91 | I2 TDD | 0-100.0 | 0.1% | UINT16 | R | |
| +18 | 0x6F92 | I3 TDD | 0-100.0 | 0.1% | UINT16 | R | |
| +19 | 0x6F93 | I4 TDD | 0-100.0 | 0.1% | UINT16 | R | |
| +20 | 0x6F94 | I1 K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | |
| +21 | 0x6F95 | I2 K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | |
| +22 | 0x6F96 | I3 K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | |
| +23 | 0x6F97 | I4 K-Factor | 1.0-999.9 | 0.1 | UINT16 | R | |
| +24 | 0x6F98 | V1 Crest Factor | 0-100.00 | 0.01 | UINT16 | R | 2 |
| +25 | 0x6F99 | V2 Crest Factor | 0-100.00 | 0.01 | UINT16 | R | 2 |
| +26 | 0x6F9A | V3 Crest Factor | 0-100.00 | 0.01 | UINT16 | R | 2 |
| +27 | 0x6F9B | Not used | 0 | 0 | UINT16 | R | |
| +28 | 0x6F9C | I1 Crest Factor | 0-100.00 | 0.01 | UINT16 | R | |
| +29 | 0x6F9D | I2 Crest Factor | 0-100.00 | 0.01 | UINT16 | R | |
| +30 | 0x6F9E | I3 Crest Factor | 0-100.00 | 0.01 | UINT16 | R | |
| +31 | 0x6F9F | I4 Crest Factor | 0-100.00 | 0.01 | UINT16 | R | |

NOTES:

¹When the 4LN3, 4LL3, 3LN3, 3LL3, 3BLN3 or 3BLL3 wiring mode is selected, the voltages will be line-to-neutral; for any other wiring mode, they will be line-to-line.

²When the 4LN3, 3LN3 or 3BLN3 wiring mode is selected, the voltages will be line-to-neutral; for any other wiring mode, they will be line-to-line voltages.

³For volts, amps, power and frequency scales and units, refer to Section 4 "Data Scales and Units".

⁴0.2-s (10/12-cycle) interval (16-cycles for GOST 13109).

⁵3-s (150/180-cycle) interval.

⁶Harmonic angles are referenced to the fundamental voltage harmonic H01 on phase L1.

⁷0.2-s (10/12-cycle) interval for EN 50160:2007, 16-cycle interval for GOST 13109, programmable 0.2-s (10/12-cycle), 3-s (150/180-cycle), 10-min, 2-h interval for GOST 32144 and EN 50160:2010.

3.4 32-bit Binary and Analog Values

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|-------------------------------|--|--------------------|--------|-----|-------|
| 11776-11777 | 0x0000 | None | 0 | | UINT32 | R | |
| | | Setpoint Status | 0x00000000 – 0xFFFFFFFF | | | | |
| 11840-11841 | | Setpoints 1-32 (alias) | 0x00000000 – 0xFFFFFFFF | | UINT32 | R | |
| 27648-27649 | | Setpoints 1-32 | 0x00000000 – 0xFFFFFFFF | | UINT32 | R | |
| 27712-27713 | | Setpoints 33-64 | 0x00000000 – 0xFFFFFFFF | | UINT32 | R | |
| | 0x0080 | Setpoint #1 | 0/1 | | | TRG | |
| | 0x0081 | Setpoint #2 | 0/1 | | | TRG | |
| | | ... | | | | | |
| | 0x00BF | Setpoint #64 | 0/1 | | | TRG | |
| 11904-11907 | | Special Inputs | | | | | |
| +0,1 | 0x0100 | Voltage disturbance | 0-100 | % | UINT32 | R | |
| +2,3 | 0x0101 | Phase rotation order | 0 = error, 1 = positive (ABC), 2 = negative (CBA) | | UINT32 | R | |
| | | Event Flags | | | | | |
| 12160-12161 | | Event flags 1-32 | 0x00000000 – 0xFFFFFFFF | | UINT32 | R | |
| 12224-12225 | | Event flags 33-64 | 0x00000000 – 0xFFFFFFFF | | UINT32 | R | |
| | 0x0300 | Event flag #1 | 0/1 | | | TRG | |
| | 0x0301 | Event flag #2 | 0/1 | | | TRG | |
| | | ... | | | | | |
| | 0x033F | Event flag #64 | 0/1 | | | TRG | |
| | | Internal Pulsed Events | | | | | |
| | 0x0400 | kWh Import pulse | 0/1 | | | TRG | |
| | 0x0401 | kWh Export pulse | 0/1 | | | TRG | |
| | 0x0402 | kWh Total pulse | 0/1 | | | TRG | |
| | 0x0403 | kvarh Import pulse | 0/1 | | | TRG | |
| | 0x0404 | kvarh Export pulse | 0/1 | | | TRG | |
| | 0x0405 | kvarh Total pulse | 0/1 | | | TRG | |
| | 0x0406 | kVAh pulse | 0/1 | | | TRG | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|--|----------------------------|--------------------|--------|-----|-------|
| | 0x0407 | Start of power demand interval pulse | 0/1 | | | TRG | |
| | 0x0408 | Start of tariff interval pulse | 0/1 | | | TRG | |
| | 0x0409 | Start of ampere demand interval pulse | 0/1 | | | TRG | |
| | 0x040A | Start of sliding power demand interval pulse | 0/1 | | | TRG | |
| | 0x040B | New month pulse | 0/1 | | | TRG | |
| | | External Triggers (UDP) | | | | | |
| | 0x0480 | External trigger #1 | 0/1 | | | TRG | |
| | 0x0481 | External trigger #2 | 0/1 | | | TRG | |
| | | ... | | | | | |
| | 0x048F | External trigger #16 | 0/1 | | | TRG | |
| | | Periodic Timers | | | | | |
| | 0x0500 | Timer #1 | 0/1 | | | TRG | |
| | 0x0501 | Timer #2 | 0/1 | | | TRG | |
| | | ... | | | | | |
| | 0x050F | Timer #16 | 0/1 | | | TRG | |
| | | Digital Inputs | | | | | 8 |
| 12544-12545 | | Digital inputs DI1–DI26 | 0x00000000 – 0xFFFFFFFF | | UINT32 | R | |
| 12608-12609 | | Not used | 0 | 0 | UINT32 | R | |
| 12672-12673 | | Not used | 0 | 0 | UINT32 | R | |
| 12736-12737 | | Not used | 0 | 0 | UINT32 | R | |
| | 0x0600 | Digital input DI1 | 0/1 | | | TRG | |
| | 0x0601 | Digital input DI2 | 0/1 | | | TRG | |
| | | ... | | | | | |
| | 0x067F | Digital input DI126 | 0/1 | | | TRG | |
| | | Pulse Inputs | | | | | 9 |
| | 0x0700 | Digital input DI1 | 0/1 | | | TRG | |
| | 0x0701 | Digital input DI2 | 0/1 | | | TRG | |
| | | ... | | | | | |
| | 0x077F | Digital input DI126 | 0/1 | | | TRG | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|--|----------------------------|--------------------|--------|-----|-------|
| | | Relay Outputs | | | | | |
| 12800-12801 | | Relay outputs RO1–RO7 | 0x00000000 – 0xFFFFFFFF | | UINT32 | R | |
| 12864-12865 | | Not used | 0 | 0 | UINT32 | R | |
| | 0x0800 | Relay output RO1 | 0/1 | | | TRG | |
| | 0x0801 | Relay output RO2 | 0/1 | | | TRG | |
| | | ... | | | | | |
| | 0x0806 | Relay output RO7 | 0/1 | | | TRG | |
| | | Static Event Flags | | | | | |
| 12928-12929 | | Static event flags: Bit 0: Phase order error Bit 1: Positive phase order Bit 2: Negative phase order Bit 3: PQ event Bit 4: General fault event Bit 5: Fault detected Bit 6: External fault trigger Bit 7: Device fault (non-critical error) Bit 8: No voltage Bit 9: Remote control | 0x00000000 – 0xFFFFFFFF | | UINT32 | R | |
| | 0x0900 | Phase order error | 0/1 | | | TRG | |
| | 0x0901 | Positive phase order | 0/1 | | | TRG | |
| | 0x0902 | Negative phase order | 0/1 | | | TRG | |
| | 0x0903 | PQ event | 0/1 | | | TRG | |
| | 0x0904 | General fault event | 0/1 | | | TRG | |
| | 0x0905 | Fault detected | 0/1 | | | TRG | |
| | 0x0906 | External fault trigger | 0/1 | | | TRG | |
| | 0x0907 | Device fault (non-critical error) | 0/1 | | | TRG | |
| | 0x0908 | No voltage | 0/1 | | | TRG | |
| | 0x0909 | Remote control | 0/1 | | | TRG | |
| 13056-13119 | | Counters | | | | | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|-------------------------|-------------------------------|--------------------|--------|-------|-----------------------|
| +0,1 | 0x0A00 | Counter #1 | 0 – 999,999,999 | | UINT32 | R/W | |
| +2,3 | 0x0A01 | Counter #2 | 0 – 999,999,999 | | UINT32 | R/W | |
| | | ... | | | | | |
| +62,63 | 0x0A1F | Counter #32 | 0 – 999,999,999 | | UINT32 | R/W | |
| 13184-13205 | | Time/Date | | | | | |
| +0,1 | 0x0B00 | Packed date | YYMMDD | | UINT32 | TRG,R | |
| +2,3 | 0x0B01 | Packed time | hhmmss | | UINT32 | TRG,R | |
| +4,5 | 0x0B02 | Day of week | 1-7, 1 = Sun, 7 = Sat | | UINT32 | TRG,R | |
| +6,7 | 0x0B03 | Year | 0-99 | | UINT32 | TRG,R | |
| +8,9 | 0x0B04 | Month | 1-12 | | UINT32 | TRG,R | |
| +10,11 | 0x0B05 | Day of month | 1-31 | | UINT32 | TRG,R | |
| +12,13 | 0x0B06 | Hours | 0-23 | | UINT32 | TRG,R | |
| +14,15 | 0x0B07 | Minutes | 0-59 | | UINT32 | TRG,R | |
| +16,17 | 0x0B08 | Seconds | 0-59 | | UINT32 | TRG,R | |
| +18,19 | 0x0B09 | Minute interval | 1-5,10,15,20,30,60 (triggers) | | UINT32 | TRG,R | Reads present minutes |
| +20,21 | 0x0B0A | Timestamp | F1 | | UINT32 | R | |
| 13248-13297 | | 1/2-Cycle Values | | | | | |
| +0,1 | 0x0B80 | V1 voltage | 0-Vmax | U1 | UINT32 | R | 1, DC-applicable |
| +2,3 | 0x0B81 | V2 voltage | 0-Vmax | U1 | UINT32 | R | 1, DC-applicable |
| +4,5 | 0x0B82 | V3 voltage | 0-Vmax | U1 | UINT32 | R | 1, DC-applicable |
| +6,7 | 0x0B83 | Not used | 0 | 0 | UINT32 | R | |
| +8,9 | 0x0B84 | V12 voltage | 0-Vmax | U1 | UINT32 | R | |
| +10,11 | 0x0B85 | V23 voltage | 0-Vmax | U1 | UINT32 | R | |
| +12,13 | 0x0B86 | V31 voltage | 0-Vmax | U1 | UINT32 | R | |
| +14,15 | 0x0B87 | I1 current | 0-Imax | U2 | UINT32 | R | DC-applicable |
| +16,17 | 0x0B88 | I2 current | 0-Imax | U2 | UINT32 | R | DC-applicable |
| +18,19 | 0x0B89 | I3 current | 0-Imax | U2 | UINT32 | R | DC-applicable |
| +20,21 | 0x0B8A | I4 current | 0-I4max | U2 | UINT32 | R | DC-applicable |
| +22,23 | 0x0B8B | In current | 0-Imax | U2 | UINT32 | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|-----------------------------|----------------------------|--------------------|--------|-----|------------------|
| +24,25 | 0x0B8C | Not used | 0 | 0 | UINT32 | R | |
| +26,27 | 0x0B8D | Not used | 0 | 0 | UINT32 | R | |
| +28,29 | 0x0B8E | Not used | 0 | 0 | UINT32 | R | |
| +30,31 | 0x0B8F | Not used | 0 | 0 | UINT32 | R | |
| +32,33 | 0x0B90 | Not used | 0 | 0 | UINT32 | R | |
| +34,35 | 0x0B91 | Zero-sequence voltage | 0-Vmax | U1 | UINT32 | R | |
| +36,37 | 0x0B92 | Zero-sequence current | 0-Imax | U2 | UINT32 | R | |
| +38,39 | 0x0B93 | Ix Zero-sequence current | 0-Ixmax | U2 | UINT32 | R | |
| +40,41 | 0x0B94 | Voltage unbalance | 0-3000 | ×0.1% | UINT32 | R | |
| +42,43 | 0x0B95 | Current unbalance | 0-3000 | ×0.1% | UINT32 | R | |
| +44,45 | 0x0B96 | Ix current unbalance | 0-3000 | ×0.1% | UINT32 | R | |
| +46,47 | 0x0B97 | Not used | | | UINT32 | R | |
| +48,49 | 0x0B98 | Frequency (1-cycle) | 0-10000 | ×0.01Hz | UINT32 | R | |
| +50,51 | 0x0B99 | Not used | 0 | 0 | UINT32 | | |
| +52,53 | 0x0B9A | Not used | 0 | 0 | UINT32 | | |
| +54,55 | 0x0B9B | I leakage current | 0-Imax | U2 | UINT32 | | |
| 13312-13383 | | 1-Cycle Phase Values | | | | | |
| +0,1 | 0x0C00 | V1 voltage | 0-Vmax | U1 | UINT32 | R | 1, DC-applicable |
| +2,3 | 0x0C01 | V2 voltage | 0-Vmax | U1 | UINT32 | R | 1, DC-applicable |
| +4,5 | 0x0C02 | V3 voltage | 0-Vmax | U1 | UINT32 | R | 1, DC-applicable |
| +6,7 | 0x0C03 | I1 current | 0-Imax | U2 | UINT32 | R | DC-applicable |
| +8,9 | 0x0C04 | I2 current | 0-Imax | U2 | UINT32 | R | DC-applicable |
| +10,11 | 0x0C05 | I3 current | 0-Imax | U2 | UINT32 | R | DC-applicable |
| +12,13 | 0x0C06 | kW L1 | -Pmax-Pmax | U3 | INT32 | R | DC-applicable |
| +14,15 | 0x0C07 | kW L2 | -Pmax-Pmax | U3 | INT32 | R | DC-applicable |
| +16,17 | 0x0C08 | kW L3 | -Pmax-Pmax | U3 | INT32 | R | DC-applicable |
| +18,19 | 0x0C09 | kvar L1 | -Pmax-Pmax | U3 | INT32 | R | |
| +20,21 | 0x0C0A | kvar L2 | -Pmax-Pmax | U3 | INT32 | R | |
| +22,23 | 0x0C0B | kvar L3 | -Pmax-Pmax | U3 | INT32 | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|---------|----------|-----------------|----------------------------|--------------------|--------|-----|---------------|
| +24,25 | 0x0C0C | kVA L1 | 0-Pmax | U3 | UINT32 | R | |
| +26,27 | 0x0C0D | kVA L2 | 0-Pmax | U3 | UINT32 | R | |
| +28,29 | 0x0C0E | kVA L3 | 0-Pmax | U3 | UINT32 | R | |
| +30,31 | 0x0C0F | Power factor L1 | -1000-1000 | ×0.001 | INT32 | R | |
| +32,33 | 0x0C10 | Power factor L2 | -1000-1000 | ×0.001 | INT32 | R | |
| +34,35 | 0x0C11 | Power factor L3 | -1000-1000 | ×0.001 | INT32 | R | |
| +36,37 | 0x0C12 | V1 voltage THD | 0-9999 | ×0.1% | UINT32 | R | 2, 4 |
| +38,39 | 0x0C13 | V2 voltage THD | 0-9999 | ×0.1% | UINT32 | R | 2, 4 |
| +40,41 | 0x0C14 | V3 voltage THD | 0-9999 | ×0.1% | UINT32 | R | 2, 4 |
| +42,43 | 0x0C15 | I1 current THD | 0-9999 | ×0.1% | UINT32 | R | 4 |
| +44,45 | 0x0C16 | I2 current THD | 0-9999 | ×0.1% | UINT32 | R | 4 |
| +46,47 | 0x0C17 | I3 current THD | 0-9999 | ×0.1% | UINT32 | R | 4 |
| +48,49 | 0x0C18 | I1 K-Factor | 10-9999 | ×0.1 | UINT32 | R | 4 |
| +50,51 | 0x0C19 | I2 K-Factor | 10-9999 | ×0.1 | UINT32 | R | 4 |
| +52,53 | 0x0C1A | I3 K-Factor | 10-9999 | ×0.1 | UINT32 | R | 4 |
| +54,55 | 0x0C1B | I1 current TDD | 0-1000 | ×0.1% | UINT32 | R | 4 |
| +56,57 | 0x0C1C | I2 current TDD | 0-1000 | ×0.1% | UINT32 | R | 4 |
| +58,59 | 0x0C1D | I3 current TDD | 0-1000 | ×0.1% | UINT32 | R | 4 |
| +60,61 | 0x0C1E | V12 voltage | 0-Vmax | U1 | UINT32 | R | |
| +62,63 | 0x0C1F | V23 voltage | 0-Vmax | U1 | UINT32 | R | |
| +64,65 | 0x0C20 | V31 voltage | 0-Vmax | U1 | UINT32 | R | |
| +66,67 | 0x0C21 | Not used | 0 | 0 | UINT32 | R | |
| +68,69 | 0x0C22 | Not used | 0 | 0 | UINT32 | R | |
| +70,71 | 0x0C23 | Not used | 0 | 0 | UINT32 | R | |
| +71,72 | 0x0C24 | V1 average | 0-Vmax | U1 | UINT32 | R | DC-applicable |
| +73,74 | 0x0C25 | V2 average | 0-Vmax | U1 | UINT32 | R | DC-applicable |
| +75,76 | 0x0C26 | V3 average | 0-Vmax | U1 | UINT32 | R | DC-applicable |
| +77,78 | 0x0C27 | I1 average | 0-I _{max} | U1 | UINT32 | R | DC-applicable |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|----------------------------------|-------------------------------------|--------------------|--------|-----|---------------|
| +79,80 | 0x0C28 | I2 average | 0-I _{max} | U1 | UINT32 | R | DC-applicable |
| +81,82 | 0x0C29 | I3 average | 0-I _{max} | U1 | UINT32 | R | DC-applicable |
| 13440-13467 | | 1-Cycle Low Phase Values | | | | | |
| +0,1 | 0x0D00 | Low L-N voltage | 0-V _{max} | U1 | UINT32 | R | |
| +2,3 | 0x0D01 | Low current | 0-I _{max} | U2 | UINT32 | R | |
| +4,5 | 0x0D02 | Low kW | -P _{max} -P _{max} | U3 | INT32 | R | DC-applicable |
| +6,7 | 0x0D03 | Low kvar | -P _{max} -P _{max} | U3 | INT32 | R | |
| +8,9 | 0x0D04 | Low kVA | 0-P _{max} | U3 | UINT32 | R | |
| +10,11 | 0x0D05 | Low PF Lag | 0-1000 | ×0.001 | UINT32 | R | |
| +12,13 | 0x0D06 | Low PF Lead | 0-1000 | ×0.001 | UINT32 | R | |
| +14,15 | 0x0D07 | Low voltage THD | 0-9999 | ×0.1% | UINT32 | R | 2, 4 |
| +16,17 | 0x0D08 | Low current THD | 0-9999 | ×0.1% | UINT32 | R | 4 |
| +18,19 | 0x0D09 | Low K-Factor | 10-9999 | ×0.1 | UINT32 | R | 4 |
| +20,21 | 0x0D0A | Low current TDD | 0-1000 | ×0.1% | UINT32 | R | 4 |
| +22,23 | 0x0D0B | Low L-L voltage | 0-V _{max} | U1 | UINT32 | R | |
| +24,25 | 0x0D0C | Low voltage interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | 2, 4 |
| +26,27 | 0x0D0D | Low current interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | 4 |
| 13504-13535 | | 1/2-Cycle Analog Inputs | | | | | |
| +0,1 | 0x0D80 | Analog input AI1 | AI1min-AI1max | | INT32 | R | |
| +2,3 | 0x0D81 | Analog input AI2 | AI2min-AI2max | | INT32 | R | |
| | | ... | | | | | |
| +30,31 | 0x0D8F | Analog input AI16 | AI16min-AI16max | | INT32 | R | |
| 13568-13595 | | 1-Cycle High Phase Values | | | | | |
| +0,1 | 0x0E00 | High L-N voltage | 0-V _{max} | U1 | UINT32 | R | |
| +2,3 | 0x0E01 | High current | 0-I _{max} | U2 | UINT32 | R | |
| +4,5 | 0x0E02 | High kW | -P _{max} -P _{max} | U3 | INT32 | R | DC-applicable |
| +6,7 | 0x0E03 | High kvar | -P _{max} -P _{max} | U3 | INT32 | R | |
| +8,9 | 0x0E04 | High kVA | 0-P _{max} | U3 | UINT32 | R | |
| +10,11 | 0x0E05 | High PF Lag | 0-1000 | ×0.001 | UINT32 | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|---------------------------------|----------------------------|--------------------|--------|-----|---------------|
| +12,13 | 0x0E06 | High PF Lead | 0-1000 | ×0.001 | UINT32 | R | |
| +14,15 | 0x0E07 | High voltage THD | 0-9999 | ×0.1% | UINT32 | R | 2, 4 |
| +16,17 | 0x0E08 | High current THD | 0-9999 | ×0.1% | UINT32 | R | 4 |
| +18,19 | 0x0E09 | High K-Factor | 10-9999 | ×0.1 | UINT32 | R | 4 |
| +20,21 | 0x0E0A | High current TDD | 0-1000 | ×0.1% | UINT32 | R | 4 |
| +22,23 | 0x0E0B | High L-L voltage | 0-Vmax | U1 | UINT32 | R | |
| +24,25 | 0x0E0C | High voltage interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | 2, 4 |
| +26,27 | 0x0E0D | High current interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | 4 |
| 13632-13663 | | 1-Second Analog Inputs | | | | | |
| +0,1 | 0x0E80 | Analog input AI1 | AI1min-AI1max | | INT32 | R | |
| +2,3 | 0x0E81 | Analog input AI2 | AI2min-AI2max | | INT32 | R | |
| | | ... | | | | | |
| +30,31 | 0x0E8F | Analog input AI16 | AI16min-AI16max | | INT32 | R | |
| 13696-13723 | | 1-Cycle Total Values | | | | | |
| +0,1 | 0x0F00 | Total kW | -Pmax-Pmax | U3 | INT32 | R | DC-applicable |
| +2,3 | 0x0F01 | Total kvar | -Pmax-Pmax | U3 | INT32 | R | |
| +4,5 | 0x0F02 | Total kVA | 0-Pmax | U3 | UINT32 | R | |
| +6,7 | 0x0F03 | Total PF | -1000-1000 | ×0.001 | INT32 | R | |
| +8,9 | 0x0F04 | Total PF lag | 0-1000 | ×0.001 | UINT32 | R | |
| +10,11 | 0x0F05 | Total PF lead | 0-1000 | ×0.001 | UINT32 | | |
| +12,13 | 0x0F06 | Total kW import | 0-Pmax | U3 | UINT32 | | DC-applicable |
| +14,15 | 0x0F07 | Total kW export | 0-Pmax | U3 | UINT32 | R | DC-applicable |
| +16,17 | 0x0F08 | Total kvar import | 0-Pmax | U3 | UINT32 | R | |
| +18,19 | 0x0F09 | Total kvar export | 0-Pmax | U3 | UINT32 | R | |
| +20,21 | 0x0F0A | 3-phase average L-N voltage | 0-Vmax | U1 | UINT32 | R | |
| +22,23 | 0x0F0B | 3-phase average L-L voltage | 0-Vmax | U1 | UINT32 | R | |
| +24,25 | 0x0F0C | 3-phase average current | 0-Imax | U2 | UINT32 | R | |
| +26,27 | 0x0F0D | Not used | 0 | 0 | UINT32 | R | |
| 13824-13841 | | 1-Cycle Auxiliary Values | | | | | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|--------------------------------------|----------------------------|--------------------|--------|-----|------------------|
| +0,1 | 0x1000 | I4 current | 0-lmax | U2 | UINT32 | R | DC-applicable |
| +2,3 | 0x1001 | In current | 0-lmax | U2 | UINT32 | R | |
| +4,5 | 0x1002 | Frequency | 0-10000 | ×0.01Hz | UINT32 | R | |
| +6,7 | 0x1003 | Voltage unbalance | 0-3000 | ×0.1% | UINT32 | R | |
| +8,9 | 0x1004 | Current unbalance | 0-3000 | ×0.1% | UINT32 | R | |
| +10,11 | 0x1005 | Not used | | | UINT32 | R | |
| +12,13 | 0x1006 | Not used | 0 | 0 | UINT32 | R | |
| +14,15 | 0x1007 | Not used | 0 | 0 | UINT32 | R | |
| +16,17 | 0x1008 | Frequency (3 decimals) | 0-100000 | ×0.001Hz | UINT32 | R | |
| +18,19 | 0x1009 | I leakage current | 0-lmax | U2 | UINT32 | R | |
| +22,23 | 0x100A | Frequency over 4 cycles (3 decimals) | 0-100.000 | 0.001Hz | UINT32 | R | |
| 13888-13935 | | Fundamental Phasor Values | | | | | |
| +0,1 | 0x1080 | V1 voltage magnitude | 0-Vmax | U1 | UINT32 | R | 2, DC-applicable |
| +2,3 | 0x1081 | V2 voltage magnitude | 0-Vmax | U1 | UINT32 | R | 2, DC-applicable |
| +4,5 | 0x1082 | V3 voltage magnitude | 0-Vmax | U1 | UINT32 | R | 2, DC-applicable |
| +6,7 | 0x1083 | Not used | 0 | 0 | UINT32 | R | |
| +8,9 | 0x1084 | I1 current magnitude | 0-lmax | U2 | UINT32 | R | DC-applicable |
| +10,11 | 0x1085 | I2 current magnitude | 0-lmax | U2 | UINT32 | R | DC-applicable |
| +12,13 | 0x1086 | I3 current magnitude | 0-lmax | U2 | UINT32 | R | DC-applicable |
| +14,15 | 0x1087 | I4 current magnitude | 0-lmax | U2 | UINT32 | R | DC-applicable |
| +16,17 | 0x1088 | V1 voltage angle | -1800-1800 | ×0.1° | INT32 | R | 2 |
| +18,19 | 0x1089 | V2 voltage angle | -1800-1800 | ×0.1° | INT32 | R | 2 |
| +20,21 | 0x108A | V3 voltage angle | -1800-1800 | ×0.1° | INT32 | R | 2 |
| +22,23 | 0x108B | Not used | 0 | 0 | UINT32 | R | |
| +24,25 | 0x108C | I1 current angle | -1800-1800 | ×0.1° | INT32 | R | |
| +26,27 | 0x108D | I2 current angle | -1800-1800 | ×0.1° | INT32 | R | |
| +28,29 | 0x108E | I3 current angle | -1800-1800 | ×0.1° | INT32 | R | |
| +30,31 | 0x108F | I4 current angle | -1800-1800 | ×0.1° | INT32 | R | |
| +32,33 | 0x1090 | Not used | 0 | 0 | UINT32 | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|------------------------------|----------------------------|--------------------|--------|-----|------------------|
| +34,35 | 0x1091 | Not used | 0 | 0 | UINT32 | R | |
| +36,37 | 0x1092 | Not used | 0 | 0 | UINT32 | R | |
| +38,39 | 0x1093 | Not used | 0 | 0 | UINT32 | R | |
| +40,41 | 0x1094 | Not used | 0 | 0 | UINT32 | R | |
| +42,43 | 0x1095 | Not used | 0 | 0 | UINT32 | R | |
| +44,45 | 0x1096 | Not used | 0 | 0 | UINT32 | R | |
| +46,47 | 0x1097 | Not used | 0 | 0 | UINT32 | R | |
| 13952-14029 | | 1-Second Phase Values | | | | | |
| +0,1 | 0x1100 | V1 voltage | 0-Vmax | U1 | UINT32 | R | 1, DC-applicable |
| +2,3 | 0x1101 | V2 voltage | 0-Vmax | U1 | UINT32 | R | 1, DC-applicable |
| +4,5 | 0x1102 | V3 voltage | 0-Vmax | U1 | UINT32 | R | 1, DC-applicable |
| +6,7 | 0x1103 | I1 current | 0-Imax | U2 | UINT32 | R | DC-applicable |
| +8,9 | 0x1104 | I2 current | 0-Imax | U2 | UINT32 | R | DC-applicable |
| +10,11 | 0x1105 | I3 current | 0-Imax | U2 | UINT32 | R | DC-applicable |
| +12,13 | 0x1106 | kW L1 | -Pmax-Pmax | U3 | INT32 | R | DC-applicable |
| +14,15 | 0x1107 | kW L2 | -Pmax-Pmax | U3 | INT32 | R | DC-applicable |
| +16,17 | 0x1108 | kW L3 | -Pmax-Pmax | U3 | INT32 | R | DC-applicable |
| +18,19 | 0x1109 | kvar L1 | -Pmax-Pmax | U3 | INT32 | R | |
| +20,21 | 0x110A | kvar L2 | -Pmax-Pmax | U3 | INT32 | R | |
| +22,23 | 0x110B | kvar L3 | -Pmax-Pmax | U3 | INT32 | R | |
| +24,25 | 0x110C | kVA L1 | 0-Pmax | U3 | UINT32 | R | |
| +26,27 | 0x110D | kVA L2 | 0-Pmax | U3 | UINT32 | R | |
| +28,29 | 0x110E | kVA L3 | 0-Pmax | U3 | UINT32 | R | |
| +30,31 | 0x110F | Power factor L1 | -1000-1000 | ×0.001 | INT32 | R | |
| +32,33 | 0x1110 | Power factor L2 | -1000-1000 | ×0.001 | INT32 | R | |
| +34,35 | 0x1111 | Power factor L3 | -1000-1000 | ×0.001 | INT32 | R | |
| +36,37 | 0x1112 | V1 voltage THD | 0-9999 | ×0.1% | UINT32 | R | 2, 5 |
| +38,39 | 0x1113 | V2 voltage THD | 0-9999 | ×0.1% | UINT32 | R | 2, 5 |
| +40,41 | 0x1114 | V3 voltage THD | 0-9999 | ×0.1% | UINT32 | R | 2, 5 |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|----------------------------------|----------------------------|--------------------|--------|-----|---------------|
| +42,43 | 0x1115 | I1 current THD | 0-9999 | ×0.1% | UINT32 | R | 5 |
| +44,45 | 0x1116 | I2 current THD | 0-9999 | ×0.1% | UINT32 | R | 5 |
| +46,47 | 0x1117 | I3 current THD | 0-9999 | ×0.1% | UINT32 | R | 5 |
| +48,49 | 0x1118 | I1 K-Factor | 10-9999 | ×0.1 | UINT32 | R | 5 |
| +50,51 | 0x1119 | I2 K-Factor | 10-9999 | ×0.1 | UINT32 | R | 5 |
| +52,53 | 0x111A | I3 K-Factor | 10-9999 | ×0.1 | UINT32 | R | 5 |
| +54,55 | 0x111B | I1 current TDD | 0-1000 | ×0.1% | UINT32 | R | 5 |
| +56,57 | 0x111C | I2 current TDD | 0-1000 | ×0.1% | UINT32 | R | 5 |
| +58,59 | 0x111D | I3 current TDD | 0-1000 | ×0.1% | UINT32 | R | 5 |
| +60,61 | 0x111E | V12 voltage | 0-Vmax | U1 | UINT32 | R | |
| +62,63 | 0x111F | V23 voltage | 0-Vmax | U1 | UINT32 | R | |
| +64,65 | 0x1120 | V31 voltage | 0-Vmax | U1 | UINT32 | R | |
| +66,67 | 0x1121 | Not used | 0 | 0 | UINT32 | R | |
| +68,69 | 0x1122 | Not used | 0 | 0 | UINT32 | R | |
| +70,71 | 0x1123 | Not used | 0 | 0 | UINT32 | R | |
| +72,73 | 0x1124 | Not used | 0 | 0 | UINT32 | R | |
| +74,75 | 0x1125 | Not used | 0 | 0 | UINT32 | R | |
| +76,77 | 0x1126 | Not used | 0 | 0 | UINT32 | R | |
| 14080-14107 | | 1-Second Low Phase Values | | | | | |
| +0,1 | 0x1200 | Low L-N voltage | 0-Vmax | U1 | UINT32 | R | |
| +2,3 | 0x1201 | Low current | 0-Imax | U2 | UINT32 | R | |
| +4,5 | 0x1202 | Low kW | -Pmax-Pmax | U3 | INT32 | R | DC-applicable |
| +6,7 | 0x1203 | Low kvar | -Pmax-Pmax | U3 | INT32 | R | |
| +8,9 | 0x1204 | Low kVA | 0-Pmax | U3 | UINT32 | R | |
| +10,11 | 0x1205 | Low PF Lag | 0-1000 | ×0.001 | UINT32 | R | |
| +12,13 | 0x1206 | Low PF Lead | 0-1000 | ×0.001 | UINT32 | R | |
| +14,15 | 0x1207 | Low voltage THD | 0-9999 | ×0.1% | UINT32 | R | 2, 5 |
| +16,17 | 0x1208 | Low current THD | 0-9999 | ×0.1% | UINT32 | R | 5 |
| +18,19 | 0x1209 | Low K-Factor | 10-9999 | ×0.1 | UINT32 | R | 5 |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|-----------------------------------|----------------------------|--------------------|--------|-----|---------------|
| +20,21 | 0x120A | Low current TDD | 0-1000 | ×0.1% | UINT32 | R | 5 |
| +22,23 | 0x120B | Low L-L voltage | 0-Vmax | U1 | UINT32 | R | |
| +24,25 | 0x120C | Low voltage interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | 2, 5 |
| +26,27 | 0x120D | Low current interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | 5 |
| 14144-14175 | | 3-Second Powers | | | | | |
| +0,1 | 0x1280 | kW L1 | -Pmax-Pmax | U3 | INT32 | R | DC-applicable |
| +2,3 | 0x1281 | kW L2 | -Pmax-Pmax | U3 | INT32 | R | DC-applicable |
| +4,5 | 0x1282 | kW L3 | -Pmax-Pmax | U3 | INT32 | R | DC-applicable |
| +6,7 | 0x1283 | kvar L1 | -Pmax-Pmax | U3 | INT32 | R | |
| +8,9 | 0x1284 | kvar L2 | -Pmax-Pmax | U3 | INT32 | R | |
| +10,11 | 0x1285 | kvar L3 | -Pmax-Pmax | U3 | INT32 | R | |
| +12,13 | 0x1286 | kVA L1 | 0-Pmax | U3 | UINT32 | R | |
| +14,15 | 0x1287 | kVA L2 | 0-Pmax | U3 | UINT32 | R | |
| +16,17 | 0x1288 | kVA L3 | 0-Pmax | U3 | UINT32 | R | |
| +18,19 | 0x1289 | Power factor L1 | -1000-1000 | ×0.001 | INT32 | R | |
| +20,21 | 0x128A | Power factor L2 | -1000-1000 | ×0.001 | INT32 | R | |
| +22,23 | 0x128B | Power factor L3 | -1000-1000 | ×0.001 | INT32 | R | |
| +24,25 | 0x128C | Total kW | -Pmax-Pmax | U3 | INT32 | R | DC-applicable |
| +26,27 | 0x128D | Total kvar | -Pmax-Pmax | U3 | INT32 | R | |
| +28,29 | 0x128E | Total kVA | 0-Pmax | U3 | UINT32 | R | |
| +30,31 | 0x128F | Total PF | -1000-1000 | ×0.001 | INT32 | R | |
| 14208-14235 | | 1-Second High Phase Values | | | | | |
| +0,1 | 0x1300 | High L-N voltage | 0-Vmax | U1 | UINT32 | R | |
| +2,3 | 0x1301 | High current | 0-Imax | U2 | UINT32 | R | |
| +4,5 | 0x1302 | High kW | -Pmax-Pmax | U3 | INT32 | R | DC-applicable |
| +6,7 | 0x1303 | High kvar | -Pmax-Pmax | U3 | INT32 | R | |
| +8,9 | 0x1304 | High kVA | 0-Pmax | U3 | UINT32 | R | |
| +10,11 | 0x1305 | High PF Lag | 0-1000 | ×0.001 | UINT32 | R | |
| +12,13 | 0x1306 | High PF Lead | 0-1000 | ×0.001 | UINT32 | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|----------------------------------|----------------------------|--------------------|--------|-----|---------------|
| +14,15 | 0x1307 | High voltage THD | 0-9999 | ×0.1% | UINT32 | R | 2, 5 |
| +16,17 | 0x1308 | High current THD | 0-9999 | ×0.1% | UINT32 | R | 5 |
| +18,19 | 0x1309 | High K-Factor | 10-9999 | ×0.1 | UINT32 | R | 5 |
| +20,21 | 0x130A | High current TDD | 0-1000 | ×0.1% | UINT32 | R | 5 |
| +22,23 | 0x130B | High L-L voltage | 0-Vmax | U1 | UINT32 | R | |
| +24,25 | 0x130C | High voltage interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | 2, 5 |
| +26,27 | 0x130D | High current interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | 5 |
| 14336-14363 | | 1-Second Total Values | | | | | |
| +0,1 | 0x1400 | Total kW | -Pmax-Pmax | U3 | INT32 | R | DC-applicable |
| +2,3 | 0x1401 | Total kvar | -Pmax-Pmax | U3 | INT32 | R | |
| +4,5 | 0x1402 | Total kVA | 0-Pmax | U3 | UINT32 | R | |
| +6,7 | 0x1403 | Total PF | -1000-1000 | ×0.001 | INT32 | R | |
| +8,9 | 0x1404 | Total PF lag | 0-1000 | ×0.001 | UINT32 | R | |
| +10,11 | 0x1405 | Total PF lead | 0-1000 | ×0.001 | UINT32 | | |
| +12,13 | 0x1406 | Total kW import | 0-Pmax | U3 | UINT32 | | DC-applicable |
| +14,15 | 0x1407 | Total kW export | 0-Pmax | U3 | UINT32 | R | DC-applicable |
| +16,17 | 0x1408 | Total kvar import | 0-Pmax | U3 | UINT32 | R | |
| +18,19 | 0x1409 | Total kvar export | 0-Pmax | U3 | UINT32 | R | |
| +20,21 | 0x140A | 3-phase average L-N voltage | 0-Vmax | U1 | UINT32 | R | |
| +22,23 | 0x140B | 3-phase average L-L voltage | 0-Vmax | U1 | UINT32 | R | |
| +24,25 | 0x140C | 3-phase average current | 0-Imax | U2 | UINT32 | R | |
| +26,27 | 0x140D | Not used | 0 | 0 | UINT32 | R | |
| 14464-14485 | | 1-Second Auxiliary Values | | | | | |
| +0,1 | 0x1500 | I4 current | 0-Imax | U2 | UINT32 | R | DC-applicable |
| +2,3 | 0x1501 | In current | 0-Imax | U2 | UINT32 | R | |
| +4,5 | 0x1502 | Frequency | 0-10000 | ×0.01Hz | UINT32 | R | |
| +6,7 | 0x1503 | Voltage unbalance | 0-3000 | ×0.1% | UINT32 | R | |
| +8,9 | 0x1504 | Current unbalance | 0-3000 | ×0.1% | UINT32 | R | |
| +10,11 | 0x1505 | Not used | | | UINT32 | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|---------------------------------|----------------------------|--------------------|--------|-----|------------------|
| +12,13 | 0x1506 | Not used | 0 | 0 | UINT32 | R | |
| +14,15 | 0x1507 | Not used | 0 | 0 | UINT32 | R | |
| +16,17 | 0x1508 | Not used | 0 | 0 | UINT32 | R | |
| +18,19 | 0x1509 | Internal temperature | -2000 to 2000 | ×0.1°C | INT32 | R | |
| +20,21 | 0x150A | Frequency (3 decimals) | 0-100000 | ×0.001Hz | UINT32 | R | |
| +22,23 | 0x150B | Vbatt | 0-3.5V | ×0.001V | UINT32 | R | |
| +24,25 | 0x150C | Internal temperature | -2000 to 2000 | ×0.1°C | INT32 | R | |
| +26,27 | 0x150D | Frequency (4 decimals) | 0-1000000 | ×0.0001Hz | UINT32 | R | |
| +28,29 | 0x150E | I leakage current | 0-lmax | U2 | UINT32 | R | |
| +30,31 | 0x150F | V3xl4kW | -Pmax-Pmax | U3 | INT32 | R | DC-applicable |
| 14528-14551 | | Present Harmonic Demands | | | | | |
| +0,1 | 0x1580 | V1 THD demand | 0-9999 | ×0.1% | UINT32 | R | 2 |
| +2,3 | 0x1581 | V2 THD demand | 0-9999 | ×0.1% | UINT32 | R | 2 |
| +4,5 | 0x1582 | V3 THD demand | 0-9999 | ×0.1% | UINT32 | R | 2 |
| +6,7 | 0x1583 | Not used | 0 | 0 | UINT32 | R | |
| +8,9 | 0x1584 | I1 THD demand | 0-9999 | ×0.1% | UINT32 | R | |
| +10,11 | 0x1585 | I2 THD demand | 0-9999 | ×0.1% | UINT32 | R | |
| +12,13 | 0x1586 | I3 THD demand | 0-9999 | ×0.1% | UINT32 | R | |
| +14,15 | 0x1587 | I4 THD demand | 0-9999 | ×0.1% | UINT32 | R | |
| +16,17 | 0x1588 | I1 TDD demand | 0-1000 | ×0.1% | UINT32 | R | |
| +18,19 | 0x1589 | I2 TDD demand | 0-1000 | ×0.1% | UINT32 | R | |
| +20,21 | 0x158A | I3 TDD demand | 0-1000 | ×0.1% | UINT32 | R | |
| +22,23 | 0x158B | I4 TDD demand | 0-1000 | ×0.1% | UINT32 | R | |
| 14592-14661 | | Present Demands | | | | | |
| +0,1 | 0x1600 | V1 volt demand | 0-Vmax | U1 | UINT32 | R | 2, DC-applicable |
| +2,3 | 0x1601 | V2 volt demand | 0-Vmax | U1 | UINT32 | R | 2, DC-applicable |
| +4,5 | 0x1602 | V3 volt demand | 0-Vmax | U1 | UINT32 | R | 2, DC-applicable |
| +6,7 | 0x1603 | I1 ampere demand | 0-lmax | U2 | UINT32 | R | DC-applicable |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|---------|----------|---|----------------------------|--------------------|--------|-----|---------------|
| +8,9 | 0x1604 | I2 ampere demand | 0-I _{max} | U2 | UINT32 | R | DC-applicable |
| +10,11 | 0x1605 | I3 ampere demand | 0-I _{max} | U2 | UINT32 | R | DC-applicable |
| +12,13 | 0x1606 | kW import block demand | 0-P _{max} | U3 | UINT32 | R | DC-applicable |
| +14,15 | 0x1607 | kvar import block demand | 0-P _{max} | U3 | UINT32 | R | |
| +16,17 | 0x1608 | kVA block demand | 0-P _{max} | U3 | UINT32 | R | |
| +18,19 | 0x1609 | kW import sliding window demand | 0-P _{max} | U3 | UINT32 | R | DC-applicable |
| +20,21 | 0x160A | kvar import sliding window demand | 0-P _{max} | U3 | UINT32 | R | |
| +22,23 | 0x160B | kVA sliding window demand | 0-P _{max} | U3 | UINT32 | R | |
| +24,25 | 0x160C | Not used | 0 | | UINT32 | R | |
| +26,27 | 0x160D | Not used | 0 | | UINT32 | R | |
| +28,29 | 0x160E | Not used | 0 | | UINT32 | R | |
| +30,31 | 0x160F | kW import accumulated demand | 0-P _{max} | U3 | UINT32 | R | DC-applicable |
| +32,33 | 0x1610 | kvar import accumulated demand | 0-P _{max} | U3 | UINT32 | R | |
| +34,35 | 0x1611 | kVA accumulated demand | 0-P _{max} | U3 | UINT32 | R | |
| +36,37 | 0x1612 | kW import predicted sliding window demand | 0-P _{max} | U3 | UINT32 | R | DC-applicable |
| +38,39 | 0x1613 | kvar import predicted sliding window demand | 0-P _{max} | U3 | UINT32 | R | |
| +40,41 | 0x1614 | kVA predicted sliding window demand | 0-P _{max} | U3 | UINT32 | R | |
| +42,43 | 0x1615 | PF (import) at Max. kVA sliding window demand | 0-1000 | ×0.001 | UINT32 | R | |
| +44,45 | 0x1616 | kW export block demand | 0-P _{max} | U3 | UINT32 | R | DC-applicable |
| +46,47 | 0x1617 | kvar export block demand | 0-P _{max} | U3 | UINT32 | R | |
| +48,49 | 0x1618 | kW export sliding window demand | 0-P _{max} | U3 | UINT32 | R | DC-applicable |
| +50,51 | 0x1619 | kvar export sliding window demand | 0-P _{max} | U3 | UINT32 | R | |
| +52,53 | 0x161A | kW export accumulated demand | 0-P _{max} | U3 | UINT32 | R | DC-applicable |
| +54,55 | 0x161B | kvar export accumulated demand | 0-P _{max} | U3 | UINT32 | R | |
| +56,57 | 0x161C | kW export predicted sliding window demand | 0-P _{max} | U3 | UINT32 | R | DC-applicable |
| +58,59 | 0x161D | kvar export predicted sliding window demand | 0-P _{max} | U3 | UINT32 | R | |
| +60,61 | 0x161E | Not used | 0 | | UINT32 | R | |
| +62,63 | 0x161F | Not used | 0 | | UINT32 | R | |
| +64,65 | 0x1620 | Not used | 0 | 0 | UINT32 | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|----------------------------------|----------------------------|--------------------|--------|-----|---------------|
| +66,67 | 0x1621 | I4 ampere demand | 0-I _{max} | U2 | UINT32 | R | DC-applicable |
| +68,69 | 0x1622 | In ampere demand | 0-I _{max} | U2 | UINT32 | R | |
| 14720-14741 | | Total Energies | | | | | |
| +0,1 | 0x1700 | kWh import | 0-999,999,999 | U5 | UINT32 | R | DC-applicable |
| +2,3 | 0x1701 | kWh export | 0-999,999,999 | U5 | UINT32 | R | DC-applicable |
| +4,5 | 0x1702 | kWh net | -999,999,999-999,999,999 | U5 | INT32 | R | DC-applicable |
| +6,7 | 0x1703 | kWh total | 0-999,999,999 | U5 | UINT32 | R | DC-applicable |
| +8,9 | 0x1704 | kvarh import | 0-999,999,999 | U5 | UINT32 | R | |
| +10,11 | 0x1705 | kvarh export | 0-999,999,999 | U5 | UINT32 | R | |
| +12,13 | 0x1706 | kvarh net | -999,999,999-999,999,999 | U5 | INT32 | R | |
| +14,15 | 0x1707 | kvarh total | 0-999,999,999 | U5 | UINT32 | R | |
| +16,17 | 0x1708 | kVAh total | 0-999,999,999 | U5 | UINT32 | R | |
| +18,19 | 0x1709 | Vh total | 0-999,999,999 | 1 Vh | UINT32 | R | |
| +20,21 | 0x170A | Ah total | 0-999,999,999 | 1 Ah | UINT32 | R | |
| +22,23 | 0x170B | kVAh import | 0-999,999,999 | U5 | UINT32 | R | |
| +24,25 | 0x170C | kVAh export | 0-999,999,999 | U5 | UINT32 | R | |
| +26,27 | 0x170D | Not used | | | UINT32 | R | |
| +28,29 | 0x170E | Not used | | | UINT32 | R | |
| +30,31 | 0x170F | Not used | | | UINT32 | R | |
| +32,33 | 0x1710 | Not used | | | UINT32 | R | |
| +34,35 | 0x1711 | Not used | | | UINT32 | R | |
| +36,37 | 0x1712 | kvarh Q1 | 0-999,999,999 | U5 | UINT32 | R | |
| +38,39 | 0x1713 | kvarh Q2 | 0-999,999,999 | U5 | UINT32 | R | |
| +40,41 | 0x1714 | kvarh Q3 | 0-999,999,999 | U5 | UINT32 | R | |
| +42,43 | 0x1715 | kvarh Q4 | 0-999,999,999 | U5 | UINT32 | R | |
| 14784-14815 | | Billing Summary Registers | | | | | |
| +0,1 | 0x1780 | Summary energy register #1 | 0-999,999,999 | U5 | UINT32 | R | |
| +2,3 | 0x1781 | Summary energy register #2 | 0-999,999,999 | U5 | UINT32 | R | |
| | | ... | | | | | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|-------------------------------------|----------------------------|--------------------|--------|-----|---------------|
| +30,31 | 0x178F | Summary energy register #16 | 0-999,999,999 | U5 | UINT32 | R | |
| 14848-14865 | | Phase Energies | | | | | |
| +0,1 | 0x1800 | kWh import L1 | 0-999,999,999 | U5 | UINT32 | R | DC-applicable |
| +2,3 | 0x1801 | kWh import L2 | 0-999,999,999 | U5 | UINT32 | R | DC-applicable |
| +4,5 | 0x1802 | kWh import L3 | 0-999,999,999 | U5 | UINT32 | R | DC-applicable |
| +6,7 | 0x1803 | kvarh import L1 | 0-999,999,999 | U5 | UINT32 | R | |
| +8,9 | 0x1804 | kvarh import L2 | 0-999,999,999 | U5 | UINT32 | R | |
| +10,11 | 0x1805 | kvarh import L3 | 0-999,999,999 | U5 | UINT32 | R | |
| +12,13 | 0x1806 | kVAh total L1 | 0-999,999,999 | U5 | UINT32 | R | |
| +14,15 | 0x1807 | kVAh total L2 | 0-999,999,999 | U5 | UINT32 | R | |
| +16,17 | 0x1808 | kVAh total L3 | 0-999,999,999 | U5 | UINT32 | R | |
| +18,19 | 0x1809 | kWh export L1 | 0-999,999,999 | U5 | UINT32 | R | DC-applicable |
| +20,21 | 0x180A | kWh export L2 | 0-999,999,999 | U5 | UINT32 | R | DC-applicable |
| +22,23 | 0x180B | kWh export L3 | 0-999,999,999 | U5 | UINT32 | R | DC-applicable |
| +24,25 | 0x180C | kvarh export L1 | 0-999,999,999 | U5 | UINT32 | R | |
| +26,27 | 0x180D | kvarh export L2 | 0-999,999,999 | U5 | UINT32 | R | |
| +28,29 | 0x180E | kvarh export L3 | 0-999,999,999 | U5 | UINT32 | R | |
| 14912-14931 | | Symmetrical Components | | | | | |
| +0, 1 | 0x1880 | Positive-sequence voltage | 0-Vmax | U1 | UINT32 | R | |
| +2, 3 | 0x1881 | Negative-sequence voltage | 0-Vmax | U1 | UINT32 | R | |
| +4, 5 | 0x1882 | Zero-sequence voltage | 0-Vmax | U1 | UINT32 | R | |
| +6, 7 | 0x1883 | Negative-sequence voltage unbalance | 0-3000 | ×0.1% | UINT32 | R | |
| +8, 9 | 0x1884 | Zero-sequence voltage unbalance | 0-3000 | ×0.1% | UINT32 | R | |
| +10, 11 | 0x1885 | Positive-sequence current | 0-Imax | U2 | UINT32 | R | |
| +12, 13 | 0x1886 | Negative-sequence current | 0-Imax | U2 | UINT32 | R | |
| +14, 15 | 0x1887 | Zero-sequence current | 0-Imax | U2 | UINT32 | R | |
| +16, 17 | 0x1888 | Negative-sequence current unbalance | 0-3000 | ×0.1% | UINT32 | R | |
| +18, 19 | 0x1889 | Zero-sequence current unbalance | 0-3000 | ×0.1% | UINT32 | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|------------------------|----------------------------|--------------------|--------|-----|-------|
| 14976-15101 | | V1 Harmonics | | | | | 2, 7 |
| +0, 1 | 0x1900 | H01 Harmonic magnitude | 0-10000 | ×0.01% | UINT32 | R | |
| +2, 3 | 0x1901 | H02 Harmonic magnitude | 0-10000 | ×0.01% | UINT32 | R | |
| | | ... | | | | | |
| +124, 125 | 0x193E | H63 Harmonic magnitude | 0-10000 | ×0.01% | UINT32 | R | |
| 15104-15229 | | V2 Harmonics | | | | | 2, 7 |
| +0, 1 | 0x1A00 | H01 Harmonic magnitude | 0-10000 | ×0.01% | UINT32 | R | |
| +2, 3 | 0x1A01 | H02 Harmonic magnitude | 0-10000 | ×0.01% | UINT32 | R | |
| | | ... | | | | | |
| +124, 125 | 0x1A3E | H63 Harmonic magnitude | 0-10000 | ×0.01% | UINT32 | R | |
| 15232-15357 | | V3 Harmonics | | | | | 2, 7 |
| +0, 1 | 0x1B00 | H01 Harmonic magnitude | 0-10000 | ×0.01% | UINT32 | R | |
| +2, 3 | 0x1B01 | H02 Harmonic magnitude | 0-10000 | ×0.01% | UINT32 | R | |
| | | ... | | | | | |
| +124, 125 | 0x1B3E | H63 Harmonic magnitude | 0-10000 | ×0.01% | UINT32 | R | |
| 16896-17021 | | V4 Harmonics | | | | | 7 |
| +0, 1 | 0x2800 | Not used | 0 | 0 | UINT32 | R | |
| +2, 3 | 0x2801 | Not used | 0 | 0 | UINT32 | R | |
| | | ... | | | | | |
| +124, 125 | 0x283E | Not used | 0 | 0 | UINT32 | R | |
| 15360-15485 | | I1 Harmonics | | | | | 7 |
| +0, 1 | 0x1C00 | H01 Harmonic magnitude | 0-10000 | ×0.01% | UINT32 | R | |
| +2, 3 | 0x1C01 | H02 Harmonic magnitude | 0-10000 | ×0.01% | UINT32 | R | |
| | | ... | | | | | |
| +124, 125 | 0x1C3E | H63 Harmonic magnitude | 0-10000 | ×0.01% | UINT32 | R | |
| 15488-15613 | | I2 Harmonics | | | | | 7 |
| +0, 1 | 0x1D00 | H01 Harmonic magnitude | 0-10000 | ×0.01% | UINT32 | R | |
| +2, 3 | 0x1D01 | H02 Harmonic magnitude | 0-10000 | ×0.01% | UINT32 | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|---|----------------------------|--------------------|--------|-----|-------|
| | | ... | | | | | |
| +124, 125 | 0x1D3E | H63 Harmonic magnitude | 0-10000 | ×0.01% | UINT32 | R | |
| 15616-15741 | | I3 Harmonics | | | | | 7 |
| +0, 1 | 0x1E00 | H01 Harmonic magnitude | 0-10000 | ×0.01% | UINT32 | R | |
| +2, 3 | 0x1E01 | H02 Harmonic magnitude | 0-10000 | ×0.01% | UINT32 | R | |
| | | ... | | | | | |
| +124, 125 | 0x1E3E | H63 Harmonic magnitude | 0-10000 | ×0.01% | UINT32 | R | |
| 17280-17405 | | I4 Harmonics | | | | | 7 |
| +0, 1 | 0x2B00 | H01 Harmonic magnitude | 0-10000 | 0.01% | UINT32 | R | |
| +2, 3 | 0x2B01 | H02 Harmonic magnitude | 0-10000 | 0.01% | UINT32 | R | |
| | | ... | | | | | |
| +124, 125 | 0x2B3E | H63 Harmonic magnitude | 0-10000 | 0.01% | UINT32 | R | |
| 15744-15807 | | V1 Harmonic Voltages (odd numbers) | | | | | 2, 4 |
| +0, 1 | 0x1F00 | H01 Harmonic voltage | 0-Vmax | U1 | UINT32 | R | |
| +2, 3 | 0x1F01 | H03 Harmonic voltage | 0-Vmax | U1 | UINT32 | R | |
| | | ... | | | | | |
| +62, 63 | 0x1F3E | H63 Harmonic voltage | 0-Vmax | U1 | UINT32 | R | |
| 15872-15935 | | V2 Harmonic Voltages (odd numbers) | | | | | 2, 4 |
| +0, 1 | 0x2000 | H01 Harmonic voltage | 0-Vmax | U1 | UINT32 | R | |
| +2, 3 | 0x2001 | H03 Harmonic voltage | 0-Vmax | U1 | UINT32 | R | |
| | | ... | | | | | |
| +62, 63 | 0x203E | H63 Harmonic voltage | 0-Vmax | U1 | UINT32 | R | |
| 16000-16063 | | V3 Harmonic Voltages (odd numbers) | | | | | 2, 4 |
| +0, 1 | 0x2100 | H01 Harmonic voltage | 0-Vmax | U1 | UINT32 | R | |
| +2, 3 | 0x2101 | H03 Harmonic voltage | 0-Vmax | U1 | UINT32 | R | |
| | | ... | | | | | |
| +62, 63 | 0x213E | H63 Harmonic voltage | 0-Vmax | U1 | UINT32 | R | |
| 18048-18111 | | V4 Harmonic Voltages (odd numbers) | | | | | 4 |
| +0, 1 | 0x3100 | Not used | 0 | 0 | UINT32 | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|---|----------------------------|--------------------|--------|-----|-------|
| +2, 3 | 0x3101 | Not used | 0 | 0 | UINT32 | R | |
| | | ... | | | | | |
| +62, 63 | 0x313E | Not used | 0 | 0 | UINT32 | R | |
| 16128-16191 | | I1 Harmonic Currents (odd numbers) | | | | | 4 |
| +0, 1 | 0x2200 | H01 Harmonic current | 0-lmax | U2 | UINT32 | R | |
| +2, 3 | 0x2201 | H03 Harmonic current | 0-lmax | U2 | UINT32 | R | |
| | | ... | | | | | |
| +62, 63 | 0x223E | H63 Harmonic current | 0-lmax | U2 | UINT32 | R | |
| 16256-16319 | | I2 Harmonic Currents (odd numbers) | | | | | 4 |
| +0, 1 | 0x2300 | H01 Harmonic current | 0-lmax | U2 | UINT32 | R | |
| +2, 3 | 0x2301 | H03 Harmonic current | 0-lmax | U2 | UINT32 | R | |
| | | ... | | | | | |
| +62, 63 | 0x233E | H63 Harmonic current | 0-lmax | U2 | UINT32 | R | |
| 16384-16447 | | I3 Harmonic Currents (odd numbers) | | | | | 4 |
| +0, 1 | 0x2400 | H01 Harmonic current | 0-lmax | U2 | UINT32 | R | |
| +2, 3 | 0x2401 | H03 Harmonic current | 0-lmax | U2 | UINT32 | R | |
| | | ... | | | | | |
| +62, 63 | 0x243E | H63 Harmonic current | 0-lmax | U2 | UINT32 | R | |
| 18176-18239 | | I4 Harmonic Currents (odd numbers) | | | | | 4 |
| +0, 1 | 0x3200 | H01 Harmonic current | 0-lmax | U2 | UINT32 | R | |
| +2, 3 | 0x3201 | H03 Harmonic current | 0-lmax | U2 | UINT32 | R | |
| | | ... | | | | | |
| +62, 63 | 0x323E | H63 Harmonic current | 0-lmax | U2 | UINT32 | R | |
| 16512-16575 | | Total Harmonic kW (odd numbers) | | | | | 4 |
| +0, 1 | 0x2500 | H01 Harmonic kW | -Pmax –Pmax | U3 | INT32 | R | |
| +2, 3 | 0x2501 | H03 Harmonic kW | -Pmax –Pmax | U3 | INT32 | R | |
| | | ... | | | | | |
| +62, 63 | 0x253E | H63 Harmonic kW | -Pmax –Pmax | U3 | INT32 | R | |
| 16640-16703 | | Total Harmonic kvar (odd numbers) | | | | | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|--|----------------------------|--------------------|--------|-----|------------------|
| +0, 1 | 0x2600 | H01 Harmonic kvar | -Pmax –Pmax | U3 | INT32 | R | 4 |
| +2, 3 | 0x2601 | H03 Harmonic kvar | -Pmax –Pmax | U3 | INT32 | R | |
| | | ... | | | | | |
| +62, 63 | 0x263E | H63 Harmonic kvar | -Pmax –Pmax | U3 | INT32 | R | |
| 16768-16831 | | Total Harmonic Power Factor (odd numbers) | | | | | 4 |
| +0, 1 | 0x2700 | H01 Harmonic PF | -1000-1000 | ×0.001 | INT32 | R | |
| +2, 3 | 0x2701 | H03 Harmonic PF | -1000-1000 | ×0.001 | INT32 | R | |
| | | ... | | | | | |
| +62, 63 | 0x273E | H63 Harmonic PF | -1000-1000 | ×0.001 | INT32 | R | |
| 17088-17099 | | Flicker | | | | | |
| +0,1 | 0x2980 | Not used | 0 | 0 | UINT32 | R | |
| +2,3 | 0x2981 | Not used | 0 | 0 | UINT32 | R | |
| +4,5 | 0x2982 | Not used | 0 | 0 | UINT32 | R | |
| +6,7 | 0x2983 | Not used | 0 | 0 | UINT32 | R | |
| +8,9 | 0x2984 | Not used | 0 | 0 | UINT32 | R | |
| +10,11 | 0x2985 | Not used | 0 | 0 | UINT32 | R | |
| 17408-17479 | | Minimum 1-Cycle Phase Values | | | | | |
| +0, 1 | 0x2C00 | V1 voltage | 0-Vmax | U1 | UINT32 | R | 1, DC-applicable |
| +2, 3 | 0x2C01 | V2 voltage | 0-Vmax | U1 | UINT32 | R | 1, DC-applicable |
| +4, 5 | 0x2C02 | V3 voltage | 0-Vmax | U1 | UINT32 | R | 1, DC-applicable |
| +6, 7 | 0x2C03 | I1 current | 0-Imax | U2 | UINT32 | R | DC-applicable |
| +8, 9 | 0x2C04 | I2 current | 0-Imax | U2 | UINT32 | R | DC-applicable |
| +10, 11 | 0x2C05 | I3 current | 0-Imax | U2 | UINT32 | R | DC-applicable |
| +12, 13 | 0x2C06 | kW L1 | -Pmax-Pmax | U3 | INT32 | R | DC-applicable |
| +14, 15 | 0x2C07 | kW L2 | -Pmax-Pmax | U3 | INT32 | R | DC-applicable |
| +16, 17 | 0x2C08 | kW L3 | -Pmax-Pmax | U3 | INT32 | R | DC-applicable |
| +18, 19 | 0x2C09 | kvar L1 | -Pmax-Pmax | U3 | INT32 | R | |
| +20, 21 | 0x2C0A | kvar L2 | -Pmax-Pmax | U3 | INT32 | R | |
| +22, 23 | 0x2C0B | kvar L3 | -Pmax-Pmax | U3 | INT32 | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|-------------------------------------|----------------------------|--------------------|--------|-----|----------------|
| +24, 25 | 0x2C0C | kVA L1 | 0-Pmax | U3 | UINT32 | R | |
| +26, 27 | 0x2C0D | kVA L2 | 0-Pmax | U3 | UINT32 | R | |
| +28, 29 | 0x2C0E | kVA L3 | 0-Pmax | U3 | UINT32 | R | |
| +30, 31 | 0x2C0F | Power factor L1 | 0-1000 | ×0.001 | UINT32 | R | Absolute value |
| +32, 33 | 0x2C10 | Power factor L2 | 0-1000 | ×0.001 | UINT32 | R | Absolute value |
| +34, 35 | 0x2C11 | Power factor L3 | 0-1000 | ×0.001 | UINT32 | R | Absolute value |
| +36, 37 | 0x2C12 | V1 voltage THD | 0-9999 | ×0.1% | UINT32 | R | 2, 4 |
| +38, 39 | 0x2C13 | V2 voltage THD | 0-9999 | ×0.1% | UINT32 | R | 2, 4 |
| +40, 41 | 0x2C14 | V3 voltage THD | 0-9999 | ×0.1% | UINT32 | R | 2, 4 |
| +42, 43 | 0x2C15 | I1 current THD | 0-9999 | ×0.1% | UINT32 | R | 4 |
| +44, 45 | 0x2C16 | I2 current THD | 0-9999 | ×0.1% | UINT32 | R | 4 |
| +46, 47 | 0x2C17 | I3 current THD | 0-9999 | ×0.1% | UINT32 | R | 4 |
| +48, 49 | 0x2C18 | I1 K-Factor | 10-9999 | ×0.1 | UINT32 | R | 4 |
| +50, 51 | 0x2C19 | I2 K-Factor | 10-9999 | ×0.1 | UINT32 | R | 4 |
| +52, 53 | 0x2C1A | I3 K-Factor | 10-9999 | ×0.1 | UINT32 | R | 4 |
| +54, 55 | 0x2C1B | I1 current TDD | 0-1000 | ×0.1% | UINT32 | R | 4 |
| +56, 57 | 0x2C1C | I2 current TDD | 0-1000 | ×0.1% | UINT32 | R | 4 |
| +58, 59 | 0x2C1D | I3 current TDD | 0-1000 | ×0.1% | UINT32 | R | 4 |
| +60, 61 | 0x2C1E | V12 voltage | 0-Vmax | U1 | UINT32 | R | |
| +62, 63 | 0x2C1F | V23 voltage | 0-Vmax | U1 | UINT32 | R | |
| +64, 65 | 0x2C20 | V31 voltage | 0-Vmax | U1 | UINT32 | R | |
| +66, 67 | 0x2C21 | Not used | 0 | 0 | UINT32 | R | |
| +68, 69 | 0x2C22 | Not used | 0 | 0 | UINT32 | R | |
| +70, 71 | 0x2C23 | Not used | 0 | 0 | UINT32 | R | |
| 17536-17547 | | Minimum 1-Cycle Total Values | | | | | |
| +0, 1 | 0x2D00 | Total kW | -Pmax-Pmax | U3 | INT32 | R | DC-applicable |
| +2, 3 | 0x2D01 | Total kvar | -Pmax-Pmax | U3 | INT32 | R | |
| +4, 5 | 0x2D02 | Total kVA | 0-Pmax | U3 | UINT32 | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|--|----------------------------|--------------------|--------|-----|------------------|
| +6, 7 | 0x2D03 | Total PF | 0-1000 | ×0.001 | UINT32 | R | Absolute value |
| +8, 9 | 0x2D04 | Total PF lag | 0-1000 | ×0.001 | UINT32 | R | |
| +10, 11 | 0x2D05 | Total PF lead | 0-1000 | ×0.001 | UINT32 | R | |
| 17664-17685 | | Minimum 1-Cycle Auxiliary Values | | | | | |
| +0, 1 | 0x2E00 | I4 current | 0-I _{max} | U2 | UINT32 | R | DC-applicable |
| +2, 3 | 0x2E01 | In current | 0-I _{max} | U2 | UINT32 | R | |
| +4, 5 | 0x2E02 | Frequency | 0-10000 | ×0.01Hz | UINT32 | R | |
| +6, 7 | 0x2E03 | Voltage unbalance | 0-3000 | ×0.1% | UINT32 | R | |
| +8, 9 | 0x2E04 | Current unbalance | 0-3000 | ×0.1% | UINT32 | R | |
| +10, 11 | 0x2E05 | Not used | | | UINT32 | R | |
| +12, 13 | 0x2E06 | Not used | 0 | 0 | UINT32 | R | |
| +14, 15 | 0x2E07 | Not used | 0 | 0 | UINT32 | R | |
| +16, 17 | 0x2E08 | Not used | 0 | 0 | UINT32 | R | 4 |
| +18, 19 | 0x2E09 | Not used | 0 | 0 | UINT32 | R | 4 |
| +20, 21 | 0x2E0A | Not used | 0 | 0 | UINT32 | R | 4 |
| 17728-17759 | | Minimum Analog Inputs | | | | | |
| +0,1 | 0x2E80 | Analog input AI1 | AI1min-AI1max | | INT32 | R | |
| +2,3 | 0x2E81 | Analog input AI2 | AI2min-AI2max | | INT32 | R | |
| | | ... | | | | | |
| +30,31 | 0x2E8F | Analog input AI16 | AI16min-AI16max | | INT32 | R | |
| 17920-17951 | | Programmable Min/Max Minimum Values | | | | | |
| +0, 1 | 0x3000 | Min/Max Register #1 | | | UINT32 | R | |
| +2, 3 | 0x3001 | Min/Max Register #2 | | | UINT32 | R | |
| | | ... | | | | | |
| +30, 31 | 0x300F | Min/Max Register #16 | | | UINT32 | R | |
| 18432-18503 | | Maximum 1-Cycle Phase Values | | | | | |
| +0, 1 | 0x3400 | V1 voltage | 0-V _{max} | U1 | UINT32 | R | 1, DC-applicable |
| +2, 3 | 0x3401 | V2 voltage | 0-V _{max} | U1 | UINT32 | R | 1, DC-applicable |
| +4, 5 | 0x3402 | V3 voltage | 0-V _{max} | U1 | UINT32 | R | 1, DC-applicable |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|---------|----------|-----------------|----------------------------|--------------------|--------|-----|----------------|
| +6, 7 | 0x3403 | I1 current | 0-Imax | U2 | UINT32 | R | DC-applicable |
| +8, 9 | 0x3404 | I2 current | 0-Imax | U2 | UINT32 | R | DC-applicable |
| +10, 11 | 0x3405 | I3 current | 0-Imax | U2 | UINT32 | R | DC-applicable |
| +12, 13 | 0x3406 | kW L1 | -Pmax-Pmax | U3 | INT32 | R | DC-applicable |
| +14, 15 | 0x3407 | kW L2 | -Pmax-Pmax | U3 | INT32 | R | DC-applicable |
| +16, 17 | 0x3408 | kW L3 | -Pmax-Pmax | U3 | INT32 | R | DC-applicable |
| +18, 19 | 0x3409 | kvar L1 | -Pmax-Pmax | U3 | INT32 | R | |
| +20, 21 | 0x340A | kvar L2 | -Pmax-Pmax | U3 | INT32 | R | |
| +22, 23 | 0x340B | kvar L3 | -Pmax-Pmax | U3 | INT32 | R | |
| +24, 25 | 0x340C | kVA L1 | 0-Pmax | U3 | UINT32 | R | |
| +26, 27 | 0x340D | kVA L2 | 0-Pmax | U3 | UINT32 | R | |
| +28, 29 | 0x340E | kVA L3 | 0-Pmax | U3 | UINT32 | R | |
| +30, 31 | 0x340F | Power factor L1 | 0-1000 | ×0.001 | UINT32 | R | Absolute value |
| +32, 33 | 0x3410 | Power factor L2 | 0-1000 | ×0.001 | UINT32 | R | Absolute value |
| +34, 35 | 0x3411 | Power factor L3 | 0-1000 | ×0.001 | UINT32 | R | Absolute value |
| +36, 37 | 0x3412 | V1 voltage THD | 0-9999 | ×0.1% | UINT32 | R | 2, 4 |
| +38, 39 | 0x3413 | V2 voltage THD | 0-9999 | ×0.1% | UINT32 | R | 2, 4 |
| +40, 41 | 0x3414 | V3 voltage THD | 0-9999 | ×0.1% | UINT32 | R | 2, 4 |
| +42, 43 | 0x3415 | I1 current THD | 0-9999 | ×0.1% | UINT32 | R | 4 |
| +44, 45 | 0x3416 | I2 current THD | 0-9999 | ×0.1% | UINT32 | R | 4 |
| +46, 47 | 0x3417 | I3 current THD | 0-9999 | ×0.1% | UINT32 | R | 4 |
| +48, 49 | 0x3418 | I1 K-Factor | 10-9999 | ×0.1 | UINT32 | R | 4 |
| +50, 51 | 0x3419 | I2 K-Factor | 10-9999 | ×0.1 | UINT32 | R | 4 |
| +52, 53 | 0x341A | I3 K-Factor | 10-9999 | ×0.1 | UINT32 | R | 4 |
| +54, 55 | 0x341B | I1 current TDD | 0-1000 | ×0.1% | UINT32 | R | 4 |
| +56, 57 | 0x341C | I2 current TDD | 0-1000 | ×0.1% | UINT32 | R | 4 |
| +58, 59 | 0x341D | I3 current TDD | 0-1000 | ×0.1% | UINT32 | R | 4 |
| +60, 61 | 0x341E | V12 voltage | 0-Vmax | U1 | UINT32 | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|---|----------------------------|--------------------|--------|-----|----------------|
| +62, 63 | 0x341F | V23 voltage | 0-Vmax | U1 | UINT32 | R | |
| +64, 65 | 0x3420 | V31 voltage | 0-Vmax | U1 | UINT32 | R | |
| +66, 67 | 0x3421 | Not used | 0 | 0 | UINT32 | R | |
| +68, 69 | 0x3422 | Not used | 0 | 0 | UINT32 | R | |
| +70, 71 | 0x3423 | Not used | 0 | 0 | UINT32 | R | |
| 18560-18571 | | Maximum 1-Cycle Total Values | | | | | |
| +0, 1 | 0x3500 | Total kW | -Pmax-Pmax | U3 | INT32 | R | DC-applicable |
| +2, 3 | 0x3501 | Total kvar | -Pmax-Pmax | U3 | INT32 | R | |
| +4, 5 | 0x3502 | Total kVA | 0-Pmax | U3 | UINT32 | R | |
| +6, 7 | 0x3503 | Total PF | 0-1000 | ×0.001 | UINT32 | R | Absolute value |
| +8, 9 | 0x3504 | Total PF lag | 0-1000 | ×0.001 | UINT32 | R | |
| +10, 11 | 0x3505 | Total PF lead | 0-1000 | ×0.001 | UINT32 | R | |
| 18668-18709 | | Maximum 1-Cycle Auxiliary Values | | | | | |
| +0, 1 | 0x3600 | I4 current | 0-Imax | U2 | UINT32 | R | DC-applicable |
| +2, 3 | 0x3601 | In current | 0-Imax | U2 | UINT32 | R | |
| +4, 5 | 0x3602 | Frequency | 0-10000 | ×0.01Hz | UINT32 | R | |
| +6, 7 | 0x3603 | Voltage unbalance | 0-3000 | ×0.1% | UINT32 | R | |
| +8, 9 | 0x3604 | Current unbalance | 0-3000 | ×0.1% | UINT32 | R | |
| +10, 11 | 0x3605 | Not used | | | UINT32 | R | |
| +12, 13 | 0x3606 | Not used | 0 | 0 | UINT32 | R | |
| +14, 15 | 0x3607 | Not used | 0 | 0 | UINT32 | R | |
| +16, 17 | 0x3608 | Not used | 0 | 0 | UINT32 | R | |
| +18, 19 | 0x3609 | Not used | 0 | 0 | UINT32 | R | |
| +20, 21 | 0x360A | Not used | 0 | 0 | UINT32 | R | |
| 18732-18795 | | Maximum Analog Inputs | | | | | |
| +0,1 | 0x3680 | Analog input AI1 | AI1min-AI1max | | INT32 | R | |
| +2,3 | 0x3681 | Analog input AI2 | AI2min-AI2max | | INT32 | R | |
| | | ... | | | | | |
| +30,31 | 0x368F | Analog input AI16 | AI16min-AI16max | | INT32 | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|--|----------------------------|--------------------|--------|-----|---------------|
| 18816-18859 | | Maximum Demands | | | | | |
| +0, 1 | 0x3700 | V1 Maximum volt demand | 0-Vmax | U1 | UINT32 | R | DC-applicable |
| +2, 3 | 0x3701 | V2 Maximum volt demand | 0-Vmax | U1 | UINT32 | R | DC-applicable |
| +4, 5 | 0x3702 | V3 Maximum volt demand | 0-Vmax | U1 | UINT32 | R | DC-applicable |
| +6, 7 | 0x3703 | I1 Maximum ampere demand | 0-Imax | U2 | UINT32 | R | DC-applicable |
| +8, 9 | 0x3704 | I2 Maximum ampere demand | 0-Imax | U2 | UINT32 | R | DC-applicable |
| +10, 11 | 0x3705 | I3 Maximum ampere demand | 0-Imax | U2 | UINT32 | R | DC-applicable |
| +12, 13 | 0x3706 | Not used | 0 | | UINT32 | R | |
| +14, 15 | 0x3707 | Not used | 0 | | UINT32 | R | |
| +16, 17 | 0x3708 | Not used | 0 | | UINT32 | R | |
| +18, 19 | 0x3709 | Maximum kW import sliding window demand | 0-Pmax | U3 | UINT32 | R | DC-applicable |
| +20, 21 | 0x370A | Maximum kvar import sliding window demand | 0-Pmax | U3 | UINT32 | R | |
| +22, 23 | 0x370B | Maximum kVA sliding window demand | 0-Pmax | U3 | UINT32 | R | |
| +24, 25 | 0x3737 | Not used | 0 | | UINT32 | R | |
| +26, 27 | 0x370D | Not used | 0 | | UINT32 | R | |
| +28, 29 | 0x370E | Not used | 0 | | UINT32 | R | |
| +30, 31 | 0x370F | Maximum kW export sliding window demand | 0-Pmax | U3 | UINT32 | R | DC-applicable |
| +32, 33 | 0x3710 | Maximum kvar export sliding window demand | 0-Pmax | U3 | UINT32 | R | |
| +34, 35 | 0x3737 | Not used | 0 | | UINT32 | R | |
| +36, 37 | 0x3712 | Not used | 0 | | UINT32 | R | |
| +38, 39 | 0x3713 | Not used | 0 | 0 | UINT32 | R | |
| +40, 41 | 0x3714 | I4 Maximum ampere demand | 0-I4max | U2 | UINT32 | R | DC-applicable |
| +42, 43 | 0x3715 | In Maximum ampere demand | 0-Imax | U2 | UINT32 | R | |
| 18944-18975 | | Programmable Min/Max Maximum Values | | | | | |
| +0, 1 | 0x3800 | Min/Max Register #1 | | | UINT32 | R | |
| +2, 3 | 0x3801 | Min/Max Register #2 | | | UINT32 | R | |
| | | ... | | | | | |
| +30, 31 | 0x380F | Min/Max Register #16 | | | UINT32 | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|-------------------------------------|----------------------------|--------------------|--------|-----|-----------------------------|
| 19008-19031 | | Maximum Harmonic Demands | | | | | |
| +0, 1 | 0x3880 | V1 THD demand | 0-9999 | ×0.1% | UINT32 | R | 2 |
| +2, 3 | 0x3881 | V2 THD demand | 0-9999 | ×0.1% | UINT32 | R | 2 |
| +4, 5 | 0x3882 | V3 THD demand | 0-9999 | ×0.1% | UINT32 | R | 2 |
| +6, 7 | 0x3883 | Not used | 0 | 0 | UINT32 | R | |
| +8, 9 | 0x3884 | I1 THD demand | 0-9999 | ×0.1% | UINT32 | R | |
| +10, 11 | 0x3885 | I2 THD demand | 0-9999 | ×0.1% | UINT32 | R | |
| +12, 13 | 0x3886 | I3 THD demand | 0-9999 | ×0.1% | UINT32 | R | |
| +14, 15 | 0x3887 | I4 THD demand | 0-9999 | ×0.1% | UINT32 | R | |
| +16, 17 | 0x3888 | I1 TDD demand | 0-1000 | ×0.1% | UINT32 | R | |
| +18, 19 | 0x3889 | I2 TDD demand | 0-1000 | ×0.1% | UINT32 | R | |
| +20, 21 | 0x388A | I3 TDD demand | 0-1000 | ×0.1% | UINT32 | R | |
| +22, 23 | 0x388B | I4 TDD demand | 0-1000 | ×0.1% | UINT32 | R | |
| 19072-19135 | | Maximum Analog Input Demands | | | | | |
| +0,1 | 0x3900 | Analog input AI1+ | AI1min-AI1max | | UINT32 | R | Positive AI readings demand |
| +2,3 | 0x3901 | Analog input AI2+ | AI2min-AI2max | | UINT32 | R | |
| | | ... | | | | | |
| +30,31 | 0x390F | Analog input AI16+ | AI16min-AI16max | | UINT32 | R | |
| +32,33 | 0x3910 | Analog input AI1- | AI1min-AI1max | | UINT32 | R | Negative AI readings demand |
| +34,35 | 0x3911 | Analog input AI2- | AI2min-AI2max | | UINT32 | R | |
| | | ... | | | | | |
| +62,63 | 0x391F | Analog input AI16- | AI16min-AI16max | | UINT32 | R | |
| 19200-19263 | | Present Analog Input Demands | | | | | |
| +0,1 | 0x3A00 | Analog input AI1+ | AI1min-AI1max | | UINT32 | R | Positive AI readings demand |
| +2,3 | 0x3A01 | Analog input AI2+ | AI2min-AI2max | | UINT32 | R | |
| | | ... | | | | | |
| +30,31 | 0x3A0F | Analog input AI16+ | AI16min-AI16max | | UINT32 | R | |
| +32,33 | 0x3A10 | Analog input AI1- | AI1min-AI1max | | UINT32 | R | Negative AI readings demand |
| +34,35 | 0x3A11 | Analog input AI2- | AI2min-AI2max | | UINT32 | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|--------------------------------|----------------------------|--------------------|--------|-----|-------|
| | | ... | | | | | |
| +62,63 | 0x3A1F | Analog input AI16- | AI16min-AI16max | | UINT32 | R | |
| 19328-19359 | | 1-Cycle Analog Inputs | | | | | |
| +0,1 | 0x3B00 | Analog input AI1 | AI1min-AI1max | | INT32 | R | |
| +2,3 | 0x3B01 | Analog input AI2 | AI2min-AI2max | | INT32 | R | |
| | | ... | | | | | |
| +30,31 | 0x3B0F | Analog input AI16 | AI16min-AI16max | | INT32 | R | |
| 19392-19423 | | Raw Analog Inputs | | | | | |
| +0, 1 | 0x3B80 | Analog input AI1 | 0-4095 | | UINT32 | R | |
| +2, 3 | 0x3B81 | Analog input AI2 | 0-4095 | | UINT32 | R | |
| | | ... | | | | | |
| +30, 31 | 0x3B8F | Analog input AI16 | 0-4095 | | UINT32 | R | |
| 19456-19459 | | TOU Parameters | | | | | |
| +0, 1 | 0x3C00 | Active tariff | 0-15 = Tariff 1-16 | | UINT32 | R/W | |
| +2, 3 | 0x3C01 | Active profile | 0-15 = Profile 1-16 | | UINT32 | R | |
| 19520-19551 | | Scaled Analog Outputs | | | | | |
| +0, 1 | 0x3C80 | Analog Output AO1 | 0-4095 | | UINT32 | R/W | |
| +2, 3 | 0x3C81 | Analog Output AO2 | 0-4095 | | UINT32 | R/W | |
| | | ... | | | | | |
| +30, 31 | 0x3C8F | Analog Output AO16 | 0-4095 | | UINT32 | R/W | |
| 19584-19615 | | Billing TOU Register #1 | | | | | |
| +0, 1 | 0x3D00 | Tariff #1 register | 0-999,999,999 | U5 | UINT32 | R | |
| +2, 3 | 0x3D01 | Tariff #2 register | 0-999,999,999 | U5 | UINT32 | R | |
| | | ... | | | | R | |
| +30, 31 | 0x3D0F | Tariff #16 register | 0-999,999,999 | U5 | UINT32 | R | |
| 19712-19743 | | Billing TOU Register #2 | | | | | |
| +0, 1 | 0x3E00 | Tariff #1 register | 0-999,999,999 | U5 | UINT32 | R | |
| +2, 3 | 0x3E01 | Tariff #2 register | 0-999,999,999 | U5 | UINT32 | R | |
| | | ... | | | | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|--------------------------------|----------------------------|--------------------|--------|-----|-------|
| +30, 31 | 0x3E0F | Tariff #16 register | 0-999,999,999 | U5 | UINT32 | R | |
| 19840-19871 | | Billing TOU Register #3 | | | | | |
| +0, 1 | 0x3F00 | Tariff #1 register | 0-999,999,999 | U5 | UINT32 | R | |
| +2, 3 | 0x3F01 | Tariff #2 register | 0-999,999,999 | U5 | UINT32 | R | |
| | | ... | | | | R | |
| +30, 31 | 0x3F0F | Tariff #16 register | 0-999,999,999 | U5 | UINT32 | R | |
| 19968-19999 | | Billing TOU Register #4 | | | | | |
| +0, 1 | 0x4000 | Tariff #1 register | 0-999,999,999 | U5 | UINT32 | R | |
| +2, 3 | 0x4001 | Tariff #2 register | 0-999,999,999 | U5 | UINT32 | R | |
| | | ... | | | | R | |
| +30, 31 | 0x400F | Tariff #16 register | 0-999,999,999 | U5 | UINT32 | R | |
| 20096-20127 | | Billing TOU Register #5 | | | | | |
| +0, 1 | 0x4100 | Tariff #1 register | 0-999,999,999 | U5 | UINT32 | R | |
| +2, 3 | 0x4101 | Tariff #2 register | 0-999,999,999 | U5 | UINT32 | R | |
| | | ... | | | | R | |
| +30, 31 | 0x410F | Tariff #16 register | 0-999,999,999 | U5 | UINT32 | R | |
| 20224-20255 | | Billing TOU Register #6 | | | | | |
| +0, 1 | 0x4200 | Tariff #1 register | 0-999,999,999 | U5 | UINT32 | R | |
| +2, 3 | 0x4201 | Tariff #2 register | 0-999,999,999 | U5 | UINT32 | R | |
| | | ... | | | | R | |
| +30, 31 | 0x420F | Tariff #16 register | 0-999,999,999 | U5 | UINT32 | R | |
| 20352-20383 | | Billing TOU Register #7 | | | | | |
| +0, 1 | 0x4300 | Tariff #1 register | 0-999,999,999 | U5 | UINT32 | R | |
| +2, 3 | 0x4301 | Tariff #2 register | 0-999,999,999 | U5 | UINT32 | R | |
| | | ... | | | | R | |
| +30, 31 | 0x430F | Tariff #16 register | 0-999,999,999 | U5 | UINT32 | R | |
| 20480-20511 | | Billing TOU Register #8 | | | | | |
| +0, 1 | 0x4400 | Tariff #1 register | 0-999,999,999 | U5 | UINT32 | R | |
| +2, 3 | 0x4401 | Tariff #2 register | 0-999,999,999 | U5 | UINT32 | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|---------------------------------|----------------------------|--------------------|--------|-----|-------|
| | | ... | | | | R | |
| +30, 31 | 0x440F | Tariff #16 register | 0-999,999,999 | U5 | UINT32 | R | |
| 21376-21407 | | Billing TOU Register #9 | | | | | |
| +0, 1 | 0x4B00 | Tariff #1 register | 0-999,999,999 | U5 | UINT32 | R | |
| +2, 3 | 0x4B01 | Tariff #2 register | 0-999,999,999 | U5 | UINT32 | R | |
| | | ... | | | | R | |
| +30, 31 | 0x4B0F | Tariff #16 register | 0-999,999,999 | U5 | UINT32 | R | |
| 21504-21535 | | Billing TOU Register #10 | | | | | |
| +0, 1 | 0x4C00 | Tariff #1 register | 0-999,999,999 | U5 | UINT32 | R | |
| +2, 3 | 0x4C01 | Tariff #2 register | 0-999,999,999 | U5 | UINT32 | R | |
| | | ... | | | | R | |
| +30, 31 | 0x4C0F | Tariff #16 register | 0-999,999,999 | U5 | UINT32 | R | |
| 21632-21663 | | Billing TOU Register #11 | | | | | |
| +0, 1 | 0x4D00 | Tariff #1 register | 0-999,999,999 | U5 | UINT32 | R | |
| +2, 3 | 0x4D01 | Tariff #2 register | 0-999,999,999 | U5 | UINT32 | R | |
| | | ... | | | | R | |
| +30, 31 | 0x4D0F | Tariff #16 register | 0-999,999,999 | U5 | UINT32 | R | |
| 21760-21791 | | Billing TOU Register #12 | | | | | |
| +0, 1 | 0x4E00 | Tariff #1 register | 0-999,999,999 | U5 | UINT32 | R | |
| +2, 3 | 0x4E01 | Tariff #2 register | 0-999,999,999 | U5 | UINT32 | R | |
| | | ... | | | | R | |
| +30, 31 | 0x4E0F | Tariff #16 register | 0-999,999,999 | U5 | UINT32 | R | |
| 21888-21919 | | Billing TOU Register #13 | | | | | |
| +0, 1 | 0x4F00 | Tariff #1 register | 0-999,999,999 | U5 | UINT32 | R | |
| +2, 3 | 0x4F01 | Tariff #2 register | 0-999,999,999 | U5 | UINT32 | R | |
| | | ... | | | | R | |
| +30, 31 | 0x4F0F | Tariff #16 register | 0-999,999,999 | U5 | UINT32 | R | |
| 22016-22047 | | Billing TOU Register #14 | | | | | |
| +0, 1 | 0x5000 | Tariff #1 register | 0-999,999,999 | U5 | UINT32 | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|---|----------------------------|--------------------|--------|-----|-------|
| +2, 3 | 0x5001 | Tariff #2 register | 0-999,999,999 | U5 | UINT32 | R | |
| | | ... | | | | R | |
| +30, 31 | 0x500F | Tariff #16 register | 0-999,999,999 | U5 | UINT32 | R | |
| 22144-22175 | | Billing TOU Register #15 | | | | | |
| +0, 1 | 0x5100 | Tariff #1 register | 0-999,999,999 | U5 | UINT32 | R | |
| +2, 3 | 0x5101 | Tariff #2 register | 0-999,999,999 | U5 | UINT32 | R | |
| | | ... | | | | R | |
| +30, 31 | 0x510F | Tariff #16 register | 0-999,999,999 | U5 | UINT32 | R | |
| 22272-22303 | | Billing TOU Register #16 | | | | | |
| +0, 1 | 0x5200 | Tariff #1 register | 0-999,999,999 | U5 | UINT32 | R | |
| +2, 3 | 0x5201 | Tariff #2 register | 0-999,999,999 | U5 | UINT32 | R | |
| | | ... | | | | R | |
| +30, 31 | 0x520F | Tariff #16 register | 0-999,999,999 | U5 | UINT32 | R | |
| 20608-20639 | | Billing Summary Accumulated Demands | | | | | |
| +0, 1 | 0x4500 | Summary register #1 | 0-Pmax | U3 | UINT32 | R | |
| +2, 3 | 0x4501 | Summary register #2 | 0-Pmax | U3 | UINT32 | R | |
| | | ... | | | | | |
| +30, 31 | 0x4503 | Summary register #16 | 0-Pmax | U3 | UINT32 | R | |
| 20672-20703 | | Billing Summary Block Demands | | | | | |
| +0, 1 | 0x4580 | Summary register #1 | 0-Pmax | U3 | UINT32 | R | |
| +2, 3 | 0x4581 | Summary register #2 | 0-Pmax | U3 | UINT32 | R | |
| | | ... | | | | | |
| +30, 31 | 0x4583 | Summary register #16 | 0-Pmax | U3 | UINT32 | R | |
| 20736-20767 | | Billing Summary Sliding Window Demands | | | | | |
| +0, 1 | 0x4600 | Summary register #1 | 0-Pmax | U3 | UINT32 | R | |
| +2, 3 | 0x4601 | Summary register #2 | 0-Pmax | U3 | UINT32 | R | |
| | | ... | | | | | |
| +30, 31 | 0x4603 | Summary register #16 | 0-Pmax | U3 | UINT32 | R | |
| 20800-20817 | | Interval Energies | | | | | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|---|----------------------------|--------------------|--------|-----|---------------|
| +0,1 | 0x4680 | kWh import | 0-999,999,999 | U5 | UINT32 | R | DC-applicable |
| +2,3 | 0x4681 | kWh export | 0-999,999,999 | U5 | UINT32 | R | DC-applicable |
| +4,5 | 0x4682 | kvarh import | 0-999,999,999 | U5 | UINT32 | R | |
| +6,7 | 0x4683 | kvarh export | 0-999,999,999 | U5 | UINT32 | R | |
| +8,9 | 0x4684 | kVAh total | 0-999,999,999 | U5 | UINT32 | R | |
| +10,11 | 0x4685 | kvarh Q1 | 0-999,999,999 | U5 | UINT32 | R | |
| +12,13 | 0x4686 | kvarh Q2 | 0-999,999,999 | U5 | UINT32 | R | |
| +14,15 | 0x4687 | kvarh Q3 | 0-999,999,999 | U5 | UINT32 | R | |
| +16,17 | 0x4688 | kvarh Q4 | 0-999,999,999 | U5 | UINT32 | R | |
| 20928-20959 | | Billing Summary Maximum Demands | | | | | |
| +0, 1 | 0x4780 | Summary register #1 | 0-Pmax | U3 | UINT32 | R | |
| +2, 3 | 0x4781 | Summary register #2 | 0-Pmax | U3 | UINT32 | R | |
| | | ... | | | | | |
| +30, 31 | 0x4783 | Summary register #16 | 0-Pmax | U3 | UINT32 | R | |
| 20992-21023 | | Billing TOU Maximum Demand Register #1 | | | | | |
| +0, 1 | 0x4800 | Tariff #1 register | 0-Pmax | U3 | UINT32 | R | |
| +2, 3 | 0x4801 | Tariff #2 register | 0-Pmax | U3 | UINT32 | R | |
| | | ... | | | | R | |
| +30, 31 | 0x480F | Tariff #16 register | 0-Pmax | U3 | UINT32 | R | |
| 21120-21151 | | Billing TOU Maximum Demand Register #2 | | | | | |
| +0, 1 | 0x4900 | Tariff #1 register | 0-Pmax | U3 | UINT32 | R | |
| +2, 3 | 0x4901 | Tariff #2 register | 0-Pmax | U3 | UINT32 | R | |
| | | ... | | | | R | |
| +30, 31 | 0x490F | Tariff #16 register | 0-Pmax | U3 | UINT32 | R | |
| 21248-21279 | | Billing TOU Maximum Demand Register #3 | | | | | |
| +0, 1 | 0x4A00 | Tariff #1 register | 0-Pmax | U3 | UINT32 | R | |
| +2, 3 | 0x4A01 | Tariff #2 register | 0-Pmax | U3 | UINT32 | R | |
| | | ... | | | | R | |
| +30, 31 | 0x4A0F | Tariff #16 register | 0-Pmax | U3 | UINT32 | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|---|----------------------------|--------------------|--------|-----|-------|
| 21056-21087 | | Billing TOU Maximum Demand Register #4 | | | | | |
| +0, 1 | 0x4880 | Tariff #1 register | 0-Pmax | U3 | UINT32 | R | |
| +2, 3 | 0x4881 | Tariff #2 register | 0-Pmax | U3 | UINT32 | R | |
| | | ... | | | | R | |
| +30, 31 | 0x488F | Tariff #16 register | 0-Pmax | U3 | UINT32 | R | |
| 21184-21215 | | Billing TOU Maximum Demand Register #5 | | | | | |
| +0, 1 | 0x4980 | Tariff #1 register | 0-Pmax | U3 | UINT32 | R | |
| +2, 3 | 0x4981 | Tariff #2 register | 0-Pmax | U3 | UINT32 | R | |
| | | ... | | | | R | |
| +30, 31 | 0x498F | Tariff #16 register | 0-Pmax | U3 | UINT32 | R | |
| 21312-21343 | | Billing TOU Maximum Demand Register #6 | | | | | |
| +0, 1 | 0x4A80 | Tariff #1 register | 0-Pmax | U3 | UINT32 | R | |
| +2, 3 | 0x4A81 | Tariff #2 register | 0-Pmax | U3 | UINT32 | R | |
| | | ... | | | | R | |
| +30, 31 | 0x4A8F | Tariff #16 register | 0-Pmax | U3 | UINT32 | R | |
| 22400-22431 | | Billing TOU Maximum Demand Register #7 | | | | | |
| +0, 1 | 0x5300 | Tariff #1 register | 0-Pmax | U3 | UINT32 | R | |
| +2, 3 | 0x5301 | Tariff #2 register | 0-Pmax | U3 | UINT32 | R | |
| | | ... | | | | R | |
| +30, 31 | 0x530F | Tariff #16 register | 0-Pmax | U3 | UINT32 | R | |
| 22464-22495 | | Billing TOU Maximum Demand Register #8 | | | | | |
| +0, 1 | 0x5380 | Tariff #1 register | 0-Pmax | U3 | UINT32 | R | |
| +2, 3 | 0x5381 | Tariff #2 register | 0-Pmax | U3 | UINT32 | R | |
| | | ... | | | | R | |
| +30, 31 | 0x538F | Tariff #16 register | 0-Pmax | U3 | UINT32 | R | |
| 22528-22559 | | Billing TOU Maximum Demand Register #9 | | | | | |
| +0, 1 | 0x5400 | Tariff #1 register | 0-Pmax | U3 | UINT32 | R | |
| +2, 3 | 0x5401 | Tariff #2 register | 0-Pmax | U3 | UINT32 | R | |
| | | ... | | | | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|--|----------------------------|--------------------|--------|-----|-------|
| +30, 31 | 0x540F | Tariff #16 register | 0-Pmax | U3 | UINT32 | R | |
| 22592-22623 | | Billing TOU Maximum Demand Register #10 | | | | | |
| +0, 1 | 0x5480 | Tariff #1 register | 0-Pmax | U3 | UINT32 | R | |
| +2, 3 | 0x5481 | Tariff #2 register | 0-Pmax | U3 | UINT32 | R | |
| | | ... | | | | R | |
| +30, 31 | 0x548F | Tariff #16 register | 0-Pmax | U3 | UINT32 | R | |
| 22656-22687 | | Billing TOU Maximum Demand Register #11 | | | | | |
| +0, 1 | 0x5500 | Tariff #1 register | 0-Pmax | U3 | UINT32 | R | |
| +2, 3 | 0x5501 | Tariff #2 register | 0-Pmax | U3 | UINT32 | R | |
| | | ... | | | | R | |
| +30, 31 | 0x550F | Tariff #16 register | 0-Pmax | U3 | UINT32 | R | |
| 22720-22751 | | Billing TOU Maximum Demand Register #12 | | | | | |
| +0, 1 | 0x5580 | Tariff #1 register | 0-Pmax | U3 | UINT32 | R | |
| +2, 3 | 0x5581 | Tariff #2 register | 0-Pmax | U3 | UINT32 | R | |
| | | ... | | | | R | |
| +30, 31 | 0x558F | Tariff #16 register | 0-Pmax | U3 | UINT32 | R | |
| 22784-22815 | | Billing TOU Maximum Demand Register #13 | | | | | |
| +0, 1 | 0x5600 | Tariff #1 register | 0-Pmax | U3 | UINT32 | R | |
| +2, 3 | 0x5601 | Tariff #2 register | 0-Pmax | U3 | UINT32 | R | |
| | | ... | | | | R | |
| +30, 31 | 0x560F | Tariff #16 register | 0-Pmax | U3 | UINT32 | R | |
| 22848-22879 | | Billing TOU Maximum Demand Register #14 | | | | | |
| +0, 1 | 0x5680 | Tariff #1 register | 0-Pmax | U3 | UINT32 | R | |
| +2, 3 | 0x5681 | Tariff #2 register | 0-Pmax | U3 | UINT32 | R | |
| | | ... | | | | R | |
| +30, 31 | 0x568F | Tariff #16 register | 0-Pmax | U3 | UINT32 | R | |
| 22912-22943 | | Billing TOU Maximum Demand Register #15 | | | | | |
| +0, 1 | 0x5700 | Tariff #1 register | 0-Pmax | U3 | UINT32 | R | |
| +2, 3 | 0x5701 | Tariff #2 register | 0-Pmax | U3 | UINT32 | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|--|----------------------------|--------------------|--------|-----|-------|
| | | ... | | | | R | |
| +30, 31 | 0x570F | Tariff #16 register | 0-Pmax | U3 | UINT32 | R | |
| 22976-23007 | | Billing TOU Maximum Demand Register #16 | | | | | |
| +0, 1 | 0x5780 | Tariff #1 register | 0-Pmax | U3 | UINT32 | R | |
| +2, 3 | 0x5781 | Tariff #2 register | 0-Pmax | U3 | UINT32 | R | |
| | | ... | | | | R | |
| +30, 31 | 0x578F | Tariff #16 register | 0-Pmax | U3 | UINT32 | R | |
| 24576-24701 | | V1/V12 Harmonic Angles | | | | | |
| +0,1 | 0x6400 | H01 Harmonic angle | -1800-1800 | ×0.1° | INT32 | R | |
| +2,3 | 0x6401 | H02 Harmonic angle | -1800-1800 | ×0.1° | INT32 | R | |
| | | ... | | | | | |
| +124,125 | 0x643E | H63 Harmonic angle | -1800-1800 | ×0.1° | INT32 | R | |
| 24704-24829 | | V2/V23 Harmonic Angles | | | | | |
| +0,1 | 0x6500 | H01 Harmonic angle | -1800-1800 | ×0.1° | INT32 | R | |
| +2,3 | 0x6501 | H02 Harmonic angle | -1800-1800 | ×0.1° | INT32 | R | |
| | | ... | | | | | |
| +124,125 | 0x653E | H63 Harmonic angle | -1800-1800 | ×0.1° | INT32 | R | |
| 24832-24957 | | V3/V31 Harmonic Angles | | | | | |
| +0,1 | 0x6600 | H01 Harmonic angle | -1800-1800 | ×0.1° | INT32 | R | |
| +2,3 | 0x6601 | H02 Harmonic angle | -1800-1800 | ×0.1° | INT32 | R | |
| | | ... | | | | | |
| +124,125 | 0x663E | H63 Harmonic angle | -1800-1800 | ×0.1° | INT32 | R | |
| 24960-25085 | | V4 Harmonic Angles | | | | | |
| +0,1 | 0x6700 | Not used | 0 | 0 | UINT32 | R | |
| +2,3 | 0x6701 | Not used | 0 | 0 | UINT32 | R | |
| | | ... | | | | | |
| +124,125 | 0x673E | Not used | 0 | 0 | UINT32 | R | |
| 25088-25213 | | I1 Harmonic Angles | | | | | |
| +0,1 | 0x6800 | H01 Harmonic angle | -1800-1800 | ×0.1° | INT32 | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|--|----------------------------|--------------------|--------|-----|------------------|
| +2,3 | 0x6801 | H02 Harmonic angle | -1800-1800 | ×0.1° | INT32 | R | |
| | | ... | | | | | |
| +124,125 | 0x683E | H63 Harmonic angle | -1800-1800 | ×0.1° | INT32 | R | |
| 25216-25341 | | I2 Harmonic Angles | | | | | |
| +0,1 | 0x6900 | H01 Harmonic angle | -1800-1800 | ×0.1° | INT32 | R | |
| +2,3 | 0x6901 | H02 Harmonic angle | -1800-1800 | ×0.1° | INT32 | R | |
| | | ... | | | | | |
| +124,125 | 0x693E | H63 Harmonic angle | -1800-1800 | ×0.1° | INT32 | R | |
| 25344-25469 | | I3 Harmonic Angles | | | | | |
| +0,1 | 0x6A00 | H01 Harmonic angle | -1800-1800 | ×0.1° | INT32 | R | |
| +2,3 | 0x6A01 | H02 Harmonic angle | -1800-1800 | ×0.1° | INT32 | R | |
| | | ... | | | | | |
| +124,125 | 0x6A3E | H63 Harmonic angle | -1800-1800 | ×0.1° | INT32 | R | |
| 25472-25597 | | I4 Harmonic Angles | | | | | 4, 6 |
| +0,1 | 0x6B00 | H01 Harmonic angle | -1800-1800 | ×0.1° | INT32 | R | |
| +2,3 | 0x6B01 | H02 Harmonic angle | -1800-1800 | ×0.1° | INT32 | R | |
| | | ... | | | | | |
| +124,125 | 0x6B3E | H63 Harmonic angle | -1800-1800 | ×0.1° | INT32 | R | |
| 25600-25653 | | 0.2-Second RMS and Auxiliary Values | | | | | |
| +0, 1 | 0x6C00 | V1 voltage | 0-Vmax | U1 | UINT32 | R | 1, DC-applicable |
| +2, 3 | 0x6C01 | V2 voltage | 0-Vmax | U1 | UINT32 | R | 1, DC-applicable |
| +4, 5 | 0x6C02 | V3 voltage | 0-Vmax | U1 | UINT32 | R | 1, DC-applicable |
| +6, 7 | 0x6C03 | Not used | 0 | 0 | UINT32 | R | |
| +8, 9 | 0x6C04 | V12 voltage | 0-Vmax | U1 | UINT32 | R | |
| +10, 11 | 0x6C05 | V23 voltage | 0-Vmax | U1 | UINT32 | R | |
| +12, 13 | 0x6C06 | V31 voltage | 0-Vmax | U1 | UINT32 | R | |
| +14, 15 | 0x6C07 | I1 current | 0-I _{max} | U2 | UINT32 | R | DC-applicable |
| +16, 17 | 0x6C08 | I2 current | 0-I _{max} | U2 | UINT32 | R | DC-applicable |
| +18, 19 | 0x6C09 | I3 current | 0-I _{max} | U2 | UINT32 | R | DC-applicable |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|--|----------------------------|--------------------|--------|-----|------------------|
| +20, 21 | 0x6C0A | I4 current | 0-I4max | U2 | UINT32 | R | DC-applicable |
| +22, 23 | 0x6C0B | In current | 0-Imax | U2 | UINT32 | R | |
| +24, 25 | 0x6C0C | Not used | 0 | 0 | UINT32 | R | |
| +26, 27 | 0x6C0D | Not used | 0 | 0 | UINT32 | R | |
| +28, 29 | 0x6C0E | Not used | 0 | 0 | UINT32 | R | |
| +30, 31 | 0x6C0F | Not used | 0 | 0 | UINT32 | R | |
| +32, 33 | 0x6C10 | Not used | 0 | 0 | UINT32 | R | |
| +34, 35 | 0x6C11 | Zero-sequence voltage | 0-Vmax | U1 | UINT32 | R | |
| +36, 37 | 0x6C12 | Zero-sequence current | 0-Imax | U2 | UINT32 | R | |
| +38, 39 | 0x6C13 | Ix Zero-sequence current | 0-Ixmax | U2 | UINT32 | R | |
| +40, 41 | 0x6C14 | Voltage unbalance | 0-3000 | ×0.1% | UINT32 | R | |
| +42, 43 | 0x6C15 | Current unbalance | 0-3000 | ×0.1% | UINT32 | R | |
| +44, 45 | 0x6C16 | Ix current unbalance | 0-3000 | ×0.1% | UINT32 | R | |
| +46, 47 | 0x6C17 | Not used | | | UINT32 | R | |
| +48, 49 | 0x6C18 | Frequency | 0-10000 | ×0.01Hz | UINT32 | R | |
| +50, 51 | 0x6C19 | Positive-sequence voltage | 0-Vmax | U1 | UINT32 | R | |
| +52, 53 | 0x6C1A | Zero-sequence voltage unbalance | 0-300.0 | ×0.1% | UINT32 | R | |
| +54, 55 | 0x6C1B | I leakage current | 0-Imax | U2 | UINT32 | R | |
| 25664-25717 | | 3-Second RMS and Auxiliary Values | | | | | |
| +0, 1 | 0x6C80 | V1 voltage | 0-Vmax | U1 | UINT32 | R | 1, DC-applicable |
| +2, 3 | 0x6C81 | V2 voltage | 0-Vmax | U1 | UINT32 | R | 1, DC-applicable |
| +4, 5 | 0x6C82 | V3 voltage | 0-Vmax | U1 | UINT32 | R | 1, DC-applicable |
| +6, 7 | 0x6C83 | Not used | 0 | 0 | UINT32 | R | |
| +8, 9 | 0x6C84 | V12 voltage | 0-Vmax | U1 | UINT32 | R | |
| +10, 11 | 0x6C85 | V23 voltage | 0-Vmax | U1 | UINT32 | R | |
| +12, 13 | 0x6C86 | V31 voltage | 0-Vmax | U1 | UINT32 | R | |
| +14, 15 | 0x6C87 | I1 current | 0-Imax | U2 | UINT32 | R | DC-applicable |
| +16, 17 | 0x6C88 | I2 current | 0-Imax | U2 | UINT32 | R | DC-applicable |
| +18, 19 | 0x6C89 | I3 current | 0-Imax | U2 | UINT32 | R | DC-applicable |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|---|----------------------------|--------------------|--------|-----|------------------|
| +20, 21 | 0x6C8A | I4 current | 0-I4max | U2 | UINT32 | R | DC-applicable |
| +22, 23 | 0x6C8B | In current | 0-Imax | U2 | UINT32 | R | |
| +24, 25 | 0x6C8C | Not used | 0 | 0 | UINT32 | R | |
| +26, 27 | 0x6C8D | Not used | 0 | 0 | UINT32 | R | |
| +28, 29 | 0x6C8E | Not used | 0 | 0 | UINT32 | R | |
| +30, 31 | 0x6C8F | Not used | 0 | 0 | UINT32 | R | |
| +32, 33 | 0x6C90 | Not used | 0 | 0 | UINT32 | R | |
| +34, 35 | 0x6C91 | Zero-sequence voltage | 0-Vmax | U1 | UINT32 | R | |
| +36, 37 | 0x6C92 | Zero-sequence current | 0-Imax | U2 | UINT32 | R | |
| +38, 39 | 0x6C93 | Ix Zero-sequence current | 0-Ixmax | U2 | UINT32 | R | |
| +40, 41 | 0x6C94 | Voltage unbalance | 0-3000 | ×0.1% | UINT32 | R | |
| +42, 43 | 0x6C95 | Current unbalance | 0-3000 | ×0.1% | UINT32 | R | |
| +44, 45 | 0x6C96 | Ix current unbalance | 0-3000 | ×0.1% | UINT32 | R | |
| +46, 47 | 0x6C97 | Not used | | | UINT32 | R | |
| +48, 49 | 0x6C98 | Frequency | 0-10000 | ×0.01Hz | UINT32 | R | |
| +50, 51 | 0x6C99 | Positive-sequence voltage | 0-Vmax | U1 | UINT32 | R | |
| +52, 53 | 0x6C9A | Zero-sequence voltage unbalance | 0-300.0 | ×0.1% | UINT32 | R | |
| +54, 55 | 0x6C9B | I leakage current | 0-Imax | U2 | UINT32 | R | |
| 26880-26993 | | 1-Minute RMS and Auxiliary Values (GOST) | | | | | |
| +0, 1 | 0x7600 | V1 voltage | 0-Vmax | U1 | UINT32 | R | 1, DC-applicable |
| +2, 3 | 0x7601 | V2 voltage | 0-Vmax | U1 | UINT32 | R | 1, DC-applicable |
| +4, 5 | 0x7602 | V3 voltage | 0-Vmax | U1 | UINT32 | R | 1, DC-applicable |
| +6, 7 | 0x7603 | Not used | 0 | 0 | UINT32 | R | |
| +8, 9 | 0x7604 | V12 voltage | 0-Vmax | U1 | UINT32 | R | |
| +10, 11 | 0x7605 | V23 voltage | 0-Vmax | U1 | UINT32 | R | |
| +12, 13 | 0x7606 | V31 voltage | 0-Vmax | U1 | UINT32 | R | |
| +14, 15 | 0x7607 | I1 current | 0-Imax | U2 | UINT32 | R | DC-applicable |
| +16, 17 | 0x7608 | I2 current | 0-Imax | U2 | UINT32 | R | DC-applicable |
| +18, 19 | 0x7609 | I3 current | 0-Imax | U2 | UINT32 | R | DC-applicable |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|---|----------------------------|--------------------|--------|-----|------------------|
| +20, 21 | 0x760A | I4 current | 0-I4max | U2 | UINT32 | R | DC-applicable |
| +22, 23 | 0x760B | In current | 0-Imax | U2 | UINT32 | R | |
| +24, 25 | 0x760C | Not used | 0 | 0 | UINT32 | R | |
| +26, 27 | 0x760D | Not used | 0 | 0 | UINT32 | R | |
| +28, 29 | 0x760E | Not used | 0 | 0 | UINT32 | R | |
| +30, 31 | 0x760F | Not used | 0 | 0 | UINT32 | R | |
| +32, 33 | 0x7610 | Not used | 0 | 0 | UINT32 | R | |
| +34, 35 | 0x7611 | Zero-sequence voltage | 0-Vmax | U1 | UINT32 | R | |
| +36, 37 | 0x7612 | Zero-sequence current | 0-Imax | U2 | UINT32 | R | |
| +38, 39 | 0x7613 | Ix Zero-sequence current | 0-Ixmax | U2 | UINT32 | R | |
| +40, 41 | 0x7614 | Voltage unbalance | 0-3000 | ×0.1% | UINT32 | R | |
| +42, 43 | 0x7615 | Current unbalance | 0-3000 | ×0.1% | UINT32 | R | |
| +44, 45 | 0x7616 | Ix current unbalance | 0-3000 | ×0.1% | UINT32 | R | |
| +46, 47 | 0x7617 | DC voltage | 0-999900 | ×0.01V | UINT32 | R | |
| +48, 49 | 0x7618 | Frequency | 0-10000 | ×0.01Hz | UINT32 | R | |
| +50, 51 | 0x7619 | Positive-sequence voltage | 0-Vmax | U1 | UINT32 | R | |
| +52, 53 | 0x761A | Zero-sequence voltage unbalance | 0-300.0 | ×0.1% | UINT32 | R | |
| +54, 55 | 0x761B | I leakage current | 0-Imax | U2 | UINT32 | R | |
| 25728-25781 | | 10-Minute RMS and Auxiliary Values | | | | | |
| +0, 1 | 0x6D00 | V1 voltage | 0-Vmax | U1 | UINT32 | R | 1, DC-applicable |
| +2, 3 | 0x6D01 | V2 voltage | 0-Vmax | U1 | UINT32 | R | 1, DC-applicable |
| +4, 5 | 0x6D02 | V3 voltage | 0-Vmax | U1 | UINT32 | R | 1, DC-applicable |
| +6, 7 | 0x6D03 | Not used | 0 | 0 | UINT32 | R | |
| +8, 9 | 0x6D04 | V12 voltage | 0-Vmax | U1 | UINT32 | R | |
| +10, 11 | 0x6D05 | V23 voltage | 0-Vmax | U1 | UINT32 | R | |
| +12, 13 | 0x6D06 | V31 voltage | 0-Vmax | U1 | UINT32 | R | |
| +14, 15 | 0x6D07 | I1 current | 0-Imax | U2 | UINT32 | R | DC-applicable |
| +16, 17 | 0x6D08 | I2 current | 0-Imax | U2 | UINT32 | R | DC-applicable |
| +18, 19 | 0x6D09 | I3 current | 0-Imax | U2 | UINT32 | R | DC-applicable |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|--|----------------------------|--------------------|--------|-----|------------------|
| +20, 21 | 0x6D0A | I4 current | 0-I4max | U2 | UINT32 | R | DC-applicable |
| +22, 23 | 0x6D0B | In current | 0-Imax | U2 | UINT32 | R | |
| +24, 25 | 0x6D0C | Not used | 0 | 0 | UINT32 | R | |
| +26, 27 | 0x6D0D | Not used | 0 | 0 | UINT32 | R | |
| +28, 29 | 0x6D0E | Not used | 0 | 0 | UINT32 | R | |
| +30, 31 | 0x6D0F | Not used | 0 | 0 | UINT32 | R | |
| +32, 33 | 0x6D10 | Not used | 0 | 0 | UINT32 | R | |
| +34, 35 | 0x6D11 | Zero-sequence voltage | 0-Vmax | U1 | UINT32 | R | |
| +36, 37 | 0x6D12 | Zero-sequence current | 0-Imax | U2 | UINT32 | R | |
| +38, 39 | 0x6D13 | Ix Zero-sequence current | 0-Ixmax | U2 | UINT32 | R | |
| +40, 41 | 0x6D14 | Voltage unbalance | 0-3000 | ×0.1% | UINT32 | R | |
| +42, 43 | 0x6D15 | Current unbalance | 0-3000 | ×0.1% | UINT32 | R | |
| +44, 45 | 0x6D16 | Ix current unbalance | 0-3000 | ×0.1% | UINT32 | R | |
| +46, 47 | 0x6D17 | Not used | | | UINT32 | R | |
| +48, 49 | 0x6D18 | Frequency | 0-10000 | ×0.01Hz | UINT32 | R | |
| +50, 51 | 0x6D19 | Positive-sequence voltage | 0-Vmax | U1 | UINT32 | R | |
| +52, 53 | 0x6D1A | Zero-sequence voltage unbalance | 0-300.0 | ×0.1% | UINT32 | R | |
| +54, 55 | 0x6D1B | I leakage current | 0-Imax | U2 | UINT32 | R | |
| 25792-25845 | | 2-Hour RMS and Auxiliary Values | | | | | |
| +0, 1 | 0x6D80 | V1 voltage | 0-Vmax | U1 | UINT32 | R | 1, DC-applicable |
| +2, 3 | 0x6D81 | V2 voltage | 0-Vmax | U1 | UINT32 | R | 1, DC-applicable |
| +4, 5 | 0x6D82 | V3 voltage | 0-Vmax | U1 | UINT32 | R | 1, DC-applicable |
| +6, 7 | 0x6D83 | Not used | 0 | 0 | UINT32 | R | |
| +8, 9 | 0x6D84 | V12 voltage | 0-Vmax | U1 | UINT32 | R | |
| +10, 11 | 0x6D85 | V23 voltage | 0-Vmax | U1 | UINT32 | R | |
| +12, 13 | 0x6D86 | V31 voltage | 0-Vmax | U1 | UINT32 | R | |
| +14, 15 | 0x6D87 | I1 current | 0-Imax | U2 | UINT32 | R | DC-applicable |
| +16, 17 | 0x6D88 | I2 current | 0-Imax | U2 | UINT32 | R | DC-applicable |
| +18, 19 | 0x6D89 | I3 current | 0-Imax | U2 | UINT32 | R | DC-applicable |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|---------------------------------|----------------------------|--------------------|--------|-----|---------------|
| +20, 21 | 0x6D8A | I4 current | 0-I4max | U2 | UINT32 | R | DC-applicable |
| +22, 23 | 0x6D8B | In current | 0-Imax | U2 | UINT32 | R | |
| +24, 25 | 0x6D8C | Not used | 0 | 0 | UINT32 | R | |
| +26, 27 | 0x6D8D | Not used | 0 | 0 | UINT32 | R | |
| +28, 29 | 0x6D8E | Not used | 0 | 0 | UINT32 | R | |
| +30, 31 | 0x6D8F | Not used | 0 | 0 | UINT32 | R | |
| +32, 33 | 0x6D90 | Not used | 0 | 0 | UINT32 | R | |
| +34, 35 | 0x6D91 | Zero-sequence voltage | 0-Vmax | U1 | UINT32 | R | |
| +36, 37 | 0x6D92 | Zero-sequence current | 0-Imax | U2 | UINT32 | R | |
| +38, 39 | 0x6D93 | Ix Zero-sequence current | 0-Ixmax | U2 | UINT32 | R | |
| +40, 41 | 0x6D94 | Voltage unbalance | 0-3000 | ×0.1% | UINT32 | R | |
| +42, 43 | 0x6D95 | Current unbalance | 0-3000 | ×0.1% | UINT32 | R | |
| +44, 45 | 0x6D96 | Ix current unbalance | 0-3000 | ×0.1% | UINT32 | R | |
| +46, 47 | 0x6D97 | Not used | | | UINT32 | R | |
| +48, 49 | 0x6D98 | Frequency | 0-10000 | ×0.01Hz | UINT32 | R | |
| +50, 51 | 0x6D99 | Positive-sequence voltage | 0-Vmax | U1 | UINT32 | R | |
| +52, 53 | 0x6D9A | Zero-sequence voltage unbalance | 0-300.0 | ×0.1% | UINT32 | R | |
| +54, 55 | 0x6D9B | I leakage current | 0-Imax | U2 | UINT32 | R | |
| 25856-25905 | | 0.2-Second Harmonics | | | | | |
| +0, 1 | 0x6E00 | V1 THD | 0-9999 | ×0.1% | UINT32 | R | 2 |
| +2, 3 | 0x6E01 | V2 THD | 0-9999 | ×0.1% | UINT32 | R | 2 |
| +4, 5 | 0x6E02 | V3 THD | 0-9999 | ×0.1% | UINT32 | R | 2 |
| +6, 7 | 0x6E03 | Not used | 0 | 0 | UINT32 | R | |
| +8, 9 | 0x6E04 | I1 THD | 0-9999 | ×0.1% | UINT32 | R | |
| +10, 11 | 0x6E05 | I2 THD | 0-9999 | ×0.1% | UINT32 | R | |
| +12, 13 | 0x6E06 | I3 THD | 0-9999 | ×0.1% | UINT32 | R | |
| +14, 15 | 0x6E07 | I4 THD | 0-9999 | ×0.1% | UINT32 | R | |
| +16, 17 | 0x6E08 | V1 interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | 2 |
| +18, 19 | 0x6E09 | V2 interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | 2 |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|---------------------------|----------------------------|--------------------|--------|-----|-------|
| +20, 21 | 0x6E0A | V3 interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | 2 |
| +22, 23 | 0x6E0B | Not used | 0 | 0 | UINT32 | R | |
| +24, 25 | 0x6E0C | I1 interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | |
| +26, 27 | 0x6E0D | I2 interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | |
| +28, 29 | 0x6E0E | I3 interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | |
| +30, 31 | 0x6E0F | I4 interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | |
| +32, 33 | 0x6E10 | I1 TDD | 0-1000 | ×0.1% | UINT32 | R | |
| +34, 35 | 0x6E11 | I2 TDD | 0-1000 | ×0.1% | UINT32 | R | |
| +36, 37 | 0x6E12 | I3 TDD | 0-1000 | ×0.1% | UINT32 | R | |
| +38, 39 | 0x6E13 | I4 TDD | 0-1000 | ×0.1% | UINT32 | R | |
| +40, 41 | 0x6E14 | I1 K-Factor | 10-9999 | ×0.1 | UINT32 | R | |
| +42, 43 | 0x6E15 | I2 K-Factor | 10-9999 | ×0.1 | UINT32 | R | |
| +44, 45 | 0x6E16 | I3 K-Factor | 10-9999 | ×0.1 | UINT32 | R | |
| +46, 47 | 0x6E17 | I4 K-Factor | 10-9999 | ×0.1 | UINT32 | R | |
| +48, 49 | 0x6E18 | V1 Crest Factor | 0-10000 | ×0.01 | UINT32 | R | 2 |
| +50, 51 | 0x6E19 | V2 Crest Factor | 0-10000 | ×0.01 | UINT32 | R | 2 |
| +52, 53 | 0x6E1A | V3 Crest Factor | 0-10000 | ×0.01 | UINT32 | R | 2 |
| +54, 55 | 0x6E1B | Not used | 0 | 0 | UINT32 | R | |
| +56, 57 | 0x6E1C | I1 Crest Factor | 0-10000 | ×0.01 | UINT32 | R | |
| +58, 59 | 0x6E1D | I2 Crest Factor | 0-10000 | ×0.01 | UINT32 | R | |
| +60, 61 | 0x6E1E | I3 Crest Factor | 0-10000 | ×0.01 | UINT32 | R | |
| +62, 63 | 0x6E1F | I4 Crest Factor | 0-10000 | ×0.01 | UINT32 | R | |
| 25920-25969 | | 3-Second Harmonics | | | | | |
| +0, 1 | 0x6E80 | V1 THD | 0-9999 | ×0.1% | UINT32 | R | 2 |
| +2, 3 | 0x6E81 | V2 THD | 0-9999 | ×0.1% | UINT32 | R | 2 |
| +4, 5 | 0x6E82 | V3 THD | 0-9999 | ×0.1% | UINT32 | R | 2 |
| +6, 7 | 0x6E83 | Not used | 0 | 0 | UINT32 | R | |
| +8, 9 | 0x6E84 | I1 THD | 0-9999 | ×0.1% | UINT32 | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|----------------------------|----------------------------|--------------------|--------|-----|-------|
| +10, 11 | 0x6E85 | I2 THD | 0-9999 | ×0.1% | UINT32 | R | |
| +12, 13 | 0x6E86 | I3 THD | 0-9999 | ×0.1% | UINT32 | R | |
| +14, 15 | 0x6E87 | I4 THD | 0-9999 | ×0.1% | UINT32 | R | |
| +16, 17 | 0x6E88 | V1 interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | 2 |
| +18, 19 | 0x6E89 | V2 interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | 2 |
| +20, 21 | 0x6E8A | V3 interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | 2 |
| +22, 23 | 0x6E8B | Not used | 0 | 0 | UINT32 | R | |
| +24, 25 | 0x6E6E | I1 interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | |
| +26, 27 | 0x6E8D | I2 interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | |
| +28, 29 | 0x6E8E | I3 interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | |
| +30, 31 | 0x6E8F | I4 interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | |
| +32, 33 | 0x6E90 | I1 TDD | 0-1000 | ×0.1% | UINT32 | R | |
| +34, 35 | 0x6E91 | I2 TDD | 0-1000 | ×0.1% | UINT32 | R | |
| +36, 37 | 0x6E92 | I3 TDD | 0-1000 | ×0.1% | UINT32 | R | |
| +38, 39 | 0x6E93 | I4 TDD | 0-1000 | ×0.1% | UINT32 | R | |
| +40, 41 | 0x6E94 | I1 K-Factor | 10-9999 | ×0.1 | UINT32 | R | |
| +42, 43 | 0x6E95 | I2 K-Factor | 10-9999 | ×0.1 | UINT32 | R | |
| +44, 45 | 0x6E96 | I3 K-Factor | 10-9999 | ×0.1 | UINT32 | R | |
| +46, 47 | 0x6E97 | I4 K-Factor | 10-9999 | ×0.1 | UINT32 | R | |
| +48, 49 | 0x6E98 | V1 Crest Factor | 0-10000 | ×0.01 | UINT32 | R | 2 |
| +50, 51 | 0x6E99 | V2 Crest Factor | 0-10000 | ×0.01 | UINT32 | R | 2 |
| +52, 53 | 0x6E9A | V3 Crest Factor | 0-10000 | ×0.01 | UINT32 | R | 2 |
| +54, 55 | 0x6E9B | Not used | 0 | 0 | UINT32 | R | |
| +56, 57 | 0x6E9C | I1 Crest Factor | 0-10000 | ×0.01 | UINT32 | R | |
| +58, 59 | 0x6E9D | I2 Crest Factor | 0-10000 | ×0.01 | UINT32 | R | |
| +60, 61 | 0x6E9E | I3 Crest Factor | 0-10000 | ×0.01 | UINT32 | R | |
| +62, 63 | 0x6E9F | I4 Crest Factor | 0-10000 | ×0.01 | UINT32 | R | |
| 25984-26033 | | 10-Minute Harmonics | | | | | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|---------|----------|-----------------------|----------------------------|--------------------|--------|-----|-------|
| +0, 1 | 0x6F00 | V1 THD | 0-9999 | ×0.1% | UINT32 | R | 2 |
| +2, 3 | 0x6F01 | V2 THD | 0-9999 | ×0.1% | UINT32 | R | 2 |
| +4, 5 | 0x6F02 | V3 THD | 0-9999 | ×0.1% | UINT32 | R | 2 |
| +6, 7 | 0x6F03 | Not used | 0 | 0 | UINT32 | R | |
| +8, 9 | 0x6F04 | I1 THD | 0-9999 | ×0.1% | UINT32 | R | |
| +10, 11 | 0x6F05 | I2 THD | 0-9999 | ×0.1% | UINT32 | R | |
| +12, 13 | 0x6F06 | I3 THD | 0-9999 | ×0.1% | UINT32 | R | |
| +14, 15 | 0x6F07 | I4 THD | 0-9999 | ×0.1% | UINT32 | R | |
| +16, 17 | 0x6F08 | V1 interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | 2 |
| +18, 19 | 0x6F09 | V2 interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | 2 |
| +20, 21 | 0x6F0A | V3 interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | 2 |
| +22, 23 | 0x6F0B | Not used | 0 | 0 | UINT32 | R | |
| +24, 25 | 0x6F0C | I1 interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | |
| +26, 27 | 0x6F0D | I2 interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | |
| +28, 29 | 0x6F0E | I3 interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | |
| +30, 31 | 0x6F0F | I4 interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | |
| +32, 33 | 0x6F10 | I1 TDD | 0-1000 | ×0.1% | UINT32 | R | |
| +34, 35 | 0x6F11 | I2 TDD | 0-1000 | ×0.1% | UINT32 | R | |
| +36, 37 | 0x6F12 | I3 TDD | 0-1000 | ×0.1% | UINT32 | R | |
| +38, 39 | 0x6F13 | I4 TDD | 0-1000 | ×0.1% | UINT32 | R | |
| +40, 41 | 0x6F14 | I1 K-Factor | 10-9999 | ×0.1 | UINT32 | R | |
| +42, 43 | 0x6F15 | I2 K-Factor | 10-9999 | ×0.1 | UINT32 | R | |
| +44, 45 | 0x6F16 | I3 K-Factor | 10-9999 | ×0.1 | UINT32 | R | |
| +46, 47 | 0x6F17 | I4 K-Factor | 10-9999 | ×0.1 | UINT32 | R | |
| +48, 49 | 0x6F18 | V1 Crest Factor | 0-10000 | ×0.01 | UINT32 | R | 2 |
| +50, 51 | 0x6F19 | V2 Crest Factor | 0-10000 | ×0.01 | UINT32 | R | 2 |
| +52, 53 | 0x6F1A | V3 Crest Factor | 0-10000 | ×0.01 | UINT32 | R | 2 |
| +54, 55 | 0x6F1B | Not used | 0 | 0 | UINT32 | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|-------------------------|----------------------------|--------------------|--------|-----|-------|
| +56, 57 | 0x6F1C | I1 Crest Factor | 0-10000 | ×0.01 | UINT32 | R | |
| +58, 59 | 0x6F1D | I2 Crest Factor | 0-10000 | ×0.01 | UINT32 | R | |
| +60, 61 | 0x6F1E | I3 Crest Factor | 0-10000 | ×0.01 | UINT32 | R | |
| +62, 63 | 0x6F1F | I4 Crest Factor | 0-10000 | ×0.01 | UINT32 | R | |
| 26046-26097 | | 2-Hour Harmonics | | | | | |
| +0, 1 | 0x6F80 | V1 THD | 0-9999 | ×0.1% | UINT32 | R | 2 |
| +2, 3 | 0x6F81 | V2 THD | 0-9999 | ×0.1% | UINT32 | R | 2 |
| +4, 5 | 0x6F82 | V3 THD | 0-9999 | ×0.1% | UINT32 | R | 2 |
| +6, 7 | 0x6F83 | Not used | 0 | 0 | UINT32 | R | |
| +8, 9 | 0x6F84 | I1 THD | 0-9999 | ×0.1% | UINT32 | R | |
| +10, 11 | 0x6F85 | I2 THD | 0-9999 | ×0.1% | UINT32 | R | |
| +12, 13 | 0x6F86 | I3 THD | 0-9999 | ×0.1% | UINT32 | R | |
| +14, 15 | 0x6F87 | I4 THD | 0-9999 | ×0.1% | UINT32 | R | |
| +16, 17 | 0x6F88 | V1 interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | 2 |
| +18, 19 | 0x6F89 | V2 interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | 2 |
| +20, 21 | 0x6F8A | V3 interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | 2 |
| +22, 23 | 0x6F8B | Not used | 0 | 0 | UINT32 | R | |
| +24, 25 | 0x6F8C | I1 interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | |
| +26, 27 | 0x6F8D | I2 interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | |
| +28, 29 | 0x6F8E | I3 interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | |
| +30, 31 | 0x6F8F | I4 interharmonics THD | 0-9999 | ×0.1% | UINT32 | R | |
| +32, 33 | 0x6F90 | I1 TDD | 0-1000 | ×0.1% | UINT32 | R | |
| +34, 35 | 0x6F91 | I2 TDD | 0-1000 | ×0.1% | UINT32 | R | |
| +36, 37 | 0x6F92 | I3 TDD | 0-1000 | ×0.1% | UINT32 | R | |
| +38, 39 | 0x6F93 | I4 TDD | 0-1000 | ×0.1% | UINT32 | R | |
| +40, 41 | 0x6F94 | I1 K-Factor | 10-9999 | ×0.1 | UINT32 | R | |
| +42, 43 | 0x6F95 | I2 K-Factor | 10-9999 | ×0.1 | UINT32 | R | |
| +44, 45 | 0x6F96 | I3 K-Factor | 10-9999 | ×0.1 | UINT32 | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|--|----------------------------|--------------------|--------|-----|-------------------------|
| +46, 47 | 0x6F97 | I4 K-Factor | 10-9999 | ×0.1 | UINT32 | R | |
| +48, 49 | 0x6F98 | V1 Crest Factor | 0-10000 | ×0.01 | UINT32 | R | 2 |
| +50, 51 | 0x6F99 | V2 Crest Factor | 0-10000 | ×0.01 | UINT32 | R | 2 |
| +52, 53 | 0x6F9A | V3 Crest Factor | 0-10000 | ×0.01 | UINT32 | R | 2 |
| +54, 55 | 0x6F9B | Not used | 0 | 0 | UINT32 | R | |
| +56, 57 | 0x6F9C | I1 Crest Factor | 0-10000 | ×0.01 | UINT32 | R | |
| +58, 59 | 0x6F9D | I2 Crest Factor | 0-10000 | ×0.01 | UINT32 | R | |
| +60, 61 | 0x6F9E | I3 Crest Factor | 0-10000 | ×0.01 | UINT32 | R | |
| +62, 63 | 0x6F9F | I4 Crest Factor | 0-10000 | ×0.01 | UINT32 | R | |
| 27136-27263 | | Present PQ Measurements (EN 50160:2007) | | | | | |
| +0,1 | 0x7800 | Not used | 0 | 0 | UINT32 | R | Last 10 min measurement |
| +2,3 | 0x7801 | Not used | 0 | 0 | UINT32 | R | " |
| +4,5 | 0x7802 | Not used | 0 | 0 | UINT32 | R | " |
| +6,7 | 0x7803 | Not used | 0 | 0 | UINT32 | R | " |
| +8,9 | 0x7804 | Not used | 0 | 0 | UINT32 | R | Last 1 hour measurement |
| +10,11 | 0x7805 | Not used | 0 | 0 | UINT32 | R | " |
| +12,13 | 0x7806 | Not used | 0 | 0 | UINT32 | R | " |
| +14,15 | 0x7807 | Not used | 0 | 0 | UINT32 | R | " |
| +16,17 | 0x7808 | Not used | 0 | 0 | UINT32 | R | " |
| +18,19 | 0x7809 | Not used | 0 | 0 | UINT32 | R | " |
| +20,21 | 0x780A | Not used | 0 | 0 | UINT32 | R | Last 10 min measurement |
| +22,23 | 0x780B | Not used | 0 | 0 | UINT32 | R | " |
| +24,25 | 0x780C | Not used | 0 | 0 | UINT32 | R | " |
| +26,27 | 0x780D | Not used | 0 | 0 | UINT32 | R | Last 2 hour measurement |
| +28,29 | 0x780E | Not used | 0 | 0 | UINT32 | R | " |
| +30,31 | 0x780F | Not used | 0 | 0 | UINT32 | R | " |
| +32,33 | 0x7810 | Not used | 0 | 0 | UINT32 | R | Last 10 min measurement |
| +34,35 | 0x7811 | Not used | 0 | 0 | UINT32 | R | " |
| +36,37 | 0x7812 | Not used | 0 | 0 | UINT32 | R | " |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|---------|----------|-------------|----------------------------|--------------------|--------|-----|-----------------------|
| +38,39 | 0x7813 | Not used | 0 | 0 | UINT32 | R | " |
| +40,41 | 0x7814 | Not used | 0 | 0 | UINT32 | R | " |
| +42,43 | 0x7815 | Not used | 0 | 0 | UINT32 | R | Last 10 s measurement |
| +44,45 | 0x7816 | Not used | 0 | 0 | UINT32 | R | |
| +46,47 | 0x7817 | Not used | 0 | 0 | UINT32 | R | |
| +48,49 | 0x7818 | Not used | 0 | 0 | UINT32 | R | |
| +50,51 | 0x7819 | Not used | 0 | 0 | UINT32 | R | |
| +52,53 | 0x781A | Not used | 0 | 0 | UINT32 | R | |
| +54,55 | 0x781B | Not used | 0 | 0 | UINT32 | R | |
| +56,57 | 0x781C | Not used | 0 | 0 | UINT32 | R | |
| +58,59 | 0x781D | Not used | 0 | 0 | UINT32 | R | |
| +60,61 | 0x781E | Not used | 0 | 0 | UINT32 | R | |
| +62,63 | 0x781F | Not used | 0 | 0 | UINT32 | R | |
| +64,65 | 0x7820 | Not used | 0 | 0 | UINT32 | R | |
| +66,67 | 0x7821 | Not used | 0 | 0 | UINT32 | R | |
| +68,69 | 0x7822 | Not used | 0 | 0 | UINT32 | R | |
| +70,71 | 0x7823 | Not used | 0 | 0 | UINT32 | R | |
| +72,73 | 0x7824 | Not used | 0 | 0 | UINT32 | R | |
| +74,75 | 0x7825 | Not used | 0 | 0 | UINT32 | R | |
| +76,77 | 0x7826 | Not used | 0 | 0 | UINT32 | R | |
| +78,79 | 0x7827 | Not used | 0 | 0 | UINT32 | R | |
| +80,81 | 0x7828 | Not used | 0 | 0 | UINT32 | R | Last 3-s measurement |
| +82,83 | 0x7829 | Not used | 0 | 0 | UINT32 | R | " |
| +84,85 | 0x782A | Not used | 0 | 0 | UINT32 | R | " |
| +86,87 | 0x782B | Not used | 0 | 0 | UINT32 | R | 2 |
| +88,89 | 0x782C | Not used | 0 | 0 | UINT32 | R | 2 |
| +90,91 | 0x782D | Not used | 0 | 0 | UINT32 | R | 2 |
| +92,93 | 0x782E | Not used | 0 | 0 | UINT32 | R | |
| +94,95 | 0x782F | Not used | 0 | 0 | UINT32 | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|--|----------------------------|--------------------|--------|-----|---------------------------------|
| +96,97 | 0x7830 | Not used | 0 | 0 | UINT32 | R | |
| +98,99 | 0x7831 | Not used | 0 | 0 | UINT32 | R | |
| +100,101 | 0x7832 | Not used | 0 | 0 | UINT32 | R | |
| +102,103 | 0x7833 | Not used | 0 | 0 | UINT32 | R | |
| +104,105 | 0x7834 | Not used | 0 | 0 | UINT32 | R | |
| +106,107 | 0x7835 | Not used | 0 | 0 | UINT32 | R | |
| +108,109 | 0x7836 | Not used | 0 | 0 | UINT32 | R | |
| +110,111 | 0x7837 | Not used | 0 | 0 | UINT32 | R | |
| +112,113 | 0x7838 | Not used | 0 | 0 | UINT32 | R | |
| +114,115 | 0x7839 | Not used | 0 | 0 | UINT32 | R | |
| +116,117 | 0x783A | Not used | 0 | 0 | UINT32 | R | |
| +118,119 | 0x783B | Not used | 0 | 0 | UINT32 | R | Last 10/12-cycle measurements |
| +120,121 | 0x783C | Not used | 0 | 0 | UINT32 | R | Last 150/180-cycle measurements |
| +122,123 | 0x783D | Not used | 0 | 0 | UINT32 | R | Last 10-s measurements |
| +124,125 | 0x783E | Not used | 0 | 0 | UINT32 | R | Last 10-min measurements |
| +126,127 | 0x783F | Not used | 0 | 0 | UINT32 | R | Last 2-h measurements |
| 27136-27263 | | Present PQ Measurements (EN 50160:2010) | | | | | |
| +0,1 | 0x7800 | Not used | 0 | 0 | UINT32 | R | Last 10-min measurement |
| +2,3 | 0x7801 | Not used | 0 | 0 | UINT32 | R | " |
| +4,5 | 0x7802 | Not used | 0 | 0 | UINT32 | R | " |
| +6,7 | 0x7803 | Not used | 0 | 0 | UINT32 | R | " |
| +8,9 | 0x7804 | Not used | 0 | 0 | UINT32 | R | Last measurement |
| +10,11 | 0x7805 | Not used | 0 | 0 | UINT32 | R | " |
| +12,13 | 0x7806 | Not used | 0 | 0 | UINT32 | R | " |
| +14,15 | 0x7807 | Not used | 0 | 0 | UINT32 | R | " |
| +16,17 | 0x7808 | Not used | 0 | 0 | UINT32 | R | " |
| +18,19 | 0x7809 | Not used | 0 | 0 | UINT32 | R | " |
| +20,21 | 0x780A | Not used | 0 | 0 | UINT32 | R | Last 10-min measurement |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|---------|----------|-------------|----------------------------|--------------------|--------|-----|-------------------------|
| +22,23 | 0x780B | Not used | 0 | 0 | UINT32 | R | " |
| +24,25 | 0x780C | Not used | 0 | 0 | UINT32 | R | " |
| +26,27 | 0x780D | Not used | 0 | 0 | UINT32 | R | Last 2-hour measurement |
| +28,29 | 0x780E | Not used | 0 | 0 | UINT32 | R | " |
| +30,31 | 0x780F | Not used | 0 | 0 | UINT32 | R | " |
| +32,33 | 0x7810 | Not used | 0 | 0 | UINT32 | R | Last 10-min measurement |
| +34,35 | 0x7811 | Not used | 0 | 0 | UINT32 | R | " |
| +36,37 | 0x7812 | Not used | 0 | 0 | UINT32 | R | " |
| +38,39 | 0x7813 | Not used | 0 | 0 | UINT32 | R | " |
| +40,41 | 0x7814 | Not used | 0 | 0 | UINT32 | R | " |
| +42,43 | 0x7815 | Not used | 0 | 0 | UINT32 | R | Last 10-s measurement |
| +44,45 | 0x7816 | Not used | 0 | 0 | UINT32 | R | |
| +46,47 | 0x7817 | Not used | 0 | 0 | UINT32 | R | |
| +48,49 | 0x7818 | Not used | 0 | 0 | UINT32 | R | |
| +50,51 | 0x7819 | Not used | 0 | 0 | UINT32 | R | |
| +52,53 | 0x781A | Not used | 0 | 0 | UINT32 | R | |
| +54,55 | 0x781B | Not used | 0 | 0 | UINT32 | R | |
| +56,57 | 0x781C | Not used | 0 | 0 | UINT32 | R | |
| +58,59 | 0x781D | Not used | 0 | 0 | UINT32 | R | |
| +60,61 | 0x781E | Not used | 0 | 0 | UINT32 | R | |
| +62,63 | 0x781F | Not used | 0 | 0 | UINT32 | R | |
| +64,65 | 0x7820 | Not used | 0 | 0 | UINT32 | R | |
| +66,67 | 0x7821 | Not used | 0 | 0 | UINT32 | R | |
| +68,69 | 0x7822 | Not used | 0 | 0 | UINT32 | R | |
| +70,71 | 0x7823 | Not used | 0 | 0 | UINT32 | R | |
| +72,73 | 0x7824 | Not used | 0 | 0 | UINT32 | R | |
| +74,75 | 0x7825 | Not used | 0 | 0 | UINT32 | R | |
| +76,77 | 0x7826 | Not used | 0 | 0 | UINT32 | R | |
| +78,79 | 0x7827 | Not used | 0 | 0 | UINT32 | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|---|----------------------------|--------------------|--------|-----|-----------------------------------|
| +80,81 | 0x7828 | Not used | 0 | 0 | UINT32 | R | 1-s/3-s/ 10/12-cycle measurements |
| +82,83 | 0x7829 | Not used | 0 | 0 | UINT32 | R | " |
| +84,85 | 0x782A | Not used | 0 | 0 | UINT32 | R | " |
| +86,87 | 0x782B | Not used | 0 | 0 | UINT32 | R | 2 |
| +88,89 | 0x782C | Not used | 0 | 0 | UINT32 | R | 2 |
| +90,91 | 0x782D | Not used | 0 | 0 | UINT32 | R | 2 |
| +92,93 | 0x782E | Not used | 0 | 0 | UINT32 | R | |
| +94,95 | 0x782F | Not used | 0 | 0 | UINT32 | R | |
| +96,97 | 0x7830 | Not used | 0 | 0 | UINT32 | R | |
| +98,99 | 0x7831 | Not used | 0 | 0 | UINT32 | R | |
| +100,101 | 0x7832 | Not used | 0 | 0 | UINT32 | R | |
| +102,103 | 0x7833 | Not used | 0 | 0 | UINT32 | R | |
| +104,105 | 0x7834 | Not used | 0 | 0 | UINT32 | R | |
| +106,107 | 0x7835 | Not used | 0 | 0 | UINT32 | R | |
| +108,109 | 0x7836 | Not used | 0 | 0 | UINT32 | R | |
| +110,111 | 0x7837 | Not used | 0 | 0 | UINT32 | R | |
| +112,113 | 0x7838 | Not used | 0 | 0 | UINT32 | R | |
| +114,115 | 0x7839 | Not used | 0 | 0 | UINT32 | R | |
| +116,117 | 0x783A | Not used | 0 | 0 | UINT32 | R | |
| +118,119 | 0x783B | Not used | 0 | 0 | UINT32 | R | Last 10/12-cycle measurements |
| +120,121 | 0x783C | Not used | 0 | 0 | UINT32 | R | Last 150/180-cycle measurements |
| +122,123 | 0x783D | Not used | 0 | 0 | UINT32 | R | Last 10-s measurements |
| +124,125 | 0x783E | Not used | 0 | 0 | UINT32 | R | Last 10-min measurements |
| +126,127 | 0x783F | Not used | 0 | 0 | UINT32 | R | Last 2-h measurements |
| 27136-27263 | | Present PQ Measurements (GOST 13109) | | | | | |
| +0,1 | 0x7800 | Not used | 0 | 0 | UINT32 | R | Last 1 min measurement |
| +2,3 | 0x7801 | Not used | 0 | 0 | UINT32 | R | " |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|---------|----------|-------------|----------------------------|--------------------|--------|-----|-------------------------|
| +4,5 | 0x7802 | Not used | 0 | 0 | UINT32 | R | " |
| +6,7 | 0x7803 | Not used | 0 | 0 | UINT32 | R | " |
| +8,9 | 0x7804 | Not used | 0 | 0 | UINT32 | R | Last 10 min measurement |
| +10,11 | 0x7805 | Not used | 0 | 0 | UINT32 | R | " |
| +12,13 | 0x7806 | Not used | 0 | 0 | UINT32 | R | " |
| +14,15 | 0x7807 | Not used | 0 | 0 | UINT32 | R | " |
| +16,17 | 0x7808 | Not used | 0 | 0 | UINT32 | R | " |
| +18,19 | 0x7809 | Not used | 0 | 0 | UINT32 | R | " |
| +20,21 | 0x780A | Not used | 0 | 0 | UINT32 | R | Last 10 min measurement |
| +22,23 | 0x780B | Not used | 0 | 0 | UINT32 | R | " |
| +24,25 | 0x780C | Not used | 0 | 0 | UINT32 | R | " |
| +26,27 | 0x780D | Not used | 0 | 0 | UINT32 | R | Last 2 hour measurement |
| +28,29 | 0x780E | Not used | 0 | 0 | UINT32 | R | " |
| +30,31 | 0x780F | Not used | 0 | 0 | UINT32 | R | " |
| +32,33 | 0x7810 | Not used | 0 | 0 | UINT32 | R | Last 3 s measurement |
| +34,35 | 0x7811 | Not used | 0 | 0 | UINT32 | R | " |
| +36,37 | 0x7812 | Not used | 0 | 0 | UINT32 | R | " |
| +38,39 | 0x7813 | Not used | 0 | 0 | UINT32 | R | " |
| +40,41 | 0x7814 | Not used | 0 | 0 | UINT32 | R | " |
| +42,43 | 0x7815 | Not used | 0 | 0 | UINT32 | R | Last 20 s measurement |
| +44,45 | 0x7816 | Not used | 0 | 0 | UINT32 | R | |
| +46,47 | 0x7817 | Not used | 0 | 0 | UINT32 | R | |
| +48,49 | 0x7818 | Not used | 0 | 0 | UINT32 | R | |
| +50,51 | 0x7819 | Not used | 0 | 0 | UINT32 | R | |
| +52,53 | 0x781A | Not used | 0 | 0 | UINT32 | R | |
| +54,55 | 0x781B | Not used | 0 | 0 | UINT32 | R | |
| +56,57 | 0x781C | Not used | 0 | 0 | UINT32 | R | |
| +58,59 | 0x781D | Not used | 0 | 0 | UINT32 | R | |
| +60,61 | 0x781E | Not used | 0 | 0 | UINT32 | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|-------------------|---|----------------------------|--------------------|--------|-----|--|
| +62,63 | 0x781F | Not used | 0 | 0 | UINT32 | R | |
| +64,65 | 0x7820 | Not used | 0 | 0 | UINT32 | R | |
| +66,67 | 0x7821 | Not used | 0 | 0 | UINT32 | R | |
| +68,69 | 0x7822 | Not used | 0 | 0 | UINT32 | R | |
| +70,71 | 0x7823 | Not used | 0 | 0 | UINT32 | R | |
| +72,73 | 0x7824 | Not used | 0 | 0 | UINT32 | R | |
| +74,75 | 0x7825 | Not used | 0 | 0 | UINT32 | R | |
| +76,77 | 0x7826 | Not used | 0 | 0 | UINT32 | R | |
| +78,79 | 0x7827 | Not used | 0 | 0 | UINT32 | R | |
| +80-127 | 0x7828- 0x783F | Not used | | | UINT32 | R | |
| 27136-27263 | | Present PQ Measurements (GOST 32144) | | | | | To include this capability in EN50160:2010 too |
| +0,1 | 0x7800 | Not used | 0 | 0 | UINT32 | R | Last 10 min measurement |
| +2,3 | 0x7801 | Not used | 0 | 0 | UINT32 | R | " |
| +4,5 | 0x7802 | Not used | 0 | 0 | UINT32 | R | " |
| +6,7 | 0x7803 | Not used | 0 | 0 | UINT32 | R | " |
| +8,9 | 0x7804 | Not used | 0 | 0 | UINT32 | R | Last 1-60 min measurement |
| +10,11 | 0x7805 | Not used | 0 | 0 | UINT32 | R | " |
| +12,13 | 0x7806 | Not used | 0 | 0 | UINT32 | R | " |
| +14,15 | 0x7807 | Not used | 0 | 0 | UINT32 | R | " |
| +16,17 | 0x7808 | Not used | 0 | 0 | UINT32 | R | " |
| +18,19 | 0x7809 | Not used | 0 | 0 | UINT32 | R | " |
| +20,21 | 0x780A | Not used | 0 | 0 | UINT32 | R | Last 10 min measurement |
| +22,23 | 0x780B | Not used | 0 | 0 | UINT32 | R | " |
| +24,25 | 0x780C | Not used | 0 | 0 | UINT32 | R | " |
| +26,27 | 0x780D | Not used | 0 | 0 | UINT32 | R | Last 2 hour measurement |
| +28,29 | 0x780E | Not used | 0 | 0 | UINT32 | R | " |
| +30,31 | 0x780F | Not used | 0 | 0 | UINT32 | R | " |
| +32,33 | 0x7810 | Not used | 0 | 0 | UINT32 | R | Last 10 min measurement |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|---------|----------|-------------|----------------------------|--------------------|--------|-----|-----------------------|
| +34,35 | 0x7811 | Not used | 0 | 0 | UINT32 | R | " |
| +36,37 | 0x7812 | Not used | 0 | 0 | UINT32 | R | " |
| +38,39 | 0x7813 | Not used | 0 | 0 | UINT32 | R | " |
| +40,41 | 0x7814 | Not used | 0 | 0 | UINT32 | R | " |
| +42,43 | 0x7815 | Not used | 0 | 0 | UINT32 | R | Last 10 s measurement |
| +44,45 | 0x7816 | Not used | 0 | 0 | UINT32 | R | |
| +46,47 | 0x7817 | Not used | 0 | 0 | UINT32 | R | |
| +48,49 | 0x7818 | Not used | 0 | 0 | UINT32 | R | |
| +50,51 | 0x7819 | Not used | 0 | 0 | UINT32 | R | |
| +52,53 | 0x781A | Not used | 0 | 0 | UINT32 | R | |
| +54,55 | 0x781B | Not used | 0 | 0 | UINT32 | R | |
| +56,57 | 0x781C | Not used | 0 | 0 | UINT32 | R | |
| +58,59 | 0x781D | Not used | 0 | 0 | UINT32 | R | |
| +60,61 | 0x781E | Not used | 0 | 0 | UINT32 | R | |
| +62,63 | 0x781F | Not used | 0 | 0 | UINT32 | R | |
| +64,65 | 0x7820 | Not used | 0 | 0 | UINT32 | R | |
| +66,67 | 0x7821 | Not used | 0 | 0 | UINT32 | R | |
| +68,69 | 0x7822 | Not used | 0 | 0 | UINT32 | R | |
| +70,71 | 0x7823 | Not used | 0 | 0 | UINT32 | R | |
| +72,73 | 0x7824 | Not used | 0 | 0 | UINT32 | R | |
| +74,75 | 0x7825 | Not used | 0 | 0 | UINT32 | R | |
| +76,77 | 0x7826 | Not used | 0 | 0 | UINT32 | R | |
| +78,79 | 0x7827 | Not used | 0 | 0 | UINT32 | R | |
| +80,81 | 0x7828 | Not used | 0 | 0 | UINT32 | R | Last 3-s measurement |
| +82,83 | 0x7829 | Not used | 0 | 0 | UINT32 | R | " |
| +84,85 | 0x782A | Not used | 0 | 0 | UINT32 | R | " |
| +86,87 | 0x782B | Not used | 0 | 0 | UINT32 | R | 2 |
| +88,89 | 0x782C | Not used | 0 | 0 | UINT32 | R | 2 |
| +90,91 | 0x782D | Not used | 0 | 0 | UINT32 | R | 2 |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|---|----------------------------|--------------------|----------|-----|---------------------------------|
| +92,93 | 0x782E | Not used | 0 | 0 | UINT32 | R | |
| +94,95 | 0x782F | Not used | 0 | 0 | UINT32 | R | |
| +96,97 | 0x7830 | Not used | 0 | 0 | UINT32 | R | |
| +98,99 | 0x7831 | Not used | 0 | 0 | UINT32 | R | |
| +100,101 | 0x7832 | Not used | 0 | 0 | UINT32 | R | |
| +102,103 | 0x7833 | Not used | 0 | 0 | UINT32 | R | |
| +104,105 | 0x7834 | Not used | 0 | 0 | UINT32 | R | |
| +106,107 | 0x7835 | Not used | 0 | 0 | UINT32 | R | |
| +108,109 | 0x7836 | Not used | 0 | 0 | UINT32 | R | |
| +110,111 | 0x7837 | Not used | 0 | 0 | UINT32 | R | |
| +112,113 | 0x7838 | Not used | 0 | 0 | UINT32 | R | |
| +114,115 | 0x7839 | Not used | 0 | 0 | UINT32 | R | |
| +116,117 | 0x783A | Not used | 0 | 0 | UINT32 | R | |
| +118,119 | 0x783B | Not used | 0 | 0 | UINT32 | R | Last 10/12-cycle measurements |
| +120,121 | 0x783C | Not used | 0 | 0 | UINT32 | R | Last 150/180-cycle measurements |
| +122,123 | 0x783D | Not used | 0 | 0 | UINT32 | R | Last 10-s measurements |
| +124,125 | 0x783E | Not used | 0 | 0 | UINT32 | R | Last 10-min measurements |
| +126,127 | 0x783F | Not used | 0 | 0 | UINT32 | R | Last 2-h measurements |
| 28160-28223 | | External Integer Measured Values | | | | | |
| +0,1 | 0x8000 | ExtiVal1 | | | INT32 | R | |
| +2,3 | 0x8001 | ExtiVal2 | | | INT32 | R | |
| | ... | ... | | | INT32 | R | |
| +62,63 | 0x801F | ExtiVal32 | | | INT32 | R | |
| 28288-28321 | | External Float Measured Values | | | | | |
| +0,1 | 0x8100 | ExtfVal1 | | | FLOAT 32 | R | |
| +2,3 | 0x8101 | ExtfVal2 | | | FLOAT 32 | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|---|---|--------------------|-------------|-----|--------|
| | ... | ... | | | FLOAT 32 | R | |
| +62,63 | 0x801F | ExtfVal32 | | | FLOAT 32 | R | |
| | | External Indication | | | | | |
| 28416-28417 | | ExtInd1:32 Bit 0: ExtInd1 ... Bit 32: ExtInd32 | 0x00000000-0xFFFFFFFF Bit Value: 0=OFF, 1=ON | | UINT32 | R | Bitmap |
| 28480-28481 | | ExtInd33:64 Bit 0: ExtInd33 ... Bit 32: ExtInd64 | 0x00000000-0xFFFFFFFF Bit Value: 0=OFF, 1=ON | | UINT32 | R | Bitmap |
| 28544-28545 | | ExtInd65:96 Bit 0: ExtInd65 ... Bit 32: ExtInd96 | 0x00000000-0xFFFFFFFF Bit Value: 0=OFF, 1=ON | | UINT32 | R | Bitmap |
| 28608-28609 | | ExtInd97:128 Bit 0: ExtInd97 ... Bit 32: ExtInd128 | 0x00000000-0xFFFFFFFF Bit Value: 0=OFF, 1=ON | | UINT32 | R | Bitmap |
| | 0x8200 | ExtInd1 | 0/1 | | UINT32 | TRG | |
| | 0x8201 | ExtInd2 | 0/1 | | UINT32 | TRG | |
| | ... | ... | | | | | |
| | 0x827F | ExtInd128 | 0/1 | | UINT32 | TRG | |
| | | External Indication (DP) | | | | | |
| | 0xBD00 | ExtInd 1-2 | 0-3 | | UINT32 | TRG | |
| | 0xBD01 | ExtInd 2-3 | 0-3 | | UINT32 | TRG | |
| | ... | ... | | | | | |
| | 0xBD7E | ExtInd 127-128 | 0-3 | | UINT32 | TRG | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|---|----------------------------|--------------------|--------|-----|----------|
| | | Switch Position Indication | | | | | |
| 29440-29471 | 0x8A00 | Not used | 0 | 0 | UINT32 | R | Not used |
| +0,1 | 0x8A00 | Not used | 0 | 0 | UINT32 | R | Not used |
| +2,3 | 0x8A01 | Not used | 0 | 0 | UINT32 | R | Not used |
| +4,5 | 0x8A02 | Not used | 0 | 0 | UINT32 | R | Not used |
| | ... | ... | | | | | |
| +30,31 | 0x8A0F | Not used | 0 | 0 | UINT32 | R | |
| | | Switch Operation-Open Indication | | | | | |
| 29568-29569 | 0x8B00 | Not used | 0 | 0 | UINT32 | R | Bitmap |
| | 0x8B00 | Not used | 0 | 0 | UINT32 | R | |
| | 0x8B01 | Not used | 0 | 0 | UINT32 | R | |
| | 0x8B02 | Not used | 0 | 0 | UINT32 | R | |
| | ... | ... | | | | | |
| | 0x8B0F | Not used | 0 | 0 | UINT32 | R | |
| | | Switch Operation-Close Indication | | | | | |
| 29632-29633 | 0x8B80 | Not used | 0 | 0 | UINT32 | R | Bitmap |
| | 0x8B80 | Not used | 0 | 0 | UINT32 | R | |
| | 0x8B81 | Not used | 0 | 0 | UINT32 | R | |
| | 0x8B82 | Not used | 0 | 0 | UINT32 | R | |
| | ... | ... | | | | | |
| | 0x8B8F | Not used | 0 | 0 | UINT32 | R | |
| 29696-29727 | | Switch Operation Counters (resettable) | | | | | |
| +0,1 | 0x8C00 | Not used | 0 | 0 | UINT32 | R | |
| +2,3 | 0x8C01 | Not used | 0 | 0 | UINT32 | R | |
| +4,5 | 0x8C02 | Not used | 0 | 0 | UINT32 | R | |
| | ... | ... | | | | | |
| +30,31 | 0x8C0F | Not used | 0 | 0 | UINT32 | R | |
| 30080-30093 | | Distance to fault | | | | | |
| +0,1 | 0x8F00 | Not used | 0 | 0 | UINT32 | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|--------------------------------------|----------------------------|--------------------|--------|-----|-------|
| +2,3 | 0x8F01 | Not used | 0 | 0 | UINT32 | R | |
| +4,5 | 0x8F02 | Not used | 0 | 0 | UINT32 | R | |
| +6,7 | 0x8F03 | Not used | 0 | 0 | UINT32 | R | |
| +8,9 | 0x8F04 | Not used | 0 | 0 | UINT32 | R | |
| +10,11 | 0x8F05 | Not used | 0 | 0 | UINT32 | R | |
| +12,13 | 0x8F06 | Not used | 0 | 0 | UINT32 | R | |
| 30208-30307 | | V1/V12 Voltage Interharmonics | | | | | 2, 7 |
| +0,1 | 0x9000 | H01 Interharmonic | 0-10000 | ×0.01% | UINT32 | R | |
| +2,3 | 0x9001 | H02 Interharmonic | 0-10000 | ×0.01% | UINT32 | R | |
| | | ... | | | | | |
| +98,99 | 0x9031 | H50 Interharmonic | 0-10000 | ×0.01% | UINT32 | R | |
| 30336-30435 | | V2/V23 Voltage Interharmonics | | | | | 2, 7 |
| +0,1 | 0x9100 | H01 Interharmonic | 0-10000 | ×0.01% | UINT32 | R | |
| +2,3 | 0x9101 | H02 Interharmonic | 0-10000 | ×0.01% | UINT32 | R | |
| | | ... | | | | | |
| +98,99 | 0x9131 | H50 Interharmonic | 0-10000 | ×0.01% | UINT32 | R | |
| 30464-30563 | | V3/V31 Voltage Interharmonics | | | | | 2, 7 |
| +0,1 | 0x9200 | H01 Interharmonic | 0-10000 | ×0.01% | UINT32 | R | |
| +2,3 | 0x9201 | H02 Interharmonic | 0-10000 | ×0.01% | UINT32 | R | |
| | | ... | | | | | |
| +98,99 | 0x9231 | H50 Interharmonic | 0-10000 | ×0.01% | UINT32 | R | |
| 30720-30819 | | I1 Current Interharmonics | | | | | 7 |
| +0,1 | 0x9400 | H01 Interharmonic | 0-10000 | ×0.01% | UINT32 | R | |
| +2,3 | 0x9401 | H02 Interharmonic | 0-10000 | ×0.01% | UINT32 | R | |
| | | ... | | | | | |
| +98,99 | 0x9431 | H50 Interharmonic | 0-10000 | ×0.01% | UINT32 | R | |
| 30848-30947 | | I2 Current Interharmonics | | | | | 7 |
| +0,1 | 0x9500 | H01 Interharmonic | 0-10000 | ×0.01% | UINT32 | R | |
| +2,3 | 0x9501 | H02 Interharmonic | 0-10000 | ×0.01% | UINT32 | R | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|-------------|----------|---|----------------------------|--------------------|--------|-----|------------------|
| | | ... | | | | | |
| +98,99 | 0x9531 | H50 Interharmonic | 0-10000 | ×0.01% | UINT32 | R | |
| 30976-31075 | | I3 Current Interharmonics | | | | | 7 |
| +0,1 | 0x9600 | H01 Interharmonic | 0-10000 | ×0.01% | UINT32 | R | |
| +2,3 | 0x9601 | H02 Interharmonic | 0-10000 | ×0.01% | UINT32 | R | |
| | | ... | | | | | |
| +98,99 | 0x9631 | H50 Interharmonic | 0-10000 | ×0.01% | UINT32 | R | |
| | | Generic TOU Registers | | | | | Point references |
| | 0x7000 | Tariff #1 register | 0-999,999,999 | U5 | UINT32 | | |
| | 0x7001 | Tariff #2 register | 0-999,999,999 | U5 | UINT32 | | |
| | | ... | | | | | |
| | 0x700F | Tariff #16 register | 0-999,999,999 | U5 | UINT32 | | |
| | | Generic TOU Maximum Demand Registers | | | | | Point references |
| | 0x7100 | Tariff #1 register | 0-Pmax | U3 | UINT32 | | |
| | 0x7101 | Tariff #2 register | 0-Pmax | U3 | UINT32 | | |
| | | ... | | | | | |
| | 0x710F | Tariff #16 register | 0-Pmax | U3 | UINT32 | | |
| | | Generic Data | | | | | Point references |
| | 0x7400 | V1 voltage | 0-Vmax | U1 | UINT32 | | 1, DC-applicable |
| | 0x7401 | V2 voltage | 0-Vmax | U1 | UINT32 | | 1, DC-applicable |
| | 0x7402 | V3 voltage | 0-Vmax | U1 | UINT32 | | 1, DC-applicable |
| | 0x7403 | Not used | 0 | 0 | UINT32 | R | |
| | 0x7404 | V12 voltage | 0-Vmax | U1 | UINT32 | | |
| | 0x7405 | V23 voltage | 0-Vmax | U1 | UINT32 | | |
| | 0x7406 | V31 voltage | 0-Vmax | U1 | UINT32 | | |
| | 0x7407 | I1 current | 0-Imax | U2 | UINT32 | | DC-applicable |
| | 0x7408 | I2 current | 0-Imax | U2 | UINT32 | | DC-applicable |
| | 0x7409 | I3 current | 0-Imax | U2 | UINT32 | | DC-applicable |
| | 0x740A | I4 current | 0-I4max | U2 | UINT32 | | DC-applicable |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|---------|----------|--------------------------|----------------------------|--------------------|--------|-----|-------|
| | 0x740B | In current | 0-lmax | U2 | UINT32 | | |
| | 0x740C | Not used | 0 | 0 | UINT32 | | |
| | 0x740D | Not used | 0 | 0 | UINT32 | | |
| | 0x740E | Not used | 0 | 0 | UINT32 | | |
| | 0x740F | Not used | 0 | 0 | UINT32 | | |
| | 0x7410 | Not used | 0 | 0 | UINT32 | | |
| | 0x7411 | Zero-sequence voltage | 0-Vmax | U1 | UINT32 | | |
| | 0x7412 | Zero-sequence current | 0-lmax | U2 | UINT32 | | |
| | 0x7413 | Ix Zero-sequence current | 0-lxmax | U2 | UINT32 | | |
| | 0x7414 | Voltage unbalance | 0-3000 | ×0.1% | UINT32 | | |
| | 0x7415 | Current unbalance | 0-3000 | ×0.1% | UINT32 | | |
| | 0x7416 | Ix current unbalance | 0-3000 | ×0.1% | UINT32 | | |
| | 0x7417 | Not used | | | UINT32 | | |
| | 0x7418 | Frequency | 0-10000 | ×0.01Hz | UINT32 | | |
| | 0x7419 | V1 THD | 0-9999 | ×0.1% | UINT32 | | 2 |
| | 0x741A | V2 THD | 0-9999 | ×0.1% | UINT32 | | 2 |
| | 0x741B | V3 THD | 0-9999 | ×0.1% | UINT32 | | 2 |
| | 0x741C | Not used | 0 | 0 | UINT32 | | |
| | 0x741D | I1 THD | 0-9999 | ×0.1% | UINT32 | | |
| | 0x741E | I2 THD | 0-9999 | ×0.1% | UINT32 | | |
| | 0x741F | I3 THD | 0-9999 | ×0.1% | UINT32 | | |
| | 0x7420 | I4 THD | 0-9999 | ×0.1% | UINT32 | | |
| | 0x7421 | V1 interharmonics THD | 0-9999 | ×0.1% | UINT32 | | 2 |
| | 0x7422 | V2 interharmonics THD | 0-9999 | ×0.1% | UINT32 | | 2 |
| | 0x7423 | V3 interharmonics THD | 0-9999 | ×0.1% | UINT32 | | 2 |
| | Not used | 0 | 0 | UINT32 | R | | |
| | 0x7425 | I1 interharmonics THD | 0-9999 | ×0.1% | UINT32 | | |
| | 0x7426 | I2 interharmonics THD | 0-9999 | ×0.1% | UINT32 | | |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|---------|----------|-------------------------------------|----------------------------|--------------------|--------|-----|-----------------|
| | 0x7427 | I3 interharmonics THD | 0-9999 | ×0.1% | UINT32 | | |
| | 0x7428 | I4 interharmonics THD | 0-9999 | ×0.1% | UINT32 | | |
| | 0x7429 | I1 TDD | 0-1000 | ×0.1% | UINT32 | | |
| | 0x742A | I2 TDD | 0-1000 | ×0.1% | UINT32 | | |
| | 0x742B | I3 TDD | 0-1000 | ×0.1% | UINT32 | | |
| | 0x742C | I4 TDD | 0-1000 | ×0.1% | UINT32 | | |
| | 0x742D | I1 K-Factor | 10-9999 | ×0.1 | UINT32 | | |
| | 0x742E | I2 K-Factor | 10-9999 | ×0.1 | UINT32 | | |
| | 0x742F | I3 K-Factor | 10-9999 | ×0.1 | UINT32 | | |
| | 0x7430 | I4 K-Factor | 10-9999 | ×0.1 | UINT32 | | |
| | 0x7431 | V1 Crest Factor | 0-10000 | ×0.01 | UINT32 | | 2 |
| | 0x7432 | V2 Crest Factor | 0-10000 | ×0.01 | UINT32 | | 2 |
| | 0x7433 | V3 Crest Factor | 0-10000 | ×0.01 | UINT32 | | 2 |
| | 0x7434 | Not used | 0 | 0 | UINT32 | | |
| | 0x7435 | I1 Crest Factor | 0-10000 | ×0.01 | UINT32 | | |
| | 0x7436 | I2 Crest Factor | 0-10000 | ×0.01 | UINT32 | | |
| | 0x7437 | I3 Crest Factor | 0-10000 | ×0.01 | UINT32 | | |
| | 0x7438 | I4 Crest Factor | 0-10000 | ×0.01 | UINT32 | | |
| | 0x7439 | I leakage current | 0-I _{max} | U2 | UINT32 | | |
| | 0x743A | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2010 |
| | 0x743B | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2010 |
| | 0x743C | Not used | 0 | 0 | UINT32 | | EN 50160:2010 |
| | 0x743D | Not used | 0 | 0 | UINT32 | | EN 50160:2010 |
| | 0x743E | Not used | 0 | 0 | UINT32 | | EN 50160:2010 |
| | 0x750A | Positive-sequence voltage | 0-V _{max} | U1 | UINT32 | | 2 |
| | 0x750B | Negative-sequence voltage | 0-V _{max} | U1 | UINT32 | | 2 |
| | 0x750C | Zero-sequence voltage | 0-V _{max} | U1 | UINT32 | | 2 |
| | 0x750D | Negative-sequence voltage unbalance | 0-3000 | ×0.1% | UINT32 | | 2 |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|---------|----------|---------------------------------|----------------------------|--------------------|--------|-----|-----------------|
| | 0x750E | Zero-sequence voltage unbalance | 0-3000 | ×0.1% | UINT32 | | 2 |
| | 0x750F | V1 impulsive voltage | 0-Vmax | U1 | UINT32 | | |
| | 0x7510 | V2 impulsive voltage | 0-Vmax | U1 | UINT32 | | |
| | 0x7511 | V3 impulsive voltage | 0-Vmax | U1 | UINT32 | | |
| | 0x7512 | Not used | 0 | 0 | UINT32 | | |
| | 0x7513 | V12 impulsive voltage | 0-Vmax | U1 | UINT32 | | |
| | 0x7514 | V23 impulsive voltage | 0-Vmax | U1 | UINT32 | | |
| | 0x7515 | V31 impulsive voltage | 0-Vmax | U1 | UINT32 | | |
| | 0x7516 | Not used | 0 | 0 | UINT32 | | |
| | 0x1900 | V1 H01 Harmonic voltage | 0-10000 | ×0.01% | UINT32 | | 2 |
| | 0x1901 | V1 H02 Harmonic voltage | 0-10000 | ×0.01% | UINT32 | | 2 |
| | | ... | | | | | |
| | 0x1931 | V1 H50 Harmonic voltage | 0-10000 | ×0.01% | UINT32 | | 2 |
| | 0x1A00 | V2 H01 Harmonic voltage | 0-10000 | ×0.01% | UINT32 | | 2 |
| | 0x1A01 | V2 H02 Harmonic voltage | 0-10000 | ×0.01% | UINT32 | | 2 |
| | | ... | | | | | |
| | 0x1A31 | V2 H50 Harmonic voltage | 0-10000 | ×0.01% | UINT32 | | 2 |
| | 0x1B00 | V3 H01 Harmonic voltage | 0-10000 | ×0.01% | UINT32 | | 2 |
| | 0x1B01 | V3 H02 Harmonic voltage | 0-10000 | ×0.01% | UINT32 | | 2 |
| | | ... | | | | | |
| | 0x1B31 | V3 H50 Harmonic voltage | 0-10000 | ×0.01% | UINT32 | | 2 |
| | 0x2980 | Not used | 0 | 0 | UINT32 | | 2 |
| | 0x2981 | Not used | 0 | 0 | UINT32 | | 2 |
| | 0x2982 | Not used | 0 | 0 | UINT32 | | 2 |
| | 0x2983 | Not used | 0 | 0 | UINT32 | | 2 |
| | 0x2984 | Not used | 0 | 0 | UINT32 | | 2 |
| | 0x2985 | Not used | 0 | 0 | UINT32 | | 2 |
| | 0x5B02 | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2007 |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|---------|----------|-------------|----------------------------|--------------------|--------|-----|-----------------|
| | 0x5B04 | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2007 |
| | 0x5B06 | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2007 |
| | 0x6005 | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2007 |
| | 0x6006 | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2007 |
| | 0x6007 | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2007 |
| | 0x6008 | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2007 |
| | 0x600A | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2007 |
| | 0x600B | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2007 |
| | 0x600C | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2007 |
| | 0x600D | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2007 |
| | 0x600F | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2007 |
| | 0x6010 | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2007 |
| | 0x6011 | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2007 |
| | 0x6012 | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2007 |
| | 0xC182 | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2010 |
| | 0xC184 | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2010 |
| | 0xC186 | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2010 |
| | 0x7805 | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2010 |
| | 0x7807 | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2010 |
| | 0x7809 | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2010 |
| | 0xC383 | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2010 |
| | 0xC385 | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2010 |
| | 0xC387 | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2010 |
| | 0xC389 | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2010 |
| | 0xC38B | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2010 |
| | 0xC38D | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2010 |

| Address | Point ID | Description | Options/Range ³ | Units ³ | Type | R/W | Notes |
|---------|----------|-------------|----------------------------|--------------------|--------|-----|-----------------|
| | 0xC38F | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2010 |
| | 0xC391 | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2010 |
| | 0xC393 | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2010 |
| | 0xC395 | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2010 |
| | 0xC397 | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2010 |
| | 0xC399 | Not used | 0 | 0 | UINT32 | | 2 EN 50160:2010 |
| | 0xC481 | Not used | 0 | 0 | UINT32 | | 2 GOST 13109 |
| | 0xC486 | Not used | 0 | 0 | UINT32 | | 2 GOST 13109 |
| | 0xC48B | Not used | 0 | 0 | UINT32 | | 2 GOST 13109 |
| | 0xCF02 | Not used | 0 | 0 | UINT32 | | 2 GOST 32144 |
| | 0xCF04 | Not used | 0 | 0 | UINT32 | | 2 GOST 32144 |
| | 0xCF06 | Not used | 0 | 0 | UINT32 | | 2 GOST 32144 |
| | 0xD083 | Not used | 0 | 0 | UINT32 | | 2 GOST 32144 |
| | 0xD084 | Not used | 0 | 0 | UINT32 | | 2 GOST 32144 |
| | 0xD085 | Not used | 0 | 0 | UINT32 | | 2 GOST 32144 |
| | 0xD086 | Not used | 0 | 0 | UINT32 | | 2 GOST 32144 |
| | 0xD087 | Not used | 0 | 0 | UINT32 | | 2 GOST 32144 |
| | 0xD088 | Not used | 0 | 0 | UINT32 | | 2 GOST 32144 |
| | 0xD089 | Not used | 0 | 0 | UINT32 | | 2 GOST 32144 |
| | 0xD08A | Not used | 0 | 0 | UINT32 | | 2 GOST 32144 |
| | 0xD08B | Not used | 0 | 0 | UINT32 | | 2 GOST 32144 |
| | 0xD08C | Not used | 0 | 0 | UINT32 | | 2 GOST 32144 |
| | 0xD08D | Not used | 0 | 0 | UINT32 | | 2 GOST 32144 |
| | 0xD08E | Not used | 0 | 0 | UINT32 | | 2 GOST 32144 |

NOTES:

¹When the 4LN3, 4LL3, 3LN3, 3LL3, 3BLN3 or 3BLL3 wiring mode is selected, the voltages will be line-to-neutral; for any other wiring mode, they will be line-to-line.

²When the 4LN3, 3LN3 or 3BLN3 wiring mode is selected, the voltages will be line-to-neutral; for any other wiring mode, they will be line-to-line voltages.

³For volts, amps, power and frequency scales and units, refer to Section 4 "Data Scales and Units".

⁴0.2-s (10/12-cycle) interval (16-cycle interval for GOST 13109).

⁵3-s interval.

⁶Harmonic angles are referenced to the fundamental voltage harmonic H01 on phase L1.

⁷0.2-s (10/12-cycle) interval for EN 50160:2007, 16-cycle interval for GOST 13109, programmable 0.2-s (10/12-cycle), 3-s (150/180-cycle), 10-min, 2-h interval for GOST 32144 and EN 50160:2010.

⁸Digital input registers return the state of the level-sensitive digital inputs in a 32-bit packed format beginning from the nearest lower point number divisible by 32. For example, registers 12544-12545 and 12548-12549 report the same 32-bit value that contains the state of digital inputs DI1:DI32. Bits that reference non-existent points will contain zeros.

⁹Pulse input registers contain the transition status of the edge sensitive digital inputs. A bit value is set to '1' if a pulse edge (either rising, falling, or any of them depending on the input polarity setting) has been detected on the input. Pulse inputs cannot be directly read but can be tested through the setpoints and/or linked to the pulse counters and Summary energy/TOU registers.

3.5 Minimum/Maximum Log Registers

| Address | Point ID | Description | Options/Range/Format ³ | Units ³ | Type | R/W | Notes |
|--------------------|----------|------------------------------|-----------------------------------|--------------------|------------------|--------|------------------|
| 35840-35971 | | Minimum Phase Values | | | | | |
| +0, 1 +2, 3 | 0x2C00 | Min. V1 voltage Timestamp | 0-Vmax F1 | U1 sec | UINT32 UINT32 | R R | 1, DC-applicable |
| +4, 5 +6, 7 | 0x2C01 | Min. V2 voltage Timestamp | 0-Vmax F1 | U1 sec | UINT32 UINT32 | R R | 1, DC-applicable |
| +8, 9 +10, 11 | 0x2C02 | Min. V3 voltage Timestamp | 0-Vmax F1 | U1 sec | UINT32 UINT32 | R R | 1, DC-applicable |
| +12, 13 +14, 15 | 0x2C03 | Min. I1 current Timestamp | 0-Imax F1 | U2 sec | UINT32 UINT32 | R R | DC-applicable |
| +16, 17 +18, 19 | 0x2C04 | Min. I2 current Timestamp | 0-Imax | U2 sec | UINT32 UINT32 | R R | DC-applicable |
| +20, 21 +22, 23 | 0x2C05 | Min. I3 current Timestamp | 0-Imax | U2 sec | UINT32 UINT32 | R R | DC-applicable |
| +24, 25 +26, 27 | 0x2C06 | Min. kW L1 Timestamp | -Pmax-Pmax | U3 sec | INT32 INT32 | R R | DC-applicable |
| +28, 29 +30, 31 | 0x2C07 | Min. kW L2 Timestamp | -Pmax-Pmax | U3 sec | INT32 INT32 | R R | DC-applicable |
| +32, 33 +34, 35 | 0x2C08 | Min. kW L3 Timestamp | -Pmax-Pmax | U3 sec | INT32 INT32 | R R | DC-applicable |
| +36, 37 +38, 39 | 0x2C09 | Min. kvar L1 Timestamp | -Pmax-Pmax | U3 sec | INT32 INT32 | R R | |
| +40, 41 +42, 43 | 0x2C0A | Min. kvar L2 Timestamp | -Pmax-Pmax | U3 sec | INT32 INT32 | R R | |
| +44, 45 +46, 47 | 0x2C0B | Min. kvar L3 Timestamp | -Pmax-Pmax | U3 sec | INT32 INT32 | R R | |
| +48, 49 +50, 51 | 0x2C0C | Min. kVA L1 Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| +52, 53 +54, 55 | 0x2C0D | Min. kVA L2 Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |

| Address | Point ID | Description | Options/Range/Format ³ | Units ³ | Type | R/W | Notes |
|------------------------|----------|-----------------------------------|-----------------------------------|--------------------|------------------|--------|----------------|
| +56, 57 +58, 59 | 0x2C0E | Min. kVA L3 Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| +60, 61 +62, 63 | 0x2C0F | Min. Power factor L1 Timestamp | 0-1000 | ×0.001 sec | UINT32 UINT32 | R R | Absolute value |
| +64, 65 +66, 67 | 0x2C10 | Min. Power factor L2 Timestamp | 0-1000 | ×0.001 sec | UINT32 UINT32 | R R | Absolute value |
| +68, 69 +70, 71 | 0x2C11 | Min. Power factor L3 Timestamp | 0-1000 | ×0.001 sec | UINT32 UINT32 | R R | Absolute value |
| +72, 73 +74, 75 | 0x2C12 | Min. V1 voltage THD Timestamp | 0-9999 | ×0.1% sec | UINT32 UINT32 | R R | 2, 4 |
| +76, 77 +78, 79 | 0x2C13 | Min. V2 voltage THD Timestamp | 0-9999 | ×0.1% sec | UINT32 UINT32 | R R | 2, 4 |
| +80, 81 +82, 83 | 0x2C14 | Min. V3 voltage THD Timestamp | 0-9999 | ×0.1% sec | UINT32 UINT32 | R R | 2, 4 |
| +84, 85 +86, 87 | 0x2C15 | Min. I1 current THD Timestamp | 0-9999 | ×0.1% sec | UINT32 UINT32 | R R | 4 |
| +88, 89 +90, 91 | 0x2C16 | Min. I2 current THD Timestamp | 0-9999 | ×0.1% sec | UINT32 UINT32 | R R | 4 |
| +92, 93 +94, 95 | 0x2C17 | Min. I3 current THD Timestamp | 0-9999 | ×0.1% sec | UINT32 UINT32 | R R | 4 |
| +96, 97 +98, 99 | 0x2C18 | Min. I1 K-Factor Timestamp | 10-9999 | ×0.1 sec | UINT32 UINT32 | R R | 4 |
| +100, 101 +102, 103 | 0x2C19 | Min. I2 K-Factor Timestamp | 10-9999 | ×0.1 sec | UINT32 UINT32 | R R | 4 |
| +104, 105 +106, 107 | 0x2C1A | Min. I3 K-Factor Timestamp | 10-9999 | ×0.1 sec | UINT32 UINT32 | R R | 4 |
| +108, 109 +110, 111 | 0x2C1B | Min. I1 current TDD Timestamp | 0-1000 | ×0.1% sec | UINT32 UINT32 | R R | 4 |
| +112, 113 +114, 115 | 0x2C1C | Min. I2 current TDD Timestamp | 0-1000 | ×0.1% sec | UINT32 UINT32 | R R | 4 |

| Address | Point ID | Description | Options/Range/Format ³ | Units ³ | Type | R/W | Notes |
|------------------------|----------|------------------------------------|-----------------------------------|--------------------|------------------|--------|---------------|
| +116, 117 +118, 119 | 0x2C1D | Min. I3 current TDD Timestamp | 0-1000 | ×0.1% sec | UINT32 UINT32 | R R | 4 |
| +120, 121 +122, 123 | 0x2C1E | Min. V12 voltage Timestamp | 0-Vmax | U1 sec | UINT32 UINT32 | R R | |
| +124, 125 +126, 127 | 0x2C1F | Min. V23 voltage Timestamp | 0-Vmax | U1 sec | UINT32 UINT32 | R R | |
| +128, 129 +130, 131 | 0x2C20 | Min. V31 voltage Timestamp | 0-Vmax | U1 sec | UINT32 UINT32 | R R | |
| +132, 133 +134, 135 | 0x2C21 | Not used | 0 | 0 | UINT32 | R | |
| +136, 137 +138, 139 | 0x2C22 | Not used | 0 | 0 | UINT32 | R | |
| +140, 141 +142, 143 | 0x2C23 | Not used | 0 | 0 | UINT32 | R | |
| 36096-36119 | | Minimum Total Values | | | | | |
| +0, 1 +2, 3 | 0x2D00 | Min. Total kW Timestamp | -Pmax-Pmax | U3 sec | INT32 UINT32 | R R | DC-applicable |
| +4, 5 +6, 7 | 0x2D01 | Min. Total kvar Timestamp | -Pmax-Pmax | U3 sec | INT32 UINT32 | R R | |
| +8, 9 +10, 11 | 0x2D02 | Min. Total kVA Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| +12, 13 +14, 15 | 0x2D03 | Min. Total PF Timestamp | -1000-1000 | ×0.001 sec | INT32 UINT32 | R R | |
| +16, 17 +18, 19 | 0x2D04 | Min. Total PF lag Timestamp | 0-1000 | ×0.001 sec | UINT32 UINT32 | R R | |
| +20, 21 +22, 23 | 0x2D05 | Min. Total PF lead Timestamp | 0-1000 | ×0.001 sec | UINT32 UINT32 | R R | |
| 36224-36243 | | Minimum Analog Inputs | | | | | |
| +0, 1 +2, 3 | 0x2E80 | Min. analog input AI1 Timestamp | AI1min-AI1max | | INT32 UINT32 | R R | |
| +4, 5 | 0x2E81 | Min. analog input AI2 | AI2min-AI2max | | INT32 | R | |

| Address | Point ID | Description | Options/Range/Format ³ | Units ³ | Type | R/W | Notes |
|--------------------|----------|--|-----------------------------------|--------------------|------------------|--------|---------------|
| +6, 7 | | Timestamp | | | UINT32 | R | |
| | | ... | | | | | |
| +16, 17 +18, 19 | 0x2E84 | Min. analog input AI5 Timestamp | AI5min-AI5max | | INT32 UINT32 | R R | |
| 36352-36395 | | Minimum Auxiliary Values | | | | | |
| +0, 1 +2, 3 | 0x2E00 | Min. I4 current Timestamp | 0-I _{max} | U2 sec | UINT32 UINT32 | R R | DC-applicable |
| +4, 5 +6, 7 | 0x2E01 | Min. In current Timestamp | 0-I _{max} | U2 sec | UINT32 UINT32 | R R | |
| +8, 9 +10, 11 | 0x2E02 | Min. Frequency Timestamp | 0-10000 | ×0.01Hz sec | UINT32 UINT32 | R R | |
| +12, 13 +14, 15 | 0x2E03 | Min. Voltage unbalance Timestamp | 0-3000 | ×0.1% sec | UINT32 UINT32 | R R | |
| +16, 17 +18, 19 | 0x2E04 | Min. Current unbalance Timestamp | 0-3000 | ×0.1% sec | UINT32 UINT32 | R R | |
| +20, 21 +22, 23 | 0x2E05 | Not used | | | UINT32 UINT32 | R R | |
| +24, 25 +26, 27 | 0x2E06 | Not used | 0 | 0 | UINT32 | R | |
| +28, 29 +30, 31 | 0x2E07 | Not used | 0 | 0 | UINT32 | R | |
| +32, 33 +34, 35 | 0x2E08 | Not used | 0 | 0 | UINT32 | R | 4 |
| +36, 37 +38, 39 | 0x2E09 | Not used | 0 | 0 | UINT32 | R | 4 |
| +40, 41 +42, 43 | 0x2E0A | Not used | 0 | 0 | UINT32 | R | 4 |
| 36608-36671 | | Programmable Min/Max Minimum Values | | | | | |
| +0, 1 +2, 3 | 0x3000 | Min. Min/Max Register #1 Timestamp | | | UINT32 UINT32 | R R | |
| +4, 5 | 0x3001 | Min. Min/Max Register #2 | | | UINT32 | R | |

| Address | Point ID | Description | Options/Range/Format ³ | Units ³ | Type | R/W | Notes |
|--------------------|----------|--|-----------------------------------|--------------------|------------------|--------|------------------|
| +6, 7 | | Timestamp | | | UINT32 | R | |
| | | ... | | | | | |
| +60, 61 +62, 63 | 0x300F | Min. Min/Max Register #16 Timestamp | | | UINT32 UINT32 | R R | |
| 36736-36755 | | Maximum Analog Inputs | | | | | |
| +0, 1 +2, 3 | 0x3680 | Max. analog input AI1 Timestamp | AI1min-AI1max | | INT32 UINT32 | R R | |
| +4, 5 +6, 7 | 0x3681 | Max. analog input AI2 Timestamp | AI2min-AI2max | | INT32 UINT32 | R R | |
| | | ... | | | | | |
| +16, 17 +18, 19 | 0x3684 | Max. analog input AI5 Timestamp | AI5min-AI5max | | INT32 UINT32 | R R | |
| 36864-37007 | | Maximum Phase Values | | | | | |
| +0, 1 +2, 3 | 0x3400 | Max. V1 voltage Timestamp | 0-Vmax | U1 sec | UINT32 UINT32 | R R | 1, DC-applicable |
| +4, 5 +6, 7 | 0x3401 | Max. V2 voltage Timestamp | 0-Vmax | U1 sec | UINT32 UINT32 | R R | 1, DC-applicable |
| +8, 9 +10, 11 | 0x3402 | Max. V3 voltage Timestamp | 0-Vmax | U1 sec | UINT32 UINT32 | R R | 1, DC-applicable |
| +12, 13 +14, 15 | 0x3403 | Max. I1 current Timestamp | 0-Imax | U2 sec | UINT32 UINT32 | R R | DC-applicable |
| +16, 17 +18, 19 | 0x3404 | Max. I2 current Timestamp | 0-Imax | U2 sec | UINT32 UINT32 | R R | DC-applicable |
| +20, 21 +22, 23 | 0x3405 | Max. I3 current Timestamp | 0-Imax | U2 sec | UINT32 UINT32 | R R | DC-applicable |
| +24, 25 +26, 27 | 0x3406 | Max. kW L1 Timestamp | -Pmax-Pmax | U3 sec | INT32 INT32 | R R | DC-applicable |
| +28, 29 +30, 31 | 0x3407 | Max. kW L2 Timestamp | -Pmax-Pmax | U3 sec | INT32 INT32 | R R | DC-applicable |
| +32, 33 +34, 35 | 0x3408 | Max. kW L3 Timestamp | -Pmax-Pmax | U3 sec | INT32 INT32 | R R | DC-applicable |

| Address | Point ID | Description | Options/Range/Format ³ | Units ³ | Type | R/W | Notes |
|--------------------|----------|-----------------------------------|-----------------------------------|--------------------|------------------|--------|----------------|
| +36, 37 +38, 39 | 0x3409 | Max. kvar L1 Timestamp | -Pmax-Pmax | U3 sec | INT32 INT32 | R R | |
| +40, 41 +42, 43 | 0x340A | Max. kvar L2 Timestamp | -Pmax-Pmax | U3 sec | INT32 INT32 | R R | |
| +44, 45 +46, 47 | 0x340B | Max. kvar L3 Timestamp | -Pmax-Pmax | U3 sec | INT32 INT32 | R R | |
| +48, 49 +50, 51 | 0x340C | Max. kVA L1 Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| +52, 53 +54, 55 | 0x340D | Max. kVA L2 Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| +56, 57 +58, 59 | 0x340E | Max. kVA L3 Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| +60, 61 +62, 63 | 0x340F | Max. Power factor L1 Timestamp | 0-1000 | ×0.001 sec | UINT32 UINT32 | R R | Absolute value |
| +64, 65 +66, 67 | 0x3410 | Max. Power factor L2 Timestamp | 0-1000 | ×0.001 sec | UINT32 UINT32 | R R | Absolute value |
| +68, 69 +70, 71 | 0x3411 | Max. Power factor L3 Timestamp | 0-1000 | ×0.001 sec | UINT32 UINT32 | R R | Absolute value |
| +72, 73 +74, 75 | 0x3412 | Max. V1 voltage THD Timestamp | 0-9999 | ×0.1% sec | UINT32 UINT32 | R R | 2, 4 |
| +76, 77 +78, 79 | 0x3413 | Max. V2 voltage THD Timestamp | 0-9999 | ×0.1% sec | UINT32 UINT32 | R R | 2, 4 |
| +80, 81 +82, 83 | 0x3414 | Max. V3 voltage THD Timestamp | 0-9999 | ×0.1% sec | UINT32 UINT32 | R R | 2, 4 |
| +84, 85 +86, 87 | 0x3415 | Max. I1 current THD Timestamp | 0-9999 | ×0.1% sec | UINT32 UINT32 | R R | 4 |
| +88, 89 +90, 91 | 0x3416 | Max. I2 current THD Timestamp | 0-9999 | ×0.1% sec | UINT32 UINT32 | R R | 4 |
| +92, 93 +94, 95 | 0x3417 | Max. I3 current THD Timestamp | 0-9999 | ×0.1% sec | UINT32 UINT32 | R R | 4 |

| Address | Point ID | Description | Options/Range/Format ³ | Units ³ | Type | R/W | Notes |
|------------------------|----------|----------------------------------|-----------------------------------|--------------------|------------------|--------|---------------|
| +96, 97 +98, 99 | 0x3418 | Max. I1 K-Factor Timestamp | 10-9999 | ×0.1 sec | UINT32 UINT32 | R R | 4 |
| +100, 101 +102, 103 | 0x3419 | Max. I2 K-Factor Timestamp | 10-9999 | ×0.1 sec | UINT32 UINT32 | R R | 4 |
| +104, 105 +106, 107 | 0x341A | Max. I3 K-Factor Timestamp | 10-9999 | ×0.1 sec | UINT32 UINT32 | R R | 4 |
| +108, 109 +110, 111 | 0x341B | Max. I1 current TDD Timestamp | 0-1000 | ×0.1% sec | UINT32 UINT32 | R R | 4 |
| +112, 113 +114, 115 | 0x341C | Max. I2 current TDD Timestamp | 0-1000 | ×0.1% sec | UINT32 UINT32 | R R | 4 |
| +116, 117 +118, 119 | 0x341D | Max. I3 current TDD Timestamp | 0-1000 | ×0.1% sec | UINT32 UINT32 | R R | 4 |
| +120, 121 +122, 123 | 0x341E | Max. V12 voltage Timestamp | 0-Vmax | U1 sec | UINT32 UINT32 | R R | |
| +124, 125 +126, 127 | 0x341F | Max. V23 voltage Timestamp | 0-Vmax | U1 sec | UINT32 UINT32 | R R | |
| +128, 129 +130, 131 | 0x3420 | Max. V31 voltage Timestamp | 0-Vmax | U1 sec | UINT32 UINT32 | R R | |
| +132, 133 +134, 135 | 0x3421 | Not used | 0 | 0 | UINT32 | R | |
| +136, 137 +138, 139 | 0x3422 | Not used | 0 | 0 | UINT32 | R | |
| +140, 141 +142, 143 | 0x3423 | Not used | 0 | 0 | UINT32 | R | |
| 37120-37143 | | Maximum Total Values | | | | | |
| +0, 1 +2, 3 | 0x3500 | Max. Total kW Timestamp | -Pmax-Pmax | U3 sec | INT32 UINT32 | R R | DC-applicable |
| +4, 5 +6, 7 | 0x3501 | Max. Total kvar Timestamp | -Pmax-Pmax | U3 sec | INT32 UINT32 | R R | |
| +8, 9 +10, 11 | 0x3502 | Max. Total kVA Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |

| Address | Point ID | Description | Options/Range/Format ³ | Units ³ | Type | R/W | Notes |
|------------------------|----------|---|-----------------------------------|--------------------|------------------|--------|-----------------------------|
| +12, 13 +14, 15 | 0x3503 | Max. Total PF Timestamp | -1000-1000 | ×0.001 sec | INT32 UINT32 | R R | |
| +16, 17 +18, 19 | 0x3504 | Max. Total PF lag Timestamp | 0-1000 | ×0.001 sec | UINT32 UINT32 | R R | |
| +20, 21 +22, 23 | 0x3505 | Max. Total PF lead Timestamp | 0-1000 | ×0.001 sec | UINT32 UINT32 | R R | |
| 37248-37375 | | Maximum Analog Input Demands | | | | | |
| +0, 1 +2, 3 | 0x3900 | Max. analog input demand AI1+ Timestamp | AI1min-AI1max | | UINT32 UINT32 | R R | Positive AI readings demand |
| +4, 5 +6, 7 | 0x3901 | Max. analog input demand AI2+ Timestamp | AI2min-AI2max | | UINT32 UINT32 | R R | |
| | | ... | | | | | |
| +60, 61 +62, 63 | 0x390F | Max. analog input demand AI16+ Timestamp | AI16min-AI16max | | UINT32 UINT32 | R R | |
| +64, 65 +66, 67 | 0x3910 | Max. analog input demand AI1- Timestamp | AI1min-AI1max | | UINT32 UINT32 | R R | Negative AI readings demand |
| +68, 69 +70, 71 | 0x3911 | Max. analog input demand AI2- Timestamp | AI2min-AI2max | | UINT32 UINT32 | R R | |
| | | ... | | | | | |
| +124, 125 +126, 127 | 0x391F | Max. analog input demand AI16- Timestamp | AI16min-AI16max | | UINT32 UINT32 | R R | |
| 37376-37419 | | Maximum Auxiliary Values | | | | | |
| +0, 1 +2, 3 | 0x3600 | Max. I4 current Timestamp | 0-I _{max} | U2 sec | UINT32 UINT32 | R R | DC-applicable |
| +4, 5 +6, 7 | 0x3601 | Max. In current Timestamp | 0-I _{max} | U2 sec | UINT32 UINT32 | R R | |
| +8, 9 +10, 11 | 0x3602 | Max. Frequency Timestamp | 0-10000 | ×0.01Hz sec | UINT32 UINT32 | R R | |
| +12, 13 +14, 15 | 0x3603 | Max. Voltage unbalance Timestamp | 0-3000 | ×0.1% sec | UINT32 UINT32 | R R | |

| Address | Point ID | Description | Options/Range/Format ³ | Units ³ | Type | R/W | Notes |
|--------------------|----------|--|-----------------------------------|--------------------|------------------|--------|------------------|
| +16, 17 +18, 19 | 0x3604 | Max. Current unbalance Timestamp | 0-3000 | ×0.1% sec | UINT32 UINT32 | R R | |
| +20, 21 +22, 23 | 0x3605 | Not used | | | UINT32 UINT32 | R R | |
| +24, 25 +26, 27 | 0x3606 | Not used | 0 | 0 | UINT32 | R | |
| +28, 29 +30, 31 | 0x3607 | Not used | 0 | 0 | UINT32 | R | |
| +32, 33 +34, 35 | 0x3608 | Not used | 0 | 0 | UINT32 | R | 4 |
| +36, 37 +38, 39 | 0x3609 | Not used | 0 | 0 | UINT32 | R | 4 |
| +40, 41 +42, 43 | 0x360A | Not used | 0 | 0 | UINT32 | R | 4 |
| 37504-37567 | | Billing Summary Maximum Demands | | | | | |
| +0, 1 +2, 3 | 0x4780 | Summary register #1 Maximum Demand Timestamp | 0-Pmax | U3 | UINT32 | R | |
| +4, 5 +6, 7 | 0x4781 | Summary register #2 Maximum Demand Timestamp | 0-Pmax | U3 | UINT32 | R | |
| | | ... | | | | | |
| +60, 61 +62, 63 | 0x4783 | Summary register #16 Maximum Demand Timestamp | 0-Pmax | U3 | UINT32 | R | |
| 37632-37719 | | Maximum Demands | | | | | |
| +0, 1 +2, 3 | 0x3700 | V1 Maximum volt demand Timestamp | 0-Vmax | U1 sec | UINT32 UINT32 | R R | 2, DC-applicable |
| +4, 5 +6, 7 | 0x3701 | V2 Maximum volt demand Timestamp | 0-Vmax | U1 sec | UINT32 UINT32 | R R | 2, DC-applicable |
| +8, 9 +10, 11 | 0x3702 | V3 Maximum volt demand Timestamp | 0-Vmax | U1 sec | UINT32 UINT32 | R R | 2, DC-applicable |
| +12, 13 +14, 15 | 0x3703 | I1 Maximum ampere demand Timestamp | 0-Imax | U2 sec | UINT32 UINT32 | R R | DC-applicable |

| Address | Point ID | Description | Options/Range/Format ³ | Units ³ | Type | R/W | Notes |
|--------------------|----------|--|-----------------------------------|--------------------|------------------|--------|---------------|
| +16, 17 +18, 19 | 0x3704 | I2 Maximum ampere demand Timestamp | 0-lmax | U2 sec | UINT32 UINT32 | R R | DC-applicable |
| +20, 21 +22, 23 | 0x3705 | I3 Maximum ampere demand Timestamp | 0-lmax | U2 sec | UINT32 UINT32 | R R | DC-applicable |
| +24, 25 +26, 27 | 0x3706 | Not used Timestamp | 0 | | UINT32 UINT32 | R R | |
| +28, 29 +30, 31 | 0x3707 | Not used Timestamp | 0 | | UINT32 UINT32 | R R | |
| +32, 33 +34, 35 | 0x3708 | Not used Timestamp | 0 | | UINT32 UINT32 | R R | |
| +36, 37 +38, 39 | 0x3709 | Maximum kW import sliding window demand Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | DC-applicable |
| +40, 41 +42, 43 | 0x370A | Maximum kvar import sliding window demand Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| +44, 45 +46, 47 | 0x370B | Maximum kVA sliding window demand Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| +48, 49 +50, 51 | 0x3737 | Not used Timestamp | 0 | | UINT32 UINT32 | R R | |
| +52, 53 +54, 55 | 0x370D | Not used Timestamp | 0 | | UINT32 UINT32 | R R | |
| +56, 57 +58, 59 | 0x370E | Not used Timestamp | 0 | | UINT32 UINT32 | R R | |
| +60, 61 +62, 63 | 0x370F | Maximum kW export sliding window demand Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | DC-applicable |
| +64, 65 +66, 67 | 0x3710 | Maximum kvar export sliding window demand Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| +68, 69 +70, 71 | 0x3737 | Not used Timestamp | 0 | | UINT32 UINT32 | R R | |
| +72, 73 +74, 75 | 0x3712 | Not used Timestamp | 0 | | UINT32 UINT32 | R R | |
| +76, 77 | 0x3713 | Not used | 0 | 0 | UINT32 | R | |

| Address | Point ID | Description | Options/Range/Format ³ | Units ³ | Type | R/W | Notes |
|--------------------|----------|--|-----------------------------------|--------------------|------------------|--------|---------------|
| +78, 79 | | | | | | | |
| +80, 81 +82, 83 | 0x3714 | I4 Maximum ampere demand Timestamp | 0-I4max | U2 sec | UINT32 UINT32 | R R | DC-applicable |
| +84, 85 +86, 87 | 0x3715 | In Maximum ampere demand Timestamp | 0-Imax | U2 sec | UINT32 UINT32 | R R | |
| 37888-37951 | | Programmable Min/Max Maximum Values | | | | | |
| +0, 1 +2, 3 | 0x3800 | Max. Min/Max Register #1 Timestamp | | | UINT32 UINT32 | R R | |
| +4, 5 +6, 7 | 0x3801 | Max. Min/Max Register #2 Timestamp | | | UINT32 UINT32 | R R | |
| | | ... | | | | | |
| +60, 61 +62, 63 | 0x380F | Max. Min/Max Register #16 Timestamp | | | UINT32 UINT32 | R R | |
| 38016-38063 | | Maximum Harmonic Demands | | | | | |
| +0, 1 +2, 3 | 0x3880 | V1 THD demand Timestamp | 0-9999 | ×0.1% sec | UINT32 UINT32 | R R | 2 |
| +4, 5 +6, 7 | 0x3881 | V2 THD demand Timestamp | 0-9999 | ×0.1% sec | UINT32 UINT32 | R R | 2 |
| +8, 9 +10, 11 | 0x3882 | V3 THD demand Timestamp | 0-9999 | ×0.1% sec | UINT32 UINT32 | R R | 2 |
| +12, 13 +14, 15 | 0x3883 | Not used | 0 | 0 | UINT32 | R | |
| +16, 17 +18, 19 | 0x3884 | I1 THD demand Timestamp | 0-9999 | ×0.1% sec | UINT32 UINT32 | R R | |
| +20, 21 +22, 23 | 0x3885 | I2 THD demand Timestamp | 0-9999 | ×0.1% sec | UINT32 UINT32 | R R | |
| +24, 25 +26, 27 | 0x3886 | I3 THD demand Timestamp | 0-9999 | ×0.1% sec | UINT32 UINT32 | R R | |
| +28, 29 +30, 31 | 0x3887 | I4 THD demand Timestamp | 0-9999 | ×0.1% sec | UINT32 UINT32 | R R | |

| Address | Point ID | Description | Options/Range/Format ³ | Units ³ | Type | R/W | Notes |
|--------------------|----------|---|-----------------------------------|--------------------|------------------|--------|-------|
| +32, 33 +34, 35 | 0x3888 | I1 TDD demand Timestamp | 0-1000 | ×0.1% sec | UINT32 UINT32 | R R | |
| +36, 37 +38, 39 | 0x3889 | I2 TDD demand Timestamp | 0-1000 | ×0.1% sec | UINT32 UINT32 | R R | |
| +40, 41 +42, 43 | 0x388A | I3 TDD demand Timestamp | 0-1000 | ×0.1% sec | UINT32 UINT32 | R R | |
| +44, 45 +46, 47 | 0x388B | I4 TDD demand Timestamp | 0-1000 | ×0.1% sec | UINT32 UINT32 | R R | |
| 38144-38207 | | Billing TOU Maximum Demand Register #1 | | | | | |
| +0, 1 +2, 3 | 0x4800 | Tariff #1 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| +4, 5 +6, 7 | 0x4801 | Tariff #2 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| | | ... | | | | R | |
| +60, 61 +62, 63 | 0x480F | Tariff #16 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| 38400-38463 | | Billing TOU Maximum Demand Register #2 | | | | | |
| +0, 1 +2, 3 | 0x4900 | Tariff #1 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| +4, 5 +6, 7 | 0x4901 | Tariff #2 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| | | ... | | | | R | |
| +60, 61 +62, 63 | 0x490F | Tariff #16 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| 38656-38719 | | Billing TOU Maximum Demand Register #3 | | | | | |
| +0, 1 +2, 3 | 0x4A00 | Tariff #1 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| +4, 5 +6, 7 | 0x4A01 | Tariff #2 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| | | ... | | | | R | |

| Address | Point ID | Description | Options/Range/Format ³ | Units ³ | Type | R/W | Notes |
|--------------------|----------|---|-----------------------------------|--------------------|------------------|--------|-------|
| +60, 61 +62, 63 | 0x4A0F | Tariff #16 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| 38272-38335 | | Billing TOU Maximum Demand Register #4 | | | | | |
| +0, 1 +2, 3 | 0x4880 | Tariff #1 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| +4, 5 +6, 7 | 0x4881 | Tariff #2 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| | | ... | | | | R | |
| +60, 61 +62, 63 | 0x488F | Tariff #16 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| 38528-38591 | | Billing TOU Maximum Demand Register #5 | | | | | |
| +0, 1 +2, 3 | 0x4980 | Tariff #1 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| +4, 5 +6, 7 | 0x4981 | Tariff #2 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| | | ... | | | | R | |
| +60, 61 +62, 63 | 0x498F | Tariff #16 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| 38784-38847 | | Billing TOU Maximum Demand Register #6 | | | | | |
| +0, 1 +2, 3 | 0x4A80 | Tariff #1 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| +4, 5 +6, 7 | 0x4A81 | Tariff #2 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| | | ... | | | | R | |
| +60, 61 +62, 63 | 0x4A8F | Tariff #16 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| 38912-38975 | | Billing TOU Maximum Demand Register #7 | | | | | |
| +0, 1 +2, 3 | 0x5300 | Tariff #1 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| +4, 5 +6, 7 | 0x5301 | Tariff #2 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |

| Address | Point ID | Description | Options/Range/Format ³ | Units ³ | Type | R/W | Notes |
|--------------------|----------|--|-----------------------------------|--------------------|------------------|--------|-------|
| | | ... | | | | R | |
| +60, 61 +62, 63 | 0x530F | Tariff #16 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| 39040-39103 | | Billing TOU Maximum Demand Register #8 | | | | | |
| +0, 1 +2, 3 | 0x5380 | Tariff #1 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| +4, 5 +6, 7 | 0x5381 | Tariff #2 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| | | ... | | | | R | |
| +60, 61 +62, 63 | 0x538F | Tariff #16 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| 39168-39231 | | Billing TOU Maximum Demand Register #9 | | | | | |
| +0, 1 +2, 3 | 0x5400 | Tariff #1 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| +4, 5 +6, 7 | 0x5401 | Tariff #2 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| | | ... | | | | R | |
| +60, 61 +62, 63 | 0x540F | Tariff #16 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| 39296-39359 | | Billing TOU Maximum Demand Register #10 | | | | | |
| +0, 1 +2, 3 | 0x5480 | Tariff #1 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| +4, 5 +6, 7 | 0x5481 | Tariff #2 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| | | ... | | | | R | |
| +60, 61 +62, 63 | 0x548F | Tariff #16 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| 39424-39487 | | Billing TOU Maximum Demand Register #11 | | | | | |
| +0, 1 +2, 3 | 0x5500 | Tariff #1 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| +4, 5 | 0x5501 | Tariff #2 register | 0-Pmax | U3 | UINT32 | R | |

| Address | Point ID | Description | Options/Range/Format ³ | Units ³ | Type | R/W | Notes |
|--------------------|----------|--|-----------------------------------|--------------------|------------------|--------|-------|
| +6, 7 | | Timestamp | | sec | UINT32 | R | |
| | | ... | | | | R | |
| +60, 61 +62, 63 | 0x550F | Tariff #16 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| 39552-39615 | | Billing TOU Maximum Demand Register #12 | | | | | |
| +0, 1 +2, 3 | 0x5580 | Tariff #1 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| +4, 5 +6, 7 | 0x5581 | Tariff #2 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| | | ... | | | | R | |
| +60, 61 +62, 63 | 0x558F | Tariff #16 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| 39680-39743 | | Billing TOU Maximum Demand Register #13 | | | | | |
| +0, 1 +2, 3 | 0x5600 | Tariff #1 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| +4, 5 +6, 7 | 0x5601 | Tariff #2 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| | | ... | | | | R | |
| +60, 61 +62, 63 | 0x560F | Tariff #16 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| 39808-39871 | | Billing TOU Maximum Demand Register #14 | | | | | |
| +0, 1 +2, 3 | 0x5680 | Tariff #1 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| +4, 5 +6, 7 | 0x5681 | Tariff #2 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| | | ... | | | | R | |
| +60, 61 +62, 63 | 0x568F | Tariff #16 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| 39936-39999 | | Billing TOU Maximum Demand Register #15 | | | | | |
| +0, 1 +2, 3 | 0x5700 | Tariff #1 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |

| Address | Point ID | Description | Options/Range/Format ³ | Units ³ | Type | R/W | Notes |
|--------------------|----------|--|-----------------------------------|--------------------|------------------|--------|-------|
| +4, 5 +6, 7 | 0x5701 | Tariff #2 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| | | ... | | | | R | |
| +60, 61 +62, 63 | 0x570F | Tariff #16 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| 40064-40127 | | Billing TOU Maximum Demand Register #16 | | | | | |
| +0, 1 +2, 3 | 0x5780 | Tariff #1 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| +4, 5 +6, 7 | 0x5781 | Tariff #2 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |
| | | ... | | | | R | |
| +60, 61 +62, 63 | 0x578F | Tariff #16 register Timestamp | 0-Pmax | U3 sec | UINT32 UINT32 | R R | |

NOTES:

¹When the 4LN3, 4LL3, 3LN3, 3LL3, 3BLN3 or 3BLL3 wiring mode is selected, the voltages will be line-to-neutral; for any other wiring mode, they will be line-to-line.

²When the 4LN3, 3LN3 or 3BLN3 wiring mode is selected, the voltages will be line-to-neutral; for any other wiring mode, they will be line-to-line voltages.

³For volts, amps, power and frequency scales and units, refer to Section 4 "Data Scales and Units".

⁴On a 0.2-s (10/12-cycle) interval (16-cycle GOST 13109 interval).

3.6 Device Control and Status Registers

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|--|----------|---|--|-------|--------|-----|---|
| Event Flags Registers (bitmap) | | | | | | | |
| 44032-44033 | | Event flags 1-32 set register (0 = no effect, 1 = set) | 0x00000000 – 0xFFFFFFFF | | UINT32 | W | Read as 0 |
| 44034-44035 | | Event flags 1-32 clear register (0=clear, 1 = no effect) | 0x00000000 – 0xFFFFFFFF | | UINT32 | W | Read as 0 |
| 44036-44037 | | Event flags 1-32 status (0 = cleared, 1 = set) | 0x00000000 – 0xFFFFFFFF | | UINT32 | R | |
| 44238-44241 | | Event flags 1-64 set register (0 = no effect, 1 = set) | 0x00000000 – 0xFFFFFFFF 0x00000000 – 0xFFFFFFFF | | UINT64 | W | Read as 0 |
| 44242-44245 | | Reserved | | | UINT32 | | Read as 0 |
| 44246-44249 | | Event flags 1-64 clear register (0=clear, 1 = no effect) | 0x00000000 – 0xFFFFFFFF 0x00000000 – 0xFFFFFFFF | | UINT64 | W | Read as 0 |
| 44250-44253 | | Reserved | | | UINT32 | | Read as 0 |
| 44254-44257 | | Event flags 1-64 status (0 = cleared, 1 = set) | 0x00000000 – 0xFFFFFFFF 0x00000000 – 0xFFFFFFFF | | UINT64 | R | |
| 44258-44261 | | Reserved | | | UINT32 | | Read as 0 |
| Remote Relay Control Registers (bitmap) | | | | | | | |
| 44038-44045 | | Reserved | | | UINT32 | | |
| 44046-44049 | | Force relay operate register: 0 = no effect, 1 = operate | 0x00000000 – 0xFFFFFFFF 0x00000000 – 0xFFFFFFFF | | UINT64 | W | Read as 0 |
| 44050-44053 | | Force relay release register: 0 = no effect, 1 = release | 0x00000000 – 0xFFFFFFFF 0x00000000 – 0xFFFFFFFF | | UINT64 | W | Read as 0 |
| 44054-44057 | | Locally latched relays status: 0 = unlatched, 1 = locally latched | 0x00000000 – 0xFFFFFFFF 0x00000000 – 0xFFFFFFFF | | UINT64 | R | |
| 44058-44061 | | Remote latched relays status: 0 = unlatched, 1 = remote latched | 0x00000000 – 0xFFFFFFFF 0x00000000 – 0xFFFFFFFF | | UINT64 | R | |
| 44062-44065 | | Direct relay control disable status: 0 = direct control enabled, 1 = direct control disabled | 0x00000000 – 0xFFFFFFFF 0x00000000 – 0xFFFFFFFF | | UINT64 | R | Direct relay control is disabled if a relay is under local automation control |
| 44066-44069 | | Relay status: 0 = open, 1 = closed | 0x00000000 – 0xFFFFFFFF 0x00000000 – 0xFFFFFFFF | | UINT64 | R | |
| 44070-44073 | | Latch relays mode: 0 = unlatched mode, 1 = latched mode | 0x00000000 – 0xFFFFFFFF 0x00000000 – 0xFFFFFFFF | | UINT64 | R | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|--------------------------------------|----------|---|---|-------|--------|-----|--|
| 44074-44077 | | Pulse relays mode: 0 = not pulse mode, 1 = pulse mode | 0x00000000 – 0xFFFFFFFF 0x00000000 – 0xFFFFFFFF | | UINT32 | R | |
| 44078-44081 | | KYZ relays mode: 0 = not KYZ mode, 1 = KYZ mode | 0x00000000 – 0xFFFFFFFF 0x00000000 – 0xFFFFFFFF | | UINT64 | R | |
| 44082-44085 | | Relay polarity mode: 0 = normal mode, 1 = inverting mode | 0x00000000 – 0xFFFFFFFF 0x00000000 – 0xFFFFFFFF | | UINT64 | R | |
| 44086-44089 | | Relay blocking mode: 0 = normal mode, 1 = blocked mode | 0x00000000 – 0xFFFFFFFF 0x00000000 – 0xFFFFFFFF | | UINT64 | R | |
| 44090-44093 | | Blocked relay status: 0 = relay unblocked, 1 = relay blocked | 0x00000000 – 0xFFFFFFFF 0x00000000 – 0xFFFFFFFF | | UINT64 | R | Relay control commands are ignored if a relay is blocked |
| 44094-44101 | | Reserved | | | UINT32 | | |
| Reset/Clear Registers | | | | | | | |
| 44102 | | Clear energies | 0 | | UINT16 | W | |
| 44103 | | Clear maximum demands | 0= clear all maximum demands 1= clear power demands 2= clear volt and ampere demands 3= clear volt demands 2 = clear ampere demands 5 = clear harmonic demands | | UINT16 | W | |
| 44104 | | Clear Billing/TOU energy registers | 0 | | UINT16 | W | |
| 44105 | | Clear Billing/TOU maximum demands | 0 | | UINT16 | W | |
| 44106 | | Clear counters | 0 = clear all counters, 1-32 = clear counter #1-32 | | UINT16 | W | |
| 44107 | | Clear Min/Max log | 0 | | UINT16 | W | |
| 44108 | | Not used | 0 | | UINT16 | W | |
| 44109-44133 | | Reserved | | | UINT16 | | |
| Device Mode Control Registers | | | | | | | |
| 44135 | | Controller/setpoints operation | 0 = disabled, 1 = enabled | | UINT16 | | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|--|----------|---|--|-------|--------|-----|-------|
| 44136 | | PQ recorder | 0 = disabled, 1 = enabled | | UINT16 | | |
| 44137 | | Not used | 0 | | UINT16 | | |
| 44138-44165 | | Reserved | | | UINT16 | | |
| Operation/Event Counters | | | | | | | |
| 44198-44199 | | Not used | 0 | 0 | UINT32 | R | |
| 44200-44201 | | Not used | 0 | 0 | UINT32 | R | |
| 44202-44203 | | Not used | 0 | 0 | UINT32 | R | |
| 44204-44205 | | Not used | 0 | 0 | UINT32 | R | |
| 44206-44207 | | Not used | | | UINT32 | R | |
| 44208-44209 | | Not used | | | UINT32 | R | |
| 44210-44211 | | Not used | 0 | 0 | UINT32 | R | |
| 44212-44213 | | Not used | 0 | 0 | UINT32 | R | |
| 44214-44215 | | Not used | 0 | 0 | UINT32 | R | |
| 44216-44261 | | Reserved | | | UINT32 | R | |
| UDP Cross-trigger Register | | | | | | | |
| 44166 | | Appendix A External trigger index | 0-15 | | UINT16 | W | |
| 44167 | | Appendix B Reserved | | | UINT16 | | |
| 44168-44237 | | Appendix C Reserved | | | UINT16 | | |
| Memory Status Registers | | | | | | | |
| 44262-44263 | | Memory size, bytes | | | UINT32 | R | |
| 44264-44265 | | Free memory, bytes | | | UINT32 | R | |
| 44266-44277 | | Reserved | | | UINT32 | R | |
| Log Notification Registers (bitmap) | | | | | | | |
| 44278-44279 | | Files 0-31 (0 = no new logs, 1 = new record logged) | 0x00000000 – 0xFFFFFFFF | | UINT32 | R | |
| 44280-44293 | | Reserved | | | UINT32 | R | |
| Setpoint Status Registers (bitmap) | | | | | | | |
| 44294-44297 | | Setpoints 1-64 status (0 = released, 1 = operated) | 0x00000000 – 0xFFFFFFFF 0x00000000 – 0xFFFFFFFF | | UINT64 | R | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|--|----------|--|--|-------|--------|-----|--------------------|
| 44298-44309 | | Reserved | | | UINT32 | R | |
| Setpoint Alarm Latch Registers (bitmap) | | | | | | | |
| 44310-44313 | | Setpoints 1-64 alarm status. When read: 0 = no setpoint operations logged, 1 = setpoint has been operated at least once since the last alarm bit reset. When written: 0 = clear setpoint alarm bit, 1 = no effect. | 0x00000000 – 0xFFFFFFFF 0x00000000 – 0xFFFFFFFF | | UINT64 | R/W | |
| 44314-44325 | | Reserved | | | | | |
| Device Diagnostics Register (bitmap) | | | | | | | |
| 44326-44327 | | Device self-diagnostics flags. When read: 0 = no faults logged, 1 = a fault bit has been set at least once since the last reset. When written: 0 = clear a fault bit, 1 = no effect. | F23 | | UINT32 | R/W | |
| 44328-44339 | | Reserved | | | | | |
| GOOSE Subscriber Status Register (bitmap) | | | | | | | |
| 44340-44341 | | Not used | 0 | | UINT32 | R | Bitmap |
| Port Identification | | | | | | | |
| 44342 | | Connection port number | 0-2 = serial port COM1- COM3, 3 = COM4 IR port, 4 = COM5 modem port, 6 = USB/Modbus port, 7-11 = Ethernet/TCP port | | UINT16 | R | |
| 44343 | | Serial port interface (COM1-COM5) | 0 = RS-232, 1 = RS-422, 2 = RS-485, 3 = infrared, 4 = dialup modem, 8 = GSM/GPRS/CDMA2000 | | UINT16 | R | |
| 44344-44345 | | Reserved | | | | | |
| Network Identification | | | | | | | |
| 44346-44373 | | | | | | | |
| +0,1 | | Ethernet network IP Address | | | UINT32 | R | Network byte order |
| +2,3 | | Ethernet network subnet mask | | | UINT32 | R | Network byte order |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|--------------------------------------|----------|---|---|-------|--------|-----|--------------------|
| +4,5 | | Ethernet network default gateway | | | UINT32 | R | Network byte order |
| +6,7 | | Not used | | | UINT32 | R | |
| +8,9 | | Not used | | | UINT32 | R | |
| +10,11 | | GPRS network IP Address | | | UINT32 | R | Network byte order |
| +12,13 | | GPRS network subnet mask | N/A | | UINT32 | R | Network byte order |
| +14,15 | | GPRS network default gateway | N/A | | UINT32 | R | Network byte order |
| +16 | | Not used | | | UINT32 | R | |
| +17 | | Cellular network type | 0 = 3GPP network (GSM, UMTS, LTE) 1 = 3GPP2 network (CDMA2000) | | UINT32 | R | |
| +18-21 | | Cellular module's mobile equipment identifier: IMEI for 3GPP networks MEID for 3GPP2 networks | IMEI (15 decimal digits): +18,19 – 8 lower digits in binary, +20,21 – 7 higher digits in binary; MEID (14 hex digits): +18,19 – 8 lower digits, +20,21 – 6 higher digits | | UINT32 | R | |
| +22,23 | | Ethernet 2 network IP address | | | UINT32 | R | Network byte order |
| +24,25 | | Ethernet 2 network subnet mask | | | UINT32 | R | Network byte order |
| +26,27 | | Ethernet 2 network default gateway | | | UINT32 | R | Network byte order |
| 44374-44377 | | Reserved | | | | | |
| Device Authorization Register | | | | | | | |
| 44378-44379 | | When write: 8-digit password. When read: 0 = access permitted, -1 = authorization required. | 0 – 99999999 (write) 0/-1 (read) | | INT32 | R/W | |
| 44380-44385 | | Reserved | | | | | |
| Communication Status | | | | | | | |
| 44394 | | RSSI (received signal strength) | 2= not known or not detectable, 51-113 = -51 to -113 dBm | | UINT16 | R | |
| 44395 | | GPRS status | 0 = not connected, | | UINT16 | R | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|-------------------------------|----------|--|---|-------|--------|-----|-------------|
| | | | 1 = not registered, 2 = registered | | | | |
| 44396 | | RSTP Status | Bit 0: RSTP Running Status bits 1-3: Network1 STP Status bits 4-6: Network1 STP Role bits 7-9: Network2 STP Status bits 10-12: Network2 STP Role bits 13-15: Future Use RSTP Port State: 0 = Disabled 1 = Broken 2 = Blocking 3 = Listening 4 = Learning 5 = Forwarding RSTP Port Role: 0 = Disabled 1 = Root 2 = Designated 3 = Alternate 4 = Backup else = Unknown | | UINT16 | R | |
| 44397-44409 | | Reserved | | | UINT16 | R | 65535 = N/A |
| Communication Counters | | | | | | | |
| 44410 | | Successful eXpertPower client connections | 0-65534 | | UINT16 | R | |
| 44411 | | Failed eXpertPower client connections | 0-65534 | | UINT16 | R | |
| 44412 | | Successful TCP notification client connections | 0-65534 | | UINT16 | R | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|--|----------|--|---------------|-------|--------|-----|-------------|
| 44413 | | Failed TCP notification client connections | 0-65534 | | UINT16 | R | |
| 44414-44441 | | Reserved | | | UINT16 | R | 65535 = N/A |
| Switch Remote Control Registers | | | | | | | |
| 44458-44459 | | Not used | 0 | | UINT32 | W | Read as 0 |
| 44460-44461 | | Not used | 0 | | UINT32 | W | Read as 0 |
| 44462-44463 | | Not used | 0 | | UINT32 | W | Read as 0 |
| 44464-44465 | | Not used | 0 | | UINT32 | W | Read as 0 |
| 44466-44481 | | Not used | 0 | | | | |
| +0 | | Not used | 0 | | UINT16 | R/W | |
| +1 | | Not used | 0 | | UINT16 | R/W | |
| +2 | | Not used | 0 | | UINT16 | R/W | |
| ... | | Not used | 0 | | | | |
| +15 | | Not used | 0 | | UINT16 | R/W | |
| +16-47 | | Reserved | | | | | |
| Switch Status Registers | | | | | | | |
| 44514-44515 | | Not used | 0 | | UINT32 | R | |
| 44516-44517 | | Not used | 0 | | UINT32 | R | |
| 44518-44519 | | Not used | 0 | | UINT32 | R | |
| 44520-44521 | | Not used | 0 | | UINT32 | R | |
| 44522-44523 | | Not used | 0 | | UINT32 | R | |
| 44524-44525 | | Not used | 0 | | UINT32 | R | |
| 44526-44541 | | Not used | 0 | | UINT16 | R | |
| +0 | | Not used | 0 | | UINT16 | R | |
| +1 | | Not used | 0 | | UINT16 | R | |
| +2 | | Not used | 0 | | UINT16 | R | |
| ... | | Not used | 0 | | | | |
| +15 | | Not used | 0 | | UINT16 | R | |
| Factory Diagnostic Registers | | | | | | | |
| 45952-46079 | | Factory diagnostic registers | | | UINT32 | R | |

3.7 Device Setup Register

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|--------------------------------|----------|---|-------------------|-------|--------|-----|------------------------|
| Device Identification | | | | | | | |
| 46080-46111 | | | | | | | |
| +0,1 | | Device serial number | 1-999999 | | UINT32 | R | |
| +2,3 | | Device model ID | 13550 | | UINT32 | R | |
| +4-11 | | Device model name | "EM235/PM335 PRO" | | CHAR16 | R | Null-terminated string |
| +12-13 | | Device options (bitmap) | F38 | | UINT32 | R | |
| +14-15 | | Not used | 0 | 0 | UINT32 | R | |
| +16-17 | | Not used | | | UINT16 | R | |
| +18 | | (0-3) 4bits: CPU board hardware revision (4-7) 4bits: CPU version X, Y, Z, V (8-15) 8bits: LCD ID | | | UINT16 | R | |
| +19 | | (0-3) 4bits: For future use (4) 1bit: "0" – IO does NOT exist, "1" – IO exists (5) 1bit: "0" – Eth. does NOT exist, "1" – Eth. exists (6) 1bit: "0" (7) 1bit "0" – AA (Anti-Aliasing filter) does NOT exist, "1" – AA exists (8-11) 4bits: Analog board hardware revision (12-15) 4bits: CT Type | | | UINT16 | R | |
| +20 | | Device firmware version number | 3101-3199 | | UINT16 | R | |
| +21 | | Device firmware build number | 1-99 | | UINT16 | R | |
| +22 | | Not used | 0 | | UINT16 | R | |
| +23 | | Not used | 0 | | UINT16 | R | |
| +24 | | Boot loader version number | | | UINT16 | R | |
| +25 | | Boot loader build number | | | UINT16 | R | |
| +26-31 | | Reserved | | | UINT16 | R | |
| Factory Device Settings | | | | | | | |
| 46112-46207 | | | | | | | |
| +0 | | V1-V3 input range | 690 | V | UINT16 | R | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|--------------------|----------|---------------------------------------|-----------------------|-------|--------|-----|-------|
| +1 | | V1-V3 input overload | 120 | % | UINT16 | R | |
| +2 | | Not used | 0 | 0 | UINT16 | R | |
| +3 | | Not used | 0 | 0 | UINT16 | R | |
| +4 | | I1-I3 input range | 1, 5 | A | UINT16 | R | |
| +5 | | I1-I3 input overload | 200 (ANSI), 200 (IEC) | % | UINT16 | R | |
| +6 | | I4 input range | 1, 5 | A | UINT16 | R | |
| +7 | | I4 input overload | 200 (ANSI), 200 (IEC) | % | UINT16 | R | |
| +8-13 | | Not used | 0 | 0 | UINT16 | R | |
| +115-4 | | Device production date and time | F1 | | UINT32 | R | |
| +12-63 | | Reserved | | | UINT16 | R | |
| +64 | | Ethernet MAC address 0-1 | 0x0500 | | UINT16 | R | |
| +65 | | Ethernet MAC address 2-3 | 0x00F0 | | UINT16 | R | |
| +66 | | Ethernet MAC address 4-5 | 0x0000-0xFFFF | | UINT16 | R | |
| +67 | | Ethernet MAC2 address 0-1 | 0x0500 | | UINT16 | R | |
| +68 | | Ethernet MAC2 address 2-3 | 0x00F0 | | UINT16 | R | |
| +69 | | Ethernet MAC2 address 4-5 | 0x0000-0xFFFF | | UINT16 | R | |
| +70-95 | | Reserved | | | UINT16 | R | |
| Basic Setup | | | | | | | |
| 46208-46239 | | | | | | | |
| +0 | | Wiring mode | F26 | | UINT16 | R/W | |
| +1 | | PT ratio (primary to secondary ratio) | 10-65000 | ×0.1 | UINT16 | R/W | |
| +2 | | PT secondary (Line-to-Line) | 500-7000 | ×0.1 | UINT16 | R/W | |
| +3 | | Not used | 0 | 0 | UINT16 | R/W | |
| +4 | | Not used | 0 | 0 | UINT16 | R/W | |
| +5 | | CT primary current | 1-30000 | A | UINT16 | R/W | |
| +6 | | CT secondary current | | | UINT16 | R/W | |
| +7 | | I4 CT primary current | 1-30000 | A | UINT16 | R/W | |
| +8 | | I4 CT secondary current | | | UINT16 | R/W | |
| +9-16 | | Reserved | | | UINT16 | R/W | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|-----------------------------|----------|--|--|-------|--------|-----|--|
| +17 | | Nominal line frequency | 50, 60 | Hz | UINT16 | R/W | |
| +18 | | Phase order | 0 = ABC, 1 = CBA | | UINT16 | R/W | |
| +19-23 | | Reserved | | | UINT16 | R/W | |
| +24 | | I maximum demand load current | 0-30000 | A | UINT16 | R/W | |
| +25 | | I4 maximum demand load current | 0-30000 | A | UINT16 | R/W | |
| +26-31 | | Reserved | | | UINT16 | R/W | |
| Demands Setup | | | | | | | |
| 46240-46255 | | | | | | | |
| +0 | | Power demand period (block interval) | 1, 2, 3, 5, 10, 15, 30, 60 | min | UINT16 | R/W | |
| +1 | | Number of demand periods in a sliding window | 1-15 | | UINT16 | R/W | |
| +2 | | Demand synchronization source input | 0 = device clock, 1-96 = DI1-DI96 | | UINT16 | R/W | A DI input is considered a pulse or KYZ input. The pulse edge restarts the power demand accumulation interval. |
| +3-7 | | Reserved | | | UINT16 | R/W | |
| +8 | | Volt demand period | 0-9000 | sec | UINT16 | R/W | |
| +9 | | Ampere demand period | 0-9000 | sec | UINT16 | R/W | |
| +10 | | Harmonic demand period | 0-9000 | sec | UINT16 | R/W | |
| +11-15 | | Reserved | | | UINT16 | R/W | |
| Device Options Setup | | | | | | | |
| 46256-46399 | | | | | | | |
| +0 | | Power calculation mode | 0 = using reactive power: $S = f(P,Q)$, 1 = using non-active power: $Q = f(S,P)$ | | UINT16 | R/W | |
| +1 | | Energy roll value | 0 = 1×10^4 , 1 = 1×10^5 , 2 = 1×10^6 , 3 = 1×10^7 , 4 = 1×10^8 , 5 = 1×10^9 | | UINT16 | R/W | |
| +2 | | Number of energy decimal places | 0-3 | | UINT16 | R/W | Default 0 |
| +3 | | Reserved | | | UINT16 | R/W | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|------------------------|----------|---|--|-------|--------|-----|---|
| +4 | | Tariff control | 0 = via a calendar scheduler, 0x4000 = via communications, 0x0100-0x010F = via tariff inputs DI1-DI16 (bits 0:3 denote the first digital input index used) | | UINT16 | R/W | |
| +5 | | Number of tariffs | 1-16 (does not have effect with a calendar tariff control option) | | UINT16 | R/W | When read with a calendar tariff control option, indicates the actual number of tariffs selected in TOU profiles |
| +6 | | Not used | 0 | | UINT16 | R/W | |
| +7 | | Energy LED test mode | 0=disabled, 1=Wh test, 2=varh test | | UINT16 | R/W | |
| +8 | | Test energy LED pulse rate, Wh/varh per pulse (in secondary units) | 1-40 | ×0.01 | UINT16 | R/W | |
| +9-11 | | Reserved | | | UINT16 | R/W | |
| +12 | | I1 direction (polarity) | 0 = Normal, 1 = Inverse | | UINT16 | R/W | |
| +13 | | I2 direction (polarity) | 0 = Normal, 1 = Inverse | | UINT16 | R/W | |
| +14 | | I3 direction (polarity) | 0 = Normal, 1 = Inverse | | UINT16 | R/W | |
| +15 | | Not used | 0 | | UINT16 | R/W | |
| +16 | | Interval energy period, min | 5, 10, 15, 20, 30 | | UINT16 | R/W | |
| +15-143 | | Reserved | | | UINT16 | R/W | |
| Time/Date Setup | | | | | | | |
| 46400-46415 | | | | | | | |
| +0 | | Local time offset, min | 0+/-720 | | INT16 | R/W | Offset in minutes from UTC (Universal Coordinated or Greenwich Mean time) |
| +1 | | Daylight savings time (DST) option | 0=DST disabled (standard time only), 1=DST enabled (fixed switching dates), 2= scheduled DST period (calendar defined switching dates) | | UINT16 | R/W | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|-------------------------------|----------|---|--|-------|--------|-----|---|
| +2 | | DST start month | 1-12 | | UINT16 | R/W | |
| +3 | | DST start week of the month | 1-4 = 1st, 2nd, 3rd and 4th week, 5=the last week of the month | | UINT16 | R/W | |
| +4 | | DST start weekday | 1-7 (1=Sun, 7=Sat) | | UINT16 | R/W | |
| +5 | | DST end month | 1-12 | | UINT16 | R/W | |
| +6 | | DST end week of the month | 1-4 = 1st, 2nd, 3 rd and 4th week, 5=last week of the month | | UINT16 | R/W | |
| +7 | | DST end weekday | 1-7 (1=Sun, 7=Sat) | | UINT16 | R/W | |
| +8 | | Clock synchronization source | 0 = GPS IRIG-B master clock, 0x0001-0x0080 = DI1-DI26 1PPM, 0x1001-0x1080 = DI1- DI26 1PPS, 0x7ffe = SNTP, 0x7fff = none | | UINT16 | R/W | A DI input is considered a pulse or KYZ input. The pulse edge aligns the clock at the nearest whole minute. |
| +9 | | Country code | ITU country calling code | | UINT16 | R/W | |
| +10 | | DST start hour | 1-6 | | UINT16 | R/W | |
| +11 | | DST end hour | 1-6 | | UINT16 | R/W | |
| +12 | | Date order | 0=MM/DD/YY 1=DD/MM/YY 2=YY/MM/DD | | UINT16 | R/W | |
| +13-15 | | Reserved | | | UINT16 | R/W | |
| Clock Setup and Status | | | | | | | |
| 46416-46447 | | | | | | | |
| +0,1 | | Local time, in seconds, since Jan 1, 1970 | F1 | sec | UINT32 | R/W | |
| +2,3 | | Fractional seconds, µsec | | µsec | UINT32 | R/W | |
| +4 | | Fractional seconds, milliseconds | 0-999 | | UINT16 | R/W | |
| +5 | | Seconds | 0-59 | | UINT16 | R/W | |
| +6 | | Minutes | 0-59 | | UINT16 | R/W | |
| +7 | | Hour | 0-23 | | UINT16 | R/W | |
| +8 | | Day of month | 1-31 | | UINT16 | R/W | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|----------------------------------|----------|---------------------------------|--|-------|--------|-----|-------|
| +9 | | Month | 1-12 | | UINT16 | R/W | |
| +10 | | Year (calendar year minus 2000) | 0-99 | | UINT16 | R/W | |
| +11 | | Weekday | 1-7 (1=Sun, 7=Sat) | | UINT16 | R | |
| +12 | | Daylight savings time status | 0 = standard time, 1 = daylight savings time is active | | UINT16 | R | |
| +13 | | IRIG-B status | 0, 1 = no signal, 2 = time unlocked, 3 = time locked | | UINT16 | R | |
| +14-31 | | Reserved | | | UINT16 | | |
| Communication Ports Setup | | | | | | | |
| 46448-46575 | | | | | | | |
| +0 | | Communication protocol | 0 = Modbus RTU, 1 = Modbus ASCII, 2 = DNP3.0, 7=IEC 60870-5 | | UINT16 | R/W | |
| +1 | | Interface | 0 = RS-232, 1 = RS-422, 2 = RS-485, 3 = infrared, 4 = dialup modem, 8 = GSM/GPRS/CDMA2000 | | UINT16 | R/W | |
| +2 | | Device address | Modbus: 1-247 DNP3.0: 0–65532 IEC 60870-5: 1-254 (1 octet), 1-65532 (2 octets) | | UINT16 | R/W | |
| +3 | | Baud rate | 1 = 300 bps, 2 = 600 bps, 3 = 1200 bps, 4 = 2400 bps, 5 = 4800 bps, 6 = 9600 bps, 7 = 19200 bps, 8 = 38400 bps, 9 = 57600 bps, 10 = 115200 bps | | UINT16 | R/W | |
| +4 | | Data format | 0 = 7 bits/even parity, 1 = 8 bits/no parity, 2 = 8 bits/even parity | | UINT16 | R/W | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|------------------------|----------|--|---|-------|--------|-----|------------------------------------|
| +5 | | CTS mode | 0 = not used, 1 = wait for CTS before sending data | | UINT16 | R/W | N/A for COM2-COM5 (read as 65535) |
| +6 | | RTS mode | 0 = not used, 1 = RTS is asserted during the transmission | | UINT16 | R/W | N/A for COM2-COM5 (read as 65535) |
| +7 | | Minimum delay before sending data | 0-1000 (default = 5) | ms | UINT16 | R/W | |
| +8 | | Inter-character timeout | 1-1000 (default = 4) | ms | UINT16 | R/W | Added to standard 4-character time |
| +9 | | Port direction | 0 = slave (default), 1 = master | | UINT16 | R/W | |
| +10 | | Receive timeout (for a master port only) | 500-30000 | ms | UINT16 | R/W | |
| +11-15 | | Reserved | | | | | |
| 46448-46463 | | COM1 Setup | | | | | |
| 46464-46479 | | COM2 Setup | | | | | Only 8 bits/no parity data format |
| 46480-46495 | | COM3 Setup | | | | | |
| 46496-46511 | | COM4 Setup | | | | | |
| 46512-46527 | | COM5 Setup | | | | | |
| 46528-46575 | | Reserved | | | | | |
| Network 1 Setup | | | | | | | |
| 46576-46607 | | | | | | | |
| +0,1 | | Device IP Address | 0x01000000-0xFFFFFFFF | | UINT32 | R/W | Network byte order |
| +2,3 | | Network subnet mask | 0x00000001-0xFFFFFFFF | | UINT32 | R/W | Network byte order |
| +4,5 | | Network default gateway | 0x00000000-0xFFFFFFFF | | UINT32 | R/W | Network byte order |
| +6,7 | | Not used | 0 | | UINT32 | R/W | |
| +8-31 | | Reserved | | | | R/W | |
| Network 2 Setup | | | | | | | |
| 46608-46639 | | | | | | | |
| +0,1 | | Device IP Address | 0x01000000-0xFFFFFFFF | | UINT32 | R/W | Network byte order |
| +2,3 | | Network subnet mask | 0x00000001-0xFFFFFFFF | | UINT32 | R/W | Network byte order |
| +4,5 | | Network default gateway | 0x00000000-0xFFFFFFFF | | UINT32 | R/W | Network byte order |
| +6-13 | | Reserved | | | | R/W | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|---------------------------------|----------|---------------------------------|------------------------|-------|--------|-----|------------------------|
| +14,15 | | Connection idle timeout | 30-300 s | | UINT32 | R/W | |
| +16-31 | | Reserved | | | | R/W | |
| Dial-up/GPRS Modem Setup | | | | | | | |
| 46640-46671 | | | | | | | |
| +0,1 | | Device IP Address | 0x01000000-0xFFFFFFFF | | UINT32 | R/W | |
| +2,3 | | Network subnet mask | 0x00000001-0xFFFFFFFF | | UINT32 | R/W | |
| +4,5 | | Network default gateway | 0x00000000-0xFFFFFFFF | | UINT32 | R/W | |
| +6,7 | | Number of dial attempts | 0-1000, 0=dial forever | | UINT32 | R/W | |
| +8,9 | | Connection timeout, sec | 0-9999 | | UINT32 | R/W | |
| +10,11 | | Delay between redials, sec | 0-9999 | | UINT32 | R/W | |
| +12,13 | | Idle connection timeout, sec | 0-9999, 0 = never | | UINT32 | R/W | |
| +14,15 | | Number of rings before answer | 0-20, 0 = never answer | | UINT32 | R/W | |
| +16-23 | | Modem init string | "AT&F&D1&C1" | | CHAR16 | R/W | Null-terminated string |
| +24,25 | | Auto-reset period, hours | 1-24, 0 = never | | UINT32 | R/W | |
| +26-31 | | Reserved | | | | | |
| Password Setup | | | | | | | |
| 46704-46715 | | | | | | | |
| +0,1 | | Password 1 (Low level) | 0-99999999 | | UINT32 | R/W | Read as 0 |
| +2,3 | | Password protection (always ON) | 1 = enabled | | UINT16 | R/W | |
| +4,5 | | Password 2 (Medium level) | 0-99999999 | | UINT32 | R/W | |
| +6,7 | | Password 3 (High level) | 0-99999999 | | UINT32 | R/W | |
| +8,9 | | Not used | | | UINT32 | R/W | |
| +10,11 | | Front panel security | Not used | | UINT32 | R/W | |
| 46716-46761 | | Reserved | | | | | |
| IEC 61850 License Setup | | | | | | | |
| 46762-46767 | | | | | | | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|--|----------|--------------------------------------|---|----------|--------|-----|------------------------------|
| +0,1 | | License code, first word | | Not used | UINT32 | R/W | |
| +2,3 | | License code, second word | | Not used | UINT32 | R/W | |
| +4,5 | | Current license type | 0=no valid license 1-31=temporary license, remaining time in days -1=permanent license -3=temporary license has expired | Not used | UINT32 | R | |
| Expert Power Service Setup | | | | | | | |
| 46768-46783 | | | | | | | |
| +0,1 | | Expert Power server IP Address | 0x01000000-0xFFFFFFFF | | UINT32 | R/W | Default = 207.232.60.18 |
| +2,3 | | Expert Power server TCP service port | 0-65535 | | UINT32 | R/W | Default = 5001 |
| +4,5 | | Expert Power client enabled | 0=client disabled, 1=client enabled | | UINT32 | R/W | |
| +6,7 | | Time to next session | 1-99999 | min | UINT32 | R/W | |
| +8,9 | | Time to next session | 1-99999 | min | UINT32 | R | Same as previous |
| +10,11 | | Connection network | 0 = Ethernet, 1=GPRS | | UINT32 | R/W | |
| +12-15 | | Reserved | | | | | |
| Internet Service Provider (ISP) account | | | | | | | |
| 46784-46879 | | | | | | | |
| +0-15 | | Dial string (telephone number) | **99***1# | | CHAR32 | R/W | GPRS network call by default |
| +16-31 | | Login name | | | CHAR32 | R/W | |
| +32-47 | | Login password | | | CHAR32 | R/W | |
| +48-63 | | Access Point Name (APN) | | | CHAR32 | R/W | |
| +64-95 | | Reserved | | | | | |
| SNTP Client Setup | | | | | | | |
| 46880-46895 | | | | | | | |
| +0,1 | | SNTP client enabled | 0=disabled, 1=enabled | | UINT32 | R/W | |
| +2,3 | | Polling interval | 60-86400 | s | UINT32 | R/W | Default = 600 s |
| +4-7 | | Reserved | 0 | | UINT32 | R/W | |
| +8,9 | | Primary SNTP server IP address | 0x01000000-0xFFFFFFFF | | UINT32 | R/W | Default = 192.36.143.151 |
| +10,11 | | Secondary SNTP server IP address | 0x01000000-0xFFFFFFFF | | UINT32 | R/W | Default = 130.149.17.21 |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|--------------------------------------|----------|----------------------------------|---------------------------|--------|--------|-----|-------|
| +12-15 | | Reserved | | | | | |
| TCP Notification Client Setup | | | | | | | |
| 46896-46991 | | | | | | | |
| +0,1 | | Client enabled | 0=disabled, 1=enabled | | UINT32 | R/W | |
| +2,3 | | Server address | 0x01000000-0xFFFFFFFF | | UINT32 | R/W | |
| +4,5 | | Server port | 0-65535 | | UINT32 | R/W | |
| +6,7 | | Message exchange address | 0-65535 | | UINT32 | R/W | |
| +8,9 | | Connection network | 0 = Ethernet, 1=GPRS | | UINT32 | R/W | |
| +10-15 | | Reserved | | | | | |
| Transformer Correction Setup | | | | | | | |
| 47072-47119 | | | | | | | |
| +0 | | Ratio correction factor | 900-1100 | ×0.001 | UINT16 | R/W | |
| +1 | | Phase angle error | -6000 to 6000 | min | INT16 | R/W | |
| +2,3 | | Reserved | | | INT16 | R/W | |
| 47072-47075 | | V1 transformer correction | | | | | |
| 47076-47079 | | V2 transformer correction | | | | | |
| 47080-47083 | | V3 transformer correction | | | | | |
| 47084-47087 | | V4 transformer correction | | | | | |
| 47088-47091 | | I1 transformer correction | | | | | |
| 47092-47095 | | I2 transformer correction | | | | | |
| 47096-47099 | | I3 transformer correction | | | | | |
| 47100-47103 | | I4 transformer correction | | | | | |
| 47104-47107 | | Not used | 0 | | | | |
| 47108-47111 | | Not used | 0 | | | | |
| 47112-47115 | | Not used | 0 | | | | |
| 47116-47119 | | Not used | 0 | | | | |
| RSTP Setup | | | | | | | |
| 48696- 48725 | | | | | | | |
| +0 | | RSTP Enabled | 0 = Disabled, 1 = Enabled | | UINT16 | R/W | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|-------------------------------|----------|------------------------------|---------------------------|--------|--------|-----|---|
| +1 | | RSTP Bridge Priority | 0–61440, in steps of 4096 | | UINT16 | R/W | Default = 32768 |
| +2 | | RSTP Hello Time | 1-10 | Second | UINT16 | R/W | Default = 2 |
| +3 | | RSTP Forward Delay | 4-30 | Second | UINT16 | R/W | Default = 15 |
| +4 | | RSTP TX Hold Count | 1-10 | BPDU | UINT16 | R/W | Default = 6 |
| +5-9 | | Reserved | | | UINT16 | R/W | |
| +10,11 | | RSTP Network1 Port Path Cost | 0-240, in steps of 16 | | UINT32 | R/W | Default = 128 |
| +12 | | RSTP Network1 Port Priority | 1-200,000,000 | | UINT16 | R/W | Default = 200,000 (for 100Mb/s Ethernet connection) |
| +13,19 | | Reserved | | | UINT16 | R/W | |
| +20,21 | | RSTP Network2 Port Path Cost | 0-240, in steps of 16 | | UINT32 | R/W | Default = 128 |
| +22 | | RSTP Network2 Port Priority | 1-200,000,000 | | UINT16 | R/W | Default = 200,000 (for 100Mb/s Ethernet connection) |
| +23,29 | | Reserved | | | UINT16 | R/W | |
| GOOSE Subscriber Setup | | | | | | | |
| 48726-48833 | | | | | | | |
| +0 | | Not used | 0 | | UINT16 | R/W | |
| +1 | | Not used | 0 | | UINT16 | R/W | |
| +2 | | Not used | 0 | | UINT16 | R/W | |
| +3-35 | | Not used | 0 | | CHAR66 | R/W | |
| +36,37 | | Not used | 0 | | UINT32 | R/W | |
| +38-40 | | Not used | 0 | | CHAR6 | R/W | |
| +41 | | Not used | 0 | | UINT16 | R/W | |
| +42-43 | | Not used | 0 | | UINT16 | R/W | |
| | | Data Set Entry #1 | | | | | |
| +44 | | Not used | 0 | | UINT16 | R/W | |
| +45 | | Not used | 0 | | UINT16 | R/W | |
| +46 | | Not used | 0 | | UINT16 | R/W | |
| +47 | | Not used | 0 | | UINT16 | R/W | |
| +48-51 | | Not used | 0 | | | | |
| ... | | ... | | | | | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|------------------------------|----------|---------------------------|---------------|-------|--------|-----|-------|
| +104-107 | | Data Set Entry #16 | | | | | |
| +108-171 | | Reserved | | | UINT16 | R/W | |
| 48898-49045 | | Reserved | | | | | |
| GOOSE Publisher Setup | | | | | | | |
| 49046-49145 | | | | | | | |
| +0 | | Not used | 0 | | UINT16 | R/W | |
| +1 | | Not used | 0 | | UINT16 | R/W | |
| +2-34 | | Not used | 0 | | CHAR66 | R | |
| +35 | | Not used | 0 | | UINT16 | R/W | |
| +36-51 | | Not used | 0 | | CHAR34 | R | |
| +53-85 | | Not used | 0 | | CHAR66 | R | |
| +86-87 | | Not used | 0 | | UINT32 | R/W | |
| +88 | | Not used | 0 | | UINT16 | R | |
| +89-91 | | Not used | 0 | | CHAR6 | R/W | |
| +92 | | Not used | 0 | | UINT16 | R | |
| +93 | | Not used | 0 | | UINT16 | R | |
| +94 | | Not used | 0 | | UINT16 | R/W | |
| +95 | | Not used | 0 | ms | UINT16 | R/W | |
| +96-99 | | Not used | 0 | | | | |
| IEC 61850 IED Setup | | | | | | | |
| 49146-49209 | | | | | | | |
| +0-11 | | Not used | 0 | | CHAR24 | R/W | |
| +12-19 | | Not used | 0 | | CHAR16 | R/W | |
| +20 | | Not used | 0 | | UINT16 | R/W | |
| +21 | | Not used | 0 | | UINT16 | R/W | |
| +22 | | Not used | 0 | | UINT16 | R/W | |
| +23 | | Not used | 0 | | UINT16 | R/W | |
| +24 | | Not used | 0 | | UINT16 | R/W | |
| +25-30 | | Not used | 0 | | CHAR32 | R/W | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|--------------------------------|----------|---------------------------------------|---------------|-------|--------|-----|-------|
| +31-63 | | Not used | 0 | | UINT16 | R/W | |
| IEC 61850 Dataset Setup | | | | | | | |
| 49210-49278 | | | | | | | |
| +0 | | Not used | 0 | | UINT16 | R/W | |
| +1 | | Not used | 0 | | UINT16 | R/W | |
| +2-34 | | Not used | 0 | | CHAR66 | R/W | |
| +35 | | Not used | 0 | | UINT16 | R/W | |
| +36-68 | | Not used | 0 | | CHAR66 | R/W | |
| IEC 61850 RCB Setup | | | | | | | |
| 49280-49351 | | | | | | | |
| | | Command registers | | | | | |
| +0 | | Not used | 0 | | UINT16 | W | |
| +1 | | Not used | 0 | | UINT16 | W | |
| | | RCB registers (read/write) | | | UINT16 | R/W | |
| +0 | | Not used | 0 | | UINT16 | R/W | |
| +1 | | Not used | 0 | | UINT16 | R/W | |
| +2-18 | | Not used | 0 | | CHAR34 | R/W | |
| +19 | | Not used | 0 | | UINT16 | R/W | |
| +20-52 | | Not used | 0 | | CHAR66 | R/W | |
| +53 | | Not used | 0 | | UINT16 | R/W | |
| +54,55 | | Not used | 0 | | UINT32 | R/W | |
| +56,57 | | Not used | 0 | | UINT32 | R/W | |
| +58,59 | | Not used | 0 | | UINT32 | R/W | |
| +60 | | Not used | 0 | | UINT16 | R/W | |
| +61 | | Not used | 0 | | UINT16 | R/W | |
| +62,63 | | Not used | 0 | | UINT32 | R/W | |
| +64 | | Not used | 0 | | UINT16 | R/W | |
| +65-71 | | Not used | 0 | | CHAR14 | R/W | |
| | | Dataset references list (read) | | | | | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|-----------------------------------|----------|---|--------------------------|---------|--------|-----|-------|
| +19 | | Not used | 0 | | UINT16 | R | |
| +20-52 | | Not used | 0 | | CHAR66 | R | |
| IEC 61850 Report Deadbands | | | | | | | |
| 49396-49444 | | | | | | | |
| +0 | | Not used | 0 | ×0.001% | UINT16 | R/W | |
| ... | | Not used | 0 | ×0.001% | UINT16 | R/W | |
| +48 | | Not used | 0 | ×0.001% | UINT16 | R/W | |
| 49445-49459 | | Reserved | | | | | |
| IEC 60870-5 Options Setup | | | | | | | |
| 49460-49494 | | Ethernet Interface #1 Setup | | | | | |
| 59318-59352 | | Ethernet Interface #2 Setup | | | | | |
| +0 | | Maximum length of variable frame, octets | 32-255 | | UINT16 | R/W | |
| +1 | | Link address length, octets | 1-2 | | UINT16 | R/W | |
| +2 | | Cause of transmission length, octets | 1-2 | | UINT16 | R/W | |
| +3 | | Length of common address of ASDU, octets | 1-2 | | UINT16 | R/W | |
| +4 | | Length of information object address, octets | 1-3 | | UINT16 | R/W | |
| +5 | | Select-before-operate timeout, s | 0-30 | | UINT16 | R/W | |
| +6 | | Short pulse duration, ms | 100-3000 | ms | UINT16 | R/W | |
| +7 | | Long pulse duration, ms | 100-3000 | ms | UINT16 | R/W | |
| +8,9 | | Time synchronization period, s | 1-86400, 0=not active | s | UINT32 | R/W | |
| +10 | | Local counter freeze period, min | 1-60, 0=not active | min | UINT16 | R/W | |
| +11 | | Cyclic data transmission period, ms | 100-30000, 0=not active | ms | UINT16 | R/W | |
| +12,13 | | Redundant connection IP address #1 | 0-0xFFFFFE, 0=not active | | UINT32 | R/W | |
| +14,15 | | Redundant connection IP address #2 | 0-0xFFFFFE, 0=not active | | UINT32 | R/W | |
| +16,17 | | Not used | 0 | | UINT32 | R/W | |
| +18 | | Not used | 0 | | UINT16 | R/W | |
| +19 | | Respond with class 1 data to class 2 requests | 0=disabled, 1=enabled | | UINT16 | R/W | |
| +20 | | Single point start mapped address | 1-4095 | | UINT16 | R/W | |
| +21 | | Single point default static object type | F30 | | UINT16 | R/W | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|--|----------|--|---|-------|--------|-----|-------|
| +22 | | Single point default event object type | F31 | | UINT16 | R/W | |
| +23 | | Double point start mapped address | 1-4095 | | UINT16 | R/W | |
| +24 | | Double point default static object type | F32 | | UINT16 | R/W | |
| +25 | | Double point default event object type | F33 | | UINT16 | R/W | |
| +26 | | Measured value start mapped address | 1-4095 | | UINT16 | R/W | |
| +27 | | Measured value default static object type | F34 | | UINT16 | R/W | |
| +28 | | Measured value default event object type | F35 | | UINT16 | R/W | |
| +29 | | Integrated totals start mapped address | 1-4095 | | UINT16 | R/W | |
| +30 | | Integrated totals default static object type | F36 | | UINT16 | R/W | |
| +31 | | Integrated totals default event object type | F37 | | UINT16 | R/W | |
| +32 | | Voltage units | 0=V, 1=kV | | UINT16 | R/W | |
| +33 | | Current units | 0=A, 1=kA | | UINT16 | R/W | |
| +34 | | Power units | 0=kW, 1=MW | | UINT16 | R/W | |
| IEC 60870-5 Class 2 Data and Counters Setup | | | | | | | |
| 49524-49619 | | Ethernet Interface #1 Setup | | | | | |
| 59382-59477 | | Ethernet Interface #2 Setup | | | | | |
| +0 | | Information object type and flags | Bits 0:7 – static object type identification (F30, F32, F34, F36), Bit 8=1 – freeze with reset, Bit 9=1 – local freeze, Bit 10=1 – cyclic data transmission, Bit 11=1 – general interrogation, Bits 12:15 – interrogation group = 0-15 (0=no group assigned) | | | | |
| +1 | | Start information object address | 1-65535 | | UINT16 | R/W | |
| +2 | | Number of elements in the range | 1-128 | | UINT16 | R/W | |
| 49524-49526 | | Object address range #1 | | | | | |
| 49527-49529 | | Object address range #2 | | | | | |
| ... | | ... | | | | | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|--|----------|--------------------------------------|---|-------|--------|-----|-------|
| 49617-46619 | | Object address range #32 | | | | | |
| IEC 60870-5 Assignable Point Map and Events Setup | | | | | | | |
| 49716-49971 | | Ethernet Interface #1 Setup | | | | | |
| 59574-59829 | | Ethernet Interface #2 Setup | | | | | |
| +0 | | Point ID | See Section 3.4 | | UINT16 | R/W | |
| +1 | | Information object type and flags | Bits 0:7 – static object type identification (F3, F5, F7), Bits 8:9 – relation (0=delta, 1= more than, 2 = less than) Bit 10=1 – class 1 assignment | | UINT16 | R/W | |
| +2,3 | | Deadband/threshold | See Section 3.4 for the point range and resolution | | INT32 | R/W | |
| 49716-49719 | | Mapped static/event point #1 | | | | | |
| 49720-49723 | | Mapped static/event point #2 | | | | | |
| ... | | ... | | | | | |
| 49968-49971 | | Mapped static/event point #64 | | | | | |
| EN 50160:2007 PQ Recorder Triggers Setup | | | | | | | |
| 50134-50453 | | | | | | | |
| +0 | | Not used | 0 | | UINT16 | R/W | |
| +1 | | Not used | 0 | | UINT16 | R/W | |
| +2 | | Not used | 0 | | UINT16 | R/W | |
| +3 | | Not used | 0 | | UINT16 | R/W | |
| +4 | | Not used | 0 | | UINT16 | R/W | |
| +5 | | Not used | 0 | | UINT16 | R/W | |
| +6 | | Not used | 0 | | UINT16 | R/W | |
| +7 | | Not used | 0 | | UINT16 | R/W | |
| +8 | | Not used | 0 | | UINT16 | R/W | |
| +9 | | Not used | 0 | | UINT16 | R/W | |
| +10 | | Not used | 0 | | UINT16 | R/W | |
| +11 | | Not used | 0 | | UINT16 | R/W | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|-------------------------------------|----------|---------------------------------------|---------------|-------|--------|-----|-------|
| +12-15 | | Not used | 0 | | UINT16 | R/W | |
| 50134-50149 | | Not used | 0 | | | | |
| 50150-50165 | | Not used | 0 | | | | |
| 50166-50181 | | Not used | 0 | | | | |
| 50182-50197 | | Not used | 0 | | | | |
| 50198-50213 | | Not used | 0 | | | | |
| 50214-50229 | | Not used | 0 | | | | |
| 50230-50245 | | Not used | 0 | | | | |
| 50246-50261 | | Not used | 0 | | | | |
| 50262-50277 | | Not used | 0 | | | | |
| 50278-50293 | | Not used | 0 | | | | |
| 50294-50309 | | Not used | 0 | | | | |
| 50310-50325 | | Not used | 0 | | | | |
| 50326-50341 | | Not used | 0 | | | | |
| 50342-50357 | | Not used | 0 | | | | |
| 50358-50453 | | Reserved | | | | | |
| EN 50160:2007 Advanced Setup | | | | | | | |
| 50838-50865 | | | | | | | |
| | | EN 50160 Compliance Statistics | | | | | |
| +0 | | Not used | 0 | | UINT16 | R/W | |
| +1 | | Not used | 0 | | UINT16 | R/W | |
| +2 | | Not used | 0 | | UINT16 | R/W | |
| +3 | | Reserved | 0 | | UINT16 | R/W | |
| | | EN 50160 Harmonics Survey | | | | | |
| +4 | | Not used | 0 | | UINT16 | R/W | |
| +5 | | Not used | 0 | | UINT16 | R/W | |
| +6-7 | | Reserved | 0 | | UINT16 | R/W | |
| | | Rapid Voltage Changes | | | | | |
| +8 | | Not used | 0 | | UINT16 | R/W | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|--|----------|--------------------------------|---------------|-------|--------|-----|-------|
| +9 | | Reserved | 0 | | UINT16 | R/W | |
| | | Flicker | | | | | |
| +10 | | Not used | 0 | | UINT16 | R/W | |
| +11 | | Reserved | 0 | | UINT16 | R/W | |
| | | Harmonic Voltage | | | | | |
| +12 | | Not used | 0 | | UINT16 | R/W | |
| +13 | | Not used | 0 | | UINT16 | R/W | |
| +14-15 | | Reserved | 0 | | UINT16 | R/W | |
| | | Interharmonic Voltage | | | | | |
| +16 | | Not used | 0 | | UINT16 | R/W | |
| +17 | | Not used | 0 | | UINT16 | R/W | |
| +18 | | Not used | 0 | | UINT16 | R/W | |
| +19 | | Reserved | 0 | | UINT16 | R/W | |
| | | Mains Signaling Voltage | | | | | |
| +20 | | Not used | 0 | | UINT16 | R/W | |
| +21 | | Not used | 0 | | UINT16 | R/W | |
| +22 | | Not used | 0 | | UINT16 | R/W | |
| +23 | | Not used | 0 | | UINT16 | R/W | |
| +24 | | Not used | 0 | | UINT16 | R/W | |
| | | Transient Overvoltage | | | | | |
| +25 | | Not used | 0 | | UINT16 | R/W | |
| +26-27 | | Not used | 0 | | UINT16 | R/W | |
| 50866-50901 | | Reserved | 0 | | UINT16 | R/W | |
| EN 50160:2010 PQ Recorder Setup | | | | | | | |
| 50134-50453 | | | | | | | |
| +0 | | Not used | 0 | | INT16 | R/W | |
| +1 | | Not used | 0 | | UINT16 | R/W | |
| +2 | | Not used | 0 | | UINT16 | R/W | |
| +3 | | Not used | 0 | | UINT16 | R/W | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|-------------------------------------|----------|------------------------------|---------------|-------|--------|-----|-------|
| +4 | | Not used | 0 | | UINT16 | R/W | |
| +5 | | Not used | 0 | | UINT16 | R/W | |
| +6 | | Not used | 0 | | UINT16 | R/W | |
| +7 | | Not used | 0 | | UINT16 | R/W | |
| +8 | | Not used | 0 | | UINT16 | R/W | |
| +9 | | Not used | 0 | | UINT16 | R/W | |
| +10 | | Not used | 0 | | UINT16 | R/W | |
| +11 | | Not used | 0 | | UINT16 | R/W | |
| +12 | | Not used | 0 | | INT16 | R/W | |
| +13 | | Not used | 0 | | INT16 | R/W | |
| +14 | | Not used | 0 | | INT16 | R/W | |
| +15 | | Not used | 0 | | UINT16 | R/W | |
| 50134-50149 | | Not used | 0 | | | | |
| 50150-50165 | | Not used | 0 | | | | |
| 50166-50181 | | Not used | 0 | | | | |
| 50182-50197 | | Not used | 0 | | | | |
| 50198-50213 | | Not used | 0 | | | | |
| 50214-50229 | | Not used | 0 | | | | |
| 50230-50245 | | Not used | 0 | | | | |
| 50246-50261 | | Not used | 0 | | | | |
| 50262-50277 | | Not used | 0 | | | | |
| 50278-50293 | | Not used | 0 | | | | |
| 50294-50309 | | Not used | 0 | | | | |
| 50310-50325 | | Not used | 0 | | | | |
| 50326-50341 | | Not used | 0 | | | | |
| 50342-50453 | | Reserved | | | | | |
| EN 50160:2010 Advanced Setup | | | | | | | |
| 50838-50879 | | | | | | | |
| | | Compliance Statistics | | | | | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|---------|----------|--------------------------------|---------------|-------|--------|-----|-------|
| +0 | | Not used | 0 | | UINT16 | R/W | |
| +1 | | Not used | 0 | | UINT16 | R/W | |
| +2 | | Not used | 0 | | UINT16 | R/W | |
| +3 | | Not used | 0 | | UINT16 | R/W | |
| +4-6 | | Not used | | | UINT16 | R/W | |
| | | Rapid Voltage Changes | | | | | |
| +7 | | Not used | 0 | | UINT16 | R/W | |
| +8 | | Not used | 0 | | UINT16 | R/W | |
| +9 | | Not used | 0 | | UINT16 | R/W | |
| | | Flicker | | | | | |
| +10 | | Not used | 0 | | UINT16 | R/W | |
| +11 | | Not used | | | UINT16 | R/W | |
| | | Harmonic Voltage | | | | | |
| +12 | | Not used | 0 | | UINT16 | R/W | |
| +13 | | Not used | 0 | | UINT16 | R/W | |
| +14-15 | | Not used | | | UINT16 | R/W | |
| | | Interharmonic Voltage | | | | | |
| +16 | | Not used | 0 | | UINT16 | R/W | |
| +17 | | Not used | 0 | | UINT16 | R/W | |
| +18 | | Not used | 0 | | UINT16 | R/W | |
| | | Mains Signaling Voltage | | | | | |
| +19 | | Not used | 0 | | UINT16 | R/W | |
| +20 | | Not used | 0 | | UINT16 | R/W | |
| +21 | | Not used | 0 | | UINT16 | R/W | |
| +22 | | Not used | 0 | | UINT16 | R/W | |
| +23 | | Not used | 0 | | UINT16 | R/W | |
| +24 | | Not used | 0 | | UINT16 | R/W | |
| +25 | | Not used | 0 | | UINT16 | R/W | |
| | | Voltage Events | | | | | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|--|----------|--------------------------------|---------------|-------|--------|-----|-------|
| +26 | | Not used | 0 | | UINT16 | R/W | |
| +27-28 | | Not used | | | UINT16 | R/W | |
| | | Recording Options | | | | | |
| +29 | | Not used | 0 | | UINT16 | R/W | |
| +30 | | Not used | 0 | | UINT16 | R/W | |
| +31-34 | | Not used | | | UINT16 | R/W | |
| | | Data Monitoring Options | | | | | |
| +35 | | Not used | 0 | | UINT16 | R/W | |
| +36-41 | | Not used | | | UINT16 | R/W | |
| 50880-50901 | | Reserved | | | UINT16 | R/W | |
| EN 50160 Harmonic Voltage Limits | | | | | | | |
| 50902-50965 | | | | | | | |
| +0 | | Not used | 0 | | UINT16 | R/W | |
| +1 | | Not used | 0 | | UINT16 | R/W | |
| +2 | | Not used | 0 | | UINT16 | R/W | |
| | | Not used | 0 | | | | |
| +48 | | Not used | 0 | | UINT16 | R/W | |
| +49-63 | | Reserved | | | | | |
| EN 50160 Interharmonic Voltage Limits | | | | | | | |
| 50966-51029 | | | | | | | |
| +0 | | Not used | 0 | | UINT16 | R/W | |
| +1 | | Not used | 0 | | UINT16 | R/W | |
| +2 | | Not used | 0 | | UINT16 | R/W | |
| | | Not used | 0 | | | | |
| +48 | | Not used | 0 | | UINT16 | R/W | |
| +49-63 | | Reserved | | | | | |
| GOST 13109 PQ Recorder Triggers Setup | | | | | | | |
| 50134-50453 | | | | | | | |
| +0 | | Not used | 0 | | UINT16 | R/W | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|-------------|----------|-------------|---------------|-------|--------|-----|-------|
| +1 | | Not used | 0 | | UINT16 | R/W | |
| +2 | | Not used | 0 | | UINT16 | R/W | |
| +3 | | Not used | 0 | | UINT16 | R/W | |
| +4 | | Not used | 0 | | UINT16 | R/W | |
| +5 | | Not used | 0 | | UINT16 | R/W | |
| +6 | | Not used | 0 | | UINT16 | R/W | |
| +7 | | Not used | 0 | | UINT16 | R/W | |
| +8 | | Not used | 0 | | UINT16 | R/W | |
| +9 | | Not used | 0 | | UINT16 | R/W | |
| +10 | | Not used | 0 | | UINT16 | R/W | |
| +11 | | Not used | 0 | | UINT16 | R/W | |
| +12 | | Not used | 0 | | UINT16 | R/W | |
| +13 | | Not used | 0 | | UINT16 | R/W | |
| +14 | | Not used | 0 | | UINT16 | R/W | |
| +15 | | Not used | 0 | | UINT16 | R/W | |
| 50134-50149 | | Not used | | | | | |
| 50150-50165 | | Not used | | | | | |
| 50166-50181 | | Not used | | | | | |
| 50182-50197 | | Not used | | | | | |
| 50198-50213 | | Not used | | | | | |
| 50214-50229 | | Not used | | | | | |
| 50230-50245 | | Not used | | | | | |
| 50246-50261 | | Not used | | | | | |
| 50262-50277 | | Not used | | | | | |
| 50278-50293 | | Not used | | | | | |
| 50294-50309 | | Not used | | | | | |
| 50310-50325 | | Not used | | | | | |
| 50326-50341 | | Not used | | | | | |
| 50342-50453 | | Reserved | | | | | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|--|----------|---|---------------|-------|--------|-----|-------|
| GOST 13109 Advanced Setup | | | | | | | |
| 50838-50879 | | | | | | | |
| | | GOST 13109 Compliance Statistics | | | | | |
| +0 | | Not used | 0 | | UINT16 | R/W | |
| +1 | | Not used | 0 | | UINT16 | R/W | |
| +2-3 | | Not used | 0 | | UINT16 | R/W | |
| | | GOST 13109 Harmonic Statistics | | | | | |
| +4 | | Not used | 0 | | UINT16 | R/W | |
| +5 | | Not used | 0 | | UINT16 | R/W | |
| +6-8 | | Not used | 0 | | UINT16 | R/W | |
| | | Voltage Change | | | | | |
| +9 | | Not used | 0 | | UINT16 | R/W | |
| | | Flicker | | | | | |
| +10 | | Not used | 0 | | UINT16 | R/W | |
| +11-13 | | Not used | 0 | | UINT16 | R/W | |
| | | Harmonic Voltage | | | | | |
| +14 | | Not used | 0 | | UINT16 | R/W | |
| +15-35 | | Not used | 0 | | UINT16 | R/W | |
| | | Peak Load Time Intervals | | | | | |
| +36 | | Not used | 0 | | UINT16 | R/W | |
| +37 | | Not used | 0 | | UINT16 | R/W | |
| +38 | | Not used | 0 | | UINT16 | R/W | |
| +39 | | Not used | 0 | | UINT16 | R/W | |
| +40 | | Not used | 0 | | UINT16 | R/W | |
| +41 | | Not used | 0 | | UINT16 | R/W | |
| 50880-50901 | | Reserved | 0 | | UINT16 | R/W | |
| GOST 32144 PQ Recorder Triggers Setup | | | | | | | |
| 50134-50373 | | | | | | | |
| +0 | | Not used | 0 | | INT16 | R/W | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|-------------|----------|-------------|---------------|-------|--------|-----|-------|
| +1 | | Not used | 0 | | UINT16 | R/W | |
| +2 | | Not used | 0 | | UINT16 | R/W | |
| +3 | | Not used | 0 | | UINT16 | R/W | |
| +4 | | Not used | 0 | | UINT16 | R/W | |
| +5 | | Not used | 0 | | UINT16 | R/W | |
| +6 | | Not used | 0 | | UINT16 | R/W | |
| +7 | | Not used | 0 | | UINT16 | R/W | |
| +8 | | Not used | 0 | | UINT16 | R/W | |
| +9 | | Not used | 0 | | UINT16 | R/W | |
| +10 | | Not used | 0 | | UINT16 | R/W | |
| +11 | | Not used | 0 | | UINT16 | R/W | |
| +12 | | Not used | 0 | | INT16 | R/W | |
| +13 | | Not used | 0 | | INT16 | R/W | |
| +14 | | Not used | 0 | | INT16 | R/W | |
| +15 | | Not used | 0 | | UINT16 | R/W | |
| 50134-50149 | | Not used | 0 | | | | |
| 50150-50165 | | Not used | 0 | | | | |
| 50166-50181 | | Not used | 0 | | | | |
| 50182-50197 | | Not used | 0 | | | | |
| 50198-50213 | | Not used | 0 | | | | |
| 50214-50229 | | Not used | 0 | | | | |
| 50230-50245 | | Not used | 0 | | | | |
| 50246-50261 | | Not used | 0 | | | | |
| 50262-50277 | | Not used | 0 | | | | |
| 50278-50293 | | Not used | 0 | | | | |
| 50294-50309 | | Not used | 0 | | | | |
| 50310-50325 | | Not used | 0 | | | | |
| 50326-50341 | | Not used | 0 | | | | |
| 50342-50357 | | Not used | 0 | | | | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|----------------------------------|----------|---|---------------|-------|--------|-----|-------|
| 50358-50373 | | Not used | 0 | | | | |
| 50374-50453 | | Reserved | | | | | |
| GOST 32144 Advanced Setup | | | | | | | |
| 50838-50879 | | | | | | | |
| | | GOST 32144 Compliance Statistics | | | | | |
| +0 | | Not used | 0 | | UINT16 | R/W | |
| +1 | | Not used | 0 | | UINT16 | R/W | |
| +2 | | Not used | 0 | | UINT16 | R/W | |
| +3 | | Not used | 0 | | UINT16 | R/W | |
| +4-7 | | Not used | | | UINT16 | R/W | |
| | | Rapid Voltage Changes | | | | | |
| +8 | | Not used | 0 | | UINT16 | R/W | |
| +9 | | Not used | | | UINT16 | R/W | |
| | | Flicker | | | | | |
| +10 | | Not used | 0 | | UINT16 | R/W | |
| +11 | | Not used | | | UINT16 | R/W | |
| | | Harmonic Voltage | | | | | |
| +12 | | Not used | 0 | | UINT16 | R/W | |
| +13 | | Not used | 0 | | UINT16 | R/W | |
| +14-15 | | Not used | | | UINT16 | R/W | |
| | | Interharmonic Voltage | | | | | |
| +16 | | Not used | 0 | | UINT16 | R/W | |
| +17 | | Not used | 0 | | UINT16 | R/W | |
| +18 | | Not used | 0 | | UINT16 | R/W | |
| +19 | | Not used | | | UINT16 | R/W | |
| | | Mains Signaling Voltage | | | | | |
| +20 | | Not used | 0 | | UINT16 | R/W | |
| +21 | | Not used | 0 | | UINT16 | R/W | |
| +22 | | Not used | 0 | | UINT16 | R/W | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|--|----------|---------------------------------|---------------|-------|--------|-----|-------|
| +23 | | Not used | 0 | | UINT16 | R/W | |
| +24 | | Not used | 0 | | UINT16 | R/W | |
| +25-34 | | Not used | 0 | | UINT16 | R/W | |
| | | Data Monitoring Options | | | | | |
| +35 | | Not used | 0 | | UINT16 | R/W | |
| | | Peak Load Time Intervals | | | | | |
| +36 | | Not used | 0 | | UINT16 | R/W | |
| +37 | | Not used | 0 | | UINT16 | R/W | |
| +38 | | Not used | 0 | | UINT16 | R/W | |
| +39 | | Not used | 0 | | UINT16 | R/W | |
| +40 | | Not used | 0 | | UINT16 | R/W | |
| +41 | | Not used | 0 | | UINT16 | R/W | |
| 50880-50901 | | Reserved | 0 | | UINT16 | R/W | |
| GOST 32144 Harmonic Voltage Limits | | | | | | | |
| 50902-50965 | | | | | | | |
| +0 | | Not used | 0 | | UINT16 | R/W | |
| +1 | | Not used | 0 | | UINT16 | R/W | |
| +2 | | Not used | 0 | | UINT16 | R/W | |
| | | ... | | | | | |
| +48 | | Not used | 0 | | UINT16 | R/W | |
| +49-63 | | Reserved | | | | | |
| GOST 32144 Interharmonic Voltage Limits | | | | | | | |
| 50966-51029 | | | | | | | |
| +0 | | Not used | 0 | | UINT16 | R/W | |
| +1 | | Not used | 0 | | UINT16 | R/W | |
| +2 | | Not used | 0 | | UINT16 | R/W | |
| | | Not used | 0 | | | | |
| +48 | | Not used | 0 | | UINT16 | R/W | |
| +49-63 | | Reserved | | | | | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|--------------------------|----------|---|--|---------------|--------|-----|-------|
| DNP Options Setup | | | | | | | |
| 51158-51183 | | | | | | | |
| +0 | | Default Binary Input Static object variation | F24 (default 0) | | UINT16 | R/W | |
| +1 | | Binary Input Change object variation | F24 (default 1) | | UINT16 | R/W | |
| +2 | | Default Binary Counter object variation | F24 (default 3) | | UINT16 | R/W | |
| +3 | | Frozen Binary Counter object variation | F24 (default 4) | | UINT16 | R/W | |
| +4 | | Reserved | | | UINT16 | R/W | |
| +5 | | Binary Counter Change Event object variation | F24 (default 2) | | UINT16 | R/W | |
| +6 | | Default Analog Input object variation | F24 (default 3) | | UINT16 | R/W | |
| +7 | | Reserved | | | UINT16 | R/W | |
| +8 | | Reserved | | | UINT16 | R/W | |
| +9 | | Analog Input Change Event object variation | F24 (default 2) | | UINT16 | R/W | |
| +10 | | Re-mapping static point indices for event objects | 0=disabled (default), 1=enabled | | UINT16 | R/W | |
| +11 | | 16-bit BC scaling | 0= $\times 1$ (default), 1= $\times 10$, 2= $\times 100$, 3= $\times 1000$ | | UINT16 | R/W | |
| +12 | | 16-bit AI scaling | 0=disabled, 1=enabled | | UINT16 | R/W | |
| +13 | | Number of Analog Input change event points | 0 to 43 (default 43) | | UINT16 | R/W | |
| +14 | | Number of Binary Input change event points | 0 to 32 (default 21) | | UINT16 | R/W | |
| +15 | | Number of Binary Counter change event points | 0 to 16 (default 0) | | UINT16 | R/W | |
| +16 | | Select/Operate Timeout | 2 to 30 seconds (default 10 sec) | | UINT16 | R/W | |
| +17 | | Multi Fragment Interval | 50 to 500 ms (default 50 ms) | | UINT16 | R/W | |
| +18-21 | | Reserved | Read as 65535 | | UINT16 | R/W | |
| +22,23 | | Time Sync Period | 1 to 86400 seconds (default 86400 sec), 0=disable time requests | | UINT32 | R/W | |
| +24 | | Voltage scale, secondary volts | 60 to 828V (default 828V) | | UINT16 | R/W | |
| +25 | | Current scale, secondary amps | 10 to 200 (default CT secondary \times CT overload) | $\times 0.1A$ | UINT16 | R/W | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|-----------------------------------|----------|-----------------------------------|--|-------|--------|-----|---|
| 51184-51189 | | Reserved | | | | | |
| DNP Events Setup | | | | | | | |
| 51190-51445 | | | | | | | |
| +0,1 | | Threshold/Deadband | See Section 3.5 for point value limits. | | UINT32 | R/W | A hysteresis for the point return threshold is 0.05Hz for frequency and 2% of the operating threshold for other points |
| +2 | | DNP point number | DNP point number available for the selected object | | UINT16 | R/W | |
| +3 | | Event scan control field (bitmap) | Bits 0-1 - DNP Object: 0=none, 1=AI, 2=BI, 3=BC Bit 2 – Object change event scan: 0= disabled, 1=enabled Bits 5-6 - DNP event poll class: 0=Class 1, 1=Class 2, 2=Class 3 Bit 7 – unused Bits 8-9 – Threshold/Deadband relation: 0=Delta, 1=more than (over threshold), 2=less than (under threshold) | | UINT16 | R/W | If Event log is enabled, the source of a DNP event will be recorded to the device Event log file as a general Setpoint #17. |
| 51190-51193 | | DNP Event #1 | | | | | |
| 51194-51197 | | DNP Event #2 | | | | | |
| | | ... | | | | | |
| 51442-51445 | | DNP Event #64 | | | | | |
| 51446-51573 | | Reserved | | | | | |
| DNP Extended Options Setup | | | | | | | |
| 51574-51590 | | | | | | | |
| +0-15 | | Device location | 1-31 ASCII characters | | CHAR32 | R/W | Null-terminated ASCII string |
| +16 | | Maximum file directory entries | 10-200 | | UINT16 | R/W | |
| 51591-51701 | | Reserved | | | | | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|-------------------------------------|----------|------------------------------------|--|-------|--------|-----|--|
| DNP Class 0 Point Assignment | | | | | | | |
| 51702-51797 | | | | | | | |
| | +0 | DNP object and variation | F25 | | UINT16 | R/W | |
| | +1 | Start point number | Start point number for the selected object | | UINT16 | R/W | |
| | +2 | Number of the points in a range | 0-128 | | UINT16 | R/W | |
| 51702-51704 | | DNP Class 0 Points Range 1 | | | | | |
| 51705-51707 | | DNP Class 0 Points Range 2 | | | | | |
| | | ... | | | | | |
| 51795-51797 | | DNP Class 0 Points Range 32 | | | | | |
| 51798-51893 | | Reserved | | | | | |
| SOE Log Labels | | | | | | | |
| 51894-52043 | | | | | | | |
| | +0 | Not used | 0 | | UINT16 | R/W | Write the event type and point number before reading following registers |
| | +1 | Not used | 0 | | UINT16 | R/W | |
| | +2-17 | Not used | 0 | | CHAR32 | R/W | |
| | +18-33 | Not used | 0 | | CHAR32 | R/W | |
| | +34-81 | Not used | 0 | | CHAR96 | R/W | |
| | +82 | Not used | 0 | | UINT16 | R/W | |
| | +83 | Not used | 0 | | UINT16 | R/W | |
| | +84-99 | Not used | 0 | | CHAR32 | R/W | |
| | +100-147 | Not used | 0 | | CHAR96 | R/W | |
| | +148 | Not used | 0 | | UINT16 | R/W | |
| | +149 | Reserved | 0 | | UINT16 | R/W | |
| 52044-52149 | | Reserved | | | | | |
| Fault Log Triggers Setup | | | | | | | |
| 52150-52277 | | | | | | | |
| | +0 | Not used | 0 | | UINT16 | R/W | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|----------------------------------|----------|---------------------|--|-------|--------|-----|--------------------|
| +1 | | Not used | 0 | | UINT16 | R/W | |
| +2 | | Not used | 0 | | UINT16 | R/W | |
| +3 | | Not used | 0 | | UINT16 | R/W | |
| +4 | | Not used | 0 | | UINT16 | R/W | |
| +5 | | Not used | 0 | | UINT16 | R/W | |
| +6-7 | | Not used | 0 | | UINT16 | R/W | |
| 52150-52157 | | Not used | 0 | | | | Enabled by default |
| 52158-52165 | | Not used | 0 | | | | |
| 52166-52173 | | Not used | 0 | | | | |
| 52174-52181 | | Not used | 0 | | | | |
| 52182-52189 | | Not used | 0 | | | | |
| 52190-52197 | | Not used | 0 | | | | |
| 52198-52205 | | Not used | 0 | | | | |
| 52206-52213 | | Not used | 0 | | | | |
| 52214-52277 | | Reserved | | | UINT16 | R/W | |
| Fault Log Recording Setup | | | | | | | |
| 52278-52341 | | | | | | | |
| +0 | | Log options, bitmap | Bit 0 – waveform log on event start: 0 = disabled, 1 = enabled; Bit 1 – waveform log on event end: 0 = disabled, 1 = enabled; Bit 2 – recording to PQ log: 0 = enabled, 1 = disabled. | | UINT16 | R/W | |
| +1 | | Not used | 0 | | UINT16 | R/W | |
| +2 | | Not used | 0 | | UINT16 | R/W | |
| +3 | | Not used | 0 | | UINT16 | R/W | |
| +4 | | Not used | 0 | | UINT16 | R/W | |
| +5 | | Not used | 0 | | UINT16 | R/W | |
| +6 | | Not used | 0 | | UINT16 | R/W | |
| +7-63 | | Reserved | 0 | | UINT16 | R/W | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|---|----------|---|--|--------|--------|-----|-------|
| IEEE 1159 PQ Log Triggers Setup (IEEE 1159 disturbance categories) | | | | | | | |
| 52342-52597 | | | | | | | |
| +0 | | Threshold, % | 0 – 2000 | x 0.1% | UINT16 | R/W | |
| +1 | | Hysteresis, % of threshold | 0 – 500 | x 0.1% | UINT16 | R/W | |
| +2 | | Log options, bitmap | Bit 0 – waveform log on event start: 0 = disabled, 1 = enabled; Bit 1 – waveform log on event end: 0 = disabled, 1 = enabled. | | UINT16 | R/W | |
| +3 | | Waveform log number | 0-7 = log #1-8 | | UINT16 | R/W | |
| +4 | | Data/RMS plot option | 0 = disabled, 1 = enabled | | UINT16 | R/W | |
| +5 | | Data log number (factory preset) | 13 = log #14 | | UINT16 | R/W | |
| +6 | | 1/2-cycle RMS plot, cycles before event | 0-20 | cycle | UINT16 | R/W | |
| +7 | | 1/2-cycle RMS plot, cycles after event | 0-20 | cycle | UINT16 | R/W | |
| +8 | | 1/2-cycle RMS plot duration, cycles | 0-10000 | cycle | UINT16 | R/W | |
| +9 | | 0.2-sec envelope RMS plot duration, seconds | 0-10000 | sec | UINT16 | R/W | |
| +10 | | 3-sec envelope RMS plot duration, minutes | 0-10000 | min | UINT16 | R/W | |
| +11 | | 10-min envelope RMS plot duration, hours | 0-10000 | hours | UINT16 | R/W | |
| +12-15 | | Reserved | 0 | | UINT16 | R/W | |
| 52342-52357 | | Impulsive | | | | | |
| 52358-52373 | | Sag | | | | | |
| 52374-52389 | | Swell | | | | | |
| 52390-52405 | | Interruption | | | | | |
| 52406-52421 | | Volt Unbalance | | | | | |
| 52422-52437 | | Frequency variation | | | | | |
| 52438-52453 | | Harmonics | | | | | |
| 52454-52469 | | Interharmonics | | | | | |
| 52470-52597 | | Reserved | | | | | |
| File Setup | | | | | | | |
| 52598-53877 | | | | | | | |
| +0 | | File type | 0 | | UINT16 | R/W | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|-------------|----------|--|--|-------|--------|-----|---|
| +1 | | File attributes (bitmap) | F3 | | UINT16 | R/W | |
| +2 | | Number of records in the file | 65535, 0 = delete file | | UINT16 | R/W | |
| +3 | | Number of sections/channels in the file | 0-32, 0 = non-partitioned file | | UINT16 | R/W | |
| +4 | | Number of parameters per section record | 1-64 for conventional data files, 34 - EN 50160:2007 statistics log, 52 - EN 50160:2007 harmonics log, 36 - EN 50160:2010 statistics log, 98 - EN 50160:2010 harmonics log, 40 - GOST 13109 statistics log, 80 - GOST 13109 harmonics log, 42 - GOST 32144 statistics log, 80 - GOST 32144 harmonics log | | UINT16 | R/W | |
| +5 | | Not Used | | | | | |
| +6 | | Section record size, bytes (for info only) | | | UINT16 | R | |
| +7 | | File record size, bytes (for info only) | | | UINT16 | R | |
| +8,9 | | Allocated file size, bytes (for info only) | | | UINT32 | R | |
| 52598-52607 | | Event Log Setup | | | | | |
| 52608-52617 | | Data Log #1 Setup | | | | | |
| 52618-52627 | | Data Log #2 Setup | | | | | |
| 52628-52637 | | Data Log #3 Setup | | | | | |
| 52638-52647 | | Data Log #4 Setup | | | | | |
| 52648-52657 | | Data Log #5 Setup | | | | | |
| 52658-52667 | | Data Log #6 Setup | | | | | |
| 52668-52677 | | Data Log #7 Setup | | | | | |
| 52678-52687 | | Data Log #8 Setup | | | | | |
| 52688-52697 | | Data Log #9 Setup | | | | | EN50160/GOST 13109/GOST 32144 compliance statistics |
| 52698-52707 | | Data Log #10 Setup | | | | | EN50160/GOST 13109/GOST 32144 harmonic statistics |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|--------------------------------|----------|--|---|-------|--------|-----|---|
| 52708-52717 | | Data Log #11 Setup | | | | | |
| 52718-52727 | | Data Log #12 Setup | | | | | |
| 52728-52737 | | Data Log #13 Setup | | | | | |
| 52738-52747 | | Data Log #14 Setup | | | | | |
| 52748-52757 | | Data Log #15 Setup | | | | | |
| 52758-52767 | | Data Log #16 Setup | | | | | |
| 52768-52777 | | Waveform Log #1 Setup | | | | | |
| 52778-52787 | | Waveform Log #2 Setup | | | | | |
| 52788-52797 | | Waveform Log #3 Setup | | | | | |
| 52798-52807 | | Waveform Log #4 Setup | | | | | |
| 52808-52817 | | Waveform Log #5 Setup | | | | | |
| 52818-52827 | | Waveform Log #6 Setup | | | | | Allocated for the transient recorder if the module is present |
| 52828-52837 | | Waveform Log #7 Setup | | | | | |
| 52838-52847 | | Waveform Log #8 Setup | | | | | |
| 52848-52857 | | Not used | | | | | |
| 52858-52867 | | PQ Log File Setup | | | | | |
| 52868-52877 | | Not used | | | | | |
| 52878-53877 not used | | | | | | | |
| Waveform Recorder Setup | | | | | | | |
| 53878-53949 | | | | | | | |
| +0 | | Sampling rate, samples per cycle | Regular waveform: 32, 64, 128, 256 | | UINT16 | R/W | |
| +1 | | Number of cycles per series | 16-10848 (32 samples/cycle), 8-5424 (64 samples/cycle), 4-2712 (128 samples/cycle), 2-1356 (256 samples/cycle) | | UINT16 | R/W | |
| +3 | | Recording time mode and number of post-event cycles in event-controlled mode | Bit 15 – mode: 0=fixed time, 1= event-controlled time Bits 0-9 – post-event cycles: 0-2048 | | UINT16 | R/W | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|-----------------------------|----------|---|---------------|-------|--------|-----|-------|
| +4 | | Number of cycles before trigger | 1-20 | | UINT16 | R/W | |
| +4,5 | | File channel mask (channels 1-32), bitmap | F9 | | UINT32 | R/W | |
| +6,7 | | File channel mask (channels 33-64), bitmap | F9 | | UINT32 | R/W | |
| 53878-53885 | | Waveform Log #1 Setup | | | | | |
| 53886-53893 | | Waveform Log #2 Setup | | | | | |
| 53894-53901 | | Waveform Log #3 Setup | | | | | |
| 53902-53909 | | Waveform Log #4 Setup | | | | | |
| 53910-53917 | | Waveform Log #5 Setup | | | | | |
| 53918-53925 | | Waveform Log #6 Setup | | | | | |
| 53926-53933 | | Waveform Log #7 Setup | | | | | |
| 53934-53941 | | Waveform Log #8 Setup | | | | | |
| 53942-53949 not used | | | | | | | |
| Data Log Setup | | | | | | | |
| 54006-55541 | | | | | | | |
| +0 | | Data log parameter #1 ID | 0x0000-0xFFFF | | UINT16 | R/W | |
| +1 | | Data log parameter #2 ID | 0x0000-0xFFFF | | UINT16 | R/W | |
| +2 | | Data log parameter #3 ID | 0x0000-0xFFFF | | UINT16 | R/W | |
| +3 | | Data log parameter #4 ID | 0x0000-0xFFFF | | UINT16 | R/W | |
| +4 | | Data log parameter #5 ID | 0x0000-0xFFFF | | UINT16 | R/W | |
| +5 | | Data log parameter #6 ID | 0x0000-0xFFFF | | UINT16 | R/W | |
| +6 | | Data log parameter #7 ID | 0x0000-0xFFFF | | UINT16 | R/W | |
| +7 | | Data log parameter #8 ID | 0x0000-0xFFFF | | UINT16 | R/W | |
| +8 | | Data log parameter #9 ID | 0x0000-0xFFFF | | UINT16 | R/W | |
| +9 | | Data log parameter #10 ID | 0x0000-0xFFFF | | UINT16 | R/W | |
| +10 | | Data log parameter #11 ID | 0x0000-0xFFFF | | UINT16 | R/W | |
| +11 | | Data log parameter #12 ID | 0x0000-0xFFFF | | UINT16 | R/W | |
| +12 | | Data log parameter #13 ID | 0x0000-0xFFFF | | UINT16 | R/W | |
| +13 | | Data log parameter #14 ID | 0x0000-0xFFFF | | UINT16 | R/W | |
| +14 | | Data log parameter #15 ID | 0x0000-0xFFFF | | UINT16 | R/W | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|--------------------------------|----------|-------------------------------|---------------|-------|--------|-----|-------|
| +15 | | Data log parameter #16 ID | 0x0000-0xFFFF | | UINT16 | R/W | |
| +16-31 | | Reserved | | | UINT16 | R/W | |
| 54006-54037 | | Data log #1 Setup | | | | | |
| 54038-54069 | | Data log #2 Setup | | | | | |
| 54070-54101 | | Data log #3 Setup | | | | | |
| 54102-54133 | | Data log #4 Setup | | | | | |
| 54134-54165 | | Data log #5 Setup | | | | | |
| 54166-54197 | | Data log #6 Setup | | | | | |
| 54198-54229 | | Data log #7 Setup | | | | | |
| 54230-54261 | | Data log #8 Setup | | | | | |
| 54262-54293 | | Data log #9 Setup | | | | | |
| 54294-54325 | | Data log #10 Setup | | | | | |
| 54326-54357 | | Data log #11 Setup | | | | | |
| 54358-54389 | | Data log #12 Setup | | | | | |
| 54390-54421 | | Data log #13 Setup | | | | | |
| 54422-54453 | | Data log #14 Setup | | | | | |
| 54454-54485 | | Data log #15 Setup | | | | | |
| 54486-54517 | | Data log #16 Setup | | | | | |
| 54518-55541 not used | | | | | | | |
| TOU Daily Profile Setup | | | | | | | |
| 55574-55701 | | | | | | | |
| +0 | | 1 st tariff change | F10 | | UINT16 | R/W | |
| +1 | | 2 nd tariff change | F10 | | UINT16 | R/W | |
| +2 | | 3 rd tariff change | F10 | | UINT16 | R/W | |
| +3 | | 4 th tariff change | F10 | | UINT16 | R/W | |
| +4 | | 5 th tariff change | F10 | | UINT16 | R/W | |
| +5 | | 6 th tariff change | F10 | | UINT16 | R/W | |
| +6 | | 7 th tariff change | F10 | | UINT16 | R/W | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|-----------------------------|----------|---|--|-------|--------|-----|-------|
| +7 | | 8 th tariff change | F10 | | UINT16 | R/W | |
| 55574-55581 | | Daily profile #1: Season 1, Day type 1 | | | | | |
| 55582-55589 | | Daily profile #2: Season 1, Day type 2 | | | | | |
| 55590-55597 | | Daily profile #3: Season 1, Day type 3 | | | | | |
| 55598-55605 | | Daily profile #4: Season 1, Day type 4 | | | | | |
| 55606-55613 | | Daily profile #5: Season 2, Day type 1 | | | | | |
| 55614-55621 | | Daily profile #6: Season 2, Day type 2 | | | | | |
| 55622-55629 | | Daily profile #7: Season 2, Day type 3 | | | | | |
| 55630-55637 | | Daily profile #8: Season 2, Day type 4 | | | | | |
| 55638-55645 | | Daily profile #9: Season 3, Day type 1 | | | | | |
| 55646-55653 | | Daily profile #10: Season 3, Day type 2 | | | | | |
| 55654-55661 | | Daily profile #11: Season 3, Day type 3 | | | | | |
| 55662-55669 | | Daily profile #12: Season 3, Day type 4 | | | | | |
| 55670-55677 | | Daily profile #13: Season 4, Day type 1 | | | | | |
| 55678-55685 | | Daily profile #14: Season 4, Day type 2 | | | | | |
| 55686-55693 | | Daily profile #15: Season 4, Day type 3 | | | | | |
| 55694-55701 | | Daily profile #16: Season 4, Day type 4 | | | | | |
| 55702-55711 not used | | | | | | | |
| TOU Calendar Setup | | | | | | | |
| 55712-56031 | | | | | | | |
| +0-9 | | Calendar entry record | | | | R/W | |
| +0 | | Daily profile (season/day type) | 0 = unused entry 1-4 = season 1, day type 0-3 5-8 = season 2, day type 0-3 9-12 = season 3, day type 0-3 13-16 = season 4, day type 0-3 128 = DST period schedule | | UINT16 | R/W | |
| +1 | | Week of month | 0=all, 1=1st, 2=2nd, 3=3 rd , 4=4th, 5=last week of the month | | UINT16 | R/W | |
| +2 | | Weekday | 0=all, 1-7 (Sun=1, Sat=7) | | UINT16 | R/W | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|------------------------------------|----------|--------------------------|---|-------|--------|-----|-------|
| +3 | | Till Weekday | 0=all, 1-7 (Sun=1, Sat=7) | | UINT16 | R/W | |
| +4 | | Month | 0=all, 1-12=January - December | | UINT16 | R/W | |
| +5 | | Day of month | 0=all, 1-31=day 1-31 | | UINT16 | R/W | |
| +6 | | Till Month | 0=all, 1-12=January - December | | UINT16 | R/W | |
| +7 | | Till Day of month | 0=all, 1-31=day 1-31 | | UINT16 | R/W | |
| +8 | | Year | 0=all, 1-99 | | UINT16 | R/W | |
| +9 | | Not used | | | UINT16 | R/W | |
| 55712-55721 | | Calendar entry #1 | | | | | |
| 55722-55731 | | Calendar entry #2 | | | | | |
| 55732-55741 | | Calendar entry #3 | | | | | |
| ... | | | | | | | |
| 56182-56191 not used | | | | | | | |
| Billing/TOU Registers Setup | | | | | | | |
| 56672-56799 | | | | | | | |
| +0 | | Not used | 0 | | UINT16 | R/W | |
| +1 | | Units of measurement | 0=none, 1=kWh, 2=kvarh, 3=kVAh, 4=m ³ , 5=CF (cubic feet), 6=CCF (hundred cubic feet) | | UINT16 | R/W | |
| +2 | | Flags (bitmap) | Bit 0=1 - TOU enabled Bit 1=1 – Energy usage profile enabled Bit 2=1 - Max. Demand profile enabled Bit 3=1 - Summary (total) profile enabled | | UINT16 | R/W | |
| +3 | | Not used | 0 | | UINT16 | R/W | |
| 56672-56675 | | Register #1 Setup | | | | | |
| 56676-56679 | | Register #2 Setup | | | | | |
| 56680-56683 | | Register #3 Setup | | | | | |
| | | ... | | | | | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|---|----------|------------------------------------|-----------------|--------|--------|-----|-------|
| 56796-56799 not used | | | | | | | |
| Billing/TOU Registers Source Setup | | | | | | | |
| 56928-57183 | | | | | | | |
| +0 | | Energy source ID | F11 | | UINT16 | R/W | |
| +1 | | Target billing/TOU register number | 0-31 | | UINT16 | R/W | |
| +2,3 | | Multiplier | 0-1000000 | ×0.001 | INT32 | R/W | |
| 56928-56931 | | Energy Source #1 | | | | | |
| 56932-56935 | | Energy Source #2 | | | | | |
| 56936-56939 | | Energy Source #3 | | | | | |
| | | ... | | | | | |
| 57180-57183 not used | | | | | | | |
| Control Setpoints Setup (SP1-SP32) | | | | | | | |
| 57184-59103 | | Setpoints 1-32 | | | | | |
| +0 | | Condition #1: Trigger parameter ID | F12 | | UINT16 | R/W | |
| +1 | | Condition #2: Trigger parameter ID | F12 | | UINT16 | R/W | |
| +2 | | Condition #3: Trigger parameter ID | F12 | | UINT16 | R/W | |
| +3 | | Condition #4: Trigger parameter ID | F12 | | UINT16 | R/W | |
| +4 | | Condition #1: Logical operator | 0 = OR, 1 = AND | | UINT16 | R/W | |
| +5 | | Condition #2: Logical operator | 0 = OR, 1 = AND | | UINT16 | R/W | |
| +6 | | Condition #3: Logical operator | 0 = OR, 1 = AND | | UINT16 | R/W | |
| +7 | | Condition #4: Logical operator | 0 = OR, 1 = AND | | UINT16 | R/W | |
| +8 | | Condition #1: Relational operator | F13 | | UINT16 | R/W | |
| +9 | | Condition #2: Relational operator | F13 | | UINT16 | R/W | |
| +10 | | Condition #3: Relational operator | F13 | | UINT16 | R/W | |
| +11 | | Condition #4: Relational operator | F13 | | UINT16 | R/W | |
| +12,13 | | Condition #1: Operate limit | | | INT32 | R/W | |
| +14,15 | | Condition #2: Operate limit | | | INT32 | R/W | |
| +16,17 | | Condition #3: Operate limit | | | INT32 | R/W | |
| +18,19 | | Condition #4: Operate limit | | | INT32 | R/W | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|---|----------|------------------------------------|---------------|---------|--------|-----|--|
| +20,21 | | Condition #1: Release limit | | | INT32 | R/W | |
| +22,23 | | Condition #2: Release limit | | | INT32 | R/W | |
| +24,25 | | Condition #3: Release limit | | | INT32 | R/W | |
| +26,27 | | Condition #4: Release limit | | | INT32 | R/W | |
| +28 | | Action #1: Action ID | F14 | | UINT16 | R/W | |
| +29 | | Action #2: Action ID | F14 | | UINT16 | R/W | |
| +30 | | Action #3: Action ID | F14 | | UINT16 | R/W | |
| +31 | | Action #4: Action ID | F14 | | UINT16 | R/W | |
| +32,33 | | Action #1: Parameter value | | | INT32 | R/W | |
| +34,35 | | Action #2: Parameter value | | | INT32 | R/W | |
| +36,37 | | Action #3: Parameter value | | | INT32 | R/W | |
| +38,39 | | Action #4: Parameter value | | | INT32 | R/W | |
| +40,41 | | Operate delay | 0-10000000 | 0.001 s | UINT32 | R/W | |
| +42,43 | | Release delay | 0-10000000 | 0.001 s | UINT32 | R/W | |
| +44-59 | | Not used | | | UINT16 | R/W | |
| 57184-57243 | | Setpoint #1 | | | | | |
| 57244-57303 | | Setpoint #2 | | | | | |
| | | ... | | | | | |
| 59044-59103 not used | | | | | | | |
| Control Setpoints Setup (SP1-SP64) | | | | | | | |
| 59104-59177 | | Setpoints 1-64 | | | | | |
| +0 | | Setpoint number | 0-63 | | UINT16 | R/W | Write a setpoint number first before reading following registers |
| +1 | | Variation | 8 | | UINT16 | R/W | |
| +2 | | Condition #1: Trigger parameter ID | F12 | | UINT16 | R/W | |
| +3 | | Condition #2: Trigger parameter ID | F12 | | UINT16 | R/W | |
| +4 | | Condition #3: Trigger parameter ID | F12 | | UINT16 | R/W | |
| +5 | | Condition #4: Trigger parameter ID | F12 | | UINT16 | R/W | |
| +6 | | Condition #5: Trigger parameter ID | F12 | | UINT16 | R/W | |
| +7 | | Condition #6: Trigger parameter ID | F12 | | UINT16 | R/W | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|---------|----------|------------------------------------|-----------------|-------|--------|-----|-------|
| +8 | | Condition #7: Trigger parameter ID | F12 | | UINT16 | R/W | |
| +9 | | Condition #8: Trigger parameter ID | F12 | | UINT16 | R/W | |
| +10 | | Condition #1: Logical operator | 0 = OR, 1 = AND | | UINT16 | R/W | |
| +11 | | Condition #2: Logical operator | 0 = OR, 1 = AND | | UINT16 | R/W | |
| +12 | | Condition #3: Logical operator | 0 = OR, 1 = AND | | UINT16 | R/W | |
| +13 | | Condition #4: Logical operator | 0 = OR, 1 = AND | | UINT16 | R/W | |
| +14 | | Condition #5: Logical operator | 0 = OR, 1 = AND | | UINT16 | R/W | |
| +15 | | Condition #6: Logical operator | 0 = OR, 1 = AND | | UINT16 | R/W | |
| +16 | | Condition #7: Logical operator | 0 = OR, 1 = AND | | UINT16 | R/W | |
| +17 | | Condition #8: Logical operator | 0 = OR, 1 = AND | | UINT16 | R/W | |
| +18 | | Condition #1: Relational operator | F13 | | UINT16 | R/W | |
| +19 | | Condition #2: Relational operator | F13 | | UINT16 | R/W | |
| +20 | | Condition #3: Relational operator | F13 | | UINT16 | R/W | |
| +21 | | Condition #4: Relational operator | F13 | | UINT16 | R/W | |
| +22 | | Condition #5: Relational operator | F13 | | UINT16 | R/W | |
| +23 | | Condition #6: Relational operator | F13 | | UINT16 | R/W | |
| +24 | | Condition #7: Relational operator | F13 | | UINT16 | R/W | |
| +25 | | Condition #8: Relational operator | F13 | | UINT16 | R/W | |
| +26,27 | | Condition #1: Operate limit | | | INT32 | R/W | |
| +28,29 | | Condition #2: Operate limit | | | INT32 | R/W | |
| +30,31 | | Condition #3: Operate limit | | | INT32 | R/W | |
| +32,33 | | Condition #4: Operate limit | | | INT32 | R/W | |
| +34,35 | | Condition #5: Operate limit | | | INT32 | R/W | |
| +36,37 | | Condition #6: Operate limit | | | INT32 | R/W | |
| +38,39 | | Condition #7: Operate limit | | | INT32 | R/W | |
| +40,41 | | Condition #8: Operate limit | | | INT32 | R/W | |
| +42,43 | | Condition #1: Release limit | | | INT32 | R/W | |
| +44,45 | | Condition #2: Release limit | | | INT32 | R/W | |
| +46,47 | | Condition #3: Release limit | | | INT32 | R/W | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|-------------------------------|----------|-----------------------------|---------------|---------|--------|-----|-------|
| +48,49 | | Condition #4: Release limit | | | INT32 | R/W | |
| +50,51 | | Condition #5: Release limit | | | INT32 | R/W | |
| +52,53 | | Condition #6: Release limit | | | INT32 | R/W | |
| +54,55 | | Condition #7: Release limit | | | INT32 | R/W | |
| +56,57 | | Condition #8: Release limit | | | INT32 | R/W | |
| +58 | | Action #1: Action ID | F14 | | UINT16 | R/W | |
| +59 | | Action #2: Action ID | F14 | | UINT16 | R/W | |
| +60 | | Action #3: Action ID | F14 | | UINT16 | R/W | |
| +61 | | Action #4: Action ID | F14 | | UINT16 | R/W | |
| +62,63 | | Action #1: Parameter value | | | INT32 | R/W | |
| +64,65 | | Action #2: Parameter value | | | INT32 | R/W | |
| +66,67 | | Action #3: Parameter value | | | INT32 | R/W | |
| +68,69 | | Action #4: Parameter value | | | INT32 | R/W | |
| +70,71 | | Operate delay | 0-10000000 | 0.001 s | UINT32 | R/W | |
| +72,73 | | Release delay | 0-10000000 | 0.001 s | UINT32 | R/W | |
| 59178-59253 not used | | | | | | | |
| Switching Device Setup | | | | | | | |
| 59255 | | Not used | 0 | | UINT16 | R/W | |
| 59256-59315 | | Not used | 0 | | | | |
| | | General | | | UINT16 | R/W | |
| +0 | | Not used | 0 | | UINT16 | R/W | |
| +1-3 | | Not used | 0 | | CHAR6 | R/W | |
| +4 | | Not used | 0 | | UINT16 | R/W | |
| +5 | | Not used | 0 | | UINT16 | R/W | |
| | | Position Indication | | | | | |
| +6 | | Not used | 0 | | UINT16 | R/W | |
| +7 | | Not used | 0 | | UINT16 | R/W | |
| +8 | | Not used | 0 | | UINT16 | R/W | |
| +9 | | Not used | 0 | | UINT16 | R/W | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|------------------------------|----------|--|-----------------------|-----------|--------|-----|-------|
| +10 | | Not used | 0 | | UINT16 | R/W | |
| +11 | | Not used | 0 | | UINT16 | R/W | |
| | | Control | | | | | |
| +12 | | Not used | 0 | | UINT16 | R/W | |
| +13 | | Not used | 0 | | UINT16 | R/W | |
| +14 | | Not used | 0 | | UINT16 | R/W | |
| +15 | | Not used | 0 | | UINT16 | R/W | |
| +16 | | Not used | 0 | | UINT16 | R/W | |
| +17 | | Not used | 0 | | UINT16 | R/W | |
| +18 | | Not used | 0 | | UINT16 | R/W | |
| +19 | | Not used | 0 | | UINT16 | R/W | |
| +20,21 | | Not used | 0 | | UINT32 | R/W | |
| +22,23 | | Not used | 0 | | UINT32 | R/W | |
| +24,25 | | Not used | 0 | | UINT32 | R/W | |
| +26,27 | | Not used | 0 | | UINT32 | R/W | |
| +28,29 | | Not used | 0 | | UINT32 | R/W | |
| +30,31 | | Not used | 0 | | UINT32 | R/W | |
| | | Interlocking | | | | | |
| +32 | | Not used | 0 | | UINT16 | R/W | |
| +33 | | Not used | 0 | | UINT16 | R/W | |
| +34 | | Not used | 0 | | UINT16 | R/W | |
| +35 | | Not used | 0 | | UINT16 | R/W | |
| +36-59 | | | | | | | |
| Periodic Timers Setup | | | | | | | |
| 61024-61087 | | | | | | | |
| +0,1 | | Time interval (positive in seconds, negative in cycles) | -100000000 -100000000 | 0.001 s/c | UINT32 | R/W | |
| 61024-61025 | | Timer #1 Setup | | 0.001 s/c | UINT32 | R/W | |
| 61026-61027 | | Timer #2 Setup | | 0.001 s/c | UINT32 | R/W | |
| | | ... | | | | | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|--------------------------------------|----------|---|--|----------|--------|-----|--------|
| 61040-61041 | | Timer #9 Setup | | 0.001s/c | UINT32 | R/W | |
| 61042-61043 | | Timer #10 Setup (factory preset) | -500 (half-cycle) | 0.001cyc | UINT32 | R | |
| 61044-61045 | | Timer #11 Setup (factory preset) | -1000 (one cycle) | 0.001cyc | UINT32 | R | |
| 61046-61047 | | Timer #12 Setup (factory preset) | 200 (200 ms = 10/12 cycles) | 0.001 s | UINT32 | R | |
| 61048-61049 | | Timer #13 Setup (factory preset) | 3000 (3 sec = 150/180 cycles) | 0.001 s | UINT32 | R | |
| 61050-61051 | | Timer #14 Setup (factory preset) | 10000 (10 sec) | 0.001 s | UINT32 | R | |
| 61052-61053 | | Timer #15 Setup (factory preset) | 600000 (10 min) | 0.001 s | UINT32 | R | |
| 61054-61055 | | Timer #16 Setup (factory preset) | 7200000 (2 hours) | 0.001 s | UINT32 | R | |
| 61056-61087 not used | | | | | | | |
| Counter Source Setup | | | | | | | |
| 61472-61727 | | | | | | | |
| +0 | | Pulse source ID | F16 | | UINT16 | R/W | |
| +1 | | Target counter number | 0-31 | | UINT16 | R/W | |
| +2,3 | | Multiplier | +/-1-10000 | | INT32 | R/W | |
| 61472-61475 | | Counter Source #1 | | | | | |
| 61476-61479 | | Counter Source #2 | | | | | |
| | | ... | | | | | |
| 61724-61727 | | | | | | | |
| Digital Inputs Setup DI1-DI26 | | | | | | | |
| 61728-61983 | | | | | | | |
| +0 | | Pulse mode | 0 = pulse, 1 = KYZ | | UINT16 | R/W | |
| +1 | | Polarity | Bit 0 – pulse polarity: 0=normal, 1=inverting Bit 1 – input polarity: 0=normal, 1=inverting | | UINT16 | R/W | |
| +2 | | De-bounce time, ms | 1-1000 | | UINT16 | R/W | Note 3 |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|--|----------|----------------------------|---|-------|--------|-----|---|
| +3 | | Flags | Bit 0 – SOE Log: 0=disabled, 1=enabled; Bit 1 – Fault Log: 0=disabled, 1=enabled; | | UINT16 | R/W | |
| 61728-61731 | | DI1 Setup | | | | | |
| 61732-61735 | | DI2 Setup | | | | | |
| | | ... | | | | | |
| 61828-61831 | | | | | | | |
| Digital Inputs Setup DI65-DI128 | | | | | | | |
| 62752-63007 | | | | | | | |
| 62752-62575 | | Not used | 0 | | | | |
| 62756-62759 | | Not used | 0 | | | | |
| | | ... | | | | | |
| 63003-63007 | | | | | | | |
| Relay Outputs Setup | | | | | | | |
| 61984-62367 | | | | | | | |
| +0 | | Operation Mode | 0=unlatched, 1=latched, 2=pulse, 3=KYZ | | UINT16 | R/W | |
| +1 | | Flags | Bit 0 – polarity: 0=normal, 1=inverting Bit 1 - retentive mode: 0=disabled, 1=enabled Bit 2 – blocking: 0=unblocked relay, 1=blocked relay Bit 3 – SOE log on output change: 0=disabled, 1=enabled | | UINT16 | R/W | A blocked relay can only be unblocked by the “unblock relay” setpoint command |
| +2 | | Pulse width, ms | 1-3000 | | UINT16 | R/W | |
| +3 | | Pulse source ID | F17 | | UINT16 | R/W | |
| +4,5 | | kWh units per pulse | 1-5000000 | ×0.1 | UINT32 | R/W | |
| 61984-61989 | | RO1 Setup | | | | | |
| 61990-61995 | | RO2 Setup | | | | | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|-----------------------------|----------|---|------------------------|-------|--------|-----|-------|
| | | ... | | | | | |
| 62008-62013 | | | | | | | |
| Analog Inputs Setup | | | | | | | |
| 62368-62559 | | | | | | | |
| +0 | | Input parameter ID | 0 = input not assigned | | UINT16 | R/W | |
| +1 | | Number of decimal places | 0-3 | | UINT16 | R/W | |
| +2,3 | | Zero scale value (0/4 mA, 0V) | | | INT32 | R/W | |
| +4,5 | | Full scale value (1/20/50 mA, 10V) | | | INT32 | R/W | |
| 62368-62373 | | AI1 Setup | | | | | |
| 62374-62379 | | AI2 Setup | | | | | |
| | | ... | | | | | |
| 62392-62397 | | AI15 Setup | | | | | |
| 62398-62559 | | Reserved | | | | | |
| 62458-62463 | | AI16 Setup | | | | | |
| 62464-62559 | | | | | | | |
| Analog Outputs Setup | | | | | | | |
| 62560-62751 | | | | | | | |
| +0 | | Output parameter ID | F18 | | UINT16 | R/W | |
| +1 | | Not used | 0 | | UINT16 | R/W | |
| +2,3 | | Zero scale value (0/4 mA) | | | INT32 | R/W | |
| +4,5 | | Full scale value (20/1 mA) | | | INT32 | R/W | |
| 62560-62565 | | AO1 Setup | | | | | |
| 62566-62571 | | AO2 Setup | | | | | |
| | | ... | | | | | |
| 62602-62607 | | AO8 Setup | | | | | |
| 62608-62751 | | | | | | | |
| Display Setup | | | | | | | |
| 48664-48695 | | | | | | | |
| +0 | | Contrast | 1 - 99 | | UINT16 | R/W | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|-----------------------------|----------|---------------------------|--------------------------|-------|--------|-----|-----------|
| +1 | | Backlight time | 0 = disabled, 1-30 | min | UINT16 | R/W | |
| +2 | | Language | 0 = English, 1 = Russian | | UINT16 | R/W | |
| +3 | | Volts resolution | 1-3 | | UINT16 | R/W | |
| +4 | | Current resolution | 1,2 | | UINT16 | R/W | |
| +5 | | Power resolution | 1-3 | | UINT16 | R/W | |
| +6 | | Load bar scale, A | 0=CT, 1-50000 | | UINT16 | R/W | |
| +7-11 | | Reserved | | | UINT16 | R/W | |
| +12-17 | | Custom ID | ID Characters | | UINT16 | R/W | |
| +18-31 | | | | | | | |
| Common Data Exchange | | | | | | | |
| 47480-47603 | | | | | | | |
| +0 | | Not used | 0 | | UINT16 | R/W | |
| +1 | | Setup array offset, words | 0-578 | | UINT16 | R/W | |
| +2 | | Block length, words | 0-120 | | UINT16 | R/W | Read as 0 |
| +3 | | Last block | 0=no, 1=yes | | UINT16 | R/W | Read as 0 |
| +4-123 | | Setup data [0...119] | | | UINT16 | R/W | |

3.8 Expansion I/O Slots Configuration

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|---|----------|---|---------------|-------|--------|-----|--------|
| Expansion I/O Slots Configuration Info | | | | | | | |
| 63008-63071 | | Expansion I/O Slots Configuration Info | | | | | |
| | +0 | I/O module type | Bitmap | | UINT16 | R | Note 2 |
| | +1 | Number of I/Os on the slot | 0-32 | | UINT16 | R | |
| | +2 | First I/O number on the slot | 0-127 | | UINT16 | R | Note 1 |
| | +3 | Last I/O number on the slot | 0-127 | | UINT16 | R | Note 1 |
| 63008-63011 | | I/O Slot #1 Configuration | | | | | |
| 63012-63015 | | I/O Slot #2 Configuration | | | | | |
| 63016-63019 | | I/O Slot #3 Configuration | | | | | |
| 63020-63023 | | I/O Slot #4 Configuration | | | | | |
| 63024-63027 | | Not used | | | | | |
| 63028-63031 | | Not used | | | | | |
| 63032-63035 | | Not used | | | | | |
| 63036-63039 | | Not used | | | | | |
| 63040-63043 | | Not used | | | | | |
| 63044-63047 | | Not used | | | | | |
| 63048-63051 | | Not used | | | | | |
| 63052-63055 | | Not used | | | | | |
| 63056-63059 | | Not used | | | | | |
| 63060-63063 | | Not used | | | | | |
| 63064-63071 | | Reserved | | | | | |
| On-board AI Configuration Info | | | | | | | |
| 63068-63071 | | On-board AI Configuration Info | | | | | |
| | +0 | On-board AI type | Bitmap | | UINT16 | R/W | Note 4 |
| | +1 | Number of On-board AIs | 0-32 | | UINT16 | R | |
| | +2 | First On-board AI number | 0-127 | | UINT16 | R | Note 1 |
| | +3 | Last On-board AI number | 0-127 | | UINT16 | R | Note 1 |

| Expansion I/O Modules Type Info | | | | | | | |
|---------------------------------|--|--|-------|--|--------|---|--|
| 63072-63119 | | Expansion I/O Modules Type Info | | | | | |
| +0 | | Number of I/O modules of this type | 0-14 | | UINT16 | R | |
| +1 | | Total number of I/O's of this type | 0-128 | | UINT16 | R | |
| +2 | | Not used | | | UINT16 | R | |
| +3 | | Not used | 0 | | UINT16 | R | |
| 63072-63075 | | DI Module Type Info | | | | | |
| 63076-63079 | | RO Module Type Info | | | | | |
| 63080-63083 | | AI Module Type Info | | | | | |
| 63084-63087 | | AO Module Type Info | | | | | |
| 63088-63119 | | Reserved | | | | | |

NOTES:

1. I/O numbers of expansion I/O modules are automatically assigned in the order of connection. The connection order is counted for each I/O module type separately. If the I/O module position is changed but its order in the chain of the modules of the same type is preserved, then all I/Os on the module will retain their I/O numbers. On the dual AI/AO module, both AI and AO will have same logical I/O range.
2. The type of a module in the corresponding slot position, number of I/Os on the module and their I/O numbers can be read through the I/O Slots Configuration Info registers. I/O module type register contains bit-mapped information on the module type and its options in bits D7:D0 as shown in the Table below.

3.8.1 I/O Module Type

| Module | Options | D7 | D6 | D5 | D4 | D3 | D2 | D1 | D0 |
|--------------|---------------|----|----|----|----|----|----|----|----|
| 8DI | | 0 | 0 | 0 | 0 | 1 | 0 | 0 | 0 |
| 4DI/2DO | | 0 | 0 | 0 | 1 | 0 | 0 | 0 | 0 |
| 4AI | ±1 mA | 0 | 0 | 1 | 0 | 1 | 0 | 0 | 0 |
| 4AI | 0-20 mA | 0 | 0 | 1 | 0 | 1 | 0 | 0 | 1 |
| 4AI | 4-20 mA | 0 | 0 | 1 | 0 | 1 | 0 | 1 | 0 |
| 4AI | 0-1 mA | 0 | 0 | 1 | 0 | 1 | 0 | 1 | 1 |
| 4AI | 0-50 mA | 0 | 0 | 1 | 0 | 1 | 1 | 0 | 0 |
| 4AI | ±10 V | 0 | 0 | 1 | 0 | 1 | 1 | 0 | 1 |
| 4AO | ±1 mA | 0 | 0 | 1 | 1 | 0 | 0 | 0 | 0 |
| 4AO | 0-20 mA | 0 | 0 | 1 | 1 | 0 | 0 | 0 | 1 |
| 4AO | 4-20 mA | 0 | 0 | 1 | 1 | 0 | 0 | 1 | 0 |
| 4AO | 0-1 mA | 0 | 0 | 1 | 1 | 0 | 0 | 1 | 1 |
| Universal CT | 1 A | 0 | 0 | 1 | 1 | 1 | 0 | 0 | 0 |
| Universal CT | 5 A | 0 | 0 | 1 | 1 | 1 | 0 | 0 | 1 |
| Universal CT | EXT.CT | 0 | 0 | 1 | 1 | 1 | 0 | 1 | 0 |
| Universal CT | HACS | 0 | 0 | 1 | 1 | 1 | 0 | 1 | 1 |
| Universal CT | PTS | 0 | 0 | 1 | 1 | 1 | 1 | 0 | 0 |
| Universal CT | CURRENT CLAMP | 0 | 0 | 1 | 1 | 1 | 1 | 0 | 1 |
| Ethernet TX | | 1 | 0 | 0 | 0 | 0 | 0 | 0 | 1 |

| Module | Options | D7 | D6 | D5 | D4 | D3 | D2 | D1 | D0 |
|---|---------|----|----|----|----|----|----|----|----|
| Profibus (COM5) | | 1 | 0 | 0 | 0 | 0 | 0 | 1 | 0 |
| Wireless WiFi (COM5) + BLE | | 1 | 0 | 0 | 0 | 0 | 0 | 1 | 1 |
| Wireless Cellular GSM/GPRS Telit (COM5) | | 1 | 0 | 0 | 0 | 0 | 1 | 0 | 0 |
| Wireless Cellular Verizon Telit (COM5) | | 1 | 0 | 0 | 0 | 0 | 1 | 1 | 0 |
| IRIG-B + RS-422/485 (COM2) | | 1 | 0 | 0 | 0 | 0 | 1 | 1 | 1 |
| CANopen | | 1 | 0 | 0 | 0 | 1 | 0 | 0 | 0 |
| Empty slot | | 1 | 1 | 1 | 1 | 1 | 1 | 1 | 1 |

3. The same de-bounce time is used for each group of eight adjacent digital inputs. To assign de-bounce time for a group, write the desired value into the setup register for the first DI in the group, e.g., DI1, DI9, DI17 and so on. The device will assign this value to the following seven inputs automatically. Any attempt to change de-bounce time for an input that is not the first in the group will be ignored. No error will occur.

3.9 File Transfer Blocks

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|-------------------------------------|----------|---|---|-----------|--------|-----|---|
| File Transfer Control Blocks | | | | | | | |
| 63120-63151 | | File Request Block | | | | | |
| +0 | | File function | 1 = ACK - acknowledgement 3 = set file position 5 = reset file position 7 = find 11 = read file 127 = erase file | | UINT16 | R/W | 1 - clears the file transfer block 3 - changes the file position 5 - sets the file position at the first (oldest) record 7 - finds a record matching an event or/and time (see Note 3) 11 - opens the file for reading from the present file position |
| +1 | | File ID | F2 | | UINT16 | R/W | |
| +2 | | Section number (functions 3, 5, 11) | 0-31, 0xFFFF = use channel ID | | UINT16 | R/W | |
| +3 | | Section channel ID (functions 3, 5, 11) | F6, F7 | | UINT16 | R/W | |
| +4 | | Record sequence number (functions 3, 11) | 0-65535 | | UINT16 | R/W | The record sequence number with function 11 does not change the file position (see Note 2). |
| +5 | | Request variation (function 11) | 0, 4 | | UINT16 | R/W | See file response headings |
| +6 | | Find key: Event type | F22 | | UINT16 | R/W | Note 3 |
| +7 | | Find key: Event number | 1 - 65535 | | UINT16 | R/W | Note 3 |
| +8, 9 | | Find key: Start time, seconds since 1/1/1970 | F1 | sec | UINT32 | R/W | Note 3 |
| +10, 11 | | Find key: Start time, fractional seconds in μ sec | | μ sec | UINT32 | R/W | Note 3 |
| +12, 13 | | Find key: End time, seconds since 1/1/1970 | F1 | sec | UINT32 | R/W | Note 3 |
| +14, 15 | | Find key: End time, fractional seconds in μ sec | | μ sec | UINT32 | R/W | Note 3 |
| +16-31 | | Reserved | | | UINT16 | R/W | |
| 63152-64943 | | File Response Block | | | | | |
| | | Data transfer area [0 – 1791] | | | UINT16 | R | |
| 64944-64951 | | File Info Request Block | | | | | |
| +0 | | File function | 9 = read file info | | UINT16 | R/W | |
| +1 | | File ID | F2 | | UINT16 | R/W | |
| +2 | | Section number | 0-31, 0xFFFF = use channel ID | | UINT16 | R/W | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|-------------|----------|---------------------------------|---------------|-------|--------|-----|-------|
| +3 | | Section channel ID | F6, F7 | | UINT16 | R/W | |
| +4 | | Not used | 0 | | UINT16 | R/W | |
| +5 | | Request variation | 0, 1, 2 | | UINT16 | R/W | |
| +6-7 | | Reserved | | | UINT16 | R/W | |
| 64952-65151 | | File Info Response Block | | | | | |
| | | Data transfer area [0 - 199] | | | UINT16 | R | |

NOTES:

1. File sections for partitioned (multi-section) files, such as TOU profile log files and waveform log files, can be requested either by a section number, or by a section channel ID. If a section number is set to 0xFFFF, the section channel ID will be used to identify the section. The section number will be returned in the response block. If a section number is written, then the corresponding channel ID will be returned in the file response block.
2. The record sequence number with function 11 (Read-File) does not change the file position and is used only as a reference to track the order of records. The file transfer block will continue to hold the same data until it is acknowledged, or until the file position is explicitly moved to another record. For multi-section Waveform files that use a single read pointer for all file sections, the Read-File request, which addresses a different file section, will refill the transfer block with data of the record from the requested file section with the identical sequence number. After acknowledgment, the file position will be moved to the next record.
3. Function 7 (Find) puts into the file request block the sequence number of the first record in the file that matches the event or/and the time. If the file ID is set to 0xFFFF, the device will search for the desired record in the waveform file that is preset by default for the fault and power quality recorders or a setpoint, depending on the event type. The file ID where a record is found is returned in the file response block header. Any one of the find keys can be omitted by setting it to 0. If one or a number of find keys are omitted, the device will use the remaining keys to locate the matching record. If the record could not be found, the device responds to the write request with the exception code 3 (illegal data). The status of the operation can be read through the file status word in the file info block.

3.9.1 File Response Blocks

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|---|----------|--|---------------|-------|--------|-----|--------------------------|
| File Info Response Block (Variation 0 – File info) | | | | | | | |
| 64952-64959 | | Block Heading | | | | | |
| +0 | | File function | 9 | | UINT16 | R | |
| +1 | | File ID | F2 | | UINT16 | R | |
| +2 | | Section number | 0-31 | | UINT16 | R | |
| +3 | | Section channel ID | F6, F7 | | UINT16 | R | |
| +4 | | Number of records in the block | 1 | | UINT16 | R | |
| +5 | | Record size, words | 36 | | UINT16 | R | |
| +6 | | Request variation | 0 | | UINT16 | R | |
| +7 | | Reserved | 0 | | UINT16 | R | |
| 64960-64997 | | File Info | | | | | |
| +0 | | File type | 0 | | UINT16 | R | |
| +1 | | File attributes | F3 | | UINT16 | R | |
| +2 | | File (section) status | F4 | | UNT16 | R | |
| +3 | | Number of sections in the file | 0-32 | | UINT16 | R | 0 = non-partitioned file |
| +4,5 | | File channel mask (channels 1-32), bitmap | F8, F9 | | UINT32 | R | |
| +6,7 | | File channel mask (channels 33-64), bitmap | F8, F9 | | UINT32 | R | |
| +8 | | Number of records in the file | 0-65535 | | UINT16 | R | |
| +9 | | Number of records until the end of the file | 0-65535 | | UINT16 | R | |
| +10 | | Current record (read position) sequence number | 0-65535 | | UINT16 | R | |
| +11 | | Current write position sequence number | 0-65535 | | UINT16 | R | |
| +12 | | First (oldest) record sequence number | 0-65535 | | UINT16 | R | |
| +13 | | Last (newest) record sequence number | 0-65535 | | UINT16 | R | |
| +14,15 | | Last record time, seconds since 1/1/1970 | F1 | sec | UINT32 | R | |
| +16,17 | | Last record time, fractional seconds | | µsec | UINT32 | R | |
| +18,19 | | First record time, seconds since 1/1/1970 | F1 | sec | UINT32 | R | |
| +20,21 | | First record time, fractional seconds | | µsec | UINT32 | R | |
| +22,23 | | Creation time, seconds since 1/1/1970 | F1 | sec | UINT32 | R | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|---|----------|--|---------------|-------|--------|-----|-------|
| +24,25 | | Creation time, fractional seconds | | µsec | UINT32 | R | |
| +26,27 | | Reset time, seconds since 1/1/1970 | F1 | sec | UINT32 | R | |
| +28,29 | | Reset time, fractional seconds | | µsec | UINT32 | R | |
| +30 | | Maximum number of records | 0-65535 | | UINT16 | R | |
| +31 | | Number of parameters per data section record | 0-52 | | UINT16 | R | |
| +32 | | Section record size, bytes | | Byte | UINT16 | R | |
| +33 | | File record size, bytes | | Byte | UINT16 | R | |
| +34,35 | | Allocated file size, bytes | | Byte | UINT32 | R | |
| File Info Response Block (Variation 1 – Current record info) | | | | | | | |
| 64952-64959 | | Block Heading | | | | | |
| +0 | | File function | 9 | | UINT16 | R | |
| +1 | | File ID | F2 | | UINT16 | R | |
| +2 | | Section number | 0-31 | | UINT16 | R | |
| +3 | | Section channel ID | F6, F7 | | UINT16 | R | |
| +4 | | Number of records in the block | 1 | | UINT16 | R | |
| +5 | | Record size, words | 8 | | UINT16 | R | |
| +6 | | Request variation | 1 | | UINT16 | R | |
| +7 | | Reserved | 0 | | UINT16 | R | |
| 64960-64997 | | File Info | | | | | |
| +0 | | File (section) status | F4 | | UINT16 | R | |
| +1 | | Number of records in the file | 0-65535 | | UINT16 | R | |
| +2 | | Number of records until the end of the file | 0-65535 | | UINT16 | R | |
| +3 | | Current record (read position) sequence number | 0-65535 | | UINT16 | R | |
| +4,5 | | Current record time, seconds since 1/1/1970 | F1 | sec | UINT32 | R | |
| +6,7 | | Current record time, fractional seconds | | µsec | UINT32 | R | |
| File Info Response Block (Variation 2 – Data log record structure) | | | | | | | |
| 64952-64959 | | Block Heading | | | | | |
| +0 | | File function | 9 | | UINT16 | R | |
| +1 | | File ID | 1-16 | | UINT16 | R | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|---------------------------------|----------|-----------------------------------|---|-------|--------|-----|-------|
| | +2 | Section number | 0-15 | | UINT16 | R | |
| | +3 | Section channel ID | F6, F7 | | UINT16 | R | |
| | +4 | Number of records in the block | 1 | | UINT16 | R | |
| | +5 | Record size, words | 2 + Number of parameters | | UINT16 | R | |
| | +6 | Request variation | 2 | | UINT16 | R | |
| | +7 | Reserved | 0 | | UINT16 | R | |
| 64960-65151 | | File Info | | | | | |
| | +0 | Not used | 0 | | UINT16 | R | |
| | +1 | Number of fields in a data record | Regular files: 1-16 Special files: EN 50160:2007 Compliance = 34 EN 50160:2007 Harmonics = 52 EN 50160:2010 Compliance = 36 EN 50160:2010 Harmonics = 98 GOST 13109 Compliance = 40 GOST 13109 Harmonics = 80 GOST 32144 Compliance = 42 GOST 32144 Harmonics = 80 | | UINT16 | R | |
| | +2 | Field 1 parameter ID | 0-0xFFFF | | UINT16 | R | |
| | +3 | Field 2 parameter ID | 0-0xFFFF | | UINT16 | R | |
| | ... | ... | | | | | |
| Event Log Response Block | | | | | | | |
| 63152-63159 | | Block Heading | | | | | |
| | +0 | Last file function | 1, 3, 5, 11 | | UINT16 | R | |
| | +1 | File ID | 0 | | UINT16 | R | |
| | +2 | Section number | 0 | | UINT16 | R | |
| | +3 | Section channel ID | 0 | | UINT16 | R | |
| | +4 | Number of records in the block | 1-32 | | UINT16 | R | |
| | +5 | Record size, words | 12 | | UINT16 | R | |
| | +6 | Request variation | 0 | | UINT16 | R | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|--------------------------------|----------|---|--|-----------|--------|-----|-------|
| +7 | | Reserved | 0 | | UINT16 | R | |
| 63160-63543 | | Event Log Records | | | | | |
| +0 | | Record status | F5 | | INT16 | R | |
| +1 | | Record sequence number | 0-65535 | | UINT16 | R | |
| +2, 3 | | Trigger time, seconds since 1/1/1970 | F1 | sec | UINT32 | R | |
| +4, 5 | | Trigger time, fractional seconds in μ sec | | μ sec | UINT32 | R | |
| +6 | | Event number | 1-65535 | | UINT16 | R | |
| +7 | | Event point/source ID | F19 | | UINT16 | R | |
| +8 | | Event effect | F20 | | UINT16 | R | |
| +9 | | Reserved | 0 | | UINT16 | R | |
| +10,11 | | Value triggered | | | INT32 | R | |
| 63160-63171 | | Record #1 | | | | | |
| | | ... | | | | | |
| 63532-63543 | | Record #32 | | | | | |
| Data Log Response Block | | | | | | | |
| 63152-63159 | | Block Heading | | | | | |
| +0 | | Last file function | 1, 3, 5, 11 | | UINT16 | R | |
| +1 | | File ID | 1-16 (F2) | | UINT16 | R | |
| +2 | | Section number | 0-31 | | UINT16 | R | |
| +3 | | Section channel ID | F6 | | UINT16 | R | |
| +4 | | Number of records in the block | 1-32 | | UINT16 | R | |
| +5 | | Record size, words | 8 + 2 \times Number of parameters | | UINT16 | R | |
| +6 | | Request variation | 0 = regular log, 4 = EN50160/GOST 13109/GOST 32144 online statistics (with file ID = 9, 10) | | UINT16 | R | |
| +7 | | Reserved | 0 | | UINT16 | R | |
| 63160-64439 | | Data Log Records | | | | | |
| +0 | | Record status | F5 | | INT16 | R | |
| +1 | | Record sequence number | 0-65535 | | UINT16 | R | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|------------------------------------|----------|--|-----------------|-----------|--------|-----|-------|
| +2,3 | | Record time, seconds since 1/1/1970 | F1 | sec | UINT32 | R | |
| +4,5 | | Record time, fractional seconds in μ sec | | μ sec | UINT32 | R | |
| +6 | | Trigger event type | F22 | | INT16 | R | |
| +7 | | Trigger event number | 1-65535 | | UINT16 | R | |
| +8,9 | | Log value #1 | | | INT32 | R | |
| +10,11 | | Log value #2 | | | INT32 | R | |
| ... | | ... | | | | R | |
| 63160-... | | Record #1 (variable length) | | | | | |
| | | ... | | | | | |
| | | Record #32 (variable length) | | | | | |
| Waveform Log Response Block | | | | | | | |
| 63152-63159 | | Block Heading | | | | | |
| +0 | | Last file function | 1, 3, 5, 11 | | UINT16 | R | |
| +1 | | File ID | 17-24, 128 (F2) | | UINT16 | R | |
| +2 | | Section number | 0-27 | | UINT16 | R | |
| +3 | | Section channel ID | F7 | | UINT16 | R | |
| +4 | | Number of records in the block | 1 | | UINT16 | R | |
| +5 | | Record size, words | 640 | | UINT16 | R | |
| +6 | | Request variation | 0 | | UINT16 | R | |
| +7 | | Reserved | 0 | | UINT16 | R | |
| 63160-63799 | | Waveform Log Record | | | | | |
| +0 | | Record status | F5 | | INT16 | R | |
| +1 | | Record sequence number | 0 - 65535 | | UINT16 | R | |
| +2,3 | | Start time, seconds since 1/1/1970 | F1 | sec | UINT32 | R | |
| +4,5 | | Start time, fractional seconds | | μ sec | UINT32 | R | |
| +6,7 | | Trigger time, seconds since 1/1/1970 | F1 | sec | UINT32 | R | |
| +8,9 | | Trigger time, fractional seconds | | μ sec | UINT32 | R | |
| +10 | | Record series number | 1-65535 | | UINT16 | R | |
| +11 | | Record serial number in a series | 0-65535 | | UINT16 | R | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|--|----------|--|---------------------------------|---------------------------|--------|-----|--------------|
| +12 | | Trigger event type | F22 | | UINT16 | R | |
| +13 | | Trigger event number | 1-65535 | | UINT16 | R | |
| +14 | | Source point ID (generic) | See Generic Data in Section 3.4 | | UINT16 | R | |
| +15 | | Trigger reference sample index | 0-511 | | UINT16 | R | |
| +16 | | Sampling rate, $\mu\text{sec/sample}$ | 600-27000 | $\times 0.1\mu\text{sec}$ | UINT16 | R | |
| +17 | | Sampling rate, samples/cycle | 16, 32, 64, 128, 256 | | UINT16 | R | |
| +18 | | Sampling frequency | 4500-6500 | $\times 0.01\text{Hz}$ | UINT16 | R | |
| +19 | | Channel offset, sampling units | +/-32767 | | INT16 | R | |
| +20,21 | | Channel multiplier, primary units | See Generic Data in Section 3.4 | | UINT32 | R | |
| +22 | | Channel divisor, sampling units | 2147-16383 | | UINT16 | R | |
| +23 | | Length of a sample series, data points | 64-512 | | UINT16 | R | |
| +24 | | Channel skew | 0-1000 | μsec | INT16 | R | |
| +25-127 | | Not used | 0 | | UINT16 | R | |
| +128 | | Sample Series | | | | | |
| +128-639 | | Sample data series points [0...511] | +/-16383 | | INT16 | R | ¹ |
| Power Quality (PQ) Log Response Block | | | | | | | |
| 63152-63159 | | Block Heading | | | | | |
| +0 | | Last file function | 1, 3, 5, 11 | | UINT16 | R | |
| +1 | | File ID | 26 | | UINT16 | R | |
| +2 | | Section number | 0 | | UINT16 | R | |
| +3 | | Section channel ID | 0 | | UINT16 | R | |
| +4 | | Number of records in the block | 1 -32 | | UINT16 | R | |
| +5 | | Record size, words | 18 | | UINT16 | R | |
| +6 | | Request variation | 0 | | UINT16 | R | |
| +7 | | Reserved | 0 | | UINT16 | R | |
| 63160-63799 | | PQ Log Records | | | | | |
| +0 | | Record status | F5 | | INT16 | R | |
| +1 | | Record sequence number | 0-65535 | | UINT16 | R | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|-------------|----------|---|---------------------------------|-----------|--------|-----|-------|
| +2,3 | | Start time, seconds since 1/1/1970 | F1 | sec | UINT32 | R | |
| +4,5 | | Start time, fractional seconds in μ sec | | μ sec | UINT32 | R | |
| +6,7 | | End time, seconds since 1/1/1970 | F1 | sec | UINT32 | R | |
| +8,9 | | End time, fractional seconds in μ sec | | μ sec | UINT32 | R | |
| +10 | | PQ event type | F22 | | UINT16 | R | |
| +11 | | PQ event number | 1-65535 | | UINT16 | R | |
| +12 | | Point ID (generic) | See Generic Data in Section 3.4 | | UINT16 | R | |
| +13 | | Reserved | 0 | | UINT16 | R | |
| +14,15 | | Value reference (base), primary units | See Generic Data in Section 3.4 | | INT32 | R | |
| +16,17 | | Value magnitude, primary units | See Generic Data in Section 3.4 | | INT32 | R | |
| 63160-63179 | | Record #1 | | | | | |
| | | ... | | | | | |
| 63780-63799 | | Record #32 | | | | | |

To restore the original sampled data in the channel units (e.g., Volts, Amps), the following conversion should be applied:

$$\text{Sampled Data [primary units]} = \frac{(\text{Data Sample} - \text{Channel Offset}) \times \text{Channel Multiplier}}{\text{Channel Divisor}}$$

3.9.2 File Response Block Alias

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|--|----------|---|---------------|-----------|--------|-----|----------------------------|
| File Response Block Alias | | | | | | | |
| 3072-3079 | | Block Heading | | | | | |
| +0 | | File function | 11 | | UINT16 | R | |
| +1 | | File ID | 0, 25, 26, 27 | | UINT16 | R/W | |
| +2 | | Section number | 0 | | UINT16 | R | |
| +3 | | Section channel ID | 0 | | UINT16 | R | |
| +4 | | Number of records in the block | 1 - 10 | | UINT16 | R/W | Write: sets the block size |
| +5 | | Record size, words | 18 | | UINT16 | R | |
| +6 | | Request variation | 0 | | UINT16 | R | |
| +7 | | Reserved | 0 | | UINT16 | R | |
| 3080-3583 | | Last 1-10 file records | | | | | |
| Power Quality (PQ) Log Response Block Alias | | | | | | | |
| 3072-3079 | | Block Heading | | | | | |
| +0 | | File function | 11 | | UINT16 | R | |
| +1 | | File ID | 26 | | UINT16 | R/W | |
| +2 | | Section number | 0 | | UINT16 | R | |
| +3 | | Section channel ID | 0 | | UINT16 | R | |
| +4 | | Number of records in the block | 1 - 10 | | UINT16 | R/W | Write: sets the block size |
| +5 | | Record size, words | 18 | | UINT16 | R | |
| +6 | | Request variation | 0 | | UINT16 | R | |
| +7 | | Reserved | 0 | | UINT16 | R | |
| 3080-3259 | | PQ Log Records | | | | | |
| +0 | | Record status | F5 | | INT16 | R | |
| +1 | | Record sequence number | 0 - 65535 | | UINT16 | R | |
| +2,3 | | Start time, seconds since 1/1/1970 | F1 | sec | UINT32 | R | |
| +4,5 | | Start time, fractional seconds in μ sec | | μ sec | UINT32 | R | |
| +6,7 | | End time, seconds since 1/1/1970 | F1 | sec | UINT32 | R | |
| +8,9 | | End time, fractional seconds in μ sec | | μ sec | UINT32 | R | |

| Address | Point ID | Description | Options/Range | Units | Type | R/W | Notes |
|-----------|----------|---------------------------------------|---------------------------------|-------|--------|-----|-------|
| +10 | | PQ event type | F22 | | UINT16 | R | |
| +11 | | PQ event number | 1 - 65535 | | UINT16 | R | |
| +12 | | Point ID (generic) | See Generic Data in Section 3.4 | | UINT16 | R | |
| +13 | | Reserved | 0 | | UINT16 | R | |
| +14, 15 | | Value reference (base), primary units | See Generic Data in Section 3.4 | | INT32 | R | |
| +16, 17 | | Value magnitude, primary units | See Generic Data in Section 3.4 | | INT32 | R | |
| 3080-3097 | | Record #1 | | | | | |
| | | ... | | | | | |
| 3242-3259 | | Record #10 | | | | | |

The block of registers 3072-3583 is the alias for the common file response block. It is intended for continuous polling of the last 1 to 10 records of the event files (Event Log, SOE Log, PQ Log or Fault Log) from SCADA systems. The alias block is preset at factory to provide access to the last ten PQ Log records. You can change factory assignments to point to another log file or change the number of the records in the transfer block by re-writing of the corresponding registers in the block heading. To update records in the alias block, at least one of the block heading registers 3072-3079 must be read first.

NOTES:

1. Registers 3080-3259 share the same data transfer buffer as the common file transfer block registers 63152-64943. Reading data from the common transfer block within the same connection session can destroy data in the alias transfer block. To guarantee that the alias block contains correct data, always read block heading registers 3072-3079 before accessing data records in the alias block.
2. If you read the block through a TCP connection and change a file ID or the number of records in the block, your assignments for the transfer block will be effective only within the current connection socket. Since the device cannot guarantee that your next connection will be made through the same socket, you should not make any assumptions regarding the present block settings. When you open a new connection, always check the block heading before accessing data records.

¹ When the 4LN3 or 3LN3 wiring mode is selected, the voltages will be line-to-neutral; for any other wiring mode, they will be line-to-line voltages.

3.10 Billing/TOU Daily and Monthly Profile Data Logs

| File Channel/Section ¹ | Record Field No. ² | Point Label | Point ID | Description | Range | Units ³ | Type | Notes |
|-----------------------------------|-------------------------------|-------------|----------|--------------------------------|---------------|--------------------|--------|-------|
| 0/0 | | | | Energy Register #1 | | | | |
| | 1 | REG1 | 0x1780 | Summary (total) energy reading | 0-999,999,999 | U5 | UINT32 | |
| | 2 | TRF1 | 0x7000 | Tariff #1 energy reading | 0-999,999,999 | U5 | UINT32 | |
| | 3 | TRF2 | 0x7001 | Tariff #2 energy reading | 0-999,999,999 | U5 | UINT32 | |
| | 4 | TRF3 | 0x7002 | Tariff #3 energy reading | 0-999,999,999 | U5 | UINT32 | |
| | 5 | TRF4 | 0x7003 | Tariff #4 energy reading | 0-999,999,999 | U5 | UINT32 | |
| | 6 | TRF5 | 0x7004 | Tariff #5 energy reading | 0-999,999,999 | U5 | UINT32 | |
| | 7 | TRF6 | 0x7005 | Tariff #6 energy reading | 0-999,999,999 | U5 | UINT32 | |
| | 8 | TRF7 | 0x7006 | Tariff #7 energy reading | 0-999,999,999 | U5 | UINT32 | |
| | 9 | TRF8 | 0x7007 | Tariff #8 energy reading | 0-999,999,999 | U5 | UINT32 | |
| | 10 | TRF9 | 0x7008 | Tariff #9 energy reading | 0-999,999,999 | U5 | UINT32 | |
| | 11 | TRF10 | 0x7009 | Tariff #10 energy reading | 0-999,999,999 | U5 | UINT32 | |
| | 12 | TRF11 | 0x700A | Tariff #11 energy reading | 0-999,999,999 | U5 | UINT32 | |
| | 13 | TRF12 | 0x700B | Tariff #12 energy reading | 0-999,999,999 | U5 | UINT32 | |
| | 14 | TRF13 | 0x700C | Tariff #13 energy reading | 0-999,999,999 | U5 | UINT32 | |
| | 15 | TRF14 | 0x700D | Tariff #14 energy reading | 0-999,999,999 | U5 | UINT32 | |
| | 16 | TRF15 | 0x700E | Tariff #15 energy reading | 0-999,999,999 | U5 | UINT32 | |
| | 17 | TRF16 | 0x700F | Tariff #16 energy reading | 0-999,999,999 | U5 | UINT32 | |
| ... | | | | ... | | | | |
| 15/15 | | | | Energy Register #16 | | | | |
| | 1 | REG16 | 0x178F | Summary (total) energy reading | 0-999,999,999 | U5 | UINT32 | |
| | 2 | TRF1 | 0x7000 | Tariff #1 energy reading | 0-999,999,999 | U5 | UINT32 | |
| | 3 | TRF2 | 0x7001 | Tariff #2 energy reading | 0-999,999,999 | U5 | UINT32 | |
| | 4 | TRF3 | 0x7002 | Tariff #3 energy reading | 0-999,999,999 | U5 | UINT32 | |
| | 5 | TRF4 | 0x7003 | Tariff #4 energy reading | 0-999,999,999 | U5 | UINT32 | |
| | 6 | TRF5 | 0x7004 | Tariff #5 energy reading | 0-999,999,999 | U5 | UINT32 | |
| | 7 | TRF6 | 0x7005 | Tariff #6 energy reading | 0-999,999,999 | U5 | UINT32 | |
| | 8 | TRF7 | 0x7006 | Tariff #7 energy reading | 0-999,999,999 | U5 | UINT32 | |

| File Channel/Section ¹ | Record Field No. ² | Point Label | Point ID | Description | Range | Units ³ | Type | Notes |
|-----------------------------------|-------------------------------|-------------|----------|-------------------------------------|---------------|--------------------|--------|-------|
| | 9 | TRF8 | 0x7007 | Tariff #8 energy reading | 0-999,999,999 | U5 | UINT32 | |
| | 10 | TRF9 | 0x7008 | Tariff #9 energy reading | 0-999,999,999 | U5 | UINT32 | |
| | 11 | TRF10 | 0x7009 | Tariff #10 energy reading | 0-999,999,999 | U5 | UINT32 | |
| | 12 | TRF11 | 0x700A | Tariff #11 energy reading | 0-999,999,999 | U5 | UINT32 | |
| | 13 | TRF12 | 0x700B | Tariff #12 energy reading | 0-999,999,999 | U5 | UINT32 | |
| | 14 | TRF13 | 0x700C | Tariff #13 energy reading | 0-999,999,999 | U5 | UINT32 | |
| | 15 | TRF14 | 0x700D | Tariff #14 energy reading | 0-999,999,999 | U5 | UINT32 | |
| | 16 | TRF15 | 0x700E | Tariff #15 energy reading | 0-999,999,999 | U5 | UINT32 | |
| | 17 | TRF16 | 0x700F | Tariff #16 energy reading | 0-999,999,999 | U5 | UINT32 | |
| 16/16 | | | | Maximum Demand Register #1 | | | | |
| | 1 | REG1 MD | 0x4780 | Summary (total) max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 2 | TRF1 MD | 0x7100 | Tariff #1 max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 3 | TRF2 MD | 0x7101 | Tariff #2 max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 4 | TRF3 MD | 0x7102 | Tariff #3 max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 5 | TRF4 MD | 0x7103 | Tariff #4 max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 6 | TRF5 MD | 0x7104 | Tariff #5 max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 7 | TRF6 MD | 0x7105 | Tariff #6 max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 8 | TRF7 MD | 0x7106 | Tariff #7 max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 9 | TRF8 MD | 0x7107 | Tariff #8 max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 10 | TRF9 MD | 0x7108 | Tariff #9 max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 11 | TRF10 MD | 0x7109 | Tariff #10 max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 12 | TRF11 MD | 0x710A | Tariff #11 max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 13 | TRF12 MD | 0x710B | Tariff #12 max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 14 | TRF13 MD | 0x710C | Tariff #13 max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 15 | TRF14 MD | 0x710D | Tariff #14 max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 16 | TRF15 MD | 0x710E | Tariff #15 max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 17 | TRF16 MD | 0x710F | Tariff #16 max. demand reading | 0-Pmax | U3 | UINT32 | |
| ... | | | | ... | | | | |
| 32/32 | | | | Maximum Demand Register #16 | | | | |

| File Channel/Section ¹ | Record Field No. ² | Point Label | Point ID | Description | Range | Units ³ | Type | Notes |
|-----------------------------------|-------------------------------|-------------|----------|-------------------------------------|--------|--------------------|--------|-------|
| | 1 | REG16 MD | 0x478F | Summary (total) max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 2 | TRF1 MD | 0x7100 | Tariff #1 max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 3 | TRF2 MD | 0x7101 | Tariff #2 max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 4 | TRF3 MD | 0x7102 | Tariff #3 max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 5 | TRF4 MD | 0x7103 | Tariff #4 max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 6 | TRF5 MD | 0x7104 | Tariff #5 max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 7 | TRF6 MD | 0x7105 | Tariff #6 max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 8 | TRF7 MD | 0x7106 | Tariff #7 max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 9 | TRF8 MD | 0x7107 | Tariff #8 max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 10 | TRF9 MD | 0x7108 | Tariff #9 max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 11 | TRF10 MD | 0x7109 | Tariff #10 max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 12 | TRF11 MD | 0x710A | Tariff #11 max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 13 | TRF12 MD | 0x710B | Tariff #12 max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 14 | TRF13 MD | 0x710C | Tariff #13 max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 15 | TRF14 MD | 0x710D | Tariff #14 max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 16 | TRF15 MD | 0x710E | Tariff #15 max. demand reading | 0-Pmax | U3 | UINT32 | |
| | 17 | TRF16 MD | 0x710F | Tariff #16 max. demand reading | 0-Pmax | U3 | UINT32 | |

¹An energy use profile section and a maximum demand profile section are allocated for registers for which a source input is selected in the Billing/TOU Register setup and for which energy use profile is enabled. A maximum demand profile section is allocated for registers for which maximum demand profile is enabled in the Billing/TOU Register setup. Not configured sections/channels are not available for download. Refer to the file channel mask in the file info for configured channels.

²The number of parameters in a section is automatically configured depending on the number of actually used tariffs selected in the TOU Daily Profiles.

³For power scale and units, refer to Section 4 "Data Scales and Units".

Chapter 4 Data Scales and Units

| Code | Condition | Value/Range | Notes |
|--|--------------|---|-------|
| Data Scales | | | |
| Vmax | | Voltage Scale × PT Ratio, V | 2 |
| V4max | | Voltage Scale × V4 PT Ratio, V | 2 |
| I _{max} | | Current Scale × CT Ratio ¹ , A, | 3 |
| I _{4max} | | Current Scale × I4 CT Ratio ¹ , A, | 3 |
| I _{xmax} | 1A secondary | 20 × CT Ratio ¹ , A (CT card) 40 × CT Ratio ¹ , A (DFRM) | |
| | 5A secondary | 100 × CT Ratio ¹ , A (CT card) 200 × CT Ratio ¹ , A (DFRM) | |
| I _{4xmax} | 1A secondary | 20 × I4x CT Ratio ¹ , A (CT card) 40 × I4x CT Ratio ¹ , A (DFRM) | |
| | 5A secondary | 100 × I4x CT Ratio ¹ , A (CT card) 200 × I4x CT Ratio ¹ , A (DFRM) | |
| P _{max} | PT Ratio = 1 | V _{max} × I _{max} × 2, W | 4 |
| | PT Ratio > 1 | (V _{max} × I _{max} × 2)/1000, kW | |
| Al _{min} Al _{max} | +/-1mA | Al _{min} = -Al full scale × 2 Al _{max} = Al full scale × 2 | |
| | 0-20mA | Al _{min} = Al zero scale Al _{max} = Al full scale | |
| | 4-20mA | Al _{min} = Al zero scale Al _{max} = Al full scale | |
| | 0-1mA | Al _{min} = Al zero scale Al _{max} = Al full scale | |
| | 0-50mA | Al _{min} = Al zero scale Al _{max} = Al full scale × 2 | |
| | +/-10V | Al _{min} = -Al full scale Al _{max} = Al full scale | |
| Data Units | | | |
| U1 | PT Ratio = 1 | 0.1V | |
| | PT Ratio > 1 | 1V | |
| U2 | | 0.01A | |
| U3 | PT Ratio = 1 | 1W/Var/VA | |
| | PT Ratio > 1 | 1kW/kvar/kVA | |
| U4 | Not used | Not used | |
| | Not used | Not used | |
| U5 | | 0.001, 0.01, 0.1, 1 kWh/kVAh/kvarh (programmable) | 5 |

¹ CT Ratio = CT primary current/CT secondary current

² The default Voltage Scale is 828V. You can change it via the Modbus Setup registers (see Section 3.1) or via the Device Options setup in PAS.

³ The default Current Scale is 4 × CT secondary current for devices with a 400% overload (ANSI) or 2 × CT secondary current for devices with a 200% overload (IEC). You can change it via the Modbus Setup registers (see Section 3.1) or via the Device Options setup in PAS.

⁴ P_{max} is rounded to whole kilowatts. If P_{max} is greater than 9,999,000 W, it is truncated to 9,999,000 W.

⁵ See Energy Decimal Places in the Device Options setup.

Chapter 5 Data Formats

| Format Code | Value | Description | Notes |
|----------------------------------|------------|--|--------------------|
| Timestamp | | | |
| F1 | | Local time in a UNIX-style format. Represents the number of seconds since midnight (00:00:00), January 1, 1970. The time is valid after January 1, 2000. | |
| File ID | | | |
| F2 | 0 | Event log | |
| | 1-8, 11-16 | Data log #1-#8, #11-#16 | |
| | 9 | Data log #9 – EN 50160/GOST 13109/GOST 32144 Compliance Statistics | |
| | 10 | Data log #10 – EN 50160/GOST 13109/GOST 32144 Harmonic Statistics | |
| | 17-24 | Waveform log #1-#8 | |
| | 25 | Not used | |
| | 26 | Power quality (PQ) log | |
| | 27 | Not used | |
| | 128 | Real time waveform capture | |
| File Attributes | | | |
| F3 | Bit 0 = 0 | Non-wrap file (stop when full) | |
| | Bit 0 = 1 | Wrap-around (circular) file | |
| | Bit 1 = 1 | Fixed (non-changeable) file attributes | |
| | Bits 4:7 = | Multi-section data log file attributes: | |
| | 0 | Regular file | |
| | 1 | TOU monthly profile log | Multi-section file |
| | 2 | TOU daily profile log | Multi-section file |
| | 3 | Not used | Multi-section file |
| | 4 | Not used | Multi-section file |
| | 5 | Not used | Multi-section file |
| | 6 | Not used | Multi-section file |
| | 7 | Not used | Multi-section file |
| | 8 | Not used | Multi-section file |
| | 9 | Not used | Multi-section file |
| 10 | Not used | Multi-section file | |
| File Status Word (bitmap) | | | |
| F4 | Bit 0 = 1 | The last record of the file is being read | |
| | Bit 8 = 1 | File is empty | |
| | Bit 9 = 1 | Reading after EOF | |

| Format Code | Value | Description | Notes |
|---|------------|---|-------|
| | Bit 10 = 1 | Corrupted record (CRC error) | |
| | Bit 11 = 1 | No file section found for the requested channel | |
| | Bit 12 = 1 | Reading after the end of a data block | |
| | Bit 13 = 1 | File is not accessible | |
| | Bit 14 = 1 | Record not found | |
| | Bit 15 = 1 | Generic read error (with one of the bits 8-14) | |
| File Record Status Word (bitmap) | | | |
| F5 | Bit 0 = 1 | The last record of the file is being read | |
| | Bit 8 = 1 | File is empty | |
| | Bit 9 = 1 | Reading after EOF | |
| | Bit 10 = 1 | Corrupted record (CRC error) | |
| | Bit 11 = 1 | No file section found for the requested channel | |
| | Bit 12 = 1 | Reading after the end of a data block | |
| | Bit 13 = 1 | File is not accessible | |
| | Bit 14 = 1 | Record not found | |
| | Bit 15 = 1 | Generic read error (with one of the bits 8-14) | |
| Billing/TOU Profile Log Channel ID | | | |
| F6 | 0-15 | Billing/TOU registers #1-#16 | |
| | 16-31 | Billing/TOU maximum demand registers #1-#16 | |
| Waveform Log Channel ID | | | |
| F7 | 0 | V1 | 1 |
| | 1 | V2 | 1 |
| | 2 | V3 | 1 |
| | 3 | Not used | |
| | 4 | I1 | |
| | 5 | I2 | |
| | 6 | I3 | |
| | 7 | I4 | |
| | 8 | Not used | |
| | 9 | Not used | |
| | 10 | Not used | |
| | 11 | Not used | |
| | 12 | Not used | |
| | 13 | DI1-16 | |
| | 14 | Not used | |
| | 15 | Not used | |
| | 16 | AI1 | |

| Format Code | Value | Description | Notes |
|--|---------------|---|-------|
| | 17 | AI2 | |
| | 18 | AI3 | |
| | 19 | AI4 | |
| | 20 | AI5 | |
| | 21 | Not used | |
| | 22 | Not used | |
| | 23 | Not used | |
| | 24 | Not used | |
| | 25 | Not used | |
| | 26 | Not used | |
| | 27 | Not used | |
| | 28 | Not used | |
| | 29 | Not used | |
| | 30 | Not used | |
| 31 | Not used | | |
| Billing/TOU Profile Log Channel Mask (bitmap) | | | |
| F8 | Bit 0:15 = 1 | Billing/TOU energy registers #1-#16 | |
| | Bit 16:31 = 1 | Billing/TOU maximum demand registers #1-#16 | |
| Waveform Log Channel Mask (bitmap) | | | |
| F9 | Bit 0 | Channel V1 | 1 |
| | Bit 1 | Channel V2 | 1 |
| | Bit 2 | Channel V3 | 1 |
| | Bit 3 | Not used | |
| | Bit 4 | Channel I1 | |
| | Bit 5 | Channel I2 | |
| | Bit 6 | Channel I3 | |
| | Bit 7 | Channel I4 | |
| | Bit 8 | Not used | |
| | Bit 9 | Not used | |
| | Bit 10 | Not used | |
| | Bit 11 | Not used | |
| | Bit 12 | Not used | |
| | Bit 13 | Channels DI1-16 | |
| | Bit 14 | Channels DI17-26 | |
| | Bit 15 | Not used | |
| | Bit 16 | Channel AI1 | |
| | Bit 17 | Channel AI2 | |

| Format Code | Value | Description | Notes |
|-----------------------------------|------------------|---------------------------------|-------|
| | Bit 18 | Channel AI3 | |
| | Bit 19 | Channel AI4 | |
| | Bit 20 | Channel AI5 | |
| | Bit 21 | Not used | |
| | Bit 22 | Not used | |
| | Bit 23 | Not used | |
| | Bit 24 | Not used | |
| | Bit 25 | Not used | |
| | Bit 26 | Not used | |
| | Bit 27 | Not used | |
| | Bit 28 | Not used | |
| | Bit 29 | Not used | |
| | Bit 30 | Not used | |
| | Bit 31 | Not used | |
| TOU Tariff Change Time | | | |
| F10 | Bits 8:15 = 0-15 | Tariff number #1-#16 | |
| | Bits 2:7 = 0-23 | Tariff start hour | |
| | Bits 0:1 = 0-3 | Tariff start quarter of an hour | |
| Billing Register Source ID | | | |
| F11 | 0x0000 | None | |
| | 0x0700-0x077F | Pulse input DI1-DI26 | |
| | 0x1700 | kWh import | |
| | 0x1701 | kWh export | |
| | 0x1702 | kWh net | |
| | 0x1703 | kWh total | |
| | 0x1704 | kvarh import | |
| | 0x1705 | kvarh export | |
| | 0x1706 | kvarh net | |
| | 0x1707 | kvarh total | |
| | 0x1708 | kVAh total | |
| | 0x1709 | kVAh import | |
| | 0x170A | kVAh export | |
| | 0x170B | kvarh Q1 | |
| | 0x170C | kvarh Q2 | |
| | 0x170D | kvarh Q3 | |
| | 0x170E | kvarh Q4 | |
| | 0x1800 | kWh L1 import | |

| Format Code | Value | Description | Notes |
|---------------------------------------|---|---|-----------------|
| | 0x1801 | kWh L2 import | |
| | 0x1802 | kWh L3 import | |
| | 0x1809 | kWh L1 export | |
| | 0x180A | kWh L2 export | |
| | 0x180B | kWh L3 export | |
| | 0x1803 | kvarh L1 import | |
| | 0x1804 | kvarh L2 import | |
| | 0x1805 | kvarh L3 import | |
| | 0x180C | kvarh L1 export | |
| | 0x180D | kvarh L2 export | |
| | 0x180E | kvarh L3 export | |
| | 0x1806 | kVAh L1 total | |
| | 0x1807 | kVAh L2 total | |
| | 0x1808 | kVAh L3 total | |
| | 0x1780-0x178F | Billing energy register #1-16 | |
| Setpoint Trigger Parameters ID | | | |
| F12 | 0x0000-0xFFFF | Any data point ID excluding energy counters | See Section 3.4 |
| | 0x0480-0x048F | External trigger #1-#16 (UDP broadcast trigger message) | |
| Setpoint Relational Operator | | | |
| F13 | 0 = NONE | No relation (used with pulsed events) | |
| | 1 = GREATER OR EQUAL | Analog value or counter is over the operate limit | |
| | 2 = LESS OR EQUAL | Analog value or counter is under the operate limit | |
| | 3 = EQUAL | Analog value or counter is equal to the operate limit | |
| | 4 = NOT EQUAL | Analog value or counter is not equal to the operate limit | |
| | 5 = ON | Binary status is 1/ON | |
| | 6 = OFF | Binary status is 0/OFF | |
| | 7 = NEW | New Min/Max value logged for the point | |
| | 8 = Delta | The absolute value of the difference between the last reported value and the current value exceeds the specified threshold | |
| | 12 = Delta+ | Incremental delta - the positive difference between the current value and the last reported value exceeds the specified threshold | |
| 13 = Delta- | Decremental delta - the positive difference between the last reported value and the current value exceeds the specified threshold | | |
| 14 = rDelta | Relative delta - the absolute value of the difference between the last tested value and the current value exceeds the specified threshold | | |

| Format Code | Value | Description | Notes |
|---------------------------|---------------|--|-------|
| | 15 = rDelta+ | Incremental relative delta - the positive difference between the current value and the last tested value exceeds the specified threshold | |
| | 16 = rDelta- | Decremental relative delta - the positive difference between the last tested value and the current value exceeds the specified threshold | |
| Setpoint Action ID | | | |
| F14 | 0x0000 | No action | |
| | 0x2000-0x203F | Set user event flag #1-#64 | |
| | 0x2100-0x213F | Clear user event flag #1-#64 | |
| | 0x3000-0x303F | Operate relay RO1-RO64 | |
| | 0x3100-0x313F | Release latched relay RO1-RO64 | |
| | 0x3700-0x373F | Unblock relay RO1-RO64 | |
| | 0x3800-0x3807 | Unblock direct control port. Lower byte 0-7: 0=all ports, 1=COM1, 2=COM2, 3=COM3, 4=COM4, 5=COM5, 6=USB, 7=Ethernet | |
| | 0x3900-0x3901 | Close breaker XCBR1-XCBR2 | |
| | 0x3902-0x390F | Close switch XSWI1-XSWI14 | |
| | 0x3A00-0x3A01 | Open breaker XCBR1-XCBR2 | |
| | 0x3A02-0x3A0F | Open switch XSWI1-XSWI14 | |
| | 0x4000-0x401F | Increment counter #1-#32 | |
| | 0x4100-0x411F | Decrement counter #1-#32 | |
| | 0x4200-0x421F | Clear counter #1-#32 | |
| | 0x5100 | Send event notification | |
| | 0x5300 | Remote control | |
| | 0x6000 | Reset total energy registers | |
| | 0x6100 | Reset total maximum demand registers | |
| | 0x6200 | Reset billing summary and TOU energy | |
| | 0x6300 | Reset billing summary and TOU maximum demands | |
| | 0x6400 | Clear all counters | |
| | 0x6500 | Clear Min/Max log registers | |
| | 0x7000 | Event log on setpoint operated | |
| | 0x7001 | Event log on setpoint released | |
| | 0x7002 | Event log on any setpoint transition | |
| | 0x7100-0x710F | Data log 1-16 | |
| | 0x7200-0x7207 | Waveform Log 1-8 | |
| | 0x7400 | Not used | |
| | 0x8000-0x800F | External trigger #1-#16 (UDP broadcast trigger message) | |

| Format Code | Value | Description | Notes |
|---|---------------|--------------------------------------|-------|
| Energy Pulse Source ID | | | |
| F15 | 0x0000 | None | |
| | 0x0400 | kWh Import pulse | |
| | 0x0401 | kWh Export pulse | |
| | 0x0402 | kWh Total pulse | |
| | 0x0403 | kvarh Import pulse | |
| | 0x0404 | kvarh Export pulse | |
| | 0x0405 | kvarh Total pulse | |
| | 0x0406 | kVAh pulse | |
| Counter Source ID | | | |
| F16 | 0x0000 | None | |
| | 0x0700-0x077F | Pulse input DI1-DI26 | |
| Relay Output Pulse Source ID | | | |
| F17 | 0x0000 | None | |
| | 0x0400 | kWh Import pulse | |
| | 0x0401 | kWh Export pulse | |
| | 0x0402 | kWh Total pulse | |
| | 0x0403 | kvarh Import pulse | |
| | 0x0404 | kvarh Export pulse | |
| | 0x0405 | kvarh Total pulse | |
| | 0x0406 | kVAh pulse | |
| | 0x0407 | Start of power demand interval pulse | |
| | 0x0408 | Start of tariff interval pulse | |
| AO Parameters ID (see Section 3.4 for data scales) | | | |
| F18 | 0x0000 | None (output disabled) | 2 |
| | | 1-Cycle Phase Values | |
| | 0x0C00 | V1 Voltage | |
| | 0x0C01 | V2 Voltage | |
| | 0x0C02 | V3 Voltage | |
| | 0x0C03 | I1 Current | |
| | 0x0C04 | I2 Current | |
| | 0x0C05 | I3 Current | |
| | 0x0C12 | V1 Voltage THD | |
| | 0x0C13 | V2 Voltage THD | |
| | 0x0C14 | V3 Voltage THD | |
| | 0x0C15 | I1 Current THD | |
| | 0x0C16 | I2 Current THD | |

| Format Code | Value | Description | Notes |
|-------------|--------|---------------------------------|-------|
| | 0x0C17 | I3 Current THD | |
| | 0x0C18 | I1 K-Factor | |
| | 0x0C19 | I2 K-Factor | |
| | 0x0C1A | I3 K-Factor | |
| | 0x0C1B | I1 Current TDD | |
| | 0x0C1C | I2 Current TDD | |
| | 0x0C1D | I3 Current TDD | |
| | 0x0C1E | V12 Voltage | |
| | 0x0C1F | V23 Voltage | |
| | 0x0C20 | V31 Voltage | |
| | | 1-Cycle Total Value | |
| | 0x0F00 | Total kW | |
| | 0x0F01 | Total kvar | |
| | 0x0F02 | Total kVA | |
| | 0x0F03 | Total PF | |
| | 0x0F04 | Total PF Lag | |
| | 0x0F05 | Total PF Lead | |
| | | 1-Cycle Auxiliary Values | |
| | 0x1000 | I4 Current | |
| | 0x1001 | In Current | |
| | 0x1002 | Frequency | |
| | | 1-Sec Phase Values | |
| | 0x1100 | V1 Voltage | |
| | 0x1101 | V2 Voltage | |
| | 0x1102 | V3 Voltage | |
| | 0x1103 | I1 Current | |
| | 0x1104 | I2 Current | |
| | 0x1105 | I3 Current | |
| | 0x111E | V12 Voltage | |
| | 0x111F | V23 Voltage | |
| | 0x1120 | V31 Voltage | |
| | | 1-Sec Total Values | |
| | 0x1400 | Total kW | |
| | 0x1401 | Total kvar | |
| | 0x1402 | Total kVA | |
| | 0x1403 | Total PF | |
| | 0x1404 | Total PF Lag | |

| Format Code | Value | Description | Notes |
|------------------------------|------------------------------------|--|-------|
| | 0x1405 | Total PF Lead | |
| | 0x140A | 3-phase average L-N voltage | |
| | 0x140B | 3-phase average L-L voltage | |
| | 0x140C | 3-phase average current | |
| | | 1-Sec Auxiliary Values | |
| | 0x1500 | I4 Current | |
| | 0x1501 | In Current | |
| | 0x1502 | Frequency | |
| | | Present Demands | |
| | 0x160F | Accumulated kW import demand | |
| | 0x1610 | Accumulated kvar import demand | |
| | 0x1611 | Accumulated kVA demand | |
| | 0x161A | Accumulated kW export demand | |
| | 0x161B | Accumulated kvar export demand | |
| Event Source/Point ID | | | |
| F19 | Appendix A | Setpoint Operation Events | |
| | 0x0000-0x59FF | Trigger parameter ID | |
| | 0x6400-0xFFFF | Trigger parameter ID | |
| | | Setpoint Action Events | |
| | 0x5A00-0x5A3F | Setpoint #1-#64 | |
| | | Communications Events | |
| | 0x5B00-0x5BFF | Data/Function point ID (low byte, see F21) | |
| | | Self-Check Diagnostics Events | |
| | 0x5D00-0x5DFF | Data/Function point ID (low byte, see F21) | |
| | | Self-Update Events | |
| | 0x5E08 | RTC DST/Standard time update | 3 |
| | | Run-time Error | |
| | 0x6014 | Library error | |
| | 0x6015 | RTOS Kernel error | |
| | 0x6016 | Task error | |
| | | Control Events | |
| | 0x6100 | Not used | |
| | 0x6101 | Not used | |
| | 0x6102 | Not used | |
| | 0x6103 | Remote control (Value: 0=OFF, 1=ON) | |
| | Hardware Diagnostics Events | | |
| 0x6201 | Permanent fault | | |

| Format Code | Value | Description | Notes |
|------------------------|---------------|---|-------|
| | 0x6202 | RAM/Data error | |
| | 0x6203 | CPU watchdog reset | |
| | 0x6204 | DSP/Sampling fault | |
| | 0x6205 | CPU exception | |
| | 0x6206 | Reserved | |
| | 0x6207 | Software watchdog reset | |
| | 0x620E | Expanded memory fault (Event effect = File ID + 1) | |
| | 0x620F | CPU EEPROM fault | |
| | 0x6210 | AC board EEPROM fault | |
| | 0x6211 | I/O board EEPROM fault | |
| | | External Events | |
| | 0x6300 | Power down | |
| | 0x6308 | Power up | |
| | 0x6309 | External reset | |
| | 0x6318 | IRIG-B signal lost | |
| | 0x6319 | IRIG-B time unlocked | |
| | 0x631A | IRIG-B time locked | |
| | 0x6320 | SNTP server failed | 4 |
| | 0x6321 | SNTP server reconnected | 4 |
| Event Effect ID | | | |
| F20 | | Communications/Self-check/Self-update Events | |
| | 0x0000 | None | |
| | 0x6000 | Total energy registers cleared | |
| | 0x6100 | All total maximum demands cleared | |
| | 0x6101 | Power maximum demands cleared | |
| | 0x6102 | Volt/Ampere maximum demands cleared | |
| | 0x6103 | Volt maximum demands cleared | |
| | 0x6104 | Ampere maximum demands cleared | |
| | 0x6105 | Harmonic maximum demands cleared | |
| | 0x6200 | Billing/TOU registers cleared | |
| | 0x6300 | Billing/TOU maximum demand registers cleared | |
| | 0x6400 | All counters cleared | |
| | 0x6401-0x641F | Counter cleared (low byte = counter ID) | |
| | 0x6500 | Min/Max log cleared | |
| | 0x6A00-0x6A1B | Log file cleared (low byte = File ID) | |
| | 0x6B00 | Not used | |
| | 0x6B06 | Communication counters cleared | |

| Format Code | Value | Description | Notes |
|-------------------------------|----------------|--|-------|
| | 0x6B07 | Switch operation counters cleared | |
| | 0xF100-0xF11F | Setpoint cleared (low byte = setpoint ID) | |
| | 0xF200 | Setup/Data cleared | |
| | 0xF300 | Setup reset (set by default) | |
| | 0xF400 | Setup changed | |
| | 0xF500 | RTC set | 3 |
| | 0xF600 | Device function/option enabled | |
| | 0xF700 | Device function/option disabled | |
| | 0xF800 | Device function restarted | |
| | 0xF900 | Device function stopped | |
| | | Control Events | |
| | 0xA0XX | Position change (bits 0:7=switch number) | |
| | 0xA1XX | Operation activated (bits 0:7=switch number) | |
| | 0xA2XX | Operation terminated (bits 0:7=switch number) | |
| | 0xA3XX | Operation terminated by timeout (bits 0:7=switch number) | |
| | | Setpoint Operation Events | |
| | 0xE100-0xE13F | Setpoint operated (low byte = setpoint ID) | |
| | 0xE200-0xE23F | Setpoint released (low byte = setpoint ID) | |
| | | Setpoint Action Events | |
| | See F14 | Setpoint action ID | |
| Data/Function Point ID | | | |
| F21 | | Data Location | |
| | 0x03 | Data memory | |
| | 0x04 | Factory setup | |
| | 0x05 | Access/Password setup | |
| | 0x06 | Basic setup | |
| | 0x07 | Communications setup | |
| | 0x08 | Real-time clock | |
| | 0x09 | Digital inputs setup | |
| | 0x0A | Pulse counters setup | |
| | 0x0B | AO setup | |
| | 0x0E | Timers setup | |
| | 0x10 | Event/alarm setpoints | |
| | 0x11 | Pulsing setup | |
| | 0x12 | User assignable register map | |
| | 0x13 | Reserved | |
| 0x14 | Data log setup | | |

| Format Code | Value | Description | Notes |
|----------------------|-----------|------------------------------|-------|
| | 0x15 | File/Memory setup | |
| | 0x16 | Billing/TOU registers setup | |
| | 0x18 | TOU daily profiles | |
| | 0x19 | TOU calendar | |
| | 0x1D | RO Setup | |
| | 0x1C | User selectable options | |
| | 0x1F | DNP 3.0 class 0 map | |
| | 0x20 | DNP 3.0 options setup | |
| | 0x21 | DNP 3.0 events setup | |
| | 0x22 | DNP 3.0 event setpoints | |
| | 0x23 | Calibration registers | |
| | 0x24 | Date/Time Setup | |
| | 0x25 | Net setup | |
| | 0x26 | AI setup | |
| | 0x27 | Waveform log setup | |
| | 0x28 | PQ log setup | |
| | 0x29 | Not used | |
| | 0x2A | Device mode control | |
| | 0x2B-0x2C | Reserved | |
| | 0x2D | Transformer correction setup | |
| | 0x2E | Not used | |
| | 0x2F | Reserved | |
| | 0x30 | IEC 60870 setup | |
| | 0x31 | Not used | |
| | 0x32 | Not used | |
| | | Device Mode/Option | |
| | 0x40 | General device operations | |
| | 0x41 | Energy test mode | |
| | 0x42 | Setpoints mode | |
| | 0x43 | PQ recorder | |
| | 0x44 | Fault recorder | |
| | | Device Diagnostics | |
| | 0x80 | Device diagnostics | |
| | 0x81 | Critical error | |
| Event Type ID | | | |
| F22 | | Setpoint Events | |
| | 0x0000 | SP: Generic setpoint event | |

| Format Code | Value | Description | Notes |
|-------------|---------------|--|-------|
| | 0x0001-0x0040 | SP1-SP64: Setpoint #1-#64 event | |
| | | IEEE 1159 PQ Events (IEEE 1159 categories) | |
| | 0x0100 | PQE: Generic IEEE1159 PQ event | |
| | 0x0102 | PQE11: Impulsive transient | |
| | 0x010C | PQE211: Sag, instantaneous | |
| | 0x010D | PQE212: Swell, instantaneous | |
| | 0x010F | PQE221: Interruption, momentary | |
| | 0x0110 | PQE222: Sag, momentary | |
| | 0x0111 | PQE223: Swell, momentary | |
| | 0x0113 | PQE231: Interruption, temporary | |
| | 0x0114 | PQE232: Sag, temporary | |
| | 0x0115 | PQE233: Swell, temporary | |
| | 0x0117 | PQE31: Interruption, sustained | |
| | 0x0118 | PQE32: Undervoltage | |
| | 0x0119 | PQE33: Overvoltage | |
| | 0x011A | PQE4: Voltage imbalance | |
| | 0x011D | PQE52: Harmonics | |
| | 0x011E | PQE53: Interharmonics | |
| | 0x0121 | Not used | |
| | 0x0122 | PQE7: Frequency variation | |
| | | Fault Events | |
| | 0x0200 | Not used | |
| | 0x0201 | Not used | |
| | 0x0202 | Not used | |
| | 0x0203 | Not used | |
| | 0x0204 | Not used | |
| | 0x0205 | Not used | |
| | 0x0206 | Not used | |
| | 0x0207 | Not used | |
| | | DI Events | |
| | 0x0300 | DI: Generic DI event | |
| | 0x0301-0x0380 | DI1- DI26: DI1-DI26 event | |
| | | RO Events | |
| | 0x0400 | RO: Generic RO event | |
| | 0x0401-0x0440 | RO1-RO7: RO1-RO7 event | |
| | | EN 50160:2007 PQ Events (EN 50160 categories) | |
| | 0x0500 | Not used | |

| Format Code | Value | Description | Notes |
|-------------|--------|--|-------|
| | 0x0501 | Not used | |
| | 0x0502 | Not used | |
| | 0x0503 | Not used | |
| | 0x0504 | Not used | |
| | 0x0505 | Not used | |
| | 0x0506 | Not used | |
| | 0x0507 | Not used | |
| | 0x0508 | Not used | |
| | 0x0509 | Not used | |
| | 0x050A | Not used | |
| | 0x050B | Not used | |
| | 0x050C | Not used | |
| | | PQ Events (GOST 13109 categories) | |
| | 0x0600 | Not used | |
| | 0x0601 | Not used | |
| | 0x0602 | Not used | |
| | 0x0603 | Not used | |
| | 0x0604 | Not used | |
| | 0x0605 | Not used | |
| | 0x0606 | Not used | |
| | 0x0607 | Not used | |
| | 0x0608 | Not used | |
| | 0x0609 | Not used | |
| | 0x060A | Not used | |
| | | PQ Events (GOST 32144 categories) | |
| | 0x0700 | Not used | |
| | 0x0701 | Not used | |
| | 0x0702 | Not used | |
| | 0x0703 | Not used | |
| | 0x0704 | Not used | |
| | 0x0705 | Not used | |
| | 0x0706 | Not used | |
| | 0x0707 | Not used | |
| | 0x0708 | Not used | |
| | 0x0709 | Not used | |
| | 0x070A | Not used | |
| | 0x070B | Not used | |

| Format Code | Value | Description | Notes |
|------------------------------------|------------|--|-------|
| | 0x070C | Not used | |
| | 0x070D | Not used | |
| | | EN 50160:2010 PQ Events (EN 50160 categories) | |
| | 0x0800 | Not used | |
| | 0x0801 | Not used | |
| | 0x0802 | Not used | |
| | 0x0803 | Not used | |
| | 0x0804 | Not used | |
| | 0x0805 | Not used | |
| | 0x0806 | Not used | |
| | 0x0807 | Not used | |
| | 0x0808 | Not used | |
| | 0x0809 | Not used | |
| | 0x080A | Not used | |
| | 0x080B | Not used | |
| | 0x080C | Not used | |
| | 0x080D | Not used | |
| | | Data Log Events | |
| | 0x0900 | Online PQ statistics | |
| Device Diagnostics (bitmap) | | | |
| F23 | Bit 0 = 1 | Critical error | |
| | Bit 1 = 1 | Permanent fault (critical error) | |
| | Bit 2 = 1 | RAM/Data error | |
| | Bit 3 = 1 | CPU watchdog reset | |
| | Bit 4 = 1 | DSP/Sampling fault | |
| | Bit 5 = 1 | CPU exception | |
| | Bit 6 | Reserved | |
| | Bit 7 = 1 | Software watchdog reset | |
| | Bit 8 = 1 | Power down | |
| | Bit 9 = 1 | Device reset | |
| | Bit 10 = 1 | Configuration reset | |
| | Bit 11 = 1 | RTC fault (critical error) | |
| | Bit 12 = 1 | Configuration fault (critical error) | |
| | Bit 13 = 1 | Low battery | |
| | Bit 14 = 1 | Expanded memory fault | |
| | Bit 15 = 1 | CPU EEPROM fault | |
| | Bit 16 = 1 | AC board EEPROM fault | |

| Format Code | Value | Description | Notes |
|-------------------------|---|---|-------|
| | Bit 17 = 1 | I/O board EEPROM fault | |
| | Bit 18 | Reserved | |
| | Bit 19 | Reserved | |
| | Bit 20 = 1 | C Library error | |
| | Bit 21 = 1 | RTOS Kernel error | |
| | Bit 22 = 1 | Task error | |
| | Bit 23 | Reserved | |
| | Bit 24 = 1 | IRIG-B signal lost | |
| | Bit 25 = 1 | IRIG-B time unlocked | |
| DNP Object Types | | | |
| F24 | | Binary Input Static Object | |
| | 0 | Single-Bit Binary Input | |
| | 1 | Binary Input With Status | |
| | | Binary Input Change Event Object | |
| | 0 | Binary Input Change Without Time | |
| | 1 | Binary Input Change With Time | |
| | | Binary Counter | |
| | 0 | 32-bit Binary Counter | |
| | 1 | 32-bit Binary Counter Without Flag | |
| | 2 | 16-bit Binary Counter | |
| | 3 | 16-bit Binary Counter Without Flag | |
| | | Binary Counter Change Event | |
| | 0 | 32-bit Counter Change Event Without Time | |
| | 1 | 32-bit Counter Change Event With Time | |
| | | 16-bit Counter Change Event Without Time | |
| | 3 | 16-bit Counter Change Event With Time | |
| | | Frozen Binary Counter | |
| | 0 | 32-bit Frozen Counter | |
| | 1 | 32-bit Frozen Counter Without Flag | |
| | 2 | 32-bit Frozen Counter With Time of Freeze | |
| 3 | 16-bit Frozen Counter | | |
| 4 | 16-bit Frozen Counter Without Flag | | |
| 5 | 16-bit Frozen Counter With Time of Freeze | | |
| | Analog Input | | |
| 0 | 32-bit Analog Input | | |
| 1 | 32-bit Analog Input Without Flag | | |
| 2 | 16-bit Analog Input | | |

| Format Code | Value | Description | Notes |
|----------------------------|--------|---|-------|
| | 3 | 16-bit Analog Input Without Flag | |
| | | Analog Input Change Event | |
| | 0 | 32-bit Analog Change Event Without Time | |
| | 1 | 32-bit Analog Change Event With Time | |
| | 2 | 16-bit Analog Change Event Without Time | |
| | 3 | 16-bit Analog Change Event With Time | |
| | | | |
| DNP Class 0 Objects | | | |
| F25 | 0x1E01 | Analog Input 30:01 | |
| | 0x1E02 | Analog Input 30:02 | |
| | 0x1E03 | Analog Input 30:03 | |
| | 0x1E04 | Analog Input 30:04 | |
| | 0x2801 | Analog Output 40:01 | |
| | 0x2802 | Analog Output 40:02 | |
| | 0x0101 | Binary Input 01:01 | |
| | 0x0102 | Binary Input 01:02 | |
| | 0x1401 | Binary Counter 20:01 | |
| | 0x1402 | Binary Counter 20:02 | |
| | 0x1405 | Binary Counter 20:05 | |
| | 0x1406 | Binary Counter 20:06 | |
| | 0x1501 | Frozen Counter 21:01 | |
| | 0x1502 | Frozen Counter 21:02 | |
| | 0x1505 | Frozen Counter 21:05 | |
| | 0x1506 | Frozen Counter 21:06 | |
| | 0x1509 | Frozen Counter 21:09 | |
| | 0x150A | Frozen Counter 21:10 | |
| | | | |
| Wiring Mode | | | |
| F26 | 0 | 3OP2 - 3-wire open delta using 2 CTs (2 element) | |
| | 1 | 4LN3 - 4-wire WYE using 3 PTs (3 element), line-to-neutral voltage readings | |
| | 2 | 3DIR2 - 3-wire direct connection using 2 CTs (2 element) | |
| | 3 | 4LL3 - 4-wire WYE using 3 PTs (3 element), line-to-line voltage readings | |
| | 4 | 3OP3 - 3-wire open delta using 3 CTs (2 1/2 element) | |
| | 5 | 3LN3 - 4-wire WYE using 2 PTs (2 1/2 element), line-to-neutral voltage readings | |

| Format Code | Value | Description | Notes |
|--|-------------|---|-------|
| | 6 | 3LL3 - 4-wire WYE using 2 PTs (2 1/2 element), line-to-line voltage readings | |
| | 8 | 3BLN3 - 3-wire broken delta using 2 PTs (2 1/2 element), line-to-neutral voltage readings | |
| | 9 | 3BLL3 - 3-wire broken delta using 2 PTs (2 1/2 element), line-to-line voltage readings | |
| | | | |
| IEC 61850 Measured Value Indices (IEC 61850 future release) | | | |
| F27 | 0 | Phase voltage | |
| | 1 | Auxiliary voltage V4 | |
| | 2 | Not used | |
| | 3 | Phase currents | |
| | 4 | Neutral current | |
| | 5 | Auxiliary current I4 | |
| | 6 | Phase currents (extended inputs) | |
| | 7 | Neutral current (extended inputs) | |
| | 8 | Auxiliary current I4 (extended inputs) | |
| | 9 | Voltage sequence | |
| | 10 | Current sequence | |
| | 11 | Current sequence (extended inputs) | |
| | 12 | Voltage unbalance | |
| | 13 | Current unbalance | |
| | 14 | Active power | |
| | 15 | Reactive power | |
| | 16 | Active power import/export | |
| | 17 | Reactive power import/export | |
| | 18 | Apparent power | |
| | 19 | Active power demand | |
| | 20 | Reactive power demand | |
| | 21 | Apparent power demand | |
| | 22 | Power factor | |
| | 23 | Power factor lag/lead | |
| | 24 | Frequency | |
| | 25 | Voltage THD | |
| | 26 | Current THD | |
| | 27 | Voltage interharmonic THD | |
| | 28 | Current interharmonic THD | |
| 29 | Current TDD | | |

| Format Code | Value | Description | Notes |
|--------------------------------------|-------|------------------------|-------|
| | 30 | Current K-factor | |
| | 31 | Not used | |
| | 32 | Not used | |
| | 33 | Analog input #1 | |
| | 34 | Analog input #2 | |
| | 35 | Analog input #3 | |
| | 36 | Analog input #4 | |
| | 37 | Analog input #5 | |
| | 38 | Analog input #6 | |
| | 39 | Analog input #7 | |
| | 40 | Analog input #8 | |
| | 41 | Analog input #9 | |
| | 42 | Analog input #10 | |
| | 43 | Analog input #11 | |
| | 44 | Analog input #12 | |
| | 45 | Analog input #13 | |
| | 46 | Analog input #14 | |
| | 47 | Analog input #15 | |
| | 48 | Analog input #16 | |
| | | | |
| Single Point Info Static Type | | | |
| F30 | 1 | M_SP_NA_1 | |
| | 2 | M_SP_TA_1 (CP24Time2a) | |
| | 30 | M_SP_TB_1 (CP56Time2a) | |
| | | | |
| Single Point Info Event Type | | | |
| F31 | 2 | M_SP_TA_1 (CP24Time2a) | |
| | 30 | M_SP_TB_1 (CP56Time2a) | |
| | | | |
| Double Point Info Static Type | | | |
| F32 | 3 | M_DP_NA_1 | |
| | 4 | M_DP_TA_1 (CP24Time2a) | |
| | 31 | M_DP_TB_1 (CP56Time2a) | |
| | | | |
| Double Point Info Event Type | | | |
| F33 | 4 | M_DP_TA_1 (CP24Time2a) | |
| | 31 | M_DP_TB_1 (CP56Time2a) | |

| Format Code | Value | Description | Notes |
|--|-------|------------------------|-------|
| Measured Value Static Type | | | |
| F34 | 9 | M_ME_NA_1 | |
| | 10 | M_ME_NB_1 | |
| | 11 | M_ME_NC_1 | |
| | 12 | M_ME_TA_1 (CP24Time2a) | |
| | 13 | M_ME_TB_1 (CP24Time2a) | |
| | 14 | M_ME_TC_1 (CP24Time2a) | |
| | 34 | M_ME_TD_1 (CP56Time2a) | |
| | 35 | M_ME_TE_1 (CP56Time2a) | |
| | 36 | M_ME_TF_1 (CP56Time2a) | |
| Measured Value Event Type | | | |
| F35 | 12 | M_ME_TA_1 (CP24Time2a) | |
| | 13 | M_ME_TB_1 (CP24Time2a) | |
| | 14 | M_ME_TC_1 (CP24Time2a) | |
| | 34 | M_ME_TD_1 (CP56Time2a) | |
| | 35 | M_ME_TE_1 (CP56Time2a) | |
| | 36 | M_ME_TF_1 (CP56Time2a) | |
| Integrated Totals Static Type | | | |
| F36 | 15 | M_IT_NA_1 | |
| | 16 | M_IT_TA_1 (CP24Time2a) | |
| | 37 | M_IT_TB_1 (CP56Time2a) | |
| Integrated Totals Event Type | | | |
| F37 | 16 | M_IT_TA_1 (CP24Time2a) | |
| | 37 | M_IT_TB_1 (CP56Time2a) | |
| Factory Device Options (bitmap) | | | |
| F38 | 0 | Not used | |
| | 1:15 | Not used | |
| | 16:19 | Not used | |
| | 20:31 | Not used | |

NOTES:

- ¹ When the 4LN3 or 3LN3 wiring mode is selected, the voltages will be line-to-neutral; for any other wiring mode, they will be line-to-line voltages.
- ² 1) For bi-directional analog output (± 1 mA), the zero scale setup corresponds to the center (0 mA) of the scale range, and the direction of the current matches the sign of the output parameter. Unsigned parameters are output within the current range 0 to +1 mA and can be scaled as in the case of single-ended analog output (0-1 mA).

For signed values, such as powers and signed power factor, the scale is always symmetrical with regard to 0 mA, and the full scale corresponds to +1 mA output for positive readings and to -1 mA output for negative readings. The zero scale (0 mA output) is permanently set in the instrument to zero for all parameters except the signed power factor for which it is set to 1.000 (see Note 2). In write requests, the zero scale is ignored.
- 2) Except for the signed power factor, the setup scale is continuous within the entire value range. For signed power factor, the setup scale is broken at +1.000 in order to provide continuous output current when the power factor changes close to ± 1.000 . The setup scale is symmetrical in the range of -0 to +0 with a center at 1.000 (-1.000 is assumed to be equal to +1.000). Negative power factor is output as -1.000 minus measured value, and non-negative power factor is output as +1.000 minus measured value. To set the entire range for power factor from -0 to +0, the scales would be specified as -0 to 0. Because of the fact that negative zero may not be transmitted through communications, the value of -0.001 is used to specify the scale of -0, and both +0.001 and 0.000 are used to specify the scale of +0.
- ³ The event value field shows the present device time in the F1 format.
- ⁴ The event value field shows the server IP address in a network byte order.